TECHNICAL DOCUMENTATION UPDATE NOTICE

Word Processing System Communications Options User's Manual

AA-5264C-TK and AD-5264C-T1

June 1979

Insert this Update Notice page in the manual as a means of maintaining an up-to-date record of changes to the manual.

Copyright © 1979 by Digital Equipment Corporation

INSTRUCTIONS

The following pages are to be placed in the Word Processing System Communications Options User's Manual as replacements for, or additions to, current pages.

| Old Page | New Page | | |
|------------------|-----------------|--|--|
| Title Page | Title Page | | |
| iii to vii | iii to vii | | |
| ix, x | ix, x | | |
| 3-35, 3-36 | 3-35, 3-36 | | |
| - · , | 3-41 to 3-49 | | |
| B-1 to B-4 | B-1 to B-6 | | |
| | D-1, D-2 | | |
| Index 1. Index 2 | Index 1 Index 2 | | |

AA-5264C-TK

and

AD-5264C-T1

Word Processing System Communications Options User's Manual

Preliminary, December 1978 1st Edition, February 1979 1st Edition (Rev), June 1979

The information in this document is subject to change without notice and should not be construed as a commitment by Digital Equipment Corporation. Digital Equipment Corporation assumes no responsibility for any errors that may appear in this document.

The software described in this document is furnished under a license and may not be used or copied except in accordance with the terms of such license.

Digital Equipment Corporation assumes no responsibility for the use or reliability of its software on equipment that is not supplied by DIGITAL.

Copyright © 1978, 1979 by Digital Equipment Corporation

Printed in U.S.A.

The following are trademarks of Digital Equipment Corporation:

| COMPUTER LABS | DIBOL | OS/8 |
|---------------|------------------|------------|
| COMTEX | DIGITAL | PDP |
| DDT | EDUSYSTEM | PHA |
| DEC | FLIP CHIP | RSTS |
| DECCOMM | FOCAL | RSX |
| DECsystem-10 | INDAC | TYPESET-8 |
| DECSYSTEM-20 | LAB-8 | TYPESET-10 |
| DECtape | MASSBUS | TYPESET-11 |
| DECUS | OMNIBUS | UNIBUS |

CONTENTS

| | | Page |
|------------|--|-------|
| PREFACE | | |
| CHAPTER 1 | INTRODUCTION | |
| 1.1 1.2 | DOCUMENT TRANSMISSION COMMUNICATIONS OPTIONAUTOMATIC DOCUMENT TRANSMISSION COMMUNICATIONS | |
| 1.3 1.4 | OPTIONCHARACTER TRANSMISSION COMMUNICATIONS OPTIONDOCUMENT COMMUNICATIONS PRODUCTS | 1-2 |
| CHAPTER 2 | ESTABLISHING A CONNECTION | |
| 2.1 2.2 | ESTABLISHING A CONNECTION WITH A BELL DATA PHONEESTABLISHING A CONNECTION WITH AN ACOUSTIC COUPLER | |
| 2.3 | ESTABLISHING A CONNECTION WITH A NULL MODEM | 2-4 |
| CHAPTER 3 | COMMUNICATION WITH A WORD STATION OR WORD TERMINAL | |
| 3.1 | DOCUMENT TRANSMISSION (DX) | 3-1 |
| 3.2 | AUTOMATIC DOCUMENT TRANSMISSION(AX) | .3-14 |
| 3.2.1 | Placing a System in Automatic Transmission | .3-14 |
| 3.2.2 | Communicating with a System Placed in AX | .3-19 |
| 3.2.3 | Sending a Document to a System Placed in AX3-23 | |
| 3.2.4 | Fetching a Document from a System Placed | |
| | in AX | .3-32 |
| 3.3 | CHARACTER TRANSMISSION (CX) | .3-35 |
| 3.3.1 | How to Use CX | .3-35 |
| 3.3.1.1 | Originating the Call | .3-35 |
| 3.3.1.2 | Using the Commands | .3-37 |
| 3.3.1.3 | Changing the Commands | .3-37 |
| 3.3.1.4 | Pausing in Mid-Operation with a Host. | .3-38 |
| 3.3.1.5 | Shutting Down | .3-38 |
| 3.3.2 | Commands Involving Documents | .3-38 |
| 3.3.2.1 | Keyboard to Document (KD) or Host | |
| | to Document (HD) | .3-38 |
| 3.3.2.2 | Document to Screen, Printer, or Host | |
| | (DS, DP, DH) | .3-40 |
| 3.3.3 | CX Print-Control Commands | |
| 3.3.3.1 | Typing Print-Control Commands | .3-42 |
| 3.3.3.2 | Testing a Document for its Print-Control | |
| 2222 | Commands | |
| 3.3.3.3 | Making a Document the Control Document | .3-47 |
| CHAPTER 4 | ERROR MESSAGES | |

iii

June 1979