

AV-C971B-TA

Reference Manual

WORD PROCESSING SYSTEM

**WPS-8 Word Processing System
Reference Manual
(Versions 2.7 and 3.0)**

Copyright © 1978 by Digital Equipment Corporation

The information in this document is subject to change without notice and should not be construed as a commitment by Digital Equipment Corporation. Digital Equipment Corporation assumes no responsibility for any errors that may appear in this document.

The software described in this document is furnished under a license and may not be used or copied except in accordance with the terms of such license.

Digital Equipment Corporation assumes no responsibility for the use or reliability of its software on equipment that is not supplied by DIGITAL.

Printed in U.S.A.

This document was typeset on DIGITAL's
DECset-8000 computerized typesetting system.

The following are trademarks of Digital Equipment Corporation:

COMPUTER LABS	DIBOL	OS/8
COMTEX	DIGITAL	PDP
DDT	EDUSYSTEM	PHA
DEC	FLIP CHIP	RSTS
DECCOMM	FOCAL	RSX
DECsystem-10	INDAC	TYPESET-8
DECSYSTEM-20	LAB-8	TYPESET-10
DECtape	MASSBUS	TYPESET-11
DECUS	OMNIBUS	UNIBUS

CONTENTS

Page

PREFACE

CHAPTER 1 INTRODUCTION

1.1	WORD PROCESSING EQUIPMENT.....	1-3
1.1.1	The Keyboard	1-7
1.1.2	The Display Screen.....	1-9
1.1.3	Storage.....	1-10
1.1.4	Printers	1-12
1.2	USING THE WORD PROCESSING SYSTEM	1-12

CHAPTER 2 OPERATING THE WS78 EQUIPMENT

2.1	TURNING ON THE MACHINE	2-1
2.2	INSERTING THE DISKETTES	2-4
2.3	BOOTSTRAPPING	2-7
2.4	TYPING THE DATE AND TIME	2-10
2.5	MAIN MENU	2-10
2.6	RESETTING THE DATE AND TIME	2-12
2.7	STOPPING.....	2-12
2.8	POWER FAILURES AND BROWN-OUTS.....	2-13

CHAPTER 2 OPERATING THE WS100 EQUIPMENT

2.1	TURNING ON THE MACHINE	2-1
2.2	BOOTSTRAPPING	2-4
2.3	INSERTING THE DISKETTES	2-5
2.4	TYPING THE DATE AND TIME	2-8
2.5	MAIN MENU	2-11
2.6	RESETTING THE DATE AND TIME	2-12
2.7	STOPPING.....	2-13
2.8	POWER FAILURES AND BROWN-OUTS.....	2-13