<u>IDENTIFICATION</u>

Product Code:

DEC-08-LRAA-D

Product Name:

Read-In-Mode Loader

Date Created:

February 23, 1965

Maintainer:

Software Services Group



	•		

1. ABSTRACT

The Rim Loader is a minimum-sized routine for reading and storing information contained in Read-In-Mode coded tapes via the ASR-33 perforated tape reader.

2. REQUIREMENTS

2.1 Storage

17 decimal (21 octal).

2.2 Equipment

4K PDP-8 with ASR-33.

3. USAGE

3.1 Loading

To place the Rim Loader into memory via the control console switches, proceed as follows:

- 3.1.1 Set 7756 in the switch register (SR).
- 3.1.2 Press LOAD ADDRESS.
- 3.1.3 Set the first instruction (6032) in the SR.
- 3.1.4 Press DEPOSIT.
- 3.1.5 Set the next instruction (6031) in the SR.
- 3.1.6 Press DEPOSIT.
- 3.1.7 Repeat steps 3.1.5 and 3.1.6 until all instructions have been deposited.

3.2 Calling Sequence

None. Cannot be called as a subroutine.

3.3 Start-up/Entry

- 3.3.1 Place the perforated tape which must be in RIM format in the pertorated-tape reader.
- 3.3.2 Make sure that the ASR-33 is on line.
- 3.3.3 Place the starting address 7756 in the switch register.
- 3.3.4 Press the LOAD ADDRESS key.
- 3.3.5 Press console START key.
- 3.3.6 Move the reader control switch to START.

3.4 Errors

There are no error stops in this routine.

4. DESCRIPTION

This is a basic routine that alternately assembles an address from two successive characters on tape, then assembles data contained in the next two characters and stores this data at the associated address.

Because a tape in Rim format is twice as long as a comparable tape in Binary format, it is suggested that the Rim Loader only be used to read in the Binary Loader. After this, the Binary Loader should be used.

5. FORMAT

5.1 External Data

Tapes to be read by this program must be in Read-In-Mode coded format.

5.1.1 Leader should be about 2 feet of Leader-Trailer codes (any code with channel 8 punched; preferably code 200).

- 5.1.1.1 Depress ALT MODE, CTRL, and @ keys simultaneously to punch 200 Leader-Trailer.
- 5.1.2 Characters representing the absolute, machine language program are arranged in an alternating pattern of address, contents, address, contents, etc. Addresses have channel 7 punched, channel 8 not punched. Contents have no punch in channel 7 or 8.
- 5.1.3 Trailer: Same as Leader.
- 5.1.4 Example of Read-In-Mode coded format:

Tape Channel 87 654 S 321	Channels 8 and 7 Indicate.
10 000 . 000	Leader code is always found first.
01 A1 . A2 00 A3 . A4	Absolute octal Address of data in next two characters.
00 D1 . D2 00 D3 . D4	Octal Data to be stored at preceeding address.
This pattern repeats in similar	r four character groups until the concluding
10 000 . 000	Trailer Code is encountered.

- 5.1.4.1 Note that actually a 3-bit group (a single octal character) is designated by the notation Al above. The "1" in this notation indicates that this particular octal character will be used as the most significant three bits in specifying the absolute address into which following data will be deposited. Correspondingly, A2, A3, and A4 designate successively less significant octal characters in the absolute address.
- 5.1.4.2 The remarks in 5.1.4.1 apply equally to Data as specified by the notation D1, D2, D3, and D4.

6. PROGRAM

6.1	Program Listing			
Abs. Addr.	Octal Contents	Tag	Instruction I Z	Comments
7756,	6032	BEG,	KCC	/clear AC and flag
7757,	6031	•	KSF	/skip if flag = 1
7760,	<i>5</i> 3 <i>57</i>		JMP1	/looking for char
<i>77</i> 61,	6036		KRB	/read buffer