

IDENTIFICATION

PRODUCT CODE: MAINDEC-08-DHRKC-H-D
PRODUCT NAME: RK8E/RK8L DATA RELIABILITY PROGRAM
DATE RELEASED: FEBRUARY, 1977
MAINTAINER: DIAGNOSTIC ENGINEERING
AUTHOR: JOHN VRUBEL/WILLIAM HEAVEY

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED UNDER A LICENSE AND MAY ONLY BE USED OR COPIED IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1972, 1975, 1976, 1977 BY DIGITAL EQUIPMENT CORPORATION

TABLE OF CONTENTS

1.	ABSTRACT
2.	RESTRICTIONS
2.1	HARDWARE
2.2	PROGRAM STORAGE
2.3	PRELIMINARY PROGRAMS
2.4	EXECUTION TIME
3.	SWITCH REGISTER SETTINGS
4.	OPERATOR AND/OR PROGRAM ACTION
4.1	STANDARD TEST PROCEDURE
4.2	RK05J DRIVE CARTRIDGE MOUNTING PROCEDURE
4.3	RK05F DRIVE MOUNTING PROCEDURE
4.4	RK0E/RK0L DATA RELIABILITY (ACCEPT MODE)
4.5	RK0E DATA RELIABILITY (MANUAL INTERVENTION MODE)
4.6	CHANGE PROGRAM IOT CODES
5.	ERRORS
5.1	USEFUL INFORMATION
5.2	ERROR HALTS
5.3	ERROR TIMEOUTS
5.4	ERROR RECOVERY AND ERROR DISCONNECT
5.5	STATUS COMPLETE TIMEOUT AND PASS COMPLETE DISCONNECT
5.6	TYPICAL ERROR TIMEOUTS
6.	RESTRICTIONS
7.	TROUBLE SHOOTING INFORMATION
8.	PROGRAM DESCRIPTION (ACCEPT MODE)
9.	CONSOLE PACKAGE ADDENDUM
10.	APT-8 HOOKS
11.	PROGRAM LISTING

1.

ABSTRACT

THE RK8E/RK8L DATA RELIABILITY PROGRAM IS DESIGNED PRIMARILY AS AN ACCEPTANCE TEST TO VERIFY DISK DATA TRANSFERS WITHIN THE DISK SYSTEM.

THE "ACCEPT MODE" OF OPERATION VERIFIES THE CAPABILITY OF TRANSFERRING A TOTAL 3 X 10(9) BITS OF DATA TO AND FROM EACH INDIVIDUAL DISK DRIVE ON THE DISK SYSTEM.

THE "MANUAL INTERVENTION MODE" IS AVAILABLE AS A HARDWARE DEBUGGING AID TO ALLOW THE OPERATOR TO SELECT DATA PATTERNS, TRANSFER LENGTHS, AND ADDRESSING.

(NOTE: LOCATION 0 CONTAINS REVISION LEVEL (IN ASCII) OF PROGRAM ON PROGRAM LOAD).

2.

RESTRICTIONS

THE RK8L CONTROL, WHICH CAN CONTROL UP TO 8 DRIVES, WILL NOT RUN WITH THE DM8E BUS ADAPTER. THE REASON FOR THIS STATEMENT IS THAT THE RK8L CONTROL USES IOTS FOR EXTENDED DRIVES 4-7 WHICH IS NOT AVAILABLE ON THE DM8E.

2.1

HARDWARE

A. PDP-8/A, 8/E, 8/F, OR 8/M COMPUTER OR OTHER FAMILY OF 8 COMPATIBLE COMPUTER WITH NECESSARY DM8E BUS ADAPTER.

B. AT LEAST 4K OF READ/WRITE MEMORY. AT LEAST 8K OF MEMORY IS NECESSARY FOR OPERATION OF THE CONSOLE PACKAGE.

C. ASR-33 TELETYPE OR EQUIVALENT

D. RK8E OR RK8L DISK CONTROL

E. RK05J OR RK05F DISK DRIVE(S)

F. FORMATTED 2200 DPI-16 SECTOR PACK(S).

NOTE: THE RK05F DISK DRIVE IS CONSIDERED AS TWO SEPARATE UNITS. WHEN ANSWERING ALL QUESTIONS THE SEPARATE DRIVES MUST BE SPECIFIED. DSK07, DSK17, DSK27, ETC.

2.2

PROGRAM STORAGE

THE PROGRAM OCCUPIES OR UTILIZES LOCATION 0000 TO LOCATION 7577 OF FIELD 0. ALL EXTENDED MEMORY LOCATIONS, IF AVAILABLE, ARE UTILIZED FOR TESTING.

2.3

PRELIMINARY PROGRAMS

THIS PROGRAM REQUIRES A FORMATTED CARTRIDGE ON ALL DRIVES TO BE TESTED.

ALL BASIC AND EXTENDED MEMORY DIAGNOSTICS SHOULD BE RUN PRIOR TO RUNNING THIS PROGRAM.

RK8E CONTROL: RUN THE RK8E DISKLESS CONTROL TEST AND THE RK8E/RK8L DISK FORMATTER IF THIS DIAGNOSTIC FAILS TO OPERATE PROPERLY.

RK8L CONTROL: RUN THE RK8L INSTRUCTION TEST AND THE RK8E/RK8L FORMATTER IF THIS DIAGNOSTIC FAILS TO OPERATE PROPERLY.

2.4 EXECUTION TIME -----

THE PROGRAM EXECUTION TIME (I.E., PASSING 3 X 10⁹ BITS OF DATA ON A DISK DRIVE), IS APROX. 4 HOURS PER DISK DRIVE ON A 4K MEMORY SYSTEM OR APROX. 3.5 HOURS PER DISK DRIVE ON SYSTEMS WITH EXTENDED MEMORY.

3. SWITCH REGISTER SETTINGS -----

SWR0#1 LOOP ON WRITE SEQUENCE.
SWR1#1 LOOP ON READ SEQUENCE.
SWR2#1 INHIBIT ALL ERROR TYPEOUTS
SWR3#1 TYPE "STATUS-COMPLETEN" REPORT.
SWR4#1 PROGRAM STOP ON HALT.
SWR5#1 DRIVE DISCONNECT AFTER PASS COMPLETION.
SWR6#1 PERFORM ONLY "OVERLAP SEEKS", DO NOT EXECUTE DATA BREAKS.

4. OPERATOR AND/OR PROGRAM ACTION -----

4.1 STANDARD TEST PROCEDURE -----

- A. START AS SPECIFIED THROUGH OUT THIS DOCUMENTATION IS KEY CLEAR AND THEN KEY CONTINUE ON PDP8/E, PDP8/M, AND PDP8/F COMPUTERS.
- B. LOAD THE PROGRAM INTO MEMORY FIELD 0 USING THE STANDARD BINARY LOADER TECHNIQUE.
- C. IF IT IS DESIRED TO CHANGE THE IOT CODES WITHIN THE PROGRAM, FOLLOW THE PROCEDURE IN SECTION 4.6.
- D. RUN THE ACCEPTANCE MODE OF DATA RELIABILITY WITH ALL DRIVES AND MEMORY AVAILABLE BY FOLLOWING THE PROCEDURE

IN SECTION 4.4.

- E. THE MANUAL INTERVENTION MODE, SECTION 4.5, MAY BE USED FOR TROUBLE SHOOTING, IF DESIRED.
- F. IF POSSIBLE SWR4#1 SHOULD ALWAYS BE USED TO STOP THE PROGRAM.
- G. IF THE PROGRAM HAS BEEN STOPPED DUE TO SWR4#1, THE PROGRAM CAN BE RESTARTED, AND THE INITIAL STARTUP QUESTIONS BYPASSED, BY USING 0205 AS THE RESTART ADDRESS.
- H. FOR THE ABSOLUTE LOCATIONS OF ALL KNOWN HALTS IN THIS PROGRAM, ACCESS PAGE 1-22 OF THE PROGRAM LISTING.

4.2

RK05J DRIVE CARTRIDGE MOUNTING PROCEDURE

THE FOLLOWING IS THE CORRECT CARTRIDGE MOUNTING PROCEDURE FOR THE RK05J DISK DRIVE. ANY DEVIATION ENCOUNTERED DURING THIS PROCEDURE WILL BE CONSIDERED AN ERROR CONDITION.

- A. SET SWITCH LABELED "RUN/LOAD" TO THE "LOAD" POSITION.
- B. TURN AC POWER TO DISK DRIVE ON.
- C. VERIFY THAT THE LIGHT LABELED "PWR" IS ON.
- D. WAIT FOR THE LIGHT LABELED "LOAD" TO COME ON.
- E. VERIFY THAT THE LIGHTS LABELED "RDY", "ON CYL", "FAULT", "WT", AND "RD" ARE OFF.
- F. OPEN ACCESS DOOR.
- G. INSERT CARTRIDGE.
- H. CLOSE ACCESS DOOR.
- I. SET SWITCH LABELED "RUN/LOAD" TO THE "RUN" POSITION.
- J. WAIT FOR THE LIGHTS LABELED "RDY" AND "ON CYL" TO COME ON.
- K. TOGGLE SWITCH LABELED "WT PROT" AND VERIFY THAT THE LIGHT LABELED "WT PROT" GOES ON AND OFF.
- L. TOGGLE SWITCH LABELED "WT PROT" UNTIL THE LIGHT LABELED "WT PROT" IS OFF.
- M. VERIFY THAT LIGHTS LABELED "FAULT", "WT", "RD", AND "LOAD" ARE OFF.

4.3

RK05F DRIVE SETUP PROCEDURE

THE FOLLOWING IS THE CORRECT SETUP PROCEDURE

FOR THE RK05F DISK DRIVE. ANY DEVIATION ENCOUNTERED DURING THIS PROCEDURE WILL BE CONSIDERED AN ERROR CONDITION.

- A. SET SWITCH LABELED "RUN/LOAD" TO THE "LOAD" POSITION.
- B. TURN AC POWER ON.
- C. VERIFY THAT LIGHT LABELED "PWR" IS ON.
- D. WAIT FOR LIGHT LABELED "LOAD" TO COME ON.
- E. VERIFY THAT LIGHTS LABELED "RDY", "ON CYL", "FAULT", "WT", AND "RD" ARE OFF.
- F. SET SWITCH LABELED "RUN/LOAD" TO THE "RUN" POSITION.
- G. WAIT FOR LIGHTS LABELED "RDY" AND "ON CYL" TO COME ON.
- H. TOGGLE SWITCH LABELED "WT PROT" AND VERIFY THAT THE LIGHT LABELED "WT PROT" GOES ON AND OFF.
- I. TOGGLE SWITCH LABELED "WT PROT" UNTIL LIGHT LABELED "WT PROT" GOES OFF.
- J. VERIFY THAT LIGHTS LABELED "FAULT", "WT", "RD", AND "LOAD" ARE OFF.

4.4

RK06/RK08L DATA RELIABILITY (ACCEPT MODE)

- A. MAKE READY ALL DRIVES TO BE TESTED USING THE RK05J DRIVE CARTRIDGE MOUNTING PROCEDURE SECTION 4.2 OR THE RK05F DRIVE PROCEDURE IN SECTION 4.3.
- B. SET SWITCH LABELED "RUN/LOAD" TO THE "LOAD" POSITION ON ALL DRIVES NOT BEING TESTED.
- C. VERIFY THAT AC POWER IS ON, ON ALL DRIVES NOT BEING TESTED.
- D. SET THE SWITCH REGISTER TO 0200 AND PRESS LOAD ADDRESS.
- E. SET THE SWITCH REGISTER TO 0000 AND PRESS START.
- F. THE OPERATOR MAY SET SWRS=1 IF IT IS DESIRED TO HAVE THE PROGRAM AUTOMATICALLY DISCONNECT EACH DISK DRIVE AS EACH MAKE THEIR PASS COMPLETION. (NOTE: IF SWRS=0, ALL DISK DRIVES WILL CONTINUE TO RUN AFTER THEIR PASS COMPLETION)
- G. THE TTY WILL PRINT THE FOLLOWING PROGRAM NAME AND QUESTION.

RK06/RK08L DATA RELIABILITY
EXTENDED R/W MEMORY (0-7)?

THE OPERATOR SHOULD THEN TYPE THE AMOUNT OF EXTENDED READ/ WRITE MEMORY BANKS NUMBERED SEQUENTIALLY FROM BANK 0, AS INDICATED BY THE TTY QUESTION.

- H. THE TTY WILL PRINT THE FOLLOWING QUESTION(S), ASKING THE

DESIRED DISK DRIVE(S) TO BE USED IN TESTING.

EXERCISE DISK07
EXERCISE DISK17
EXERCISE DISK27
EXERCISE DISK37
EXERCISE DISK47
EXERCISE DISK57
EXERCISE DISK67
EXERCISE DISK77

FOR THE QUESTION(S) ABOVE, TYPE Y FOR YES, IF IT IS DESIRED TO TEST THE DISK DRIVE IN QUESTION, OTHERWISE, TYPE N FOR NO.

I. THE TTY WILL PRINT THE FOLLOWING QUESTION.

ACCEPT MODE?

THE OPERATOR SHOULD THEN TYPE Y FOR YES TO RUN THE ACCEPTANCE MODE OF OPERATION.

J. THE TTY WILL PRINT THE FOLLOWING QUESTION.

ARE YOU SURE?

IF THE OPERATOR IS CERTAIN OF THE AMOUNT OF MEMORY, THE DISK DRIVE(S) SELECTED, AND THE MODE OF OPERATION, TYPE Y FOR YES. TYPING N FOR NO WILL RESULT IN A REPEAT OF ALL MESSAGES AND QUESTIONS ENCOUNTERED THUS FAR.

K. THE PROGRAM SHOULD START TESTING THE DISK DRIVE(S) AND MEMORY SELECTED.

L. THE "STATUS=COMPLETE" TIMEOUT SHOULD OCCUR UPON PASS COMPLETION OF EACH DISK DRIVE. ALL OTHER TIMEOUTS OR HALTS WILL BE CONSIDERED AS AN ERROR CONDITION. SEE SECTION 5.5 FOR "STATUS=COMPLETE" TIMEOUT.

M. A SUCCESSFUL PASS COMPLETE ON A DISK DRIVE WILL BE CONSIDERED AS NO "HARD" ERRORS AND NO MORE THAN ONE (1) "SOFT" ERROR PER PASS COMPLETE.

N. IF ANY ERRORS DO OCCUR, THE OPERATOR SHOULD ACCESS SECTION 5 IN THIS DOCUMENTATION.

4.5

RK8E/RK8L DATA RELIABILITY (MANUAL INTERVENTION MODE)

THE MANUAL INTERVENTION MODE IS AVAILABLE AS A TROUBLE SHOOTING AID AND SHOULD ONLY BE USED FOR SUCH PURPOSES, IF DESIRED.

A. MAKE READY ALL DISK DRIVES TO BE TESTED USING THE RK05J DRIVE CARTRIDGE MOUNTING PROCEDURE SECTION 4.2. OR THE RK05F DRIVE PROCEDURE SECTION 4.3.

B. SET SWITCH LABELED "RUN/LOAD" TO THE "LOAD" POSITION ON

ALL DRIVES NOT BEING TESTED.

- C. VERIFY THAT AC POWER IS ON, ON ALL DRIVES NOT BEING TESTED.
- D. SET THE SWITCH REGISTER TO 0200 AND PRESS LOAD ADDRESS.
- E. SET THE SWITCH REGISTER TO 0000 AND PRESS START.
- F. THE TTY WILL PRINT THE FOLLOWING PROGRAM NAME AND QUESTION.

RK0E/RK0L DATA RELIABILITY
EXTENDED R/W MEMORY (0-7)?

THE OPERATOR SHOULD THEN TYPE THE AMOUNT OF EXTENDED READ/
WRITE MEMORY BANKS NUMBERED SEQUENTIALLY FROM BANK 0, AS
INDICATED BY THE TTY QUESTION.

- G. THE TTY WILL PRINT THE FOLLOWING QUESTION(S), ASKING THE
DESIRED DISK DRIVE(S) TO BE USED IN TESTING.

EXERCISE DISK0?
EXERCISE DISK1?
EXERCISE DISK2?
EXERCISE DISK3?
EXERCISE DISK4?
EXERCISE DISK5?
EXERCISE DISK6?
EXERCISE DISK7?

FOR THE QUESTION(S) ABOVE, TYPE Y FOR YES, IF IT IS DESIRED
TO TEST THE DISK DRIVE IN QUESTION, OTHERWISE, TYPE N FOR
NO.

- H. THE TTY WILL PRINT THE FOLLOWING QUESTION.

ACCEPT MODE?

THE OPERATOR SHOULD THEN TYPE N FOR NO TO RUN THE MANUAL
INTERVENTION MODE OF OPERATION.

- I. THE TTY WILL THEN PRINT THE FOLLOWING QUESTION, ASKING
IF THE OPERATOR DESIRES TO SELECT A CONSTANT MEMORY FIELD,
RATHER THAN THE NORMAL RANDOM FIELD SELECTION.

FIELD?

IF THE OPERATOR DESIRES TO SELECT A CONSTANT FIELD,
TYPE Y FOR YES, OTHERWISE, TYPE N FOR NO. IF Y WAS TYPED THE
TTY WILL SPACE OUT ONCE AND WAIT FOR THE OPERATOR TO TYPE
THE DESIRED FIELD IN OCTAL (0-7).

- J. THE TTY WILL PRINT THE FOLLOWING QUESTION, ASKING IF THE
OPERATOR DESIRES TO SELECT A CONSTANT TRACK, RATHER THAN
THE NORMAL RANDOM TRACK SELECTION.

TRACK?

IF THE OPERATOR DESIRES TO SELECT A CONSTANT TRACK, TYPE Y FOR YES, OTHERWISE, N FOR NO. IF Y WAS TYPED, THE TTY WILL SPACE OUT ONCE AND WAIT FOR THE OPERATOR TO INPUT THE DESIRED TRACK ADDRESS (00000-14537).

- K. THE TTY WILL PRINT THE FOLLOWING QUESTION, ASKING IF THE OPERATOR DESIRES TO SELECT HALF BLOCK OR FULL BLOCK TRANSFERS, RATHER THAN THE NORMAL RANDOM SELECTION.

BLOCK LENGTH?

IF THE OPERATOR DESIRES TO CHANGE THE BLOCK LENGTH, TYPE Y FOR YES, OTHERWISE, N FOR NO. IF Y WAS TYPED THE TTY WILL SPACE OUT ONCE AND WAIT FOR THE OPERATOR TO TYPE THE BLOCK LENGTH DESIRED (0-256 WORD BLOCK OR 1-128 WORD BLOCK).

- L. THE TTY WILL PRINT THE FOLLOWING QUESTION, ASKING IF THE OPERATOR DESIRES TO SELECT A CONSTANT NUMBER OF SECTORS TO BE TRANSFERED, RATHER THAN THE NORMAL RANDOM SECTOR SELECTION.

EXTRA SECTORS?

IF THE OPERATOR DESIRES TO SELECT A CONSTANT AMOUNT OF SECTORS, TYPE Y FOR YES, OTHERWISE, N FOR NO. IF Y WAS TYPED THE TTY WILL SPACE OUT ONCE, AND WAIT FOR THE OPERATOR TO TYPE IN THE EXTRA SECTORS DESIRED (00-17). (NOTE: IF THE FIELD AND THE BLOCK LENGTH PREVIOUSLY SELECTED WAS 0, THE AMOUNT OF EXTRA SECTORS WILL BE LIMITED TO 07. OTHERWISE THE MAXIMUM AMOUNT IS LIMITED TO 17.)

- M. THE TTY WILL PRINT THE FOLLOWING QUESTION, ASKING IF THE OPERATOR DESIRES TO SELECT A DATA PATTERN, RATHER THAN NORMAL RANDOM DATA SELECTION.

DATA?

IF THE OPERATOR DESIRES TO SELECT A DATA PATTERN, TYPE Y FOR YES, OTHERWISE, N FOR NO. IF Y WAS TYPED, THE TTY WILL DO A "CRLF" AND WAIT FOR THE OPERATOR TO TYPE IN 12 OCTAL DATA WORDS TO BE USED IN TESTING.

- N. THE TTY WILL PRINT THE FOLLOWING QUESTION.

ARE YOU SURE?

IF THE OPERATOR IS CERTAIN OF THE INFORMATION SELECTED, TYPE Y FOR YES. TYPING N FOR NO WILL RESULT IN A REPEAT OF ALL MESSAGES AND QUESTIONS ENCOUNTERED THUS FAR.

- P. THE PROGRAM SHOULD START EXECUTING THE OPERATIONS SELECTED.

- R. IF ERRORS ARE ENCOUNTERED, ACCESS SECTION 5 IN THIS DOCUMENTATION.

THE PROGRAM NORMALLY RECOGNIZES DEVICE IOT CODE X74X. TO CHANGE THE DEVICE IOT CODES WITHIN THE PROGRAM:

- A. SET THE SWITCH REGISTER TO 0204 AND PRESS LOAD ADDRESS.
- B. SET THE SWITCH REGISTER TO 0000, SET SWITCH REGISTER BITS 3-8 TO THE DESIRED DEVICE IOT CODE, AND PRESS START.
- C. THE PROGRAM WILL CHANGE THE DEVICE IOT CODES WITHIN THE PROGRAM AND THEN HALT.
- D. PRESSING KEY CONTINUE WILL START THE PROGRAM AT LOCATION 0200 (SEE SECTIONS 4.4 OR 4.5 FOR OPERATION INSTRUCTIONS).

5. ERRORS -----

5.1 USEFUL INFORMATION -----

ALL STATUS ERRORS WILL BE REPORTED AS STATUS ERRORS. ALL DATA ERRORS WILL BE REPORTED AS DISK DATA ERRORS.

WHEN DATA IS BEING READ OFF THE DISK AND A CRC ERROR OCCURRES THE PROGRAM WILL REPORT THE ERROR AS A READ STATUS ERROR. THE PROGRAM WILL THEN CHECK THE DATA READ FOR DATA ERRORS. IF DATA ERRORS EXIST THEY WILL BE REPORTED AS DISK DATA ERRORS.

5.2 ERROR HALTS -----

ERROR HALTS FOR WHICH THERE ARE NO ERROR TYPEOUTS ARE LISTED AND DEFINED AS FOLLOWS.

BIGSTP	MASTER ERROR HALT FOR ALL OF THE FOLLOWING ERROR STOPS. WHEN THE COMPUTER HALTS THE AC REGISTER WILL INDICATE THE PC OF THE FAILING ERROR STOP.
INTER1	NO DISK INTERRUPT
ERHLT0	SKIP TRAP FOR IOT "DLSC"
ERHLT2	SKIP TRAP FOR IOT "OCLR"
ERHLT3	SKIP TRAP FOR IOT "DLRG"
ERHLT5	SKIP TRAP FOR IOT "DRST"
ERHLT6	SKIP TRAP FOR IOT "DLDC"
BADHLT	CHECKSUM FAILED BUT WORD-BY-WORD COMPARE WORKED

NODSKS

NO DISKS AVAILABLE TO RUN

FLDHLT

PROGRAM WILL ONLY RUN IN FIELD 0

FOR THE ABSOLUTE LOCATIONS OF THE HALTS LISTED ABOVE,
ACCESS PAGE 1-22 OF THE PROGRAM LISTING.

5.3

ERROR TYPEOUTS

WHEN AN ERROR OCCURRES THE PROGRAM WILL PRINT AN
"ERROR HEADER" WHICH WILL SPECIFY THE PARTICULAR TYPE
OF ERROR FOUND AT THE TIME OF THE FAILURE.

POSSIBLE "ERROR HEADERS" ARE AS FOLLOWS.

WRITE STATUS ERROR
READ STATUS ERROR
DISK DATA ERROR
RECALIBRATE STATUS ERROR

AFTER THE "ERROR HEADER" MENTIONED ABOVE IS TYPED, THE
PROGRAM WILL PRINT THE FOLLOWING ERROR INFORMATION
FOUND AT THE TIME OF THE FAILURE, PERTAINING TO THE
FAILURE. POSSIBLE TYPEOUTS ARE AS FOLLOWS.

PC: PROGRAM LOCATION OF THE ACTUAL FAILURE.
ST: CONTENTS OF THE STATUS REGISTER.
EX: EXTENDED DRIVE BIT
CM: SOFTWARE COMMAND REGISTER.
IA: INITIAL SOFTWARE DISK ADDRESS REGISTER OR THE
CYLINDER, SURFACE, AND SECTOR BITS.
DA: FINAL SOFTWARE DISK ADDRESS REGISTER OR THE
CYLINDER, SURFACE, AND SECTOR BITS.
CA: SOFTWARE INITIAL CURRENT ADDRESS
WC: SOFTWARE INITIAL WORD COUNT
FW: SOFTWARE FINAL WORD COUNT
AS: SECTOR IN ERROR ON THE PARTICULAR CYLINDER
AND SURFACE IN QUESTION.
WA: WORD ADDRESS WITHIN THE SECTOR IN ERROR
AD: BREAK ADDRESS OF DATA BREAK IN COMPUTEX.
DG: EXPECTED DATA
DB: DATA FOUND DURING DATA BREAK.

ERROR RECOVERY AND ERROR DISCONNECT

WHEN A READ, WRITE, OR DISK DATA ERROR OCCURS (SEE SECTION 5,3), THE PROGRAM WILL TRY TO REPEAT THE FAILING SEQUENCE FOUR (4) TIMES. IF THE ERROR HAS OCCURRED FOUR (4) TIMES SIMULTANEOUSLY, THE ERROR WILL BE CONSIDERED AS A NON-RECOVERABLE ERROR, THE "ERROR HEADER" WILL BE CHANGED TO INDICATE "NON-RECOVERABLE" ERROR, ANOTHER DISK ADDRESS WILL BE SELECTED FOR TESTING. IF A "SOFT" ERROR SHOULD OCCUR ON A TRACK, THE PROGRAM WILL RETRY THE READ SEQUENCE (64) TIMES BEFORE SELECTING ANOTHER TRACK FOR TESTING. (NOTE: THIS 64 RETRY'S ON "SOFT" ERRORS WILL BE TERMINATED ON A "HARD" ERROR).

POSSIBLE NON-RECOVERABLE ERROR HEADERS ARE AS FOLLOWS.

NON-RECOVERABLE READ STATUS ERROR
NON-RECOVERABLE WRITE STATUS ERROR
NON-RECOVERABLE DISK DATA ERROR

IF A NON-RECOVERABLE READ OR WRITE ERROR SHOULD OCCUR, THE DISK IN QUESTION WILL THEN BE RECALIBRATED (RESTORED TO CYLINDER 0). IF THE RECALIBRATE SEQUENCE FAILS, THE DISK DRIVE IN ERROR WILL BE DISCONNECTED BY THE PROGRAM AND NO LONGER BE TESTED.

THE FOLLOWING "DISCONNECT" AND "STATUS-COMPLETE" TYPEOUTS SHOULD OCCUR.

RECALIBRATE ERROR DISCONNECT!
DISK X DISCONNECTED!
DSK HARD SOFT COMP
X 0030 0010 0001
X 0240 5670 0001

IF ALL DISKS ON THE SYSTEM HAVE BEEN DISCONNECTED DO TO RECALIBRATE ERRORS THE FOLLOWING TYPEOUT WILL OCCUR AND THE PROGRAM WILL HALT.

DISK SYSTEM SHUT DOWN, NO DISKS TO RUN!

STATUS-COMPLETE TYPEOUT AND PASS COMPLETE DISCONNECT

ALL ERRORS AND PASS COMPLETES ARE TALLIED BY THE PROGRAM PER DISK DRIVE.

THE FOLLOWING IS AN EXAMPLE OF THE "STATUS-COMPLETE" TYPEOUT THAT WILL OCCUR WHEN \$WR3=1 INDICATING TYPE THIS REPORT, A PASS COMPLETE OCCURS ON A DRIVE UNDER TEST, OR A DRIVE IS DISCONNECTED DO TO A RECALIBRATE ERROR.

DSK HARD SOFT COMP
X XXXX XXXX XXXX
X XXXX XXXX XXXX
X XXXX XXXX XXXX

X XXXX XXXX XXXX

THE TYPEOUT AS MENTIONED ABOVE IS DESCRIBED AS FOLLOWS.

DSK DISK DRIVE IN QUESTION.

HARD ALL ERRORS OTHER THAN THAT DEFINED AS
A SOFT ERROR.

SOFT A READ CRC STATUS ERROR WITH BAD DATA PER
TRANSFER WITH RECOVERY POSSIBLE WITHIN FOUR (4)
RETRYs. (NOTE: FOUR (4) CONSECUTIVE RETRYs WILL
BE CONSIDERED AS A NON-RECOVERABLE ERROR OR A
"HARD" ERROR).

COMP PASS COMPLETES. <3 X 10(9) BITS>

IF SWRS=1 INDICATING "DISCONNECT ON PASS COMPLETION", AND
A DISK DRIVE UNDER TEST MAKES A PASS COMPLETION, THE
FOLLOWING TYPEOUT WILL OCCUR AND THE DRIVE WILL BE
DISCONNECTED.

DISK X PASS COMPLETE!
DISK X DISCONNECTED!
DSK HARD SOFT COMP
X XXXX XXXX XXXX
X XXXX XXXX XXXX

IF SWRS=0 INDICATING DON'T "DISCONNECT ON PASS COMPLETION",
AND A DISK DRIVE UNDER TEST MAKES A PASS COMPLETION, THE
FOLLOWING TYPEOUT WILL OCCUR AND THE DRIVE WILL CONTINUE
TO RUN.

DISK X PASS COMPLETE!
DSK HARD SOFT COMP
X XXXX XXXX XXXX
X XXXX XXXX XXXX

IF SWRS=1 AND ALL DRIVES HAVE MADE THEIR PASS COMPLETION
AND HAVE BEEN DISCONNECTED, THE FOLLOWING TYPEOUT WILL
OCCUR AND THE COMPUTER WILL HALT.

DISK SYSTEM SHUT DOWN, NO DISKS TO RUN!

5.6

TYPICAL ERROR TYPEOUTS

THE FOLLOWING IS AN EXAMPLE OF AN "ERROR HEADER" AND
ERROR TYPEOUT THAT COULD HAVE OCCURRED ON A WRITE STATUS
ERROR. (NOTE CRC IN THE STATUS INDICATOR "STI")

WRITE STATUS ERROR
PC:2371 ST:4010 EX:0001 CM:4000 IA:0001 DA:0002
CA:3600 WC:7000 FW:0000

THE FOLLOWING IS AN EXAMPLE OF AN ERROR TYPEOUT THAT COULD
HAVE OCCURRED IF THE STATUS REGISTER FAILED ON A SEEK
ONLY FUNCTION.

SEEK STATUS ERROR

PC:2076 ST:4002 EX:0001 CM:3000 DA:4007

THE FOLLOWING IS A TYPICAL EXAMPLE OF AN "ERROR HEADER"
AND ERROR TYPEOUT THAT COULD HAVE OCCURRED ON A DISK
DATA ERROR. (NOTE: ADDITION DATA ERRORS IN BUFFER)

DISK DATA ERROR

PC:1674 ST:4010 EX:0001 CM:1432 IA:1035 DA:1021
CA:0001 WC:5000 FW:7400
AS:0015 WA:0007 AD:0010 DG:0537 DB:0536
AS:0015 WA:0077 AD:0100 DG:7777 DB:7776
AS:0016 WA:0002 AD:0403 DG:6167 DB:6166

6. RESTRICTIONS

ALL DISK DRIVES SHOULD BE SET TO THE LOAD POSITION
THAT ARE NOT BEING TESTED.

7. TROUBLE SHOOTING INFORMATION

IOT

FUNCTION

6740 DLSC

LOAD SECTOR COUNTER AND EXTENDED
DRIVE BIT FOR RK8L.

AC

--

0-3

LOAD THE DESIRED AMOUNT OF SECTORS
TO BE TRANSFERRED WITH THE BINARY
VALUE IN AC BITS 0-3.

4

EXTENDED DRIVE BIT FOR DRIVES 4-7

6741 DSKP

"SKIP" SKIP IF TRANSFER DONE FLAG
OR ERROR FLAG IS SET.

6742 DCLR

"CLEAR" FUNCTION IS REGULATED BY
AC BITS 10 AND 11. THE AC IS THEN
CLEARED.

AC10

AC11

0

0

CLEAR THE AC AND STATUS REGISTER.

0

1

CLEAR THE AC, CONTROL, AND MAJOR
REGISTERS. THIS INSTRUCTION WILL
STOP THE CONTROL EVEN IF IT IS
WRITING A HEADER. THIS IS THE ONLY
INSTRUCTION THAT CLEARS MAINTENANCE
MODE.

1 0

CLEAR AC, RECALIBRATE DISK DRIVE,
AND CLEAR STATUS REGISTER.

6743 DLAG

"LOAD DISK ADDRESS AND GO" LOAD THE
DISK CYLINDER, SURFACE, AND SECTOR
FROM THE AC, CLEAR THE AC, AND DO
THE COMMAND IN THE COMMAND REGISTER.

AC
--

0-6

CYLINDER

7

SURFACE (1=UPPER) (0=LOWER)

8-11

SECTOR

6744 DLCA

"LOAD CURRENT ADDRESS" LOAD THE
CURRENT ADDRESS FROM AC. THE AC
IS THEN CLEARED.

AC
--

0-11

CURRENT ADDRESS

6745 DRST

"READ STATUS" CLEAR THE AC AND
READ THE CONTENTS OF THE STATUS
REGISTER INTO THE AC.

AC
--

0
1
2
3
4
5
6
7
8
9
10
11

TRANSFER DONE
READY TO SEEK, READ, OR WRITE.
NOT USED
SEEK FAIL
DISK FILE READY
CONTROL BUSY ERROR
TIME OUT ERROR
WRITE LOCK ERROR
CRC ERROR
DATA RATE ERROR
DRIVE STATUS ERROR
CYLINDER ADDRESS ERROR

6746 DLDC

"LOAD COMMAND" LOAD THE COMMAND
REGISTER FROM AC, CLEAR THE AC,
AND CLEAR THE STATUS REGISTER.

AC
--

0-2#0
0-2#1
0-2#2
0-2#3
0-2#4

READ DATA
READ ALL
WRITE LOCK
SEEK ONLY
WRITE DATA

0-205	WRITE ALL
0-206	NOT USED
0-207	NOT USED
3	ENABLE INTERRUPT
4	ENABLE SET TRANSFER DONE ON SEEK DONE
5	HALF BLOCK 120 WORDS
6	EXTENDED MEMORY ADDRESS
7	EXTENDED MEMORY ADDRESS
8	EXTENDED MEMORY ADDRESS
9	UNIT SELECT
10	UNIT SELECT
11	EXTENDED CYLINDER ADDRESS

6747 DMAN

"MAINTENANCE IOT" LOAD THE MAINTENANCE REGISTER FROM THE AC. THE FUNCTION IS REGULATED BY THE AC BITS. MAINTENANCE MODE CAN ONLY BE CLEARED BY DCLK "CLEAR CONTROL".

AC
--

0	ENTER MAINTENANCE MODE
1	ENABLE SHIFT TO LOWER BUFFER
2	AC BIT 10, CRC REGISTER, AND THE LOWER DATA BUFFER ARE CONNECTED AS A SHIFT REGISTER. AC BIT 10 DATA SHIFTS TO THE CRC, THE CRC SHIFTS TO THE LOWER DATA BUFFER.
3	SHIFT COMMAND REGISTER TO THE LOWER DATA BUFFER.
4	SHIFT THE SURFACE AND SECTOR REGISTER TO THE LOWER DATA BUFFER.
5	SHIFT AC 10 DATA TO THE UPPER DATA BUFFER. THE UPPER BUFFER SHOULD SINK IN THE SILO WHEN FULL.
6	ONE SINGLE CYCLE BREAK REQUEST. DIRECTION IS REGULATED BY FUNCTION IN THE COMMAND REGISTER.
7	CLEAR AC THEN READ THE LOWER DATA BUFFER TO THE AC.
8	NOT USED.
9	NOT USED.
10	USED AS DATA WITH OTHER BITS IN THE MAINTENANCE MODE.
11	NOT USED

8. PROGRAM DESCRIPTION (ACCEPT MODE)

THE FOLLOWING IS BRIEF DESCRIPTION OF THE STEPS TAKEN BY THE PROGRAM WHEN RUNNING THE ACCEPT MODE.

A. A RANDOM FIELD IS GENERATED. IF FIELD GENERATED IS A NON-EXISTING FIELD, THE MAXIMUM FIELD AVAILABLE WILL BE USED.

- B. A RANDOM BLOCK LENGTH IS GENERATED (128 OR 256 WORD SECTORS).
- C. A RANDOM AMOUNT OF SEQUENTIAL SECTORS TO TRANSFER IS GENERATED. IF THE FIELD PREVIOUSLY SELECTED WAS AN EXTENDED FIELD OR IF HALF BLOCK TRANSFERS WERE SELECTED (128 WORD SECTORS), THE AMOUNT OF SECTORS WILL BE LIMITED TO 17(8). IF THE FIELD SELECTED WAS FIELD 0 AND IF FULL BLOCK TRANSFERS WERE SELECTED(256 WORD SECTORS), THE AMOUNT OF SECTORS WILL BE LIMITED TO 7(8).
- D. A RANDOM STARTING SECTOR WILL BE GENERATED. THE RANDOM AMOUNT OF EXTRA SECTORS PREVIOUSLY GENERATED WILL BE ADDED TO THIS STARTING SECTOR, DETERMINING THE ACTUAL LENGTH OF THE DATA TRANSFER. IF THE STARTING SECTOR WAS 14 AND THE AMOUNT OF EXTRA SECTORS WAS 6, SECTORS 14, 15, 16, 17, 00, 01, AND 02 WILL BE USED FOR TRANSFERING DATA.
- E. AN INITIAL SOFTWARE WORD COUNT WILL BE CALCULATED.
- F. AN INITIAL RANDOM CURRENT ADDRESS WILL BE GENERATED. IF THE FIELD PREVIOUSLY GENERATED WAS FIELD 0, THE CURRENT ADDRESS WILL BE LIMITED WITHIN THE END OF THE PROGRAM +4000 LOCATIONS.
- G. THE BUFFER SELECTED WILL BE FILLED WITH RANDOM DATA, CHECKSUMMED, AND THE CHECKSUM SAVED. (NOTE: BUFFER IS DEPENDENT ON FIELD, WORD COUNT, BLOCK LENGTH, AND CURRENT ADDRESS PREVIOUSLY SELECTED.)
- H. THE PROGRAM WILL THEN POLE THE DISK DRIVES. DRIVE SELECTION IS SEQUENTIAL, THAT IS DISK0, DISK1, DISK2, ETC.
- I. DATA WILL BE WRITTEN ON THE SELECTED DISK DRIVE TO COMPLETE THE SEEK OPERATION USING THE RANDOM PARAMETERS GENERATED ABOVE. AS DATA IS WRITTEN, A BACK GROUND PROGRAM WILL CLEAR THE BUFFER AREA ALREADY WRITTEN ON THE DISK.
- J. WHEN THE WRITE AND CLEAR IS COMPLETE, DATA WILL BE READ OFF THE CURRENT DRIVE INTO THE BUFFER AREA. AS DATA IS READ, A BACK GROUND PROGRAM WILL CHECKSUM THE BUFFER INFORMATION ALREADY READ OFF THE DISK.
- K. WHEN THE READ AND CHECKSUM IS COMPLETE, THE CHECKSUM FOUND WILL BE COMPARED TO THE CHECKSUM SAVED PREVIOUS TO THE WRITE OPERATION. IF CHECKSUMS DO NOT COMPARE OR IF A CRC ERROR HAS OCCURRED, A WORD BY WORD COMPARE WILL BE MADE TO DETERMINE AND TYPE OUT THE BAD DATA FOUND.
- L. STEPS A-H WILL BE REPEATED AND THE DRIVE POLE WILL BE STARTED AT THE CURRENT DRIVE +1.
- M. FOR ALL POSSIBLE ERRORS, SEE SECTION 5 IN THIS DOCUMENT.

9.

CONSOLE PACKAGE ADDENDUM

9.1. DESCRIPTION -----

THE CONSOLE PACKAGE HAS BEEN ADDED TO THIS DIAGNOSTIC TO ALLOW THE PROGRAM TO RUN WITH NO HARDWARE SWITCH REGISTER AND TO HAVE COMMUNICATIONS WITH THE DIAGNOSTIC VIA A TERMINAL. THE DIAGNOSTIC CAN BE RUN IN TWO MODES WITH THE CONSOLE PACKAGE . 1) RUNNING WITH THE CONSOLE PACKAGE ACTIVE . THIS ALLOWS THE OPERATOR CONTROL OF THE DIAGNOSTIC THROUGH THE TERMINAL. THE DIAGNOSTIC WILL ASK FOR THE VALUE OF THE PSEUDO SWITCH REGISTER, BEFORE CONTINUING WITH EXECUTION OF THE DIAGNOSTIC. ALL ERRORS AND PASS COMPLETES WILL BE PRINTED AT THE TERMINAL. NO HALTS WILL BE EXECUTED. 2) CONSOLE PACKAGE NOT ACTIVE-THIS WILL RESULT IN THE NORMAL STANDALONE OPERATION OF THE PROGRAM AS DISCRIBED IN SECTIONS 1 THROUGH 8 OF THIS DUCUMENT,

9.2 RESTRICTIONS -----

- 1) RUNNING THE CONSOLE PACKAGE REQUIRES THAT THE PSEUDO SWITCH REGISTER BE USED.
- 2) ONCE RUNNING THE CONSOLE PACKAGE NONACTIVE AND NOW DESIRE TO RUN IT ACTIVE, ONE MUST RELOAD THE DIAGNOSTIC AND INITILIZE FOR A ACTIVE CONSOLE PACKAGE.

9.3 INITIALIZATION -----

FOR A ACTIVE CONSOLE PACKAGE -----

- 1.) SET LOCATION 21 BIT0=0 TO INDICATE USE PSEUDO SWITCH REGISTER.
- 2.) SET LOCATION 22 BIT3=1 TO INDICATE CONSOLE PACKAGE ACTIVE.

FOR A NON ACTIVE CONSOLE PACKAGE -----

- 1.) SET LOCATION 21 BIT0=1 TO INDICATE NOT TO USE PSEUDO SWITCH REGISTER, BUT TU USE HARDWARE SWITCHES.
- 2.) SET LOCATION 22 BIT3=0 TO INDICATE CONSOLE PACKAGE NOT ACTIVE.

9.4 CONTROL CHARACTERS -----

CONTROL CHARACTERS ARE USED TO GIVE THE OPERATOR THE

ABILITY TO PERFORM THE FOLLOWING FUNCTIONS.
NOTE: THE PROGRAM WILL RESPOND TO THE CONTROL
CHARACTER IN FIVE (5) SECONDS OR LESS.

CONTROL C

THIS WILL START THE LOADER THAT IS
IN LOCATION 7600.

CONTROL R

THIS WILL RESTART THE PROGRAM AND
REASK THE SWITCH REGISTER QUESTION AS
DESCRIBED IN SETION 9.6.

CONTROL E

THIS WILL CONTINUE THE PROGRAM FROM
AN ERROR IF ALLOWED BY THE DIAGNOSTIC
OR FROM A WAITING STATEMENT.

CONTROL L

THIS WILL SWITCH THE TERMINAL MESSAGES
FROM THE DISPLAY TO A LINE PRINTER.
TO RESTORE THE MESSAGES ON THE TERMINAL
CONTROL L MUST BE TYPED AGAIN. IF
NO PRINTER IS AVAILBLE AND CONTROL L
IS TYPED THE RESULT WILL BE THAT THE
CONSOLE PACKAGE WILL WAIT FOR CONTROL C OR R.
THE CONTROL L WILL OUTPUT TO THE LINE
PRINTER AND THE PROGRAM WILL
ATTEMPT TO CONTINUE AS IF A CONTROL E
WAS TYPED IN.

CONTROL D

THIS WILL ALLOW THE ABILITY TO CHANGE
THE SWITCH REGISTER DURING PROGRAM
OPERATION. TYPING THIS CHARACTER WILL RESULT
IN AN INTERIGATION OF THE SWITCH REGISTER
QUESTION AS DESCRIBED IN SECTION 9.6.

CONTROL S

THIS WILL STOP PROGRAM EXECTUION AND WAIT IN A
LOOP FOR A CONTINUE. THE ONLY WAY TO CONTINUE
WILL BE TO TYPE A CONTROL Q, R OR C .
THIS IS A NONPRINTING CHARACTER.

CONTROL Q

THIS IS TO CONTINUE A PROGRAM AFTER A CONTROL
S IS TYPED. THIS IS A NONPRINTING CHARACTER.

9.5

WAITING MESSAGE

THE WAITING MESSAGE IS USED TO ALLOW THE OPERATOR TIME
TO MAKE A DECISION AS TO WHAT CONTROL CHARACTER
TO TYPE. THIS MESSAGE MAY APPEAR AT THE END
OF PASS MESSAGE IF THE HALT ON PASS BIT IS SET. THE CONTROL
CHARACTERS MAY NOW BE USED TO PERFORM THE NEEDED FUNCTION.

THE WAITING MESSAGE MAY BE PRINTED AFTER A ERROR MESSAGE
IF THE HALT ON ERROR BIT IS SET, HERE AGAIN THE CONTROL
CHARACTERS MAY BE USED.
THE WAITING MESSAGE MAY BE PRINTED IF OPERATOR INTERVENTION
IS REQUIRED.

9.6 SWITCH REGISTER MESSAGE

THIS MESSAGE IS USED TO SETUP THE PSEUDO SWITCH REGISTER
BEFORE PROGRAM EXECUTION TAKES PLACE, THE SWITCH REGISTER
IS SETUP WHEN THE FOURTH CHARACTER IS ENTERED OR A CARRIAGE
RETURN IS TYPED

SR=0000 4000

UNDER SCORING INDICATES OPERATUR RESPONSE

9.7 END OF PASS

THE NORMAL PASS COMPLETE TYPEOUT AS DESCRIBED IN SECTION
5.5 IS USED.

9.8 ERRORS

THE STANDARD ERROR REPORTS AS DESCRIBED IN SECTION 5
OF THIS DOCUMENT WILL BE USED.

9.9 SWITCH REGISTER SETTINGS

THE STANDARD SWITCH SETTINGS AS DESCRIBED IN SECTION 3
OF THIS DOCUMENT WILL BE USED.

9.10 PARAMETER CONTROL WORDS

THE CONSOLE PACKAGE USES THE LUCATIONS 20 21 22 FOR THE
FOLLOWING PURPOSES.

LOCATION 20
PSEUDO SWITCH REGISTER

LOCATION 21
HARDWARE IDENTIFIER 1

LOCATION 22

HARDWARE IDENTIFIER 2

LOCATION 0021

BIT ---	OCTAL VALUE -----	FUNCTION WHEN 0 -----	FUNCTION WHEN 1 -----
0	4000	USE PSEUDO SWITCHES	USE HARDWARE SWITCHES
1	2000	NO OPTION 1	HAS OPTION 1
2	1000	NO OPTION 2	HAS OPTION 2
3	400	NO 8A SIMULATOR	HAS 8A SIMULATOR
4	200	NO OPTION SIMULATOR	HAS OPTION SIMULATOR
5	100	NOT ON 8A XOR	ON 8A XOR
6	40	NOT PDP8-E TYPE CPU	PDP8-E TYPE CPU

7-11

8A MEMORY SIZE EX. 1K=00
2K=01
7K=06

32K=31

LOCATION 0022

BIT ---	OCTAL VALUE -----	FUNCTION WHEN 0 -----	FUNCTION WHEN 1 -----
0	4000	NOT ON ACT8A LINE	ON ACT 8A LINE
1	2000	NOT ON ACT 8E LINE	ON ACT 8E LINE
2	1000	NOT YET DEFINED	
3	400	DEACTIVE CONSOLE PACKAGE	ACTIVE CONSOLE PACKAGE

9.11

LOCATION CHANGES -----

THE FOLLOWING FIELD 1 LOCATIONS CAN BE CHANGED TO MEET
THE SPECIFIC NEED FOR MODIFICATION OF THE DIAGNOSTIC.

0246

IS THE LOCATION FOR THE VALUE OF THE
NUMBER OF PROGRAM PASSES NEED TO
PRINT THE END OF PASS MESSAGE.

1037

IS THE LOCATION SET FOR THE NUMBER OF
FILLER CHARACTERS AFTER A CRLF SET TO FOUR (4)

10.

APT-8 HOOKS -----

10.1 DESCRIPTION

TWO INTERFACES HAVE BEEN PROVIDED WHICH ALLOW THIS DIAGNOSTIC TO RUN UNDER THE STANDARD APT-8 SYSTEM. THESE INTERFACES ARE:

1. TIMING INTERFACE

2. ERROR INTERFACE

EACH WILL BE EXPLAINED IN DETAIL.

10.2 SETUP

THE FOLLOWING INFORMATION MUST BE INDICATED DURING THE INITIAL PROGRAM START UP.

1. SINGLE OR MULTIPLE DRIVE TESTING.
2. DRIVE OR DRIVES TO BE TESTED.
3. DIAGNOSTIC RUNNING UNDER APT-8.
4. THE AMOUNT OF MEMORY IN 1K INCREMENTS.

IF SINGLE DRIVE TESTING BIT 5 OF ADDRESS 22 MUST BE SET TO A ONE (1) WITH BITS 6-11 CONTAINING THE DRIVE TO BE TESTED. IF MULTIPLE DRIVES ARE TO BE DONE BIT MUST BE SET TO A ZERO (0) AND BIT 6-11 CONTAINING THE HIGHEST NUMBER DRIVE TO BE TESTED. WHEN MULTIPLE DRIVE TESTING ONLY A SPECIFIC NUMBER OF DRIVES CAN BE INDICATED. THE PROGRAM ASSUMES THE DRIVES ARE TO BE DONE BEGINNING WITH DRIVE ZERO (0) AND FINISHING WITH THE HIGHEST DRIVE INDICATED. IF MULTIPLE DRIVES OTHER THAN CONSECUTIVELY NUMBERED DRIVES BEGINNING WITH DRIVE ZERO (0) ARE TO BE DONE, THEY MUST BE DONE AS SINGLE DRIVES AND TESTED INDEPENDANTLY.

THE PROGRAM ALLOWS DRIVES 0-7 TO BE SELECTED. USER SHOULD NOT EXCEED 0-3 DRIVES FOR THE MK8E CONTROL.

BIT ZERO OF ADDRESS 22 MUST BE SET TO A ONE TO INDICATE THAT THE PROGRAM WILL RUN UNDER APT-8.

NOTE: IT SHOULD BE NOTED AT THIS TIME THAT WHILE RUNNING UNDER APT-8 THE HARDWARE SWITCH REGISTER IS INOPERATIVE. ONLY THE HALT AND SINGLE STEP SWITCH WILL EFFECT THE PROGRAM RUN.

AMOUNT OF MEMORY IN 1K INCREMENTS SHOULD BE STORED IN BITS 7-11 OF LOCATION 21. AN ADDITION OF 1 TO THE NUMBER OF BITS IN 7-11 INCREASES MEMORY SIZE BY 1K. EX. 4K=3; 8K=7. REMEMBER TO RETAIN STATUS OF BITS WHEN MODIFYING LOCATION 21.

APT-8 INTERFACES:

10.3.1. TIMING

APT-8 IS NOTIFIED OF PROGRAM RUN BETWEEN .2 SEC AND 2.0 SEC ON A 1.2 MICROSECOND MEMORY CYCLE. THIS WILL ALLOW THE DIAGNOSTIC TO RUN WITHOUT CAUSING AN APT-8 TIMEOUT ERROR IF THE DIAGNOSTIC IS TO BE RUN ON THE SLOWER MOS MEMORY.

10.3.2. ERRORS

ONLY THE DRIVE IN ERROR IS REPORTED TO APT-8 SYSTEM. SYSTEM. ERRORS WHICH CAUSE A PROGRAMMED HALT CAUSE A TIMEOUT ERROR. IF A PROGRAMMED HALT SHOULD OCCUR, THE ERROR PC WILL APPEAR IN THE AC ON THE DEVICE UNDER TEST. PROGRAMMED HALTS ARE EXPLAINED EARLIER IN THIS DOCUMENT.

11. PROGRAM LISTING

```

/RK8E/RK8L DATA RELIABILITY PROGRAM: MU-88-DHRKC-H
/
/MAINDEC-88-DHRKC-H=L
/
/COPYRIGHT 1972,1975,1976,1977 DIGITAL EQUIP. CORP.
/
/MAYNARD, MASS. 01754
/
0001      FIELD 1
/
/CONSOL SRC-V2=RB- CONSOLE PACKAGE
/
/THE PROGRAM SHOULD CHECK FOR A CONTROL CHARACTER FROM THE TERMINAL
/EVERY FIVE(5) SECONDS OR SOONER.

/LUICATIONS THAT NEED TO BE SET UP FOR USING THE CONSOLE PACKAGE.

/CNTVAL IN XCSPASS THIS LOCATION DETERMINDS THE NUMBER OF
/PROGRAM COMPLETIONS THAT ARE NEEDED BEFORE THE PASS MESSAGE IS TYPED
/THE VALUE SHOULD PUT THE PASS MESSAGE OUT IN THE RANGE OF 1 TO 5 MINUTES.
/THIS SHOULD BE A POSITIVE NUMBER.

/CBSTRY THIS IS FOUND IN CNTRL ROUTINE CONTROL R PART
/IT IS THE RETURN WHEN CONTROL R IS ENTERED (RESTART PROGRAM)
/THE RETURN JUMPS TO XDOBN WHICH CONTAINS CBSTRY SO PUT THE LABEL CBSTRY
/WHERE YOU WANT TO RESTART THE PROGRAM.

/SETUP1 IN XCBERR THIS IS THE MASK BIT FOR HALT ON ERROR
/PLACE THE CORRECT BIT IN THIS LOCATION FOR HALTING ON ERRORS.

/SETUP2 IN XCSPASS THIS IS THE MASK FOR HALT A END OF PASS.

/THE CALL TABLE IS A CONDITIONAL ASSEMBLY.
/TO ASSEMBLE THE CALL REMOVE THE / BEFORE CONSOL=0.
/IN COMBINING THE CONSOL PACKAGE TO A DIAGNOSTIC.
/THE CALL TABLE IS TO BE AT THE BEGINNING OF A PROGRAM.

```

```

0000      CONSOL=0
0001          PSKF= 0001
0002          PCLF= 0002
0003          PSKE= 0003
0004          PSTB= 0004
0005          PSIE= 0005
0006          GTF= 0006
0007          ACL= 7701
0008          CAF= 0007
0009          HQL= 7421
0010          HQA= 7501
/
0020      *20
/
0020      F10WR, 0
0021      F10P1, 4000

```

```

0022      0000      F10P2, 0
/
/IFDEF CONSOL *
/
0024      *24
/
0024      4424          C0PASS* JMS I .
0025      0200          XCSPAS .
0026      4425          C0CKSW* JMS I .
0027      0202          XC6SW .
0028      4426          C0TTYI* JMS I .
0029      0272          XC0TTY .
0030      4427          C0CNTR* JMS I .
0031      0400          XC0CNT .
0032      4430          C0PRNT* JMS I .
0033      0303          XC0PNT .
0034      4431          C0SWIT* JMS I .
0035      0656          XC0PSW .
0036      4432          C0OCTA* JMS I .
0037      1000          XC0OCT .
0038      4433          C0CRLF* JMS I .
0039      1023          XC0CRL .
0040      4434          C0ECHO* JMS I .
0041      1063          XC0ECH .
0042      4435          C0TYPE* JMS I .
0043      1077          XC0TYP .
0044      4436          C0ERR* JMS I .
0045      1207          XC0ERR .
0046      4437          C0INQU* JMS I .
0047      0635          XC0ING .
0048      4440          C0CKPA* JMS I .
0049      1041          XC0CKP .
0050      4441          C0PAUS* JMS I .
0051      0337          XC0PAU .
/
/*****
/ *20          /PSEUDO SWITCH REGISTER
/
/ *21          /HARDWARE INDICATORS
/4000=USE FRONT PANEL SWITCH REGISTER
/0000=USE THE PSEUDO SWITCH REGISTER LOC.20
/
/ *22          /SYSTEM CONFIGURATION
/4000=CONSOL PACKAGE SET ACTIVE
/0000=CONSOL PACKAGE SET DEACTIVE
/
/ *23          /RESERVED FOR FUTURE USE
/
0200      *200
/
/*****
/C0PASS

```

```

/THIS IS CALLED AT THE END OF EACH PROGRAM COMPLETION
/THE VALUE OF** CNTVAL** WILL BE DETERMINED BY THE TIME IT TAKES
/THE PROGRAM TO COMPLETE THIS MANY CPASS TO BE IN THE 1 TO 4 MINUTE
/RANGE
/      CPASS*JMS      XCSPAS
/EX, OF CALL      CPASS
/      /      MLT      /HALT IF NON CONSOL PACKAGE
/      JMP      START1      /CONTINUE RUNNING THIS PROGRAM

```

```

/RETURN TO LOCATION CALL PLUS ONE WITH THE AC=0 IF NON CONSOL PACKAGE AND MLT
/IF CONTINUE TO RUN THEN RETURN TO CALL PLUS2 AC=0
/THE LOCATION SETUP2 IS THE MASK BIT FOR THE HALT AT END OF PASS
/CHECK THAT IT IS CORRECT FOR THE CURRENT PROGRAM

```

/CALLS USED BY XCSPAS ARE CHKCLA=XC8CRLP=XC8OCTA=XC8SW=XC8PNT=XC8ING=

```

0200 0000 XCSPAS, 0
0201 7200 CLA
0202 4777* JMS CHKCLA /IS WORD 22 BIT 3 ACTIVE CONSOLE?
0203 5212 JMP DOPACK /IS CLASSIC
0204 4776* JMS C8GET /GET REGISTERS.
0205 4262 JMS XC8SW /DEACTIVE CONSOL CHECK SR SETTING
0206 0375 AND 4000 /FOR HALT ON END OF CPASS
0207 7640 SZA CLA /IS HALT 0 CONTINUE
0210 5600 JMP I XCSPAS /GO TO HALT
0211 5230 JMP C8BY1 /CONTINUE ON RUNNING PROGRAM
0212 4232 DOPACK, JMS CKCOUT /CLASS CHECK CPASS COUNT
0213 5230 JMP C8BY1 /CPASS COUNT NOT DONE REDO PROGRAM
0214 2250 ISZ PASCNT /CPASS COUNT DONE SET CPASS COUNT
0215 4774* JMS XC8CRLP
0216 4303 JMS XC8PNT /CP8PNT BUFFER
0217 0253 MESPAS /
0220 1250 TAD PASCNT /GET NUMBER
0221 4773* JMS XC8OCTA /CONVERT IT TO ASCII
0222 4774* JMS XC8CRLP /DO A CARRIAGE RETURN
0223 4776* JMS C8GET /GET REGISTERS.
0224 4262 JMS XC8SW /CHECK A HALT AT END OF CPASS
0225 0375 SETUP2, AND 4000 /MASK BIT
0226 7640 SZA CLA /HALT 01 NO SKIP CONTINUE 00
0227 4772* JMS XC8ING /STOP PROGRAM EXECUTION=LOOK FOR INPUT
0230 2200 C8BY1, ISZ XCSPAS /BUMP RETURN
0231 5600 JMP I XCSPAS
0232 0000 CKCOUT, 0
0233 1251 TAD DOSET /CHECK IF SET UP NEEDED
0234 7640 SZA CLA /SET UP CPASS COUNT VALUE
0235 5242 JMP NOSET /IS CPASS COUNT VALUE OK
0236 1252 TAD CNTVAL /CPASS COUNT VALUE ON
0237 7040 CMA /SET COUNT VALUE FOR THIS PROG
0240 3247 DCA DOCNT /SET TO NEGATIVE
0241 2251 ISZ DOSET /STONE IN HERE
0242 2247 NOSET, ISZ DOCNT /INDICATE VALUE SET UP
0243 5230 JMP C8BY1 /COUNT THE NUMBER OF PASSES
/EXIT FOR ANOTHER PASS

```

```

0244 3251 DCA DOSET /SET TO CP8PNT CPASS
0245 2232 ISZ CKCOUT /BUMP RETURN FOR
0246 5632 JMP I CKCOUT /CPASS C8TYPE OUT
0247 0000 DOCNT, 0
0250 0000 PASCNT, 0
0251 0000 DOSET, 0
0252 0000 CNTVAL, 0
0253 0410 MESPAS, TEXT "DMRKC PASS "
0254 2213
0255 0310
0256 4040
0257 2001
0260 2323
0261 4000

```

/*****

/C8CKSW

```

/THIS ROUTINE CAN BE USED INPLACE OF A READ THE SWITCHES LAS.
/ROUTINE THAT WILL CHECK WHERE TO READ THE
/C8 SWITCHES FROM IE, FROM PANEL OR PSEUDO SWITCH REGISTER
/THE SELECTION IS DETERMINED BY THE STATE OF BIT 0 IN LOCATION 21.

```

```

/C8CKSW= JMS XC8SW /READ THE C8SWIT REGISTER
/EX, JMS XC8SW /RETURN WITH THE CONTENTS OF SWITCH REGISTER

```

/RETURN TO NEXT LOCATION FOLLOWING CALL WITH THE AC= TO VALUE OF C8SWIT SETTING

/CALLS USED ARE=XC8CKPA=

```

0262 0000 XC8SW, 0
0263 4771* JMS XC8CKPA /GO CHECK THE IF ANY CONTRL
0264 7000 NOP
0265 1021 TAD 21 /GET MU FOR INDICATOR
0266 7710 SPA CLA /CHECK IF FROM PANEL 4000
0267 7614 7614 /DO LAS AND SKIP GET FROM PANEL WITH LAS
0270 1020 TAD 20 /PSEUDO SWITCH
0271 5662 JMP I XC8SW /EXIT WITH STATUS BIT IN AC.

```

/*****

/C8TTY1

```

/THIS ROUTINE WILL LOOK FOR A INPUT FROM THE TERMINAL
/AND REMOVE ANY PARITY BITS, THEN MAKE IT 8 BIT ASCII.

```

```

/C8TTY1= JMS XC8TTY /READ CHAR FROM THE CONSOL DEVICE
/EX, JMS XC8TTY /RETURN TO CALL PLUS ONE AC CONTAINS THE CHAR
/

```

```

/*****
/CALLS USED=NONE= BUT C6CHAR IS OFF PAGE AND IN ROUTINE CALLED XC6ECHO
/
/
0272 0000      XC6TTY, 0
0273 6031      KSF                                /LOOK FOR KEYBOARD FLAG
0274 5273      JMP                                -=1
0275 6036      KRS                                /GET CHAR
0276 0370      AND                                (177      /MASK FOR 7 BITS
0277 1367      TAD                                (200      /ADD THE EIGHTH BIT
0300 3766      DCA                                C6CHAR      /STORE IT
0301 1766      TAD                                C6CHAR
0302 5672      JMP I                                XC6TTY      /EXIT

/*****
/C6PRNT

/THIS ROUTINE WILL TYPE THE CONTENTS OF THE C6 PRINT BUFFER. THE LOCATION
/OF THE BUFFER WILL BE IN THE ADDRS FOLLOWING THE CALL. PRINTING OF THE BUFFER
/WILL STOP WHEN A 00 CHAR IS DETECTED. CHANACTERS ARE PACKED 2 PER WORD.
/
C6PRNT= JMS XC6PNT

/EX.      JMS      XC6PNT                /C6PRNT THE CONTENTS OF THE FOLLOWING BUFFER
/          RES377                /LOCATION OF C6PRNT BUFFER

/C6PRNT WILL USE THE LOCATION FOLLOWING THE CALL AS THE POINTER FOR THE
/C6PRNT ROUTINE, RETURN TO CALL PLUS TWO WITH AC= 0

/CALLS USED ARE=XC6TYPE=XC6PNT

0303 0000      XC6PNT, 0
0304 7300      CLA CLL
0305 1703      TAD I                                XC6PNT      /GET C6PRNT BUFFERS STARTING LOCATION
0306 3336      DCA                                PTSTOR      /STORE IN PTSTOR
0307 2303      ISZ                                XC6PNT      /BUMP RETURN
0310 1736      C6D01, TAD I                        PTSTOR      /GET DATA WORD
0311 0365      AND                                (7700      /MASK FOR LEFT BYTE
0312 7450      SNA                                /CHECK IF 00 TERMINATE
0313 5703      JMP I                                XC6PNT      /EXIT
0314 7500      SMA                                /IS AC MINUS
0315 7020      CML                                /MAKE CHAR A 300 AFTER ROTATE
0316 7001      IAC                                /MAKE CHAR A 200 AFTER ROTATE
0317 7012      RTR
0320 7012      RTR
0321 7012      RTR
0322 4764      JMS                                XC6TYPE      /PUT CHAR IN BITS 4-11 MAKE IT 8 BIT ASCII
0323 1736      TAD I                                PTSTOR      /C6PNT IT ON CONSOLE
                                /GET DATA WORD

```

```

0324 0363      AND                                (0077      /MASK FOR RIGHT BYTE
0325 7450      SNA                                /CHECK IF 00 TERMINATOR
0326 5703      JMP I                                XC6PNT      //EXIT
0327 1362      TAD                                (3740      /ADD FUDGE FACTOR TO DETERMINE IF 200
0330 7500      SMA                                /OR 300 IS TO BE ADD TO CHAR
0331 1361      TAD                                (100      /ADD 100
0332 1360      TAD                                (240      /ADD 200
0333 4764      JMS                                XC6TYPE      /C6TYPE ONLY BITS 4-11
0334 2336      ISZ                                PTSTOR      /BUMP POINTER FOR NEXT WORD
0335 5310      JMP                                C6D01      /DO AGAIN
0336 0000      PTSTOR, 0                          /STOP FOR C6PRNT BUFFER
/*****

/C6PAUS
/THIS ROUTINE WILL CHECK IF THE CONSOLE PACKAGE IS ACTIVE. IF ACTIVE
/IT WILL RETURN TO CALL PLUS ONE AC= 0. AND DO THAT INSTRUCTION.
/IF THE CONSOLE PACKAGE IS NOT ACTIVE THE CALL WILL BE REPLACED
/WITH A 7402 HALT AND THEN RETURN TO THE HALT.
/
C6PAUS= JMS XC6PAU
/
/
/EX.      JMS      XC6PAUS                /CHECK IF ON ACTIVE CONSOLE IF NOT HALT HERE
/          ANYTHING                /RETURN HERE IF ON ACTIVE CONSOLE
/
/
/CALLS USED ARE=CHKCLA=

0337 0000      XC6PAU, 0
0340 7300      CLA CLL
0341 4777      JMS                                CHKCLA      /CHECK LOC 22 BIT 3 CONSOLE BIT
0342 5350      JMP                                C6D03      /GO DO CONSOLE PART RETURN CALL+1
0343 7040      CMA                                /DEACTIVE CONSOLE PACKAGE PUT HLT IN CALL
0344 1337      TAD                                XC6PAU      /GET CORRECT RETURN ADDR
0345 3337      OCA                                XC6PAU      /SET UP RETURN
0346 1357      TAD                                (7402      /GET CODE FOR HLT
0347 3737      DCA I                                XC6PAU      /PUT HALT IN CALL LOCATION
0350 5737      C6D03, JMP I                                XC6PAU      /GO TO HALT OR RETURN TO NEXT LOCATION

```

```

0357 7402
0360 0240
0361 0100
0362 3740
0363 0077
0364 1077
0365 7700
0366 1075
0367 0200
0370 0177
0371 1041

```

0372	0635
0373	1000
0374	1023
0375	0400
0376	0624
0377	1200
	0400

PAGE

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88 89 90 91 92 93 94 95 96 97 98 99 100

```

/SCBNTM
/THIS ROUTINE WILL CHECK FOR THE PRESENCE OF CONTROL CHARACTERS
/IT WILL CHECK FOR THE FOLLOWING CHAN C-R-U-L-S
/      SCBCTR= JMB XCBCNT

```

```

/EX.      JMS      XCBCNTR      /CHECK FOR CONTROL CHARACTER
/          JMP      ANYTHING     /LOC FOLLOWING CALL IS FOR CONTINUING THE PROGRAM
/          JMP      ANYTHING     /LOC. IS FOR RETURN IF INMODE SET AND NOT CNTRL CHAR

```

```

/RETURN IS TO CALL PLUS ONE IF CONTINUE
/RETURN IS TO CALL PLUS TWO IF INMODE SET AND NOT CONTROL CHAR
/RETURN IS TO CALL PLUS TWO IF INMODE IS NOT SET AND NO
/CONTROL CHAR .,THIS WILL PRINT THE CHARACTER AND A ?
/CLEAR THE AC AND RETURN CALL+2.

```

```

/CALLS USED ARE-CHKCLA-XC8TYPE-XC8CLRF-C8GET-UPAROW-XC8TYI-XC8PSW-
/

```

```

0400 0000 XCB CNT, 0
0401 3777' DCA ACBSAVE /SAVE THE AC
0402 4776' JMO CMKCLA /CHECK LOC.22 BITS FOR CONSOLE BIT
0403 5206 JMP +3 /ON ACTIVE CONSOLE
0404 1777' TAD ACBSAVE /DEACTIVE CONSOLEGET AC FOR RETURN
0405 5000 JMP I XCB CNT /EXIT NOT ON ACTIVE CONSOLE
0406 6004 GTF
0407 3775' DCA FLSAVE
0410 7501 MGA
0411 3774' DCA MGSBVE /SAVE THE MG
0412 3255 DCA INDEXA /SET DISPLACEMENT INTO TABLE B
0413 1257 TAD XTBLA /GET ADDR OF TABLE A
0414 3256 DCA GETDAT /CONTAINS POINTER TO CONTROL CHAR
0415 1656 REDDA, TAD I GETDAT /GET CONTROL CHAR FROM TABLE
0416 7450 SNA /CHECK FOR A 0 END OF TABLE
0417 5226 JMP DONEA /END OF TABLE NO CONTROL CHAR
0420 1773' TAD C0CHAR /COMPARE CHAN TO CONTROL CHAR
0421 7650 SNA CLA /0 IF MATCH
0422 5243 JMP GOITA /MATCH
0423 2255 ISZ INDEXA /NO MATCH NOT END OF TABLE REDD
0424 2256 ISZ GETDAT /BUMP INDEX FOR EXIT WHEN CONTROL FOUND
0425 5215 JMP REDDA /BUMP GETDAT FOR COMPARE OF NEXT CNTRL CHAR.
0426 1772' DONEA, TAD INMODE /CHECK IF PROGRAM EXPECTS CHAR
0427 7648 SZA CLA /1=CHAN EXPECTED 0= NO CHAR EXPECTED
0430 5240 JMP EXITA /CHAN EXPECTED

```

```

0431 1773'      TAO      C8CHAR      /GET CHAR= NOT CONTROL+ NOT EXPECTED
0432 4771'      JMS      XC8TYPE     /C8PKMT CHAR
0433 1370       TAO      (277        /GET CUDE FOR "2"
0434 4771'      JMS      XC8TYPE
0435 4767'      JMS      XC8CRLF
0436 2200       ISZ      XC8CNT       /BUMP RETURN
0437 5600       JMP I     XC8CNT      /EXIT CALL#2
0440 2200       EXITA,   ISZ      XC8CNT /BUMP RETURN FOR MAIN PROGRAM CHECK OF CHAR
0441 1773'      TAO      C8CHAR      /PUT CHAR IN AC.
0442 5600       JMP I     XC8CNT      /EXIT
0443 1773'      GOITA,   TAO      C8CHAR /GET THE CONTENTS OF CHAR
0444 1366       TAO      (100        /ADD 100 TO FORM A GOOD ASCII CHARACTER
0445 3773'      DCA      C8CHAR      /RESTORE CUFFECT CHAR
0446 1260       TAO      XTABL8     /GET START OF TABLE B
0447 1255       TAO      INDEXA     /GET NUM F \ INTO TABLE
0450 3254       DCA      GOTOA      /STORE IT
0451 1654       TAO I     GOTOA      /GET THE ROUTINE STARTTING ADDRESS
0452 3254       DCA      GOTOA      /STORE IT IN HERE
0453 5654       JMP I     GOTOA      /GOTO CONTROL CHAR ROUTINE
0454 0000       GOTOA,   0000      /ADD OF CNTRL ROUTINE TO EXECUTE
0455 0000       INDEXA,   0000     /DISPLACEMENT INTO CNTRL TABLE
0456 0000       GETDAT,   0000     /LOCATION OF ADPRS OF CONTROL CHAR.
0457 0461       XTABLA,   TABLA     /ADUMS OF TABLA
0460 0471       XTABL8,   TABL8     /ADUMS OF TABL8
0461 7575       TABLA,    7575      /CNTRL C BACK TO MONITOR 203
0462 7564       7564      /CNTRL L SWITCH ERROR PRINTING DEVICE 214
0463 7557       7557      /CNTRL Q START DISPLAYING CHAR. AGAIN 221
0464 7556       7556      /CNTRL R BACK TO BEGINNING OF PROGRAM 222
0465 7555       7555      /CNTRL S STOP SENDING CHAR TO DISPLAY WAIT FOR CNTRL Q 223
0466 7573       7573      /CNTRL E CONTINUE WITH PROGRAM 205
0467 7574       7574      /CONTRL D CHANGE SWITCH REGISTER ON FLY
0470 0000       0000

```

```

0471 0551      TABLB, CNTRLB
0472 0537      CNTRLB
0473 0500      CNTRLD
0474 0511      CNTRLR
0475 0521      CNTRL3
0476 0545      CNTRLE
0477 0600      CNTRLD
/
/CONTROL Q
/START SENDING CHAN. TO THE DISPLAY
/THIS WILL RETURN CONTROL TO CALL THAT WAS SET BY
/THE CALL FOR CONTROL 3.

```

```

0500 3772*  CNTRLQ, DCA      INMODE      /SET SUFT PLAG FOR UNEXPECTED CHAN
0501 1335      TAD      C08SETS      /CHECK IF CONTROL 3 TYPED IN
0502 7640      SZA CLA
0503 5306      JMP      BYMETH      /CONTROL 3 TYPED IN
0504 4765*     JMS      C06ET      /NO CONTROL 3 TYPED PREVIOUSLY
0505 5600      JMP I     XC0CNTN     /LEAVE VIA CNTR ENTRY ADDRESS
0506 3335      BYMETH, DCA      C08SETS      /CLEAR THE SUFT FLAG
0507 4765*     JMS      C06ET      /RESTORE REGISTERS
0510 5736      JMP I     C06ETH      /EXIT TO ADDRESS SET BY CONTROL 3

```

```

/
/CONTROL R
/GO TO THE QUESTION C8SWIT
0511 3764' CNTRLR, DCA TTYLPT /CLEAR THE TYPE FLAG SET TO TTY
0512 3335 DCA C8SETS /CLEAR S0FT FLAG FOR CNTRL S
0513 3772' DCA INMODE
0514 4763' JMS UPAROW /PRINT THE " AND C8CHAN
0515 3762' C8BY4, DCA C8SWST /CLEAR FLAG FOR CNTRL D OR R
0516 6203 CIP CIP 0
0517 5720 JMP I XDUSH /GO TO ADDRS OF C8SWIT
0520 0200 XDUSH, BGN /DOSH IS LABEL FOR C8SWIT QUESTION
/
/CONTROL S
/STOP SENDING CHAR. TO DISPLAY UNTIL A "Q IS RECEIVED
/
/
0521 1335 CNTRL8, TAD C8SETS /IF1 DO NOT STORE IN C8RETR
0522 7640 SZA CLA
0523 5327 JMP C8D07 /DONT SET UP C8RETR
0524 7001 IAC /MAKE RETURN CALL PLUS 2
0525 1200 TAD XC8CNT /GET RETURN FOR THIS CALL
0526 3336 DCA C8RETR /STORE IT HERE FOR USE BE CNTRL Q
0527 2335 C8D07, ISZ C8SETS /SET FLAG TO SAVE CALL
0530 4761' JMS XC8TTY1 /LOOK FOR THE INPUT
0531 4763' JMS C8GET /GE: REGISTERS
0532 4200 JMS XC8CNTR /CHECK FOR THE CONTROL CHAR
0533 7200 CLA
0534 5321 JMP CNTRL8 /IF NOT A CNTRL Q R C REASK
0535 0000 C8SETS, 0
0536 0000 C8RETR, 0
/
/SWITCH OUTPUT FROM ONE OUTPUT DEVICE TO ANOTHER- THE TWO OUTPUTS ARE THE
/CONSOLE AND THE PRINTER WITH DEVICE CODE 06.
/
/
0537 1764' CNTRL8, TAD TTYLPT /GET PRESENT C8SWIT INDICATOR
0540 7040 CMA /COMPLEMENT IT
0541 3764' DCA TTYLPT /STORE NEW C8SWIT
0542 4763' JMS UPAROW /C8PNT " AND CHAR ON NEW DEVICE
0543 4765' JMS C8GET /RESTORE THE REGISTERS
0544 5600 JMP I XC8CNT /EXIT
/
/CONTROL E
/CONTINUE RUNNING FROM A INQUIRE OR ERROR
/
/
0545 4763' CNTRL8, JMS UPAROW /PRINT THE CONTROL CHAR
0546 3762' DCA C8SWST /CLEAR ENTHY FLAG.
0547 4765' JMS C8GET /GET THE REGISTERS
0550 5600 JMP I XC8CNT /RETURN TO CALL PLUS ONE
/
/CONTROL C

```

```

/RETURN TO MONITOR CONTROL C
0551 3764' CNTRLC, DCA TTYLPT /CLEAR THE LPT FLAG TO PRINT ON DISPLAY
0552 3762' DCA C8SWST /CLEAR ENTHY FLAG.
0553 4763' JMS UPAROW /C8PNT " AND LETTER IN CHAR
0554 6203 CIP CIP 0 /GO TO 0 FLD
0555 6007 CAF /CLEAR THE WORLD
0556 3760 JMP I (7600 /GO TO DIAGNOSTIC MONITOR
/*****
/
/
/
0560 7600
0561 0272
0562 0745
0563 0615
0564 1121
0565 0624
0566 0100
0567 1023
0570 0277
0571 1077
0572 1076
0573 1075
0574 1346
0575 1347
0576 1200
0577 1345
0600 PAGE
/
/CONTROL D
/CHANGE THE SWITCH REGISTER ANYTIME CNTRL D AND RETURN TO
/THE PROGRAM RUNNING.
/
0600 4215 CNTRLD, JMS UPAROW
0601 1213 TAD C8SETD /CHECK IF THE RETURN ADDRS IS SAFE
0602 7640 SZA CLA
0603 5207 JMP C8D011 /DO NOT CHANGE THE RETURN ADDRS
0604 1777' TAD XC8CNT /GET THE RETURN ADDRS AND SAVE IT
0605 3214 DCA C8RETR /SAVE THE RETURN HERE
0606 2213 ISZ C8SETD /INDICATE RETURN SAVED DONT DESTROY
0607 4256 C8D011, JMS XC8PSW /GO CHANGE THE SWITCH REGISTER
0610 3213 DCA C8SETD /CLEAR THE FLAG
0611 4224 JMS C8GET /RESTORE THE AC MQ LINK ETC
0612 5614 JMP I C8METD /RETURN TO THE PROGRAM
/
0613 0000 C8SETD, 0
0614 0000 C8METD, 0
/
/THIS WILL TYPE A UP ARROW AND THE CHAN IN C8CHAN.
0615 0000 UPAROW, 0 /C8PNT THE " AND THE CHAR C8TYPED IN

```

```

0616 1376      TAD      (356      /CQUE FOR "
0617 4775*     JMS      XC8TYPE
0620 1774*     TAD      C8CHAR      /C8TYPE THE CHAR
0621 4775*     JMS      XC8TYPE
0622 4773*     JMS      XC8CRLF
0623 5615      JMP I    UPAROW      /EXIT

```

/

```

0624 0800   CGET, 0
0625 7200   CLA
0626 1772*   TAD      MQSAVE
0627 7421   MQL      /RESTORE MQ
0630 1771*   TAD      FLSAVE
0631 7804   RAL      /RESTORE THE LINK
0632 7200   CLA
0633 1770*   TAD      ACSAVE
0634 5624   JMP I     CGET      /GET THE REGISTERS

```

[illegible]

```

/COINQU
/COINQU ROUTINE WILL PRINT A WAITING
/AND THE PROGRAM IS EXPECTING A CONTROL CHAR INPUT
/IF CONTINUE FROM CONTROL CHAR RETURN IS CALL PLUS ONE
/IF NO CONTROL CHAM ENTERED THEN WAITING IS REPRINTED
/AND PROGRAM WAITS FOR A CONTRL CHAM AGAIN.

```

/ C0INGU • JMS XC0ING

```

/EX.      JMS      XCSING      /CM WILL PRINT A WAITINGAND WAIT FOR INPUT
/          00 ANYTHING      /RETURN IS CALL PLUS ONE AC *0 CONTINUE

```

/CALLS USED ARE=CHKCLA-XCOPNT-XCOTYI-COGET-XCOCNTR=

```

0635 0000      XCQING, 0
0636 7308      CLA CLL
0637 4767*      JMS      CHKCLA      /CHECK LOC 22 BIT 3 CONSOLE BIT
0640 7410      SKP      /ACTIVE CONSOLE PACKAGE
0641 5635      JMP I     XCQING      /NOT CONSOLE LEAVE
0642 4766*      JMS      XCQPNT
0643 0651      WATME8      /INQUIR WAITTING
0644 4765*      JMS      XCQTTYI    /GET CHARACTER
0645 4224      JMS      CGGET
0646 4777*      JMS      XCQCNTN    /CHECK IF CONTROL CHARACTER
0647 5635      JMP I     XCQING      /EXIT AND CONTINUE
0650 5236      JMP      XCQING+1    /REASK
0651 2701      WATME8, TEXT  "WAITING "
0652 1124
0653 1116

```

0654 0740
0655 0000

[illegible]

/CSWIT

```

/ROUTINE WILL CHECK IF CONSOL IS ACTIVE IF IT IS ACTIVE DISPLAY
/8M QUESTION . IN NOT ACTIVE IT WILL NOT PRINT THE 8M QUESTION BUT
/RETURN TO CALL PLUS ONE AC=0.
/CBSWIT WILL SET UP THE PSEUDO SWITCH
/REGISTER WITH THE NEW DATA ENTERED

```

1
1 CASWIT - JMS XCOPAW

```

/EX,          JMS      XC0PSW          /SET UP PSEUDO COWBIT REGISTER IF
                                         /ON THE CONSOL PACKAGE, RETURN IS CALL PLUS ONE AC = 0

```

/CALLS USED ARE-CHKCLA-XC8PSN-XC8PNT-XC8DCTA-XC8TYPE-

```
0656 0888      XC8PSW, B
0657 4767*    JMS      CHKCLA      /CHECK LOC 22 BIT 3 CONSOLE BIT
0660 7410      SKP       /ACTIVE CONSOLE
0661 5656      JMP I     XC8PSW     /DEACTIVE CONSOLE PACKAGE
                                   /RETURN WITHOUT ASKING PSEUDO SWITCH
0662 1345      TAD      C88WST     /IS THE SOFT FLAG SET FOR SWITCH?
0663 7640      SZA CLA      /SKIP IF ONE ENTRY AT A TIME OK
0664 5764*    JMP      C8BY4     /SECOND ENTRY WITH OUT A EXIT GO TO SW QUESTION
0665 2345      ISZ      C88WST     /FIRST ENTRY SET FLAG
0666 4766*    CONOPS, JMS     XC8PNT /C8PKNI SW=
0667 8747      MESA
0670 1020      TAD      Z0        /GET CONTENTS OF SW
0671 4763*    JMS      XC8OCTA     /CONVERT IT TO ASCII
0672 1362      TAD      (40       /GET SPACE
0673 4775*    JMS      XC8TYPE
0674 2761*    ISZ      INMODE     /SET FLAG FOR CHAR EXECTED
0675 4760*    JMS      XC8ECHO     /LOOK FOR INPUT
0676 4315      JMS      T8TCHM     /NOT CONTROL TEST IT IS LEGAL
0677 1774*    TAD      C8CHAR     /STORE NEW CHAR IN SW REG
0700 3020      DCA      Z0
                                     .
0701 1357      TAD      (=3       /GET A MINUS 3
0702 3346      DCA      TMPCNT     /STORE IN TEMP COUNT
0703 4760*    GETCH1, JMS     XC8ECHO /GET NEXT CHAR
0704 4315      JMS      T8TCHM     /CHECK IF CR+ GOOD CHAN
0705 1020      TAD      Z0        /GET COSMIT REGISTER
0706 7106      RTL CLL           /ROTATE IT LEFT 3 PLACES
0707 7004      RAL
0710 1774*    TAD      C8CHAN     /GET CHAN+ ADD IT TO PREVIOUS CONTENTS
0711 3020      DCA      Z0        /SAVE NEW CONTENTS
0712 2346      ISZ      TMPCNT     /BUMP COUNT
0713 5303      JMP      GETCH1     /JMP BACK+ GET NEXT CHAR
0714 5342      JMP      ENDIT     /END 4 CHAN C8TYPE IN
```

```

0715 0000 TSTCHA, 0
0716 7041 CIA
0717 1356 TAD (215
0720 7650 SNA CLA
0721 5342 JMP ENDIT
0722 1774* TAD C0CHAR
0723 1355 TAD (-260
0724 7710 SPA CLA
0725 5336 JMP ERR1
0726 1774* TAD C0CHAR
0727 1354 TAD (-270
0730 7700 SNA CLA
0731 5336 JMP ERR1
0732 1774* TAD C0CHAR
0733 0353 AND (7
0734 3774* DCA C0CHAR

0735 5715 JMP I TSTCHA
0736 1352 ERN1, TAD (277
0737 4775* JMS XC0TYPE
0740 4773* JMS XC0CRLF
0741 5266 JMP C0RDPS
0742 4773* ERN1, JMS XC0CRLF
0743 3345 DCA C0SWST
0744 5656 JMP I XC0PSW
0745 0000 C0SWST, 0

0746 0000 TMPCNT, 0
0747 2322 MESA, TEXT "SR= "
0750 7540
0751 0000

0752 0277
0753 0007
0754 7510
0755 7520
0756 0215
0757 7775
0760 1063
0761 1076
0762 0040
0763 1000
0764 0515
0765 0272
0766 0303
0767 1200
0770 1345
0771 1347
0772 1346
0773 1023
0774 1075
0775 1077
0776 0336
0777 0400

```

```

/CMPL CHAR IN AC
/TEST IF IT IS A CARRIAGE RETURN
/SKIP IN NOT CR,
/HAS CARRIAGE RETURN
/NOT CR, GET CHAR
/CHECK IF IT IS IN RANGE
/IF NOT POSITIVE C0ERR CHAR SMALLER THEN 260
/C0ERR= CHAR TOO SMALL
/GET CHAR
/GET A=270+ CHECK IF IT IS LARGER THEN 7
/SKIP IF LESS THEN 7
/C0ERR ON CHAR NOT IN RANGE
/GET CHAR
/MASK FOR RIGHT BYTE
/STONE IN CHAR
/GET CHAR IN AC
/EXIT
/C0PHNT
/7
/
/EXIT+ ASK AGAIN
/DO A CR LF
/CLEAR THE PSW ENTRY FLAG
/EXIT ROUTINE

```

```

1000 PAGE
/COOCTA

/OCTAL TO ASCII CONVERSION
/THIS ROUTINE WILL TAKE THE OCTAL NUMBER IN THE AC AND CONVERT IT TO ASCII
/THE RESULT WILL BE PRINTED ON THE CONSOLE TERMINAL
/ COOCTA= JMS XC0OCT
/
/EX. JMS XC0OCTA /AC CONTAINS NUMBER TO BE CHANGE
/ RETURN IS TO CALL PLUS ONE AC=0
/
/CALLS USED ARE=XC0TYPE=

1000 0000 XC0OCT, 0
1001 7106 CLL RTL
1002 7006 RTL
1003 3221 DCA C0TMP1
1004 1377 TAD (-4
1005 3222 DCA C0CKP
1006 1221 TAD C0TMP1
1007 0376 AND (0007
1010 1375 TAD (260
1011 4277 JMS XC0TYPE
1012 1221 TAD C0TMP1
1013 7006 RTL
1014 7004 RAL
1015 3221 DCA C0TMP1
1016 2222 ISZ C0CKP
1017 5206 JMP C0UO4
1020 5600 JMP I XC0OCT
1021 0000 C0TMP1, 0
1022 0000 C0CKP, 0

/*****

/C0CRLF
/C0TYPE CR AND LF WITH FILLERS FOLLOWING EACH LF AND CR
/
/ C0CRLF= JMS XC0CRL
/
/EX. JMS XC0CRLF /C0PHNT A CR AND LF WITH FILL
/ /RETURN TO CALL PLUS ONE AC =0
/CALLS USED ARE=XC0TYPE=

1023 0000 XC0CRLF, 0
1024 7300 CLA CLL
1025 1374 TAD (215
1026 4277 JMS XC0TYPE
1027 1237 TAD FILLER
1030 7040 CMA
1031 3240 DCA FILCNT

```

```

/POSITION THE FIRST CHAR FOR PRINTING
/SAVE CORRECT POSITIONED WORD HERE

/STONE COUNTER IN HERE
/GET FIRST NUMBER
/MASK
/ADD THE PRINT CONSTANT
/TYPE THE NUMBER
/

/PUT NEXT NUMBER IN POSITION
/STONE IT
/DONE YET WITH FOUR NUMBERS
/NOT YET DU MORE
/DONE WITH FOUR

```

```

/GET CODE FOR CR
/STONE FILLER IN HERE

```

```

1032 1373 TAD (212 /GET CODE FOR LF
1033 4277 C800R, JMS XC8TYPE /CHECK ON FILLER CHAR
1034 2240 ISZ FILCNT /TYPE A NON PRINTING CHAR
1035 5233 JMP C800Z /EXIT
1036 5623 JMP I XC8CRL /FILLER SET FOR 4 CHAR
1037 0004 FILLER, 0004 /COUNTER FOR FILL
1040 0000 FILCNT, 0

```

```

//*****
/C8CKPA
/THIS ROUTINE WILL CHECK IF A CHARACTER WAS ENTERED FROM THE
/TERMINAL. IF THE FLAG IS SET AND THE CONSOLE PACKAGE IS
/ACTIVE A CHECK IS MADE TO DETERMINE IF IT IS A CONTROL CHAR.
/IF IT WAS A CONTROL CHAR THEN ITS CONTROL FUNCTION IS PERFORMED.
/IF NOT A CONTROL CHARACTER OR A CONTROL E-D-L-O- IT WILL DO
/THE CONTROL FUNCTION AND RETURN TO CALL PLUS 2.
/A NON CONTROL CHARACTER WILL BE PRINTED AND A "Z" IT WILL RETURN TO
/CALL PLUS 2.
/IF NO FLAG IS SET OR THE CONSOLE IS NOT ACTIVE THE RETURN IS TO
/CALL PLUS 1.

```

```

/ C8CKPA= JMS XC8CKP

```

```

/EX. JMS XC8CKPA /CALL TO CHECK IF CONTROL CHAR SET
/ ANYTHING(SKIP) /RETURN IF NOT FLAG OR NOT CONSOLE ACTIVE
/ ANYTHING(JMP EXIT SKIP CHAIN) /RETURN IF NOT CONTROL OR CONTINUE CONTROL

```

```

/CALLS USED ARE-XC8TTYI-XC8CNTR-C8GET-

```

```

1041 0000 XC8CKP, 0
1042 3772 DCA ACBAVE /SAVE THE AC
1043 6004 GTF /SAVE THE FLAG
1044 3771 DCA FLBAVE /SAVE THE FLAG
1045 7501 MGA /PUT MU IN AC
1046 3770 DCA MGBAVE /SAVE THE MU
1047 6031 KSF /CHECK THE KEYBOARD FLAG
1050 5261 JMP C8BY3 /EXIT TO CALL PLUS 1
1051 4767 JMS CMKCLA /CHECK LOC 20 BIT 3 CONSOLE BIT
1052 7410 SKP /ACTIVE CONSOLE PACKAGE
1053 5261 JMP C8BY3 /EXIT TO CALL PLUS 1
1054 4764 JMS XC8TTYI /SET THE CHAR
1055 4765 JMS C8GET /SET THE FLAG
1056 4764 JMS XC8CNTR /CHECK IF CONTROL CHAR.
1057 7000 NOP /RETURN IF A CONTINUE CHAR.
1060 2241 ISZ XC8CKP /BUMP RETURN FOR CALL PLUS 2
1061 4765 JMS C8GET /GET REGISTERS
1062 5641 JMP I XC8CKP /SAVE GOOD BY

```

```

//*****

```

```

/C8ECHU
/THIS ROUTINE WILL LOOK FOR A CHAR FROM THE KEYBOARD. STORE IT IN LOCATION CHAR
/CHECK IF IT WAS A CONTROL CHARACTER- SET INMODE- PRINT CHARACTER

```

```

/ C8ECHU = JMS XC8ECH
/EX. JMS XC8ECH /LOOK FOR CONSOLE CHAR C8PRT IT
/RETURN CALL PLUS ONE AC = CHAR C8TYPED IN

```

```

/CALLS USED ARE-XC8TTYI-XC8CNTR-C8GET-XC8ECH-XC8TYPE

```

```

1063 0000 XC8ECH, 0
1064 4766 JMS XC8TTYI /WAIT FOR CHAR FROM KEYBOARD
1065 4765 JMS C8GET /RESTORE THE REGISTERS
1066 2276 ISZ INMODE /SET INMODE IDENTIFYING THIS AS A EXPECTED CHAR
1067 4764 JMS XC8CNTR /GO CHECK IF IT IS A CONTROL CHAR
1070 5663 JMP I XC8ECH /WAS A CONTROL CHAR- CONTINUE RUNNING
1071 4277 JMS XC8TYPE /NOT A CONTROL CHAR C8PRT IT
1072 3276 DCA INMODE /CLEAR FLAG THAT CHAR EXPECTED
1073 1276 TAD C8CHAR /GET CHAR IN AC
1074 5663 JMP I XC8ECH /EXIT
1075 0000 C8CHAR, 0
1076 0000 INMODE, 0

```

```

//*****

```

```

/C8TYPE
/THIS ROUTINE WILL C8PRT ON THE CONSOLE OR THE LPT WITH DEVICE CODE 66.
/
/ C8TYPE= JMS XC8TYP

```

```

/EX. JMS XC8TYPE /C8PNT THE CHAR IN THE AC.
/ /RETURN CALL PLUS ONE AC =0000
/ /DO NOT CLEAN THE LINK IN THIS ROUTINE NEEDED BYC8OCT

```

```

/CALLS USED ARE-C8HANG-XC8CNTR-XC8PNT-XC8CRLP-XC8INQU-

```

```

1077 0000 XC8TYP, 0
1080 3320 DCA PNTBUF /STORE CHAR
1081 1321 TAD TTYLPT /CHECK 0-TTY 7777=LPT
1082 7640 SZA CLA /DO OUT PUT ON LPT
1083 5312 JMP XDULPT
1084 1320 TAD PNTBUF
1085 6046 TLF
1086 6041 T8F
1087 5306 JMP .-1
1088 6042 TCF
1089 5316 JMP C8BY5
1090 1320 XDULPT, TAD PNTBUF /GET CHAR
1091 6066 PSTB PCLF /C8PNT IT
1092 4322 JMS C8HANG /CHECK KEYBOARD IF HUNG
1093 6062 PCLF /CLEAR THE FLAG
1094 7600 C8BY5, 7600 /CLEAR THE AC

```



```

1117 5677      JMP I   XC8TYP      /EXIT
1120 0000      PNTBUF, 0
1121 0000      TTYLPT, 0

1122 0000      C0HANG, 0
1123 7200      CLA
1124 1316      TAD      C0BYS      /GET CONSTANT 7600
1125 3320      OCA      PNTBUF    /PNTBUF IS NOW A COUNTER
1126 6661      PSKF      /SKIP ON PRINTER DONE
1127 7410      SKP      /NOT DONE YET
1130 5722      JMP I   C0HANG    /SAW FLAG DONE
1131 2345      ISZ      C0CONT    /FIRST COUNTER FAST ONE
1132 5326      JMP      ,=4      /CHECK IF FLAG SET YET
1133 2320      ISZ      PNTBUF    /MADE 4096 COUNTS ON FAST COUNTER
1134 5331      JMP      ,=5      /KEEP IT UP FOR 5 SEC
1135 1764      TAD      XC0CNTR   /GET THE RETURN ADDRESS IN CONTROL
1136 3322      OCA      C0HANG    /SAVE IT IN HANG
1137 3321      OCA      TTYLPT    /ALLOW PRINTING ON TTY
1140 4763      JMS      XC0PNT
1141 1146      MESHANG
1142 4223      JMS      XC0CRLF   /LPT ERROR
1143 4762      JMS      XC0INQU   /PRINT WAITING
1144 5722      JMP I   C0HANG    /CONTINUE TO SAVE ADDRESS
1145 0000      C0CONT, 0
1146 1420      MESHANG,TEXT      "LPT ERROR"
1147 2440
1150 0522
1151 2217
1152 2200

```

PAGE

```

/*****
/*****

```

```

/THIS ROUTINE WILL CHECK LOCATION 22 THE HARD WARE CONFIG WORD,
/TO SEE IF THE CONSOLE BIT 3 (400) IS SET IF SET THEN RETURN
/TO CALL PLUS TWO FOR A ACTIVE CONSOLE PACKAGE AC=0
/IF NOT SET THEN TO CALL PLUS ONE FOR A DEACTIVE CONSOLE PACKAGE.

```

```

1200 0000      CHKCLA, 0
1201 7200      CLA
1202 1022      TAD      22        /GET THE CONTENT OF LOCATION 22
1203 0377      AND      (400)    /MASK FOR BIT 3 (400)
1204 7650      SNA CLA
1205 2200      ISZ      CHKCLA
1206 5600      JMP I   CHKCLA

```

/C0ERR

```

/THIS ROUTINE WILL DETERMINE WHAT TO DO WHEN A C0ERR IS ENCOUNTERED
/Will check if classic system, will check C0SWIT registers,
/

```

/C0ERR= JMS XC0ERR

/EX. JMS XC0ERR

/GO TO C0ERR CALL IF NOT CONSOLE

/

/RETURN IS CALL PLUS ONE AC =0000

/CALLS USED ARE=CHKCLA=XC0CRLF=XC0SN=XC0INQU=XC0PNT=XC0OCTA=

```

1207 0000      XC0ERR, 0
1210 6002      IOF
1211 3345      OCA      AC0SAVE   /SAVE AC
1212 6004      GTF
1213 3347      OCA      FL0SAVE   /SAVE THE FLAGS
1214 7501      MGA
1215 3346      OCA      MQ0SAVE   /SAVE THE MQ
1216 7340      CLA CLL CMA
1217 1207      TAD      XC0ERR    /SUBTRACT A 1 FOR TRUE LOCATION
1220 3344      OCA      PC0SAVE   /GET RETURN LOCATION
1221 6201      CDF
1222 7340      CLA CLL CMA
1223 1776      TAD I   (CLASIK)   /SAVE ADD OF C0ERR CALL
1224 3316      OCA      REALPC    /GET REAL PC.
1225 6211      CDF      10       /SAVE IT.
1226 4200      JMS      CHKCLA   /CHECK LOC.22 BIT 3 CONSOLE BIT
1227 7410      SKP      /ACTIVE CONSOLE PACKAGE
1230 5270      JMP      NTCLAS   /NOT CLASSIC SYSTEM
1231 4775      JMS      C0GET    /GET REGISTERS.
1232 4774      JMS      XC0SW    /CHECK SWITCH REG FOR BIT THAT INDICATES
1233 0373      SETUP1, AND      10000 /NO ERROR MESSAGE
1234 7640      SZA CLA
1235 5262      JMP      C0U010   /MASK FOR BIT FOR NO ERROR PRINTING
1236 4772      JMS      XC0CRLF   /IF THIS ERROR MESSAGE IS TO ALWAYS
1237 4771      JMS      XC0PNT    /BE PRINTED LEAVE AND VALUE AT 0000
1240 1320      ERRMES
1241 4771      JMS      XC0PNT    /SKIP IF BIT IS 0 PRINT ERROR MESSAGE
1242 1330      MESPC
1243 1316      TAD      REALPC    /DO NOT PRINT
1244 4770      JMS      XC0OCTA   /PRINT THE ERROR MESSAGE
1245 4771      JMS      XC0PNT
1246 1333      MESAC

```

```

1247 1345      TAD      ACSAVE
1250 4770"     JMS      XC8OCTA
1251 4771"     JMS      XC8PNT
1252 1336      MESMQ    /PRINT MQ
1253 1346      TAD      MQSAVE
1254 4770"     JMS      XC8OCTA
1255 4771"     JMS      XC8PNT
1256 1341      MESFL    /PRINT FL
1257 1347      TAD      FLSAVE
1260 4770"     JMS      XC8OCTA
1261 4772"     JMS      XC8CRLF
1262 4775"     C8DD10, JMS      C8GET
1263 4774"     JMS      XC8SW
1264 7610      SKP CLA
1265 5300      JMP      C8BY2
1266 4767"     JMS      XC8INQ
1267 5300      JMP      C8BY2
1270 4775"     NTCLAS, JMS      C8GET
1271 4774"     JMS      XC8SW
1272 7610      SKP CLA
1273 5607      JMP I      XC8ERR
1274 1366      TAD      (7402)
1275 3744      DCA I      PCSAVE
1276 4775"     JMS      C8GET
1277 5744      JMP I      PCSAVE
1300 4775"     JMS      C8GET
1301 5607      JMP I      XC8ERR
/
1302 7402      /ROUTNS, HLT
1303 7000      NOP
1304 3317      DCA      MYAC
1305 6201      CDF      0
1306 1020      TAD      SWM
1307 3765      DCA I      (SWR)
1310 1776      TAD I      (CLASIX)
1311 3315      DCA      CLTRN
1312 1317      TAD      MYAC
1313 6202      CIF      0
1314 5715      JMP I      CLTRN
/RETURN TO FIELD 0,
1315 0000      CLTRN, 0
1316 0000      REALPC, 0
1317 0000      MYAC, 0
/
1320 0410      /ERNMES, TEXT "DHRKC FAILED "
1321 2213
1322 0310
1323 4040
1324 0601
1325 1114
1326 0504
1327 4000
1330 4040      MESPC, TEXT " PC:"

```

```

1331 2003
1332 7200
1333 4040      MESAC, TEXT " AC:"
1334 0103
1335 7200
1336 4040      MESMQ, TEXT " MQ:"
1337 1521
1340 7200
1341 4040      MESFL, TEXT " FL:"
1342 0614
1343 7200
1344 7777      PCSAVE, 7777
1345 7777      ACSAVE, 7777
1346 7777      MQSAVE, 7777
1347 7777      FLSAVE, 7777
/
1365 0020
1366 7402
1367 0635
1370 1000
1371 0303
1372 1023
1373 0000
1374 0624
1375 0624
1376 1514
1377 0400
0000      FIELD 0

```

0000	00000000	00000000	11101111	11111111	11000000	00000000	00000000	00000000
0100	00000000	00000000	00000000	00000000	00000000	00000000	00000000	00000000
0200	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
0300	11111111	11111111	11111111	11111111	11111111	10000001	11111111	11111111
0400	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
0500	11111111	11111111	11111111	11111111	11111111	11111110	11111111	11111111
0600	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
0700	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
1000	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
1100	11111111	11111111	11111111	11111111	11111111	11000000	00111111	11111111
1200	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
1300	11111111	11111111	11111111	11111111	11111111	00000000	00000111	11111111
1400								
1500								
1600								
1700								
2000								
2100								
2200								
2300								
2400								
2500								
2600								
2700								
3000								
3100								
3200								
3300								
3400								
3500								
3600								
3700								

4000
4100
4200
4300
4400
4500
4600
4700
5000
5100
5200
5300
5400
5500
5600
5700
6000
6100
6200
6300
6400
6500
6600
6700
7000
7100
7200
7300
7400
7500
7600
7700

```

/
/NOTES:LOCATION 0 CONTAINS THE REVISION
/LEVEL (IN ASCII) ON PROGRAM LOAD.
/
/ALL KNOWN HALTS
/
1400 0556 ERHLT0 /SKIP TRAP DLSC
1401 0563 ERHLT2 /SKIP TRAP DCLR
1402 2561 ERHLT3 /SKIP TRAP DLAG
1403 2544 ERHLT5 /SKIP TRAP DRST
1404 0547 ERHLT6 /SKIP TRAP DLDC
1405 3130 INTER1 /NO DISK INTERRUPT
1406 2362 INTER2 /UNDEFINED INTERRUPT
1407 0206 FLDHLT /PROGRAM WILL ONLY RUN IN FIELD 0
1410 2702 NODSKS /NO DISKS AVAILABLE TO RUN
1411 0603 STPHLT /PROGRAM STOP FROM SWR4=1
1412 2755 CHNHLT /IOT CHANGE HALT
1413 1707 BAUHLT /COMPUTER MUST BE DOWN, CHECKSUM FAILED
/
1414 3136 BIGSTP /BUT WORD-BY-WORD COMPARE WORKED.
/STOP FOR ALL ERROR HALTS.
/
6740 DLSC=6740 /LOAD SECTOR COUNTER
6741 DSKP=6741 /SKIP ON TRANSFER DONE OR ERROR
6742 DCLR=6742 /CLEAR DISK CONTROL LOGIC
6743 DLAG=6743 /LOAD ADDRESS AND GO
6744 DLCA=6744 /LOAD CURRENT ADDRESS
6745 DRST=6745 /READ STATUS REGISTER
6746 DLDC=6746 /LOAD COMMAND REGISTER
/
4406 LAS=JMS I XLAS
4407 CLASIC=JMS I XCLAS
4427 RANDAT=JMS I XRNWRD
4430 DISCON=JMS I XDUMP
4431 SPACE=JMS I XSPAC
4432 ONEIN=JMS I XOCT1
4433 FORIN=JMS I XOCT4
4434 SETGEN=JMS I XSTGEN
/
4435 SETFLD=JMS I XSTFLD
4437 YESNO=JMS I XCHKYN
/
4436 SELCHK=JMS I XCKPOT
4440 RANGEN=JMS I XRNODM
4442 REBRAN=JMS I XREBRN
4441 DISKGO=JMS I XDSKGO
4443 RECAL=JMS I XRESTR
4444 RECEIV=JMS I XWAIT
4446 ERROR=JMS I XERRD
4447 RDSTAT=JMS I XRDST
4453 LDADD=JMS I XLDDAD
4450 DSKSKP=JMS I XSDKPK

```

```

4451 LDCMD=JMS I XLDCM
4452 LOCUR=JMS I XLDCA
4454 CLRALL=JMS I XCLDR
4455 PRNTER=JMS I XPRN
4456 OCTEL=JMS I XPROCT
4445 TYPE=JMS I XPRINT
4457 CRLF=JMS I XCMLF
4426 GENDAT=JMS I XGNDAT
4424 CHK22=JMS I XCHK22
4425 KTICK=JMS I XKTCK
/
0000 *0
/
0000 0310 /
0001 5001 /REVISION "H"; INTERRUPT SERVICE RETURN
0002 0002 /DCA SAVAC SAVE AC AT INT.
0003 0003 /RAL SHIFT LINK AT TIME OF INT.
0004 0004 /DCA SVLNK SAVE LINK AT TIME OF INT.
0005 0005 /JMP I 5 RETURN TO INT. SERVICE
/RETURN POINTER
/
0006 1546 XLAS, MYLAS
0007 1514 XCLAS, CLASIK
/
0010 *10
/
0010 0000 AUTO10, 0
/
0011 0000 AUTO11, 0
/
0012 0000 AUTO12, 0
/
0013 0004 K0004, 0004
0014 0070 K0070, 0070
0015 0100 K0100, 0100
0016 0200 K0200, 0200
0017 0400 K0400, 0400
/
0020 *20
/
0020 0000 SWK, 0
0021 4000 OP1, 4000
0022 0000 OP2, 0
/
0023 2156 KAERRO, AERROR
0024 0523 XCHK22, CHEK22
0025 1154 XKTCK, XKTICK
0026 1737 XGNDAT, GNDAT
0027 2600 XRNWRD, RNWRD
0030 2637 XDUMP, DUMP
0031 1506 XSPAC, SPAC
0032 2400 XOCT1, OCT1
0033 2430 XOCT4, OCT4
0034 1753 XSTGEN, STGEN
0035 2703 XSTFLD, STFLD

```

```

0036 2060 XCKPOT, CKKPOT
0037 2035 XCHKYN, CKKYN
0040 1715 XRNDOM, RANDOM
0041 2200 XD8KGO, D8KGO
0042 1761 XRSRAN, RSRAN
0043 3052 XRESTR, RESTOR
0044 2000 XWAIT, WAIT
0045 2620 XPRINT, PRINT
0046 1200 XERRO, ERRO
0047 2541 XRDST, RDST
0050 0751 X8UKP, 8UKP
0051 0542 XLOCM, LDCM
0052 2550 XLOCA, LDCA
0053 2554 XLOAD, LOAD
0054 0560 XCLDR, CLDR
0055 1450 XPRN, PRN
0056 1426 XFROCT, FROCT
0057 1414 XCHLP, UPONE
0060 0000 AMOUNT, 0
0061 0001 K0001, 0001
0062 0003 K0003, 0003
0063 0006 K0006, 0006
0064 0007 K0007, 0007
0065 0010 K0010, 0010
0066 0017 K0017, 0017
0067 0260 K0260, 0260
0070 0277 K0277, 0277
0071 0770 A0770, 0770
0072 7007 A7007, 7007
0073 4000 K4000, 4000
0074 4100 K4100, 4100
0075 1000 K1000, 1000
0076 1777 K1777, 1777
0077 7700 K7700, 7700
0100 7760 K7760, 7760
0101 7777 K7777, 7777
0102 0077 K0077, 0077
0103 6201 K0620, 0620
0104 7400 K7400, 7400
/
/
/
0105 7764 M12, -12
/
/
/
0106 7774 M4, -4
0107 7770 M10, -10
0110 7775 K7775, 7775
/
/
/
0111 0000 TRASH1, 0
0112 0000 TRASH2, 0
0113 0000 TRASH3, 0
0114 0000 UPDATE, 0
0115 0000 POLDSK, 0

```

```

0116 0000 OPNTAL, 0
0117 0000 BUFTAL, 0
0120 0000 PCNEG, 0
0121 0000 STNEG, 0
0122 0000 EXNEG, 0
0123 0000 CMNEG, 0
0124 0000 INTDA, 0
0125 0000 DAMEG, 0
0126 0000 CAMEG, 0
0127 0000 WCNEG, 0
0130 0000 FWMNEG, 0
0131 0000 ASNEG, 0
0132 0000 WAMEG, 0
0133 0000 ADREG, 0
0134 0000 DGREG, 0
0135 0000 DBNEG, 0
0136 0000 INTCM, 0
0137 0000 STATRY, 0
0140 0000 DATTRY, 0
0141 0000 CHKSAV, 0
0142 0000 FNDSUM, 0
0143 0000 MAXFLD, 0
0144 7607 MAXTIM, 7607
0145 3240 MAXTRK, 3240
0146 3600 BGNBUF, 8TRBUF
0147 0000 CONSEC, 0
0150 7777 CLKCNT, -1
/
/
/
0151 0756 DATPOT, DAT1
0152 3522 TIMPOT, 00TH1
0153 3537 STAPOT, D0HRD=3
0154 3512 RUNPUT, D8K0B
/
/
/
0155 0000 CRCNT, 0
0156 0000 CRCFLG, 0
0157 0000 DATFLG, 0
0160 0000 SPFLD, 0
0161 0000 SPTRK1, 0
0162 0000 SPTRK2, 0
0163 0000 SPSEC, 0
0164 0000 SPBLK, 0
0165 0000 ERFLG, 0
0166 0000 SAVAC, 0
0167 0000 SVLNN, 0
0170 0000 FIWIM, 0
0171 0000 TRYCNT, 0
0172 3213 XTEXT, TEXTC
0173 3142 PRNDAT, TYPDAT
0174 0000 SAVCM, 0
0175 0000 CLNBAK, 0
/
/
/
0176 3131 BGMILT, BIGHLT
0200 0200
/
/
/

```

```

/START OF PROGRAM BY OPERATOR;
/AT 0200, TTY INTERIGATION;
/AT 0201, CHANGE IOT DEVICE CODES;
/AT 0202, RESTART AT SEEK ROUTINE;
/
0200 4777' BGN, JMS APT8 /TO REGULAR TEST
0201 5776' JMP CHNG /CHANGE IOT ROUTINE
0202 5775' JMP RUN
0203 3156 DCA CRCFLG /CLEAR CRC FLAG
0204 6224 RIF
0205 7440 SZA /FIELD 0777?
0206 4576 FLUMLT, JMS I BGHLT /WILL ONLY RUN IN FIELD 0777?
0207 1103 TAD KCOF
0210 3211 DCA ,+1
0211 7402 MLT /MAKE DF=IF
/
/SETUP INTERRUPT SERVICE;
/
0212 1362 TAD ACUCA
0213 3001 DCA 1 /SETUP AC DCA
0214 1250 TAD KRUT
0215 3002 DCA 2 /SETUP ROTATE LINK
0216 1361 TAD LNKDCA
0217 3003 DCA 3 /SETUP SAVE LINK
0220 1360 TAD K5405
0221 3004 DCA 4 /SETUP JMP RETURN
0222 1363 TAD BRRRET
0223 3005 DCA 5 /RETURN POINTER
/
/CLEAR DATA INFORMATION TABLE
/AT END OF PROGRAM;
/
0224 1077 STRTEX, TAD K7700
0225 3111 DCA TRASH1 /CLEAR COUNTER
0226 1774' TAD RANJMS
0227 3773' DCA SWDAT /SET INSTRUCTION SWITCH
0230 7340 CLA CLL CMA
0231 1152 TAD TIMPOT
0232 3010 DCA AUTO10 /LOCATION POINTER
0233 3410 DCA I AUTO10 /CLEAR
0234 2111 ISZ TRASH1
0235 5233 JMP ,+2 /MORE TO CLEAR
0236 3157 DCA DATFLG
0237 5775' SKPNOP, JMP RUN
/
/
/PRINT PROGRAM NAME AND
/ASK OPERATOR ABOUT AMOUNT
/OF MEMORY;
/
0240 4457 CRLF
0241 4455 PRNTER /PRINT "RK8E/RK8L DATA RELIABILITY"
0242 3307 MESS1
0243 4455 PRNTER /PRINT "AMOUNT OF MEMORY"
0244 3346 MESS

```

```

0245 4432 ONEIN /RECEIVE ONE OCTAL
0246 0070 0070 /LIMITS
0247 5243 JMP ,+4 /INPUT ERROR
0250 7004 KRUT, RAL
0251 7006 RTL
0252 7040 CMA /COMPLEMENT
0253 3143 DCA MAXFLD /MAXIMUM FIELD POINTER
0254 4772' JMS CLAFLD /CHECK FOR CLASSIC.
0255 3111 ALLAGN, DCA TRASH1
0256 1107 TAD M10
0257 3112 DCA TRASH2
0260 3060 DCA AMOUNT /A FEW POINTERS
/
/ASK OPERATOR ABOUT DISK(S) TO TEST;
/
0261 1111 NEXT, TAD TRASH1
0262 1154 TAD RUNPOT
0263 3113 DCA TRASH3 /SAVE RUN POINTER
0264 4455 PRNTER /PRINT "EXERCISE"
0265 3325 MESS2
0266 7340 CLA CLL CMA
0267 4455 PRNTER /PRINT "DISK"
0270 3332 MESS3
0271 1067 TAD K0260
0272 1111 TAD TRASH1 /ADD IN DISK NUMBER
0273 4445 TYPE /TYPE DISK NUMBER
0274 1070 TAD K0277
0275 4445 TYPE /TYPE ?
0276 4444 RECEIV /RECEIVE KEY INPUT
0277 4437 YESNO /WAS IT YES OR NO
0300 5255 JMP ALLAGN /NEITHER
0301 5304 JMS ,+3 /WAS A NO
0302 2060 ISZ AMOUNT /AMOUNT OF DISK FOUND
0303 7340 CLA CLL CMA /AC TO 7777 FOR EXISTING DISK
0304 3513 DCA I TRASH3 /SETUP RUN POINTER
0305 2111 ISZ TRASH1
0306 2112 ISZ TRASH2
0307 5261 JMP NEXT /ASK ABOUT NEXT DISK
/
/
/ASK IF ACCEPT MODE;
/
0310 1060 TAD AMOUNT /GET AMOUNT FOUND
0311 7650 SNA CLA /WERE ANY FOUND
0312 5224 JMP STRTEX /OPERATOR ERROR NO DISK INPUT
0313 4455 PRNTER /PRINT "ACCEPT MODE?"
0314 3363 MESS6
0315 4444 RECEIV /RECEIVE INPUT
0316 4437 YESNO /YES OR NO???
0317 5313 JMP ,+4 /NEITHER ALL AGAIN
0320 7610 SKP CLA /MANUAL TEST
0321 5771' JMP ASKSUR /ASK "ARE YOU SURE"
/
/
/IF ACCEPT MODE, INTERGATE

```

```

/ABOUT CONSTANI FIELD1
/
0322 4455 MANUAL, PRINTER /PRINT "FIELD?"
0323 3404 MESS
0324 4444 RECEIV /RECEIVE Y OR N
0325 4437 YESNO /CHECK FOR Y OR N
0326 5322 JMP MANUAL /NEITHER Y OR N
0327 5345 JMP ASKNX1 /WAS A N, ASK ABOUT NEXT
0330 4431 SPACE /SPACE OUT ONE
0331 4432 ONEIN /GET 1 OCTAL
0332 0070 0070 /LIMITS
0333 5322 JMP MANUAL /INPUT ERROR ASK AGAIN
0334 7104 CLL RAL
0335 7006 RTL
0336 3160 DCA SPFLD /SAVE INPUT
0337 1160 TAD SPFLD
0340 1143 TAD MAXFLD /COMPARE TO MAXIMUM
0341 7700 SNA CLA /U.K.?
0342 5322 JMP MANUAL /INPUT ERROR
0343 7340 CLA CLL CMA
0344 3770 DCA FLOFLG /SETUP FIELD FLAG
/
/INTERIGATE ABOUT CONSTANT TRACK1
ASKNX1, PRINTER /PRINT "TRACK?"
0346 3410 MESS
0347 4444 RECEIV /RECEIVE Y OR N
0350 4437 YESNO /CHECK FOR Y OR N
0351 5345 JMP ASKNX1 /ERROR, ASK AGAIN
0352 5767 JMP ASKNX2 /N, ASK ABOUT NEXT
0353 4431 SPACE
0354 4432 ONEIN /RECEIVE 1 IN OCTAL
0355 0010 0010 /LIMITS
0356 5345 JMP ASKNX1 /ERROR, ASK AGAIN
0357 5766 JMP SAVE1 /TU SAVE SOME ROOM.
/
0360 5405 K5405, 5405
0361 3167 LNKDCA, DCA SVLNK
0362 3166 ACUCA, DCA SAVAC
0363 2304 BRKRET, RETURN
/
0366 0400
0367 0406
0370 3572
0371 0513
0372 1404
0373 2601
0374 0522
0375 0600
0376 2730
0377 0070
0400 PAGE
/
/
```

```

/INTERIGATE ABOUT CONSTANT
/BLOCK LENGTH1
/
0400 3161 SAVE1, DCA SPTRK1 /SAVE EXTENDED TRACK BIT
0401 4433 FORIN /GET FOUR IN OCTAL.
0402 5777 JMP ASKNX1 /ERROR, ASK AGAIN
0403 3162 DCA SPTRK2 /SAVE CYL., SURFACE, AND SECTOR
0404 7340 CLA CLL CMA
0405 3776 DCA TRKFLG /SETUP TRACK FLAG
/
0406 4455 ASKNX2, PRINTER /PRINT "BLOCK LENGTH?"
0407 3424 MESS1
0410 4444 RECEIV /RECEIVE INPUT
0411 4437 YESNO /CHECK FOR Y OR N
0412 5206 JMP ASKNX2 /ERROR, ASK AGAIN
0413 5225 JMP ASKNX3 /N, ASK ABOUT NEXT
0414 4431 SPACE /Y, SPACE OUT 1
0415 4432 ONEIN /RECEIVE 1 IN OCTAL
0416 0010 0010 /LIMITS
0417 5206 JMP ASKNX2 /ERROR, ASK AGAIN
0420 7640 SZA CLA /SET HALF BLOCK?
0421 7340 CLA CLL CMA /YES
0422 3164 DCA SPBLK /SETUP BLOCK NUMBER
0423 7340 CLA CLL CMA
0424 3775 DCA MLFFLG /SETUP BLOCK FLAG
/
/INTERIGATE ABOUT CONSTANT
/SECTORS1
/
0425 4455 ASKNX3, PRINTER /PRINT "EXTRA SECTORS?"
0426 3414 MESS10
0427 4444 RECEIV /RECEIVE INPUT
0430 4437 YESNO /CHECK FOR Y OR N
0431 5225 JMP ASKNX3 /INPUT ERROR
0432 5264 JMP ASKNX5 /N, ASK ABOUT NEXT
0433 4431 SPACE /SPACE OUT 1
0434 4432 ONEIN /RECEIVE 1 IN OCTAL
0435 0010 0010 /LIMITS
0436 5225 JMP ASKNX3 /ERROR, ASK AGAIN
0437 7104 CLL RAL
0440 7006 RTL
0441 3163 DCA SPSEC /SAVE IT
0442 4432 ONEIN /RECEIVE 1 IN OCTAL
0443 0070 0070 /LIMITS
0444 5225 JMP ASKNX3 /INPUT ERROR, ASK AGAIN
0445 1163 TAD SPSEC /ADD IN LAST
0446 3163 DCA SPSEC /SAVE ALL
0447 1164 TAD SPBLK
0450 7640 SZA CLA /BLOCK LENGTH 0????
0451 5254 JMP .+3 /NO LIMIT IS 17.
0452 1160 TAD SPFLD
0453 7640 SZA CLA /FIELD 0?????
0454 1065 TAD K0010 /LIMIT IS 17.
0455 1064 TAD K0007
```

```

0456 7140      CLL CMA
0457 1163      TAD      SPSEC      /COMPARE SECTOR INPUT;
0460 7630      SZL CLA      /IN LIMITS???
0461 5225      JMP      ASKNX3      /NO, INPUT ERROR
0462 7340      CLA CLL CMA
0463 3774      DCA      SECFLG      /SETUP SECTOR FLAG

/
/
/INTERIGATE ABOUT "OPERATOR
/SELECT DATA"
/
0464 4455      ASKNX5, PRNTER      /PRINT "DATA?"
0465 3433      MES13
0466 1322      TAD      RANJMS
0467 3773      DCA      SWDAT      /SET INSTRUCTION SWITCH
0470 4444      RECEIV      /RECEIVE INPUT
0471 4437      YESND      /Y OR N
0472 5264      JMP      ASKNX5      /ERROR, ASK AGAIN
0473 5313      JMP      ASKSUR      /ASK "ARE YOU SURE"
0474 1346      TAD      KSKP
0475 3773      DCA      SWDAT      /SET INSTRUCTION SWITCH
0476 1105      TAD      M12
0477 3111      DCA      TRASH1      /SETUP WORD COUNTER
0500 7340      CLA CLL CMA
0501 1151      TAD      DATPOT      /GET POT POINTER
0502 3010      DCA      AUTO10
0503 4457      CRLF
0504 4433      FORIN
0505 5264      JMP      ASKNX5      /RECEIVE 4 IN OCTAL
0506 3410      DCA I      AUTO10      /INPUT ERROR, ASK AGAIN
0507 2111      ISZ      TRASH1      /SAVE DATA
0510 5303      JMP      L=5      /UPDATE COUNTER
0511 7340      CLA CLL CMA      /GET NEXT
0512 3157      DCA      DATFLG      /SETUP DATA FLAG

/
/ASK IF HE'S SURE;
/
0513 4455      ASKSUR, PRNTER      /PRINT "ARE YOU SURE"
0514 3436      MES14
0515 4444      RECEIV      /GET INPUT
0516 4437      YESND      /Y OR N
0517 5313      JMP      ASKSUR      /INPUT ERROR
0520 5772      JMP      STRTEX      /ALL AGAIN
0521 5771      JMP      RUN      /START DATA TESTING
0522 4426      RANJMS, GENDAT

/THIS ROUTINE TESTS FOR BEING ON APT.
/IF ON APT RETURN IS PLUS ONE, IF NOT RETURN IS PLUS TWO.
/
0523 0000      CHEK22, 0
0524 1022      TAD      22
0525 7700      SMA CLA      /ON APT?
0526 2323      ISZ      CHEK22      /NO, UPDATE RETURN.
0527 5723      JMP I      CHEK22      /AND RETURN.

```

```

/ROUTINE TO NOTIFY APT.
/
0530 0000      KTIME, 0
0531 4424      CHK22
0532 7410      SKP
0533 5730      JMP I      KTIME      /ON APT.
0534 6002      IOF      /NOT ON APT, GO ABOUT NORMAL RUN.
0535 6201      CDF      00      /TURN INTERRUPT SYSTEM OFF
                                /DATA FIELD SHOULD ALWAYS
                                /BE ZERO IN PROGRAM RUN.
                                /CHANGED TO CURRENT DATA FIELD.

0536 6272      CIF      70
0537 4741      JMS I      K6500
0540 5730      JMP I      KTIME      /RETURN,

/
/ K6500, 6500
/
/
/SUBROUTINE TO LOAD COMMAND REGISTER
/
0542 0000      LOCH, 0
0543 3123      DCA      CMREG
0544 1123      TAD      CMREG
0545 6746      IOT6, OLDC
0546 7610      KSKP, SKP CLA      /LOAD COMMAND REGISTER
0547 4576      ERHLT6, JMS I      BGHLT
0550 1122      TAD      EXREG
0551 7110      CLL RAM
0552 7630      SZL CLA
0553 1016      TAD      K0200
0554 6740      IOT6, OLDC
0555 7610      SKP CLA      /LOAD EXT. DRIVE
0556 4576      ERHLT6, JMS I      BGHLT      /SKIP TRAP IOT6
0557 5742      JMP I      LOCH      /EXIT

/
/
/SUBROUTINE TO ISSUE "DCLR" CLEAR IOT
/
0560 0000      CLDR, 0
0561 6742      IOT2, DCLR      /DCLR "CLEAR IOT"
0562 5760      JMP I      CLDR      /EXIT
0563 4576      ERHLT2, JMS I      BGHLT      /ERROR SKIP TRAP

0571 0600
0572 0224
0573 2601
0574 3574
0575 3575
0576 3573
0577 0345
0600
PAGE
/
/
/SETUP ADDRESSING, COMMAND,
/AND DATA PARAMETERS;

```



```

/MAKE FIELD1
/
0600 4406 RUN, LAS /GET THE SWITCHES.
0601 0016 AND K0200 /MASK MALT SW,
0602 7640 SZA CLA /TIME TO MALT?
0603 7402 STPMHT, HLT /MALT FROM SWR4=1.
0604 1777 TAD FLOFLG /GET FIELD FLAG
0605 7650 SNA CLA /WAS IT SET?
0606 5211 JMP ,+3 /NO, USE RANDOM FIELD
0607 1160 TAD SPFLD /YES, GET OPERATOR FIELD
0610 5230 JMP RNFLD /GO
0611 7301 CLA CLL IAC
0612 1143 TAD MAXFLD /GET MAXIMUM FIELD POINTER
0613 7650 SNA CLA /ANY FIELDS THERE
0614 5230 JMP RNFLD /NO EXTENDED FIELDS TO USE
0615 4440 RANGEN /YES, GET A RANDOM FIELD
0616 0014 AND K0070 /MASK
0617 7450 SNA /COULD BE 0
0620 5230 JMP RNFLD /WAS DON'T HAVE TO CHECK LIMITS
0621 3136 DCA INTCM /SAVE FIELD FOUND
0622 1136 TAD INTCM
0623 1143 TAD MAXFLD /ADD IN MAXIMUM FIELD POINTER
0624 7710 SPA CLA /IN LIMITS????
0625 5231 JMP RNFLD+1 /YES, USE IT
0626 1143 TAD MAXFLD /NO, USE MAXIMUM IN THE MACHINE
0627 7040 CMA
0630 3136 RNFLD, DCA INTCM
/MAKE BLOCK LENGTH1
/
0631 1776 TAD HLFFLG /GET BLOCK FLAG
0632 7650 SNA CLA /WAS IT SET????
0633 4440 RANGEN /NO, USE RANDOM
0634 1164 TAD SPBLK /MASK
0635 0015 AND K0100 /INITIAL HALF BLOCK BIT ****
0636 1136 TAD INTCM
0637 3136 DCA INTCM
0640 1136 TAD INTCM
0641 0015 AND K0100 /MASK
0642 7640 SZA CLA /HALF BLOCK SET????
0643 1016 TAD K0200 /YES, SETUP WC POINTER
0644 1104 TAD K7400 /WC BUILDER
0645 3112 DCA TRASH2
0646 1112 TAD TRASH2
0647 7041 CIA
0650 3114 DCA UPDATE /UPDATER FOR FWREG
0651 1136 TAD INTCM
0652 0350 AND A0170 /MASK FIELD BITS
0653 7640 SZA CLA /WERE THERE ANY
0654 1065 TAD K0010 /YES
0655 1064 TAD K0007 /MAKE MAXIMUM SECTOR POINTER
0656 3111 DCA TRASH1 /SAVE IT
/MAKE AMOUNT OF SECTORS
/TO TRANSFER1

```

```

0657 1775 TAD SECFLG /GET SECTOR FLAG
0660 7650 SNA CLA /WAS IT SET????
0661 4440 RANGEN /USE RANDOM
0662 1163 TAD SPSEC /GET OPERATOR INPUT
0663 0111 AND TRASH1 /MASK OUT
0664 3147 DCA CONSEC /SAVE
0665 1147 TAD CONSEC
0666 7040 CMA
0667 3111 DCA TRASH1 /CONSECUTIVE TO DO
/MAKE WORD COUNT1
/
0670 1112 TAD TRASH2 /COMPUTE INITIAL WC
0671 2111 ISZ TRASH1
0672 5270 JMP ,+2 /UPDATE BY BUILDER
0673 3127 DCA WCEG /INITIAL WORD COUNT ****
/MAKE CURRENT ADDRESS1
/
0674 4440 RANGEN /GENERATE RANDOM CA
0675 3126 DCA CAREG /SAVE IT
0676 1136 TAD INTCM
0677 0014 AND K0070 /MASK FIELD BITS
0700 7640 SZA CLA /EXTENDED FIELD????
0701 5317 JMP FILLUP /INITIAL CA 0,K,****
0702 1146 TAD BGNBUF
0703 7140 CMA CLL
0704 1126 TAD CAREG
0705 7620 SNA CLA /GREATER THAN PROGRAM+1
0706 5315 JMP CONCUR /NO, USE CONSTANT VALUE
0707 1127 TAD WCEG /GET WORD COUNT
0710 7041 CIA
0711 1126 TAD CAREG /ADD IN CA
0712 1016 TAD K0200
0713 7630 SZA CLA /WITHIN BOUNDS????
0714 5317 JMP FILLUP /YES, INITIAL CA 0,K,****
0715 1146 CONCUR, TAD BGNBUF /NO, USE PROGRAM+1
0716 3126 DCA CAREG /SAVE IT
/ROUTINE TO FILL AND CHECK SUM BUFFER
/
0717 4425 FILLUP, K7ICK /NOTIFY APT IF NEED BE.
0720 4434 SETGEN /SETUP AND SAVE GENERATOR
0721 1106 TAD M4
0722 3137 DCA SATRY /SETUP TRY COUNTER
0723 4435 REPILL, SETFLD /FIELD+ BUFTAL+ AUTO 11+ 12
0724 3325 DCA ,+1 /FIELD TO BUFFER IN AC
0725 7402 HLT /CDF TO BUFFER
0726 3141 DCA CMKSAV /START WITH 0
0727 4427 NEWRD, RANDAT /GENERATE DATA
0730 3111 UCA TRASH1 /SAVE OUTPUT WORD
0731 1111 TAD TRASH1 /GET BACK WORD
0732 3411 DCA I AUTO11 /STORE IN BUFFER
0733 7100 CLL

```

```

0734 1111 TAD TRASH1 /GET BACK WORD
0735 1141 TAD CHRSAY /ADD IN LAST
0736 7430 S2L /LINK SET??
0737 7001 IAC /ADD IT IN
0740 3141 DCA CHRSAY /SAVE FOR NEXT
0741 2117 ISZ BUPTAL /UPDATE BUFFER TALLY
0742 5327 JMP NEWRD /MORE WORDS TO GO
0743 6201 CDF 0
0744 1165 TAD ERPLG
0745 7650 SNA CLA /ERROR FLAG SET????
0746 5774 JMP POLNEX /POLE DRIVES
0747 5773 JMP REWRT /YES, MUST BE A WRITE ERROR

```

```

0750 0170 AD170, 0170
/
/SUBROUTINE TO ISSUE "DSKP" DISK SKIP IOT
/

```

```

0751 0000 SDAP, 0
0752 6741 IOT1, DSKP /DISK SKIP IOT
0753 7410 SKP /DID NOT SKIP
0754 2351 ISZ 0DKP
0755 5751 JMP I 0DKP /EXIT

```

```

/PLACE FOR DATA IN MANUAL MODE
/

```

```

0756 0000 DAT1, 0000
0757 0000 DAT2, 0000
0760 0000 DAT3, 0000
0761 0000 DAT4, 0000
0762 0000 DAT5, 0000
0763 0000 DAT6, 0000
0764 0000 DAT7, 0000
0765 0000 DAT8, 0000
0766 0000 DAT9, 0000
0767 0000 DAT10, 0000
0770 0000 DAT11, 0000
0771 0000 DAT12, 0000
/

```

```

0773 1047
0774 1000
0775 3574
0776 3575
0777 3572
1000

```

```

PAGE
/
/ROUTINE TO SELECT DRIVE NO.
/SEQUENTIAL SELECTION 0,1,2,3,0,1,ETC.
/

```

```

1000 2115 POLNEX, ISZ POLDISK /UPDATE POLE POINTER
1001 1115 TAD POLDISK /GET POINTER
1002 4436 SELCHK /CHECK IF DISK ON SYSTEM,
1003 5200 JMP POLNEX /NO, TRY NEXT DRIVE
1004 1115 TAD POLDISK
1005 7112 CLL RTM
1006 0061 AND K0001

```

```

1007 3122 DCA EXREG /SET EXT, DRIVE BIT
/

```

```

/DRIVE COMPLETED, START
/WRITE SEQUENCE1
/SELECT DISK ADDRESS,
/

```

```

1010 1115 GOTIT, TAD POLDISK /GET DRIVE NO.
1011 0062 AND K0003 /MASK
1012 7104 CLL RAL /MOVE TO 9=10.
1013 1136 TAD INTCM /ADD IN OTHER.
1014 3136 DCA INTCM /SAVE INITIAL COMMAND.
1015 1777 TAD TRKFLG /GET TRACK FLAG
1016 7650 SNA CLA /WAS IT SET????
1017 4440 RANGEN /GET RANDOM DA.
1020 1161 TAD SPTRK1 /GET OPERATOR CONSTANT INPUT.
1021 0061 AND K0001 /MASK EXT, BIT.
1022 1136 TAD INTCM /ADD IN OTHER.
1023 3136 DCA INTCM /SAVE COMPLETE INITIAL COMMAND.
1024 1777 TAD TRKFLG /GET TRACK FLAG
1025 7650 SNA CLA /WAS IT SET????
1026 4440 RANGEN /USE RANDOM
1027 1162 TAD SPTRK2 /GET INPUT
1030 3124 DCA INTDA /SAVE INITIAL DA.
1031 1777 TAD TRKFLG
1032 7640 SZA CLA /INPUT BY OPERATOR?
1033 5247 JMP REWRT /LET HIM FAIL??
1034 1136 TAD INTCM
1035 7010 RAR
1036 7620 SNA CLA /EXT BIT SET?
1037 5247 JMP REWRT /NO, DON'T LIMIT DA.
1040 1145 TAD MAXTRK
1041 1124 TAD INTDA
1042 7630 S2L CLA /BEYOND MAXIMUM LIMIT?
1043 5247 JMP REWRT /NO, DONT LIMIT.
1044 1124 TAD INTDA
1045 7040 CMA
1046 3124 DCA INTDA /YES, SET TO LEGAL LIMIT.
/

```

```

/WRITE INFORMATION1
/CLEAR BUFFER ON THE FLY1
/

```

```

1047 4441 REWRT, DISKGO /GO WRITE
1050 4400 4400 /WRITE DATA POINTER
1051 5263 JMP REREAD /WRITE O.K.
1052 7340 CLA CLL CMA
1053 3165 DCA ERPLG /SET WRITE ERROR FLAG
1054 4442 RESRAN /RESET GENERATOR
1055 2137 ISZ STATRY /UPDATE WRITE RE-TRY
1056 5776 JMP REFILL /TRY AGAIN
/

```

```

/CHECK FOR LOOP ON WRITE1
/

```

```

1057 4406 LAS /GET SWITCH 0
1060 7710 TRYTIM, SPA CLA /LOOP ON WRITE????
1061 5775 JMP REFILL=2 /YES, TRY WRITE AGAIN

```

```

1062 5351      JMP      STRREL      /RESUME ALL UNIVES ON ERROR
1063 1260      REREAD, TAD      TRYTIM
1064 3171      DCA      TRYCNT      /SETUP FOR SOFT ERROR RETRY
1065 3165      DCA      ERFLG      /CLEAR ERROR FLAG
1066 1106      TAD      M4
1067 3137      DCA      STATRY      /SETUP TRY COUNTER
1070 1106      TAD      M4
1071 3140      DCA      DATTRY      /SETUP TRY COUNTER
1072 3155      DCA      CRCCNT      /CLEAR CRC COUNTER!!!!

```

```

/
/READ INFORMATION;
/CHECK BUFFER ON THE FLY;
/

```

```

1073 4441      RDRY,   DISKGO      /READ DATA
1074 0400      0400      /READ DATA POINTER
1075 7610      SKP CLA      /DATA READ O.K.
1076 5305      JMP      RDSTA      /STATUS ERROR
1077 3155      DCA      CRCCNT      /CLEAR CRC COUNTER;

```

```

/
/CHECK DATA ON NO STATUS ERRORS;
/

```

```

1100 4774*     JMS      DTCHK      /CHECK DATA
1101 5324      JMP      RERUN      /DATA O.K.
1102 2140      ISZ      DATTRY      /UPDATE READ RE-TRY
1103 5273      JMP      RDRY      /TRY AGAIN
1104 5323      JMP      RERUN-1     /TRY TO SEEK IT
1105 1121      RDSTA, TAD      STREG      /GET STATUS READ
1106 0865      AND      K0810      /MASK CRC
1107 7450      SNA      /CRC ERROR????
1110 5320      JMP      UPTRY      /NO, TRY READ AGAIN
1111 3156      DCA      CRCFLG      /YES, SET FLAG
1112 2155      ISZ      CRCCNT      /UPDATE CRC POINTER

```

```

/
/CHECK DATA AFTER CRC ERROR;
/

```

```

1113 4774*     JMS      DTCHK      /CHECK DATA
1114 7610      SKP CLA      /IS A HARD ERROR;
1115 7340      CLA CLL CMA      /SET RETRY COUNTER;
1116 3165      DCA      ERFLG      /SETUP FOR 64 RETRYs IF AC=7777
1117 7410      SKP      /CHECK ON RETRY!!!!
1120 3155      UPTRY, DCA      CRCCNT
1121 2137      ISZ      STATRY      /UPDATE TRY POINTER
1122 5273      JMP      RDRY      /TRY AGAIN
1123 3165      DCA      ERFLG      /IS A HARD ERROR
1124 3155      RERUN, DCA      CRCCNT      /CLEAR CRC COUNT
1125 3156      DCA      CRCFLG      /CLEAR CRC FLAG
1126 4773*     JMS      CKTIM      /CHECK TIME POINTERS
1127 1165      TAD      ERFLG
1130 7650      SNA CLA      /IS IT 64 RETRYs FOR SOFT ERROR?
1131 5334      JMP      ,+3      /NO DON'T BOTHER
1132 2171      ISZ      TRYCNT      /YES, UPDATE RETRY COUNTER
1133 5266      JMP      REREAD+3   /TRY AGAIN

```

```

/
/CHECK FOR LOOP ON READ;
/

```

```

1134 4406      LAS      /GET SWITCH 1
1135 7104      CLL RAL
1136 7710      SPA CLA      /LOOP????
1137 5263      JMP      REREAD      /YES, LOOP
1140 1137      TAD      STATRY      /TEST FOR HARD ERROR
1141 7650      SNA CLA
1142 5351      JMP      STRREL      /YES
1143 3165      DCA      ERFLG      /CLEAR ERROR FLAG

```

```

/
/CHECK FOR TYPE STATUS
/REPORT;
/

```

```

1144 4406      LAS      /MASK
1145 0017      AND      K0400      /TYPE STATUS REPORT????
1146 7640      SZA CLA
1147 4772*     JMS      TPSTA      /YES
1150 5771*     JMP      RUN      /DU NEXT DRIVE

```

```

/
/RESTORE DRIVE AFTER ERROR
/

```

```

1151 1123      STRREL, TAD      CMREG      /GET DRIVE NO.
1152 4443      RECAL      /RESTORE
1153 5771*     JMP      RUN      /START NEXT DRIVE

```

```

/
/ROUTINE TO DETERMINE IF TIMING NEEDS TO BE FOR APT SYSTEM.
/

```

```

1154 0000      XKTICK, 0
1155 4424      CHK22      /TEST FOR APT
1156 7410      SKP      /NO, RETURN TO NORMAL RUN
1157 5754      JMP I      XKTICK
1160 6201      CDF      0
1161 2150      ISZ      CLKCNT      /LONG COUNTER FOR APT
1162 5366      JMP      EXTICK      /NORMAL RETURN
1163 1100      TAD      K7760      /INIT COUNTER
1164 3150      DCA      CLKCNT
1165 4770*     JMS      KTIME      /NOTIFY APT
1166 6201      EXTICK, CDF 0
1167 5754      JMP I      XKTICK
1170 0530
1171 0600
1172 3000
1173 2450
1174 1600
1175 0721
1176 0723
1177 3573
1200 0000
1201 7001

```

```

PAGE
/
/ERROR HANDLER;
/UPDATE "SOFT" ON "HARD" TALLYS;
/PRINT ERROR TEXT AND DATA;
/CHECK INHIBIT ENROR SW;
/

```

```

ERNO, 0
IAC
/UPDATE AC FLAG

```

```

1202 3374      DCA      PCNTR2      /SAVE NON-RECOVERABLE POINTER;
      /
      /COMPUTE WAY TO "HARD"/"SOFT" TALLYS;
      /
1203 1377      TAD      K7773
1204 3375      DCA      PCNTR3      /LINE COUNTER
1205 1123      TAD      CMREG      /GET LAST COMMAND
1206 0063      AND      K0006      /MASK DRIVE NUMBER
1207 7170      CLL CML CMA RAR
1210 3373      DCA      PCNTR1      /SETUP COUNTER
1211 1062      TAD      K0003
1212 2373      ISZ      PCNTR1
1213 5211      JMP      ,+2      /COMPUTE WAY TO BUFFER
1214 1153      TAD      STAPOT
1215 3373      DCA      PCNTR1      /POINTER TO BUFFER
      /
      /DETERMINE IF ERROR IS "HARD" OR "SOFT";
      /
1216 1156      TAD      CRCFLG      /GET CRC FLAG
1217 7650      SNA CLA      /CRC ERROR???
1220 5251      JMP      NT$OFT      /NO, WAS DEFINITELY A HARD ERROR;
1221 1600      TAD I      ERRO      /GET ERROR POINTER;
1222 7650      SNA CLA      /WAS IT FIRST TIME?
1223 5255      JMP      NTERR      /NO ERROR, ADDITIONAL CRC DATA;
1224 1125      TAD      DAREG      /COMPARE FAILING SECTOR TO
1225 0066      AND      K0017      /SECTOR WHERE DATA ERROR
1226 7041      CIA          /OCCURRED;
1227 1131      TAD      ASREG
1230 7640      SZA CLA      /SAME SECTOR?
1231 5251      JMP      NT$OFT      /NO, "HARD" ERROR
1232 7340      CLA CLL CMA
1233 1155      TAD      CRCCNT      /GET CRC COUNTER
1234 7450      SNA          /WAS THIS FIRST POSSIBLE "SOFT"?
1235 5245      JMP      SOFT      /YES, UPDATE "SOFT" TALLY;
1236 1110      TAD      K7775      /CHECK IF NONRECOVERABLE "SOFT";
1237 7650      SNA CLA      /WAS IT?
1240 2373      ISZ      PCNTR1      /NO, DUMP "SOFT" TALLY;
1241 1773      TAD I      PCNTR1      /OTHERWISE DUMP "HARD" TALLY;
1242 7440      SZA          /DUNT GO BACK WARDS!!!!!!
1243 1101      TAD      K7777      /DUMP APPROPRIATE TALLY!!
1244 5254      JMP      NTERR=1      /DUMP IT;
1245 1101      SOFT, TAD      K7777
1246 1773      TAD I      PCNTR1      /REDUCE HARD ERROR COUNT
1247 3773      DCA I      PCNTR1
1250 2373      ISZ      PCNTR1      /YES, UPDATE POINTER
1251 1101      NT$OFT, TAD      K7777
1252 2773      ISZ I      PCNTR1      /UPDATE ERROR COUNT
1253 7610      SKP CLA
1254 3773      DCA I      PCNTR1      /HOLD AT 7777
      /
      /CHECK INHIBIT SW;
      /
1255 4423      NTERR, JMS I      K$ERRO      /REPORT ERROR TO APT IF REQUIRED
1256 4406      LAB
1257 7106      CLL RTL

```

```

1260 7710      SPA CLA      /INHIBIT ERRORS???
1261 5356      JMP      ERROEX+1      /YES
      /
      /CHECK FOR NO HEADER ON SECOND DATA ERROR;
      /
1262 1600      DONEAD, TAD I      ERRO      /GET TEXT POINTER
1263 7650      SNA CLA      /DATA ERROR?
1264 5355      JMP      ERROEX      /EXIT
      /
      /TYPE ERROR MESSAGE;
      /
1265 4457      CRLF
1266 4457      CRLF
1267 1374      TAD      PCNTR2      /GET NON-RECOV. FLAG
1270 7640      SZA CLA      /WAS IT SET
1271 5275      JMP      ,+4      /NO DON'T TYPE IT
1272 7340      CLA CLL CMA
1273 4455      PRNTER
1274 3355      MES4          /PRINT "NON-RECOVERABLE "
1275 1600      TAD I      ERRO      /GET TEXT POINTER;
1276 1376      TAD      HEUTAD      /MAKE ERROR HEADER POINTER;
1277 3120      DCA      PCREG      /SAVE POINTER;
1280 1520      TAD I      PCREG      /GET CORRECT TEXT;
1281 3304      DCA      ,+3
1282 7340      CLA CLL CMA
1283 4455      PRNTER      /PRINT HEADER
1284 7402      HLT
1285 7340      CLA CLL CMA
1286 4455      PRNTER      /PRINT "ERROR"
1287 3303      MES0
1288 4457      CRLF
1289 1200      TAD      ERRO
1290 3120      DCA      PCREG      /SAVE PC
1291 2200      ISZ      ERRO
1292 1600      TAD I      ERRO
1293 3371      DCA      ESARE
1294 2200      ISZ      ERRO      /UPDATE FOR RETURN
1295 1172      TAD      XTEXT
1296 3374      DCA      PCNTR2
1297 1372      TAD      XREG
1298 3010      DCA      AUTO10
1299 1105      TAD      M12
1300 3373      DCA      PCNTR1      /COUNTER FOR # OF HEADS
1301 1371      STHAUT, TAD      ESARE      /GET TEXT POINTER
1302 7500      SNA
1303 5363      JMP      NOTEX      /NOT THIS ONE
1304 7104      CLL RAL
1305 3371      DCA      ESARE
1306 2375      ISZ      PCNTR3      /UPDATE LINE FILL COUNTER
1307 7610      SKP CLA      /NO CRLF
1308 4457      CRLF
1309 1374      TAD      PCNTR2      /GET TEXT MESSAGE POINTER
1310 2374      ISZ      PCNTR2
1311 2374      ISZ      PCNTR2
1312 3343      DCA      ,+3      /STORE FOR PRNTER

```

```

1341 7340          CLA CLL CMA
1342 4455          PRINTER
1343 7402          MLT
1344 1410          TAD I      AUTO10
1345 4456          UCTEL
1346 2373          AGAIN,    ISZ      PCNTR1
1347 5325          JMP      STKAUT
1350 1520          TAD I      PCMEG
1351 1106          TAD      M4
1352 7650          SNA CLA
1353 4573          JMS I      PRNDAT
1354 5360          JMP      ,+4
1355 4573          JMS I      PRNDAT
1356 2200          ISZ      ERMO
1357 2200          ISZ      ERNO
1360 7301          CLA CLL IAC
1361 4454          CLRALL
1362 5600          JMP I      ERNO
1363 7104          NOTEX,    CLL RAL
1364 3371          DCA      ESAVE
1365 2374          ISZ      PCNTR2
1366 2374          ISZ      PCNTR2
1367 2010          ISZ      AUTO10
1370 5346          JMP      AGAIN

/
1371 0000          ESAVE,    0
1372 0117          XREG,      PCREG-1
1373 0000          PCNTR1,    0
1374 0000          PCNTR2,    0
1375 0000          PCNTR3,    0
1376 1377          HEDTAD,    BUFPNT-1
1377 7773          K7773,    7773

/
1400             PAGE
/
/POINTERS FOR TEXT INFORMATION!
/
1400 3247          BUFPNT,    ERTX1
1401 3255          ERTX2
1402 3264          ERTX3
1403 3276          ERTX4

/
/ROUTINE TO CHECK FOR CLASSIC AND LIMIT
/TRANSFERS TO FIELD 0 IF AVAILABLE.
/
1404 0000          CLAFLO,    0
1405 1022          TAD      22
1406 0017          AND      K0000
1407 7650          SNA CLA
1410 5604          JMP I      CLAFLO
1411 7340          CLA CLL CMA
1412 3143          DCA      MAXFLO
1413 5604          JMP I      CLAFLO

/
/ROUTINE TO DO CRLF

```

```

1414 0000      / UPONE, 0
1415 7300      CLA CLL
1416 1224      TAD      K0215
1417 4445      TYPE
1420 1225      TAD      K0212
1421 4445      TYPE
1422 4445      TYPE
1423 5614      JMP I    UPONE

1424 0215      K0215, 0215
1425 0212      K0212, 0212

/ROUTINE TO PRINT FOUR OCTAL
/
1426 0000      0
1427 7006      RTL
1430 7006      RTL
1431 3214      DCA      UPONE
1432 1106      TAD      M4
1433 3250      DCA      PRN
1434 1214      TAD      UPONE
1435 0064      AND      K0007
1436 1067      TAD      K0260
1437 4445      TYPE
1440 1214      TAD      UPONE
1441 7006      RTL
1442 7004      RAL
1443 3214      DCA      UPONE
1444 2250      ISZ      PRN
1445 5234      JMP      .+11
1446 4431      SPACE
1447 5626      JMP I    FRUCT

/

/SUBROUTINE TO PRINT TEXT
/
1450 0000      PRN, 0
1451 7650      SNA CLA
1452 4457      CRLF
1453 1650      TAD I    PRN
1454 2250      ISZ      PRN
1455 3226      DCA      FRUCT

1456 7300      MKPRN, CLA CLL
1457 1626      TAD I    FRUCT
1460 0077      AND      K7700
1461 7450      SNA
1462 5304      JMP      EXIT
1463 7500      SMA
1464 7020      CML
1465 7001      IAC
1466 7012      RTR
1467 7012      RTR

```

```

1470 7012      RTR
1471 4445      TYPE
1472 1026      TAD I   FRUCT
1473 0102      AND     K0077
1474 7450      SNA
1475 5304      JMP     EXIT
1476 1313      TAD     K3740
1477 7500      SNA
1500 1074      TAD     K4100
1501 4431      SPACE           /SPACE OUT 1
1502 2226      ISZ     FRUCT
1503 5256      JMP     MRPRN    /MORE TO PRINT
1504 7300      EXIT,   CLA CLL
1505 5650      JMP I   PRN
/
/ROUTINE TO SPACE OUT 1
/
1506 0000      SPAC,   0
1507 1312      TAD     K0240
1510 4445      TYPE
1511 5706      JMP I   SPAC
/
1512 0240      K0240, 240
1513 3740      K3740, 3740
/
/THIS ROUTINE WILL BE A SKIP INSTRUCTION FOR SYSTEMS WITHOUT CLASSIC
/OTHERWISE IT WILL EXECUTE THE NEXT INSTRUCTION IN FIELD 0 AND THEN
/SKIP THE INSTRUCTION AFTER THAT ONE.
/
1514 0000      CLASIK, 0
1515 3345      DCA     SAVEAC    /SAVE CURRENT AC.
1516 1714      TAD I   CLASIK    /GET INSTRUCTION TO EXECUTE.
1517 3344      DCA     ROUTMP    /SAVE IT.
1520 2314      ISZ     CLASIK
1521 1022      TAD     UP2
1522 0017      AND     K0400
1523 7640      SZA CLA           /ARE WE ON CLASSIC?
1524 5327      JMP     ,+3        /YES.
1525 1345      TAD     SAVEAC    /NO, THEN
1526 5714      JMP I   CLASIK    /EXIT.
1527 2314      ISZ     CLASIK
1530 6211      COF     10
1531 1020      TAD     SWR
1532 3777      DCA I   (SWR)     /SAVE SWITCH REGISTER.
1533 1021      TAD     UP1
1534 3776      DCA I   (OP1)     /SAVE CONTROL 1.
1535 1022      TAD     OP2
1536 3775      DCA I   (OP2)
1537 1344      TAD     ROUTMP
1540 3774      DCA I   (ROUTNS)  /SAVE ROUTINE IN FIELD 1.
1541 1345      TAD     SAVEAC    /GET BACK AC.
1542 6212      CIF     10
1543 5774      JMP I   (ROUTNS)  /GO AND EXECUTE INSTRUCTION.
/
1544 0000      ROUTMP, 0

```

```

1545 0000      SAVEAC, 0
/
/ROUTINE TO GET THE SWITCHES.
/
1546 0000      MYLAS, 0
1547 4407      CLASIK    /CHECK FOR CLASSIC.
1550 4425      CCKSW     /GET SWITCHES.
1551 7604      TAD     7604
1552 5746      JMP I   MYLAS    /EXIT.
/
/ROUTINE TO RESET REGISTERS FOR ERROR PRINTER
/
1553 0000      SETREG, 0
1554 1073      TAD     K4000    /GET STATUS
1555 3121      DCA     STREG    /SAVE FOR ERROR PRINTER
1556 7340      CLA CLL CMA     /DECREASE BY 1
1557 1111      TAD     TRASH1   /GET SECTOR POINTER
1560 0066      AND     K0017
1561 1112      TAD     TRASH2   /ADD IN ADDRESS
1562 3125      DCA     DAREG    /SAVE FOR ERROR PRINTER
1563 1170      TAD     FINTIM   /CHECK IF FIRST SECTOR
1564 7640      SZA CLA     /IF 80, DON'T UPDATE COMMAND
1565 5753      JMP I   SETREG   /NO, DON'T!
1566 1174      TAD     SAVCM    /GET COMMAND REG.
1567 3123      DCA     CMREG    /SAVE FOR ERROR PRINTER
1570 5753      JMP I   SETREG   /RETURN
/
1574 1302
1575 0022
1576 0021
1577 0020
1600 1600      PAGE
/
/ROUTINE TO CHECK DATA READ
/
1600 0000      DTCHK, 0
1601 1156      TAD     CRCFLG   /GET CRC FLAG
1602 7640      SZA CLA     /WAS IT SET?
1603 5212      JMP     WRDCHK    /YES, THEN WORD BY WORD CHECK!!!
1604 1142      TAD     FND8SUM   /GET CHECK SUM FOUND
1605 7041      CIA
1606 1141      TAD     CHKSAV    /COMPARE TO GOOD VALUE SAVED
1607 7650      SNA CLA     /WERE THEY THE SAME
1610 5600      JMP I   DTCHK    /YES, DATA O.K.
1611 7340      CLA CLL CMA
1612 5446      WRDCHK, DCA I   XEMRO /SETUP CHECKSUM ERROR FLAG
1613 1123      TAD     CMREG
/
1614 0015      AND     K0100
1615 7640      SZA CLA     /HALF BLOCK SET??
1616 1016      TAD     K0200    /YES!
1617 1104      TAD     K7400
1620 3112      DCA     TRASH2
1621 1112      TAD     TRASH2
1622 7040      CMA

```

```

1623 3314      DCA      MSKER
1624 7340      CLA CLL  CMA
1625 3142      DCA      FNDSUM
1626 4442      RESRAN
1627 1130      TAD      FWNREG
1630 4435      SETFLD
1631 3246      DCA      GOCDF
1632 1112      TAD      TRASH2
1633 3361      DCA      RSRAN
1634 1124      TAD      INTDA
1635 3353      DCA      STGEN
1636 1361      DTR1,   TAD      RSRAN
1637 0314      AND      MSKER
1640 3132      DCA      WAREG
1641 1353      TAD      STGEN
1642 0066      AND      K0017
1643 3131      DCA      ASREG
1644 4427      RANDAT
1645 3134      DCA      DGNEG
1646 7402      GOCDF,  HLT/COF
1647 1411      TAD I    AUTO11
1650 6201      COF      0
1651 3135      DCA      DBNEG
1652 1011      TAD      AUTO11
1653 3133      DCA      ADREG
1654 1135      TAD      DBREG
1655 7041      CIA
1656 1134      TAD      DGNEG
1657 7650      SNA CLA
1660 5272      JMP      NOERR
1661 2142      ISZ      FNDSUM
1662 5310      JMP      NTRKS
1663 1156      TAD      CRCFLG
1664 7650      SNA CLA
1665 1140      TAD      DATTRY
1666 2200      ISZ      DTCHK
1667 4446      ERROR
1670 0004      0004
1671 7760      7760
1672 2361      NOERR,  ISZ      RSRAN
1673 5300      JMP      .+5
1674 2353      ISZ      STGEN
1675 7000      NOP
1676 1112      TAD      TRASH2
1677 3361      DCA      RSRAN
1678 2117      ISZ      BUFTAL
1679 5236      JMP      DTN1
1682 1446      TAD I    XEWRD
1683 7650      SNA CLA
1684 3155      DCA      CRCCNT
1685 2446      ISZ I    XEWRD
1686 5600      JMP I    DTCHK
1687 4576      BADMLT, JMS I 0GMLT
1688 4446      NTRKS,  ERROR
1689 0000      0000

```

/SET FIRST TIME FLAG
/NO, SETUP RANDOM GENERATOR
/GET FINAL WC
/GET AUTO11+ BUFTAL+ FIELD
/SAVE FIELD CDF

/GENERATE DATA
/SAVE GOOD DATA POINTER
/COF TO BUFFER FIELD
/GET BAD DATA WORD
/MOVE DF
/SAVE BAD WORD
/GET ADDRESS
/SAVE FOR PRINTER
/GET DATA READ

/COMPARE TO GOOD VALUE
/WERE THEY THE SAME
/YES, NO ERROR
/FIRST TIME PRINT????
/NO, JUST ADDRESS AND DATA
/GET CRC FLAG
/IF SET NO NON-RECOVERABLE.
/NO, GET NON-RECOVERABLE FLAG,
/UPDATE FOR ERROR RETURN
/ERROR DATA
/PRINTER
/POINTER

/UPDATE BUFFER TALLY
/MORE WORDS TO CHECK
/GET ERROR INDICATOR
/WAS THERE AN ERROR?
/NO, CLEAR CRC COUNTER
/CHECK FOR COMPUTER ERROR
/ALL O.K.
/COMPUTER MUST BE DOWN, CHECKSUM
/OTHER ERRORS IN BUFFER

```

1712 0000      0000
1713 5272      JMP      NOERR
1714 0000      /
      MSKER, 0
      /
      /ROUTINE TO GENERATE RANDOM NUMBERS
      /
1715 0000      RANDOM, 0
1716 7301      CLA CLL  IAC
1717 1373      TAD      RAD1
1720 1374      TAD      RAD2
1721 1375      TAD      RAD3
1722 3373      DCA      RAD1
1723 7004      RAL
1724 1373      TAD      RAD1
1725 1374      TAD      RAD2
1726 1375      TAD      RAD3
1727 3374      DCA      RAD2
1730 7004      RAL
1731 1373      TAD      RAD1
1732 1374      TAD      RAD2
1733 1375      TAD      RAD3
1734 3375      DCA      RAD3
1735 1375      TAD      RAD3
1736 5715      JMP I    RANDOM
      /
      /EXIT, RANDOM NUMBER IN AC
      /
      /ROUTINE TO GENERATE RANDOM DATA
      /
1737 0000      GNDAT, 0
1740 7301      CLA CLL  IAC
1741 1367      TAD      RAN1
1742 1370      TAD      RAN2
1743 7106      CLL RTL
1744 3367      DCA      RAN1
1745 1370      TAD      RAN2
1746 7012      RTH
1747 1367      TAD      RAN1
1750 3370      DCA      RAN2
1751 1370      TAD      RAN2
1752 5737      JMP I    GNDAT
      /
      /ROUTINE TO SAVE RANDOM GENERATOR
      /
1753 0000      STGEN, 0
1754 1367      TAD      RAN1
1755 3371      DCA      SAV1
1756 1370      TAD      RAN2
1757 3372      DCA      SAV2
1760 5753      JMP I    STGEN
      /
      /ROUTINE TO RESET RANDOM GENERATOR
      /
1761 0000      RSRAN, 0
1762 1371      TAD      SAV1
1763 3367      DCA      RAN1

```

```
1764 1372      TAD      SAV2
1765 3370      DCA      RAN2
1766 5701      JMP I     RSMAN

      /
1767 1234      RAN1,    1234
1770 5670      RAN2,    5670
      /
1771 0000      SAV1,    0
1772 0000      SAV2,    0
1773 1234      RAD1,    1234
1774 5670      RAD2,    5670
1775 4321      RAD3,    4321
      /
      /
2000          PAGE
      /
      /ROUTINE TO WAIT FOR KEY FROM OPERATOR.
      /
2000 0000      WAIT,    0
2001 6032      KCC
2002 6031      KBF
2003 5202      JMP      ,=1
2004 6036      KRB
2005 0234      AND      K177
2006 1016      TAD      K0200
2007 3235      DCA      CHKN
      /SAVE CHARACTER
2010 1022      TAD      22
      /CHECK FOR CLASSIC
2011 0017      AND      K0400
      /MASK CLASSIC BIT
2012 7650      SNA CLA
      /CLASSIC=NON ZERO
2013 5226      JMP      WAIT1
2014 1235      TAD      CHKN
      /RESTORE CHAR. FOR CLASSIC
2015 6211      CDF      10
2016 3777      DCA      C0CHAR
      /SAVE CHARACTER.
2017 2776      ISZ      INMODE
2020 1777      TAD      C0CHAR
      /GET BACK AC.
2021 6201      CDF      0
2022 4407      CLASIC
      /CHECK FOR CLASSIC.
2023 4427      CSCNTR
      /ROUTINE TO EXECUTE.
2024 7000      NOP
2025 7300      CLA CLL
      /CLEAR CLASSIC AC RETURN
2026 1235      WAIT1,   CHKN
      /RESTORE CHARACTER
2027 6046      TLR
2030 6041      TSP
2031 5230      JMP      ,=1
2032 6042      TCF
2033 5600      JMP I     WAIT
      /EXIT
2034 0177      K177,    0177
      /
      /ROUTINE TO CHECK FOR YES OR NU
      /
2035 0000      CHKN,    0
2036 3200      DCA      WAIT
      /SAVE POINTER
2037 1235      TAD      CHKN
      /GET PC STORED
2040 3260      DCA      CHKPOT
      /SAVE IT
```

```
2041 1200      TAD      WAIT
2042 2235      ISZ      CHKN
2043 7041      CIA
2044 1257      TAD      K0316
2045 7650      SNA CLA
      /WAS IT A NO
2046 5635      JMP I     CHKN
      /YES
2047 1200      TAD      WAIT
2050 2235      ISZ      CHKN
2051 7041      CIA
2052 1256      TAD      K0331
2053 7650      SNA CLA
      /WAS IT A YES
2054 5635      JMP I     CHKN
      /YES
2055 5600      JMP I     CHKPOT
      /WAS NEITHER
      /
      /
2056 0331      K0331,   0331
2057 0316      K0316,   0316
      /
      /ROUTINE TO CHECK DISK RUN POINTERS
      /
2060 0000      CHKPOT, 0
2061 0064      AND      K0007
2062 1154      TAD      HUNPOT
2063 3200      DCA      WAIT
2064 1600      TAD I     WAIT
      /GET RUN POINTER
2065 7640      SZA CLA
      /RUN THIS DRIVE
2066 2260      ISZ      CHKPOT
      /NO
2067 5600      JMP I     CHKPOT
      /EXIT
      /
      /ROUTINE TO TEST FOR APT AND SET UP APPROPRIATE
      /REGISTERS IN UN THE SYSTEM.
      /
2070 0000      APT0,    0
2071 4424      CHK22
2072 5301      JMP      ,+7
      /TEST FOR APT
2073 4407      CLASIC
      /YES
2074 4431      C00WIT
2075 7000      NOP
2076 1355      TAD      K7000
2077 3775      DCA      SKPNOP
2100 5351      JMP      EXAPT0
      /EXIT
2101 1022      TAD      OP2
2102 0354      AND      K7377
      /NOP CONSOLE PACKAGE
2103 3022      DCA      UP2
2104 1355      TAD      K7000
2105 3774      DCA      MYLAS+3
      /NOP SWITCH REGISTER
      /NO OPERATOR INTERVENTION ALLOWED
2106 1022      TAD      OP2
2107 0064      AND      K0007
      /GET # OF DRIVES
2110 3111      DCA      TRASH1
2111 1022      TAD      OP2
2112 0015      AND      K0100
2113 7650      SNA CLA
      /SINGLE DRIVE = NON ZERO AC
2114 5325      JMP      M0USKS
      /NO.
```



```
2115 7301      CLL CLA IAC
2116 3000      DCA AMOUNT
2117 1111      TAD TRASH1      /ONLY ONE DRIVE
2120 1154      TAD HUNPOT      /GET DRIVE NUMBER
2121 3111      DCA TRASH1
2122 7300      CLL CLA CMA
2123 3511      DCA I TRASH1    /UU THIS DRIVE
2124 5302      JMP MEMSET
2125 1111      MOD8K0, TAD TRASH1
2126 7000      CMA
2127 3112      DCA TRASH2      /SAVE THE NUMBER OF DRIVES
2130 3111      DCA TRASH1
2131 1111      TAD TRASH1
2132 1154      TAD HUNPOT      /ESTABLISH DRIVE
2133 3113      DCA TRASH3
2134 7300      CLL CLA CMA
2135 3513      DCA I TRASH3    /UU THIS DRIVE
2136 2111      ISZ TRASH1
2137 2000      ISZ AMOUNT
2140 2112      ISZ TRASH2      /DONE?
2141 5331      JMP MOD8K0+4    /MORE TO DO
2142 1021      MEMSET, TAD 21
2143 7012      RTR
2144 0004      AND K0007
2145 7104      CLL RAL
2146 7006      RTL
2147 7040      CMA
2150 3143      DCA MAXFLD      /NEGATIVE AMOUNT OF FIELDS.
2151 2270      EXAPT0, ISZ APT0
2152 2270      ISZ APT0
2153 5070      JMP I APT0
/
2154 7377      K7377, 7377
2155 7000      K7000, 7000
/
/THIS ROUTINE WILL NOTIFY APT OF AN ERROR.
/ONLY THE DRIVE IN ERROR IS ESTABLISHED.
/
2156 0000      AERROR, 0
2157 4424      CHK22
2160 7410      SKP
2161 5756      JMP I AERROR      /CHECK FOR APT=0.
2162 6002      IOF
2163 7200      CLA
2164 1115      TAD PDLSK
2165 0004      AND K0007      /DRIVE NUMBER
2166 6201      CDF 00
2167 6272      CIF 70
2170 5772      JMP I K0520
2171 7402      MLT
/NOTIFY APT
/SOMETHING WENT WRONG IF IT GETS HERE
/
2172 6520      K0520, 6520
2174 1551
2175 0237
2176 1076
```

```
2177 1075      PAGE
2178 2200
/
/ROUTINE TO WRITE OR READ SECTORS SELECTED
/
2200 0000      DSKGO, 0
2201 7300      CLA CLL CMA
2202 3170      DCA FINTIM
2203 3156      DCA CRCFLG
2204 1126      TAD CAREG
2205 4452      LDCUR
2206 1127      TAD WCREG
2207 3130      DCA FWREG
2208 1124      TAD INTDA
2209 3111      DCA TRASH1
2210 1124      TAD INTDA
2211 0100      AND K7700
2212 3112      DCA TRASH2
2213 1136      TAD INTCH
2214 1600      TAD I DSKGO
2215 4451      LDCMD
2216 1123      TAD CMREG
2217 1075      TAD K1000
2218 3174      DCA SAVCH
2219 1111      TAD TRASH1
2220 0006      AND K0017
2221 1112      TAD TRASH2
2222 4453      LDADD
2223 6001      ION
/
/ROUTINE TO CLEAR OR CHECK SUM BUFFER ON THE FLY!
/
2230 3777*     GOBAK, DCA TIMER2
2231 3142      DCA FNU00M
2232 4435      SETFLD
2233 3254      DCA CHNCDF
2234 1170      TAD FINTIM
2235 7050      SNA CLA
2236 5241      JMP STNWRK
2237 4776*     JMS TIME
2238 5234      JMP 4
2239 1117      STNWRK, TAD BUPTAL
2240 7041      CIA
2241 1130      TAD FWREG
2242 7450      SNA
2243 5274      JMP WRKDON
2244 7041      CIA
2245 3175      DCA CLNBAK
2246 1175      TAD CLNBAK
2247 7041      CIA
2248 1117      TAD BUPTAL
2249 3117      DCA BUPTAL
2250 7402      CHNCDF, MLT
2251 1123      TAD CMREG
2252 7700      SNA CLA
/READ OR WRITE
/SETUP FIRST TIME POINTER
/CLEAR CRC FLAG!
/GET INITIAL CURRENT ADDRESS
/LOAD CURRENT ADDRESS
/SETUP FINAL WC
/GET INITIAL STARTING SECTOR
/SAVE
/GET DISK ADDRESS
/MASK
/SAVE
/GET INITIAL COMMAND
/GET READ OR WRITE
/LOAD COMMAND
/MAKE READ ALL OR WRITE ALL
/SAVE FOR SWITCH TO CONSECUTIVE MODE
/SECTOR TO DO
/MASK
/ADD TO TRACK
/LOAD AND GO
/TURN INTERRUPT ON
/CLEAR LONG TIMER
/CLEAR SUM CHECK
/GET FIELD TO BUFFER
/SAVE CDF
/TIME TO GO
/YES!!!!
/WAIT FOR FIRST INTERRUPT
/NOT HERE YET
/COMPARE TO SOFTWARE FINAL
/WAIT FOR DISK???
/YES!!!!
/SAVE DIFFERENCE
/UPDATE BUFFER TALLY
/CDF TO BUFFER FIELD
```

```

2257 5264 JMP WABRD /WAS A READ!!
2260 3411 GOCLR, DCA I AUTO11 /WAS A WRITE, CLEAR BUFFER
2261 2175 ISZ CLWBAK /UPDATE TALLY
2262 5260 JMP GOCLR /MORE TO CLEAR
2263 5274 JMP WRKDON /DONE WITH SOME
2264 1142 WABRD, TAD FNDOSUM
2265 7100 GOCHK, CLL
2266 1411 TAD I AUTO11 /GET WORD
2267 7430 ISZ
2270 7801 IAC
2271 2175 ISZ CLWBAK /UPDATE CLEAR POINTER
2272 5265 JMP GOCHK /MORE TO CHECKSUM
2273 3142 DCA FNDOSUM /SAVE IT
2274 6201 WRKDON, COF 0
2275 1117 TAD BUPTAL
2276 7650 SNA CLA /LAST WORD DONE????
2277 5302 JMP DSKEK /EXIT
2300 4776 JMS TIME /TIME AND WAIT
2301 5241 JMP BTRWRK /WAIT FOR INT, OR DONE!!!!
2302 2200 DSKEK, ISZ DSNGO
2303 5600 JMP I DSNGO /EXIT

/
/ INTERRUPT SERVICE
/

2304 6741 RETURN, DSKEK /DISK SKIP IOT
2305 5353 JMP NODSKP /NOT THE DISK
2306 2111 ISZ TRASH1 /UPDATE SECTOR NUMBER
2307 7000 NOP /IT WON'T WORK WITHOUT IT!!
2310 1114 TAD UPVATE /UPDATE WORD COUNT
2311 1130 TAO FWREG
2312 3130 DCA FWREG
2313 6745 STATUS, ORST /READ STATUS
2314 1073 TAD K4000
2315 7440 SZA /ONLY DONE FLAG?
2316 5337 JMP STATER /STATUS ERROR
2317 1130 TAD FWREG
2320 7650 SNA CLA /LAST TRANSFER?
2321 5365 JMP TRDONE /TRANSFER IS DONE
2322 3170 DCA FINTIM /CLEAR FIRST TIME POINTER!
2323 1174 TAD SAVCH /GET READ OR WRITE COMMAND
2324 6746 RDLWRL, DLOC /LOAD COMMAND REGISTER
2325 1111 TAO TRASH1 /GET SECTOR TO DO
2326 0066 AND K0017 /MASK OFF
2327 1112 TAD TRASH2 /ADD IN TRACK
2330 6743 LODGO, DLAG /LOAD DISK ANPD GO
2331 1107 RETRN, TAD SVLNK /GET LINK
2332 7110 CLL RAM
2333 1166 TAD SAVAC /GET AC
2334 6244 RMF /RESTORE FIELDS
2335 6001 ION /TURN INTERRUPT ON
2336 5400 JMP I 0 /EXIT
2337 4775 STATER, JMS SETREG /SETUP REGISTERS!
2340 1123 TAD CMREG
2341 7710 SNA CLA /WRITE OR READ
2342 7001 IAC /WRITE

```

[illegible]

```

2424 0064      AND      K0007      /MASK
2425 2200      ISZ      OCT1
2426 2200      INERN,  ISZ      OCT1
2427 5000      JMP I      OCT1      /GOOD EXIT

/
/ROUTINE TO RECEIVE FOUR OCTAL
/
2430 0000      OCT4,  0
2431 1106      TAD      M4
2432 3341      DCA      RDST      /SETUP COUNTER
2433 3350      DCA      LDCA      /START WITH 0
2434 4432      ONEIN     /RECEIVE ONE OCTAL
2435 0070      0070      /LIMITS
2436 5630      JMP I      OCT4      /ENRUR EXIT
2437 1350      TAD      LDCA      /GET LAST
2440 2341      ISZ      RDST      /UPDATE COUNTER
2441 7410      SKP
2442 5266      JMP      ,+4      /EXIT
2443 7004      HAL
2444 7006      RTL
2445 5233      JMP      OCT4+3
2446 2230      ISZ      OCT4
2447 5630      JMP I      OCT4      /EXIT OCTAL IN AC

```

/ROUTINE TO UPDATE AND CHECK FOR PASS COMPLETE

```

2450 0000      CKTIM,  0
2451 1115      TAD      POLDISK
2452 0064      AND      K0007      /SETUP CURRENT DRIVE #
2453 3341      DCA      RDST      /POINTER
2454 1341      TAD      RDST
2455 1152      TAD      TIMPOT      /GET TIME POINTER
2456 3354      DCA      LDAD      /SAVE IT
2457 7301      CLA CLL IAC      /ONE FOR 0
2458 1147      TAD      CONSEC      /GET AMOUNT DONE
2459 1754      TAD I      LDAD      /ADD IN AMOUNT COMPLETED 50 FAR
2460 3754      DCA I      LDAD      /SAVE IT
2461 7620      SNL CLA      /LINK UP????
2462 5650      JMP I      CKTIM      /NO, EXIT
2463 4440      RANGEN      /GET RANDOM NUMBER
2464 3777      DCA      RAN1      /RE-PRIME GENERATOR
2465 4440      RANGEN      /GET RANDOM NUMBER
2466 3776      DCA      RAN2      /RE-PRIME GENERATOR
2467 7100      CLL
2468 1354      TAD      LDAD
2469 1013      TAD      K0004
2470 3354      DCA      LDAD      /SECOND TIME POINTER
2471 2754      ISZ I      LDAD      /UPDATE IT
2472 1754      TAD I      LDAD      /GET COUNT
2473 1144      TAD      MAXTIM      /ADD IN FUDGE FACTOR
2474 7620      SNL CLA      /PASS COMPLETE????
2475 5650      JMP I      CKTIM      /NO, EXIT
2476 3754      DCA I      LDAD      /ZERU SECCUND COUNTER
2477 1341      TAD      RDST
2478 7040      CMA

```

```

2505 3341      DCA      RDST      /SETUP COUNTER
2506 1362      TAD      CMPPOT      /ADD IN POINTER
2507 1062      TAD      K0003
2508 2341      ISZ      RDST      /COMPUTE BUFFER
2509 5307      JMP      ,+2
2510 3341      DCA      RDST      /SAVE ADDRESS POINTER
2511 7340      CLA CLL CMA
2512 2741      ISZ I      RDST      /UPDATE PASS COMPLETE POINTER
2513 7610      SKP CLA
2514 3741      DCA I      RDST      /HOLD AT 7777
2515 4457      CRLF
2516 4455      PRNTER      /PRINT "DISK"
2517 3477      MES17
2518 1115      TAD      POLDISK      /GET DISK POLE NUMBER
2519 0064      AND      K0007      /MASK
2520 1067      TAD      K0260
2521 4445      TYPE      /TYPE DISK NO.
2522 7340      CLA CLL CMA
2523 4455      PRNTER      /PRINT "PASS COMPLETE"
2524 3502      MES18
2525 4406      LAS
2526 0015      AND      K0100      /MASK
2527 7650      SNA CLA      /PASS COMPLETE DISCONNECT????
2528 5337      JMP      ,+3      /NO WAY!!!!
2529 4430      DISCON      /DUMP DRIVE
2530 5775      JMP      RUN      /MORE TO TEST!!!!
2531 4774      JMS      TPSTA      /STATUS=COMPLETE TYPEOUT
2532 5650      JMP I      CKTIM      /EXIT

```

/SUBROUTINE TO READ STATUS REGISTER

```

2541 0000      RDST,  0
2542 0745      IQ15,  DRST      /READ STATUS IOT
2543 7410      SKP
2544 4576      ERMLT5, JMS I  BGHLT      /SKIP TRAP
2545 3121      DCA      STREG      /SAVE RESULTS
2546 1121      TAD      STREG
2547 5741      JMP I      RDST      /EXIT

```

/SUBROUTINE TO LOAD CURRENT ADDRESS REGISTER

```

2550 0000      LDCA,  0
2551 0744      IQ14,  DLCA      /LOAD CURRENT ADDRESS IOT
2552 4425      KTICK
2553 5750      JMP I      LDCA      /NOTIFY APT

```

/SUBROUTINE TO LOAD TRACK ADDRESS REGISTER

```

2554 0000      LDAD,  0
2555 3125      DCA      DAMEG
2556 1125      TAD      DAMEG
2557 0743      IQ13,  DLAG      /LOAD DISK ADDRESS REGISTER
2558 5754      JMP I      LDAD      /EXIT
2559 4576      ERMLT3, JMS I  BGHLT      /ENRUR SKIP TRAP

```

```

/
2562 3541  CMPDPT, DUCMP-3
2574 3000
2575 0000
2576 1770
2577 1767
2600 2600  PAGE
/
/ROUTINE TO GET RANDOM OR OPERATOR DATA
/
2600 0000  RNWRD, 0
2601 7402  SWDAT, MLT
2602 5000  JMP I RNWRD
2603 6201  CDF 0
2604 1412  TAD I AUTO12
2605 7402  RECDF, MLT
2606 2116  ISZ OPNTAL
2607 5000  JMP I RNWRD
2610 3220  DCA PRINT
2611 1105  TAD M12
2612 3116  DCA OPNTAL
2613 7340  CLA CLL CMA
2614 1151  TAD DATPOT
2615 3012  DCA AUTO12
2616 1200  TAD PRINT
2617 5000  JMP I RNWRD

/ROUTINE TO TYPE
/
2620 0000  PRINT, 0
2621 3237  DCA DUMP
2622 4424  CHK22
2623 5235  JMP PREXIT
2624 1237  TAD DUMP
2625 4407  CLASIC
2626 4435  CBTYP
2627 7410  SKP
2630 5620  JMP I PRINT
2631 0046  TFS
2632 0041  TSF
2633 5232  JMP ,=1
2634 0042  TCF
2635 7200  PREXIT, CLA
2636 5620  JMP I PRINT

/ROUTINE TO DUMP AND REPORT DISK STATUS
/
2637 0000  DUMP, 0
2640 4424  CHK22
2641 5637  JMP I DUMP
2642 4455  PRNTER
2643 3477  MES17
2644 1115  TAD POLOSK
2645 0064  AND K0007
2646 3200  DCA RNWRD

```

```

2647 1200  TAD RNWRD
2650 1067  TAD K0200
2651 4445  TYPE
2652 7340  CLA CLL CMA
2653 4455  PRNTER
2654 3445  MES15
2655 4777  JMS TPSTA
2656 1200  TAD RNWRD
2657 1154  TAD RUNPOT
2660 3200  DCA RNWRD
2661 3000  DCA I RNWRD
2662 3200  DCA RNWRD
2663 1106  TAD M4
2664 3220  DCA PRINT
2665 1200  TAD RNWRD
2666 4436  SELCHK
2667 7610  SKP CLA
2670 5637  JMP I DUMP
2671 2200  ISZ RNWRD
2672 2220  ISZ PRINT
2673 5265  JMP ,=0
2674 4457  CRLF
2675 4455  PRNTER
2676 3477  MES17
2677 7340  CLA CLL CMA
2700 4455  PRNTER
2701 3455  MES16
2702 4576  N008XB, JMS I BGHLT

/ROUTINE TO SETUP FIELD TO BUFFER+ AUTO11+ BUFFER TALLY
/
2703 0000  STFLD, 0
2704 7041  CIA
2705 1127  TAD WCMEG
2706 3117  DCA BUFTAL
2707 7340  CLA CLL CMA
2710 1126  TAD CAMEG
2711 3011  DCA AUTO11
2712 1157  TAD DATFLG
2713 7650  SNA CLA
2714 5322  JMP ,=0
2715 1105  TAD M12
2716 3116  DCA OPNTAL
2717 7340  CLA CLL CMA
2720 1151  TAD DATPOT
2721 3012  DCA AUTO12
2722 1136  TAD INTCM
2723 0014  AND K0070
2724 1103  TAD KCOF
2725 3205  DCA RECDF
2726 1205  TAD RECDF
2727 5703  JMP I STFLD

```

```

/ROUTINE TO CHANGE DEVICE IOT CODES
/

```

```

2730 4407  CHANG, CLASSIC  /CHECK FOR CLASSIC.
2731 4431  C88WIT  /ROUTINE TO EXECUTE.
2732 7000  NOP
2733 4406  LAS
2734 0071  AND  A0770  /GET SWITCHES
2735 3776  DCA  LDCM  /MASK 3=0
2736 1360  TAD  CHNPOT  /SAVE DESIRED CODE
2737 3111  DCA  TRASH1  /POINTER
2740 1357  TAD  CNTR1  /ADDRESS POINTER
2741 3112  DCA  TRASH2  /AMOUNT TO DO
2742 1511  CHANGR, TAD I  TRASH1  /SETUP COUNTER
2743 3113  DCA  TRASH3  /GET ADDRESS POINTER
2744 1513  TAD I  TRASH3  /SAVE ADDRESS
2745 0072  AND  A7007  /GET OLD CODE
2746 1776  TAD  LDCM  /MASK OFF OLD CODE
2747 3513  DCA I  TRASH3  /AUD IN DESIRED CODE
2750 2111  ISZ  TRASH1  /RESTORE
2751 2112  ISZ  TRASH2  /UPDATE POINTER
2752 5342  JMP  CHANGR  /UPDATE CHANGE COUNTER
2753 4407  CLASSIC  /MORE TO CHANGE
2754 4436  C8ERR  /CHECK FOR CLASSIC.
2755 7402  CHNHLT, HLT  /ROUTINE TO EXECUTE.
2756 5775  JMP  BGN  /IOTS CHANGED, HIT CONTINUE OR
                     /IF ON CONSOLE PACKAGE
                     /CONTROL E TO START PROGRAM.

```

```

2757 7763  /CNTR1, 7763
2760 2761  /CHNPOT, CHNPOT+1
2761 2304  RETURN
2762 2313  STATUS
2763 2324  RDLWRL
2764 2330  LODGO
2765 0554  IOT0
2766 0752  IOT1
2767 0561  IOT2
2770 2557  IOT3
2771 2551  IOT4
2772 2542  IOT5
2773 0549  IOT6

```

```

2775 0200  /
2776 0542  PAGE
2777 3000  /
3000 0000  /ROUTINE TO TYPE STATUS REPORT
3001 4424  TPSTA, 0
3002 5600  CHK22
3003 4457  JMP I  TPSTA
3004 4455  CRLF
3005 3372  PRNTR
3006 1107  MEO7
3007 3245  TAD  M10
                     DCA  TSAVE1

```

/PRINT "DISK HARD SOFT COMP"

/MAXIMUM TO DO

```

3010 3246  DCA  TSAVE2
3011 3247  DCA  TSAVE3
3012 1246  CHKRES, TAD  TSAVE2  /CLEAR SOME COUNTERS
3013 1062  TAD  K0003
3014 3246  DCA  TSAVE2
3015 1246  TAD  TSAVE2
3016 1153  TAD  STAPOT
3017 3251  DCA  TSAVE5
3020 1247  TAD  TSAVE3
3021 4436  SELCHK
3022 5241  JMP  NOTSTA  /LOCATION OF DISK STATUS
3023 4457  CRLF  /CHECK RUN POINTER
3024 4431  SPACE  /DISK NOT RUNNING
3025 1247  TAD  TSAVE3
3026 1067  TAD  K0260
3027 4445  TYPE
3030 4431  SPACE  /SPACE OUT ONE
3031 4431  SPACE  /SPACE OUT ONE
3032 7346  CLA CLL  CMA RTL
3033 3250  DCA  TSAVE4
3034 1051  TAD I  TSAVE5  /COUNTER FOR FOUR WORDS
3035 4456  OCTEL  /GET STATUS
3036 2251  ISZ  TSAVE5  /TYPE IT
3037 2250  ISZ  TSAVE4
3040 5234  JMP  .-4
3041 2247  NOTSTA, ISZ  TSAVE3  /UPDATE DRIVE NUMBER
3042 2245  ISZ  TSAVE1
3043 5212  JMP  CHKRES  /MORE TO REPORT
3044 5600  JMP I  TPSTA  /EXIT

```

```

3045 0000  TSAVE1, 0
3046 0000  TSAVE2, 0
3047 0000  TSAVE3, 0
3050 0000  TSAVE4, 0
3051 0000  TSAVE5, 0
/
/ROUTINE TO RECALIBRATE SELECTED DRIVE
/DISCONNECT DRIVE ON ERROR!
/

```

```

3052 0000  RESTOR, 0
3053 0063  AND  K0006
3054 3200  DCA  TPSTA  /SAVE DRIVE NUMBER
3055 1077  TAD  K7700
3056 3341  DCA  TIMER2  /SETUP COUNTER
3057 2340  ISZ  TIMER1
3060 5257  JMP  .-1
3061 2341  ISZ  TIMER2  /WAIT FOR DISK TO COOL OFF!
3062 5257  JMP  .-3
3063 1200  TAD  TPSTA
3064 4451  LDCM
3065 7326  CLA CLL  CML RTL  /CURRENT DRIVE
3066 4454  CLRALL  /LOAD COMMAND
3067 4450  DSKSKP  /ENABLE RECALIBRATE BIT
3070 5267  JMP  .-1  /"RECALIBRATE"
3071 4447  ROSTAT  /DISK SKIP IOT
                     /WAIT FOR FIRST DONE FLAG
                     /READ STATUS

```

```

3072 7500      SMA
3073 5311      JMP RESERR
3074 0076      AND K1777
3075 7640      SZA CLA
3076 5311      JMP RESERR
3077 4454      RESTA, CLRALL
3100 1016      TAD K0200
3101 1200      TAD TPSTA
3102 4451      LDCHD
3103 4450      DSKSKP
3104 5303      JMP .-1
3105 4447      RDSTAT
3106 1073      TAD K4000
3107 7650      SNA CLA
3110 5652      JMP I RESTOR
3111 7300      RESERR, CLA CLL
3112 4446      ERROR
3113 0003
3114 7500      7500
3115 4457      CRLF
3116 4457      CRLF
3117 4455      PRINTER
3120 3174      MES19
3121 4430      DISCON
3122 5652      JMP I RESTOR

/ROUTINE TO TIME AND WAIT
/
TIME, 0
3123 0000      ISZ TIMER1
3124 2340      JMP I TIME
3125 5723      ISZ TIMER2
3126 2341      JMP I TIME
3127 5723      INTER1, JMS I BGHLT
3130 4576      /NO INTERRUPT OCCURRED, I GUESS!

/ROUTINE TO COMBINE ERROR HALTS,
/WHEN THE COMPUTER HALTS THE AC
/IT WILL EQUAL THE PC ON THE FAILING
/HAULT INSTRUCTION.
/
3131 0000      BIGHLT, 0
3132 7300      CLA CLL
3133 1331      TAD BIGHLT
3134 4407      CLASIC
3135 4436      CGERR
3136 7402      BIGSTP, HLT
3137 5332      JMP .-3

/
TIMER1, 0
3140 0000      TIMER2, 0
3141 0000

/ROUTINE TO TYPE OUT DATA INFORMATION
/
3142 0000      TYPDAT, 0
3143 4455      PRINTER

```

/PRINT"RECALIBRATE ERROR DISCONNECT"

/DISCONNECT DISK

/MORE DISK AVAILABLE

/EXIT

/EXIT

/NO INTERRUPT OCCURRED, I GUESS!

/LOAD AC WITH PC.

/CHECK FOR CLASSIC.

/ROUTINE TO EXECUTE.

/AC=PC.

/NON-RECOVERABLE.

/PRINT "A81"

```

3144 3235      TEXAS
3145 1131      TAD ASREG
3146 4456      OCTEL
3147 7340      CLA CLL CNA
3150 4455      PRINTER
3151 3237      TEXWA
3152 1132      TAD WAREG
3153 4456      OCTEL
3154 7340      CLA CLL CNA
3155 4455      PRINTER
3156 3241      TEXAD
3157 1133      TAD ADREG
3160 4456      OCTEL
3161 7340      CLA CLL CNA
3162 4455      PRINTER
3163 3243      TEXDG
3164 1134      TAD DGREG
3165 4456      OCTEL
3166 7340      CLA CLL CNA
3167 4455      PRINTER
3170 3245      TEXDB
3171 1135      TAD DBREG
3172 4456      OCTEL
3173 5742      JMP I TYPDAT

/
MES19, TEXT
3174 2205      "RECALIBRATE ERROR DISCONNECT!"
3175 0301
3176 1411
3177 0222
3200 0124
3201 0540
3202 0522
3203 2217
3204 2240
3205 0411
3206 2303
3207 1716
3210 1605
3211 0324
3212 4100

/
3213 2003      TEXPC, TEXT "PC1"
3214 7200
3215 2324      TEXST, TEXT "ST1"
3216 7200
3217 0530      TEXEX, TEXT "EX1"
3220 7200
3221 0315      TEXCM, TEXT "CM1"
3222 7200
3223 1101      TEXIA, TEXT "IA1"
3224 7200
3225 0401      TEXDA, TEXT "DA1"
3226 7200
3227 0301      TEXCA, TEXT "CA1"
3230 7200

```

/PRINT "WA1"

/PRINT "AD1"

/PRINT "DG1"

/PRINT "DB1"

3231	2703	TEXWC, TEXT	"WC1"
3232	7200		
3233	0627	TEXFW, TEXT	"FW1"
3234	7200		
3235	0123	TEXAB, TEXT	"AB1"
3236	7200		
3237	2701	TEXWA, TEXT	"WA1"
3240	7200		
3241	0104	TEXAD, TEXT	"AD1"
3242	7200		
3243	0407	TEXDG, TEXT	"DG1"
3244	7200		
3245	0402	TEXDB, TEXT	"DB1"
3246	7200		
/			
3247	2205	ERTX1, TEXT	"READ STATUS"
3250	0104		
3251	4023		
3252	2401		
3253	2425		
3254	2300		
3255	2722	ERTX2, TEXT	"WRITE STATUS"
3256	1124		
3257	0540		
3260	2324		
3261	0124		
3262	2523		
3263	0000		
3264	2205	ERTX3, TEXT	"RECALIBRATE STATUS"
3265	0301		
3266	1411		
3267	0222		
3270	0124		
3271	0540		
3272	2324		
3273	0124		
3274	2523		
3275	0000		
3276	0411	ERTX4, TEXT	"DISK DATA"
3277	2313		
3300	4004		
3301	0124		
3302	0100		
/			
3303	4005	ME80, TEXT	" ERROR"
3304	2222		
3305	1722		
3306	0000		
3307	2213	ME81, TEXT	"MK8E/RK8L DATA RELIABILITY"
3310	7005		
3311	5722		
3312	1370		
3313	1440		
3314	0401		
3315	2401		

3316	4022		
3317	0514		
3320	1101		
3321	0211		
3322	1411		
3323	2431		
3324	0000		
3325	0530	ME82, TEXT	"EXERCISE"
3326	0522		
3327	0311		
3330	2305		
3331	0000		
3332	4004	ME83, TEXT	" DISK"
3333	1123		
3334	1300		
3335	1617	ME84, TEXT	"NON-RECOVERABLE "
3336	1655		
3337	2205		
3340	0317		
3341	2605		
3342	2201		
3343	0214		
3344	0540		
3345	0000		
3346	0530	ME85, TEXT	"EXTENDED R/W MEMORY(0-7)T"
3347	2405		
3350	1604		
3351	0504		
3352	4022		
3353	5727		
3354	4015		
3355	0515		
3356	1722		
3357	3150		
3360	6055		
3361	6751		
3362	7700		
3363	0103	ME86, TEXT	"ACCEPT MODE?"
3364	0305		
3365	2024		
3366	4015		
3367	1704		
3370	0577		
3371	0000		
3372	0423	ME87, TEXT	"DSK HAND SOFT COMP"
3373	1340		
3374	1001		
3375	2204		
3376	4023		
3377	1706		
3400	2440		
3401	0317		
3402	1520		

3403	0000		
3404	0611	ME88, TEXT	"FIELD?"
3405	0514		
3406	0477		
3407	0000		
3410	2422	ME89, TEXT	"TRACK?"
3411	0103		
3412	1377		
3413	0000		
3414	0530	ME810, TEXT	"EXTRA SECTORS?"
3415	2422		
3416	0140		
3417	2305		
3420	0324		
3421	1722		
3422	2377		
3423	0000		
3424	0214	ME811, TEXT	"BLOCK LENGTH?"
3425	1703		
3426	1340		
3427	1405		
3430	1607		
3431	2410		
3432	7700		
3433	0401	ME813, TEXT	"DATA?"
3434	2401		
3435	7700		
3436	0122	ME814, TEXT	"ARE YOU SURE?"
3437	0540		
3440	3117		
3441	2540		
3442	2325		
3443	2205		
3444	7700		
3445	4004	ME815, TEXT	" DISCONNECTED!"
3446	1123		
3447	0317		
3450	1016		
3451	0503		
3452	2405		
3453	0441		
3454	0000		
3455	2331	ME816, TEXT	"SYSTEM SHUT DOWN, NO DISKS TO RUN!"
3456	2324		
3457	0515		
3460	4023		
3461	1025		
3462	2440		
3463	0417		
3464	2716		
3465	5440		
3466	1617		
3467	4004		
3470	1123		
3471	1323		

3472	4024		
3473	1740		
3474	2225		
3475	1641		
3476	0000		
3477	0411	ME817, TEXT	"DISK "
3500	2313		
3501	4000		
3502	4020	ME818, TEXT	" PASS COMPLETE!"
3503	0123		
3504	2340		
3505	0317		
3506	1520		
3507	1405		
3510	2405		
3511	4100		

3512	0000	D8K08, 0
3513	0000	D8K10, 0
3514	0000	D8K20, 0
3515	0000	D8K30, 0
3516	0000	D8K40, 0
3517	0000	D8K50, 0
3520	0000	D8K60, 0
3521	0000	D8K70, 0

3522	0000	D0TM1, 0
3523	0000	D1TM1, 0
3524	0000	D2TM1, 0
3525	0000	D3TM1, 0
3526	0000	D4TM1, 0
3527	0000	D5TM1, 0
3530	0000	D6TM1, 0
3531	0000	D7TM1, 0
3532	0000	D0TM2, 0
3533	0000	D1TM2, 0
3534	0000	D2TM2, 0
3535	0000	D3TM2, 0
3536	0000	D4TM2, 0
3537	0000	D5TM2, 0
3540	0000	D6TM2, 0
3541	0000	D7TM2, 0

3542	0000	D0MRD, 0
3543	0000	D0SOF, 0
3544	0000	D0CMP, 0
3545	0000	D1MRD, 0
3546	0000	D1SOF, 0
3547	0000	D1CMP, 0
3550	0000	D2MRD, 0
3551	0000	D2SOF, 0
3552	0000	D2CMP, 0


```
3553 0000 D3MRD, 0
3554 0000 D38OF, 0
3555 0000 D3CMP, 0
3556 0000 D4MRD, 0
3557 0000 D48OF, 0
3560 0000 D4CMP, 0
3561 0000 D5MRD, 0
3562 0000 D58OF, 0
3563 0000 D5CMP, 0
3564 0000 D6MRD, 0
3565 0000 D68OF, 0
3566 0000 D6CMP, 0
3567 0000 D7MRD, 0
3570 0000 D78OF, 0
3571 0000 D7CMP, 0
/
3572 0000 FLDFLG, 0
3573 0000 TRKFLG, 0
3574 0000 SECFLG, 0
3575 0000 HLFFLG, 0
/
/
/
3600 PAGE
/
3600 STRBUF=.
/
8888
```

```
0000 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11111111
0100 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11111110

0200 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11111111
0300 11111111 11111111 11111111 11111111 11111111 11111111 11110011 11111111

0400 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11111111
0500 11111111 11111111 11111111 11111111 11111111 11111111 11110000 01111111

0600 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11111111
0700 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11011111

1000 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11111111
1100 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11111111

1200 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11111111
1300 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11111111

1400 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11111111
1500 11111111 11111111 11111111 11111111 11111111 11111111 11111111 10001111

1600 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11111111
1700 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11111100

2000 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11111111
2100 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11101111

2200 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11111111
2300 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11111111

2400 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11111111
2500 11111111 11111111 11111111 11111111 11111111 11111111 11100000 00001111

2600 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11111111
2700 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11110111

3000 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11111111
3100 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11111111

3200 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11111111
3300 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11111111

3400 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11111111
3500 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11111100

3600
3700
```

4000
4100

4200
4300

4400
4500

4600
4700

5000
5100

5200
5300

5400
5500

5600
5700

6000
6100

6200
6300

6400
6500

6600
6700

7000
7100

7200
7300

7400
7500

7600
7700

AD170 0730	C8GET 0624	CONCUR 0715	DAT3 0760
A0770 0071	C8HANG 1122	CONSEC 0147	DAT4 0761
A7007 0072	C8INQU 4437	CONSUL 0000	DAT5 0762
ACDCA 0362	C8OCTA 4432	CRCENT 0155	DAT6 0763
ACL 7701	C8PA83 4424	CRCPLG 0156	DAT7 0764
ACSAVE 1345	C8PAUS 4441	CRLF 4457	DAT8 0765
ADREG 0133	C8PRNT 4430	D8CMP 3544	DAT9 0766
AERROR 2156	C8RDP3 0666	D8HRU 3542	DATPLG 0157
AGAIN 1346	C8RETD 0614	D8SOF 3543	DATPOT 0151
ALLAGN 0255	C8RETR 0536	D8TM1 3522	DATTRY 0140
AMOUNT 0060	C8RETD 0613	D8TM2 3532	DBREG 0135
APT8 2270	C8RETS 0535	DICMP 3547	DCLR 6742
ASKNX1 0345	C8SWIT 4431	DIMRU 3545	D8REG 0134
ASKNX2 0406	C8SW8T 0745	D18UP 3546	DISCOM 4430
ASKNX3 0425	C8TMT1 1021	D1TM1 3523	DISKGO 4441
ASKNX5 0464	C8TTYI 4426	D1TM2 3533	DLAG 6743
ASKSUR 0513	C8TYPE 4435	D2CMP 3552	DLCA 6744
ASREG 0131	CAF 6007	D2HRU 3550	DLDC 6746
AUTO10 0010	CAREG 0126	D2SOF 3551	DLSC 6740
AUTO11 0011	CENTR1 2757	D2TM1 3524	D8CNT 0247
AUTO12 0012	CHANG 2750	D2TM2 3534	DOMEAD 1262
BADHLT 1707	CHANGR 2742	D3CMP 3555	DONEA 0426
BGHLT 0176	CHEK22 0523	D3HRU 3553	DOPACK 0212
BGN 0200	CHK22 4424	D3SOF 3554	D8SET 0251
BGNBUF 0146	CHKCLA 1200	D3TM1 3525	D8ST 6745
BIGHLT 3131	CHKPOT 2000	D3TM2 3535	D8K08 3512
BIGSTP 3136	CHKRE0 5012	D4CMP 3560	D8K10 3513
BRKRET 0363	CHKSAV 0141	D4HRU 3556	D8K20 3514
BUFPNT 1400	CHKYN 2035	D4SOF 3557	D8K30 3515
BUFTAL 0117	CHNCDF 2254	D4TM1 3526	D8K40 3516
BYRETR 0506	CHNHLT 2755	D4TM2 3536	D8K50 3517
C8BY1 0230	CHNPOT 2760	D5CMP 3563	D8K60 3520
C8BY2 1300	CKCOUT 0232	D5HRU 3561	D8K70 3521
C8BY3 1061	CKTIM 2450	D5SOF 3562	D8KEX 2302
C8BY4 0515	CLAFLO 1404	D5TM1 3527	D8KGO 2200
C8BY5 1116	CLASIC 4407	D5TM2 3537	D8KF 6741
C8CHAR 1075	CLASIK 1514	D6CMP 3566	D8K8KP 4450
C8CKP 1022	CLDR 0560	D6HRU 3564	DTCMK 1600
C8CKPA 4440	CLKCNT 0150	D6SOF 3565	UTR1 1636
C8CKSW 4425	CLRALL 4454	D6TM1 3530	DUMP 2637
C8CNTR 4427	CLRBAK 0175	D6TM2 3540	ENDIT 0742
C8CNT 1145	CLRTRN 1315	D7CMP 3571	ERFLG 0165
C8CRLF 4433	CMPPOT 2562	D7HRU 3567	ERHLT0 0556
C8DO1 0310	CMREG 0123	D7SOF 3570	ERHLT2 0563
C8DO10 1262	CNTRLC 0551	D7TM1 3531	ERHLT3 2561
C8DO11 0607	CNTRLD 0600	D7TM2 3541	ERHLT5 2544
C8DO2 1033	CNTRLE 0545	UAREL 0125	ERHLT6 0547
C8DO3 0350	CNTRLL 0537	DAT1 0756	ERR1 0736
C8DO4 1006	CNTRLO 0500	DAT10 0767	ERRM65 1520
C8DO7 0527	CNTRLR 0511	DAT11 0770	ERRO 1200
C8ECNO 4434	CNTRL3 0521	DAT12 0771	ERROEX 1555
C8ERR 4436	CNTVAL 0252	DAT2 0757	ERROR 4446

ERTX1	3247	K0001	0061	M12	0105	NTWKS	1710
ERTX2	3255	K0003	0062	M4	0106	UCT1	2400
ERTX3	3264	K0004	0013	MANUAL	0322	UCT4	2430
ERTX4	3276	K0006	0063	MAXPLD	0143	UCTEL	4456
ESAVE	1371	K0007	0064	MAXTIM	0144	ONEIN	4432
EXAPT8	2151	K0010	0065	MAXTRK	0145	OP1	0021
EXIT	1504	K0017	0066	MEMSET	2142	OP2	0022
EXITA	0440	K0070	0014	MES0	3303	OPRTAL	0116
EXREG	0122	K0077	0102	MES1	3307	PASCNT	0250
EXTICK	1166	K0100	0015	MES10	3414	PCLF	6662
F1OP1	0021	K0200	0016	MES11	3424	PCNTR1	1373
F1OP2	0022	K0212	1425	MES13	3433	PCNTR2	1374
F1SHR	0020	K0215	1424	MES14	3436	PCNTR3	1375
FILCNT	1040	K0240	1512	MES15	3445	PCREG	0120
FILLER	1037	K0260	0067	MES16	3455	PCSAVE	1344
FILLUP	0717	K0277	0070	MES17	3477	PNTBUF	1120
FIRTIM	0170	K0316	2057	MES18	3502	POLDISK	0115
FIDFLG	3572	K0331	2056	MES19	3174	POLNEX	1000
FIDMLT	0206	K0400	0017	MES2	3325	PREXIT	2635
FLSAVE	1347	K1800	0075	MES3	3332	PRINT	2020
FNDSUM	0142	K177	2034	MES4	3335	PRN	1450
FORIN	4433	K1777	0076	MES5	3346	PRNDAT	0173
FROCT	1426	K3740	1513	MES6	3363	PRNTER	4455
FWREG	0130	K4000	0073	MES7	3372	P8IE	6665
GENDAT	4426	K4100	0074	MES8	3404	P8KE	6663
GETCH1	0703	K5405	0360	MES9	3410	P8KF	6661
GETDAT	0456	K6500	0541	MES1A	0747	P8TH	6664
GNDAT	1737	K6520	2172	MESAC	1533	PTSTOR	0336
GOBAK	2230	K7000	2155	MESFL	1541	RAD1	1773
GOCDF	1646	K7377	2154	MESMAN	1146	RAD2	1774
GOCMK	2265	K7400	0104	MESMU	1336	RAD3	1775
GOCRLR	2260	K7700	0077	MESPAS	0253	RAN1	1767
GOITA	0443	K7760	0100	MESPC	1530	RAN2	1770
GOTIT	1010	K7773	1377	MODSKS	2125	RANDAT	4427
GOTOA	0454	K7775	0110	MOA	7501	RANDOM	1715
GTF	0004	K7777	0101	MOL	7421	RANGEN	4440
HEDTAD	1376	KAERRO	0023	MOSAVE	1346	RANJMS	0522
HLFFLG	3575	KCOF	0103	MRPRN	1456	RDLWRL	2324
INDEXA	0455	KROT	0230	MSKEN	1714	R0ST	2541
INERR	2426	K8KP	0546	MYAC	1317	R0STA	1105
INMODE	1076	KTICK	4425	MYLAB	1546	R0STAT	4447
INTCM	0136	KTIME	0530	NEWRO	0727	R0TRY	1073
INTDA	0124	L8	4406	NEXT	0261	REALPC	1316
INTER1	3130	LOAD	2554	NODSKP	2353	RECAL	4443
INTER2	2362	LOADD	4453	NODSKS	2702	RECDP	2005
IOT0	0554	LOCA	2550	NOERR	1072	RECEIV	4444
IOT1	0752	LOCM	0542	NOSET	0242	REDOA	0415
IOT2	0561	LOCMO	4451	NOTEX	1363	REFILL	0723
IOT3	2557	LOCUR	4452	NOTSTA	3041	REREAD	1063
IOT4	2551	LNKDCA	0361	NTCLAS	1270	RERUN	1124
IOT5	2542	LODGO	2330	NTERN	1255	RESERR	3111
IOT6	0545	M10	0107	NTSOFT	1251	RESRAN	4442

RESTA	3077	TABLB	0471	XC8CNL	1023
RESTOR	3052	TEXAD	3241	XC8ECH	1063
RETRN	2331	TEXAS	3235	XC8EKR	1007
RETURN	2304	TEXCA	3227	XC8ING	0035
REWRT	1047	TEXCM	3221	XC8OCT	1000
RNFLD	0630	TEXDA	3225	XC8PAS	0200
RNRDR	2000	TEXDB	3245	XC8PAU	0337
ROUTNS	1302	TEXDG	3243	XC8PNT	0303
ROUTMP	1544	TEXEX	3217	XC8PSW	0056
RSRAN	1761	TEXFW	3233	XC8SW	0262
RUN	0000	TEXIA	3223	XC8TTY	0272
RUNPOT	0154	TEXPC	3213	XC8TYP	1077
SAV1	1771	TEXST	3215	XCHKZ2	0024
SAV2	1772	TEXWA	3237	XCHKYN	0037
SAVAC	0166	TEXWC	3231	XCKPUT	0056
SAVCM	0174	TIME	3123	XCLAS	0007
SAVE1	0000	TIMER1	3140	XCLUR	0034
SAVEAC	1545	TIMER2	3141	XCRLP	0057
SOKP	0751	TIMER3	2374	XDOLPT	1112
SECFLG	3574	TIMPOT	0152	XDO5W	0520
SELCHK	4436	TMPCNT	0746	XDSKWD	0041
SETFLD	4435	TPSTA	3000	XDUMP	0030
SETGEN	4434	TRASH1	0111	XERRU	0046
SETREG	1553	TRASH2	0112	XFROCT	0056
SETUP1	1233	TRASH3	0113	XGNDAT	0026
SETUP2	0225	TRDONE	2365	XKTCK	0025
SKPNOP	0237	TRKFLG	3573	XKTICK	1154
SOFT	1245	TRYCNT	0171	XLAS	0006
SPAC	1506	TRYTIM	1000	XLOAD	0053
SPACE	4431	TSAVE1	3045	XLOCA	0052
SPBLK	0164	TSAVE2	3046	XLOCM	0051
SPFLD	0160	TSAVE3	3047	XOCT1	0032
SPSEC	0163	TSAVE4	3050	XOCT4	0033
SPTRK1	0161	TSAVE5	3051	XPRINT	0045
SPTRK2	0162	TSYCHA	0715	XPRN	0055
STAPOT	0153	TYLPT	1121	XRDST	0047
STATER	2337	TYPOAT	3142	XREG	1572
STATRY	0137	TYPE	4445	XRESTR	0043
STATUS	2313	UPAROW	0615	XRDUM	0040
STFLD	2703	UPDATE	0114	XRNWD	0027
STGEN	1753	UPONE	1414	XRSRAN	0042
STPHLT	0003	UPTRY	1120	XSDKP	0050
STRAUT	1325	WAIT	2000	XSPAC	0031
STRBUF	3000	WAIT1	2026	XSTFLD	0055
STREG	0121	WAREG	0132	XSTGEN	0034
STRREL	1151	WABRD	2264	XTABLA	0057
STRTEX	0224	WATHES	0651	XTABLB	0060
STRWRK	2241	WCREG	0127	XTEXT	0172
SVLNK	0167	WROCHK	1612	XWALT	0044
SWDAT	2601	WRKDON	2274	YESNU	4437
SWR	0020	XC8CKP	1041		
TABLA	0461	XC8CNT	0400		

ERRORS DETECTED: 0

LINKS GENERATED: 163

RUN-TIME: 6 SECONDS

3K CORE USED