

IDENTIFICATION

Product Code: MAINDEC-12-DIEA-D
Product Name: FLOAT 1'S & Ø'S THROUGH MEMORY
Date Created: September 23, 1969
Maintainer: Diagnostic Group
Author: James Kelly

MEMDATA

8 MORE

START 20

PSK 100 back to
be talked. Take
100 sh./bank.

100's more unsorted
next one in hand
of last

wrote out MEM A PIN

1. ABSTRACT

This memory exerciser floats a word with a single bit set followed by a word with a single bit cleared thru each memory address. In bank 0 all memory locations not reserved for the program itself i.e., from address 0240 to 7777 are tested. In extended memory all addresses 0000 to 7777 inclusive are tested. In general the algorithm for testing is as follows: Set the accumulator to 4000; rotate the number right 4096 times. At the conclusion, test to see if the accumulator is 4000. This test ascertains that each core in all tested locations can store a one, and that relatively rapid access to each memory location does not disturb its contents.

The second major test is to set the accumulator 3777 I.E., all but one bit set to ones, and then rotating this number thru each memory location 4096 times prior to testing - any detected errors will be indicated by either a message type out or an error halt.

2. MACHINE REQUIREMENTS

- a. A standard PDP-5, 8 8/S, 8I, 8L, 12 or Linc-8.
- b. An ASR-33 teletype or equivalent.
- c. If the PDP-5 being tested has extended memory, the CIF and CDF instructions must be compatible with the PDP-8.

2.2 Preliminary Programs

All basic instruction and memory diagnostics must have been successfully run prior to attempting to run (FLOAT 1's & 0's TEST)

3. LOADING PROCEDURES

3.1 Method

This program must be loaded with the binary loader. If you are unfamiliar with the proper binary loading procedures, refer to the User Handbook for your computer, or appendix "A" of this write up.

- a. Set the teletype reader switch to FREE.
- b. Open the teletype reader and insert the program tape so that the arrows on the tape are visible to, and pointing toward the operator.
- c. Close the reader and set the reader switch to START.
- d. Set the teletype from panel switch to ON-LINE.
- e. Set the LEFT switches to 7777.
- f. Set the RIGHT switches to 4000.
- g. Set the MODE switch to 8 mode.
- h. Depress I/O preset.
- i. Depress START LS.
- j. When the program tape has been read in, the computer will halt.
- k. The ACCUMULATOR must be equal to 0000; if it is not, an error has occurred and one might try reloading the binary loader.

STARTING PROCEDURE

- a. Remove the paper tape from the teletype reader.
- b. Set the three right most switches SR9, 10, 11 to the number of the memory bank you wish to test. In a basic machine with no extended memory, this would be 000.
- c. Set the MODE switch to 8 mode.
- d. Depress I/O preset.
- e. Depress START 20.
- f. The program, when properly running, will cause the AC to flicker, and the MA to count up. One pass will take approximately 10 min.

4.1 Switch Settings

In general, switches 0, 1, 2 allow the test engineer to select the mode of error indication, I.E., type out or error halt. The normal mode with switches 0, 1, 2 on a zero is an error halt. To modify these circumstances proceed as follows:

SR00 = 1 Suppress halt
 SR01 = 1 Suppress typing
 SR02 = 1 Scope Loop on error

These designated switches have an order of precedence associated with them, which is designed for maximum flexibility.

In the event of an error, the first switch to be tested is switch 0; if it is 0 the computer will halt at address 0063. Depress continue to check switch 1 and obtain printout. If it is a 1, I.E., suppress halt, we test switch 1. If switch 1 is 0 the following "typical" error message will ensue:

```

FLOAT  I/O
ADDR   DATA
0241   6000
```

This message is interpreted as follows:

- 1) The "ADDR" address of the memory location under test. Indicates which memory address was being tested when the failure was detected.
- 2) "DATA" indicate the data in this memory location the correct data for the Float 1 test is 4000 the correct data for Float 0 test is 3777.

Handwritten notes:
 Done 11
 9-77
 2001

APPENDIX A

PDP-8 MODE PERFORATED-TAPE LOADER

READIN MODE LOADER

The readin mode (RIM) loader is a minimum length, basic, perforated-tape program for the 33 ASR. It is initially stored in memory by manual use of the operator console keys and switches. The loader is permanently stored in 18 locations of page 37.

The RIM loader can only be used in conjunction with the 33ASR reader (not the high-speed perforated-tape reader). Because a tape in RIM format is, in effect, twice as long as it need be, it is suggested that the RIM loader be used only to read the binary loader when using the 33 ASR. (NOTE: Some PDP-12 diagnostic program tapes are in RIM format).

The complete PDP-12 RIM loader (SA=7756 is as follows:

Absolute Address	Octal Content	Tag	Instruction I Z	Comments
7756	6032	BEG,	KCC	/CLEAR AC AND FLAG
7757	6031		KSF	/SKIP IF FLAG=1
7760	5357		JMP-1	/LOOKING FOR CHARACT
7761,	6036		KRB	/READ BUFFER
7762,	7106		CLL RTL	
7763,	7006		RTL	/CHANNEL 8 IN ACO
7764,	7510		SPA	/CHECKING FOR LEADER
7765,	5357		JMP BEG+1	/FOUND LEADER
7766,	7006		RTL	/OK, CHANNEL 7 IN LINK
7767,	6031		KSF	
7770,	5367		JMP-1	
7771,	6034		KRS	/READ, DO NOT CLEAR
7772,	7420		SNL	/CHECKING FOR ADDRESS
7773,	3776		DCA 1 TEMP	/STORE CONTENT
7774,	3376		DCA TEMP	/STORE ADDRESS
7775,	5356		JMP BEG	/NEXT WORD
7776,	0	TEMP,	0	/TEMP STORAGE
7777,	5XXX		JMP X	/JMP START OF BIN LOADER

Placing the RIM loader in core memory by way of the operator console keys and switches is accomplished as follows:

- a. Set the starting address 7756 in the LEFT switches.
- b. Set the first instruction (6032) in the RIGHT switches.
- c. Press the FILL switch.
- d. Set the next instruction (6031) in the RIGHT switches.
- e. Press the FILL STEP switch.
- f. Repeat steps d and e until all 16 instructions have been deposited.

To load a tape in RIM format, place the tape in the reader, set the LEFT switches to the starting address 7756 of the RIM loader (not of the program being read), press the START LS key, and start the Teletype reader.

sam

/FLOAT 1'S AND 0'S
 /COPYRIGHT 1969, DIGITAL EQUIPMENT CORP., MAYFARL, MASS.
 /THIS CORE MEMORY EXERCISER IS FULLY COMPATIBLE WITH A FAMILY
 /OF 2 COMPUTERS INCLUDING POP-5, 8, 81, 81, 85, 12 AND LINC-8
 /SR02=1 INHIBIT ERROR HALT
 /SR01=1 INHIBIT TYPEOUT
 /SR02=1 SCOPE LOOP ON ERROR

/THIS MEMORY EXERCISER EVALUATES THE ENTIRE CORE MEMORY
 /FROM ADDRESS K242 TO 7777 IN BANK0 AND ALL ADDRESSES IN
 /EXTENDED MEMORY FOR THE TENDENCY TO PICK UP OR DROP BITS
 /THE TEST FOR DROPPING BITS IS PERFORMED BY ROTATING A
 /SINGLE 1 BIT THRU EACH MEMORY ADDRESS 4096 TIMES AND
 /TESTING THE RESULT. THE TEST FOR PICKING UP BITS IS PERFORMED
 /BY FLOATING A SINGLE 2 BIT THRU EACH MEMORY ADDRESS
 /4096 TIMES AND TESTING THE RESULT.

/TO ENSURE MAXIMUM TEST TIME AND MINIMUM BIT FIDDLING
 /TIME THE DATA IS ONLY TESTED AT THE CONCLUSION OF
 /THE TEST FOR EACH ADDRESS RATHER THAN AFTER EACH ROTATE.

/TO TEST ANY OR ALL EXTENDED MEMORY SET SWITCHES 9, 10, 11
 /TO THE EXTENDED BANK NUMBER.

/ SR09=EXTENDED MEMORY
 / SR10=EXTENDED MEMORY
 / SR11=EXTENDED MEMORY

0001	0070	*1	0070	/EXTENDED MEMORY MASK
0002	0000	K0070	0000	/GENERAL STORAGE REGISTER
0003	0201	REGA	0201	/CHANGE DATA FIELDS
0004	0240	K6201	0240	/BOTTOM OF TEST
0005	0000	TALLY	0000	
0006	7774	K7774	7774	
0007	1026	K1026	1026	

0010	0000	*10	0000	
0011	0000	AUTO10	0000	
0012	0157	DONYET	0000	
0013	0000	MESSA	K215=1	
0014	4000	REGB	0000	
0015	0000	M4000	=4000	
		TEMP	0000	

0000
 0001 7674
 0002 7675
 0003 7676
 0004 7677
 0005 7678
 0006 7679
 0007 7680
 0008 7681
 0009 7682
 0010 7683
 0011 7684
 0012 7685
 0013 7686
 0014 7687
 0015 7688
 0016 7689
 0017 7690
 0018 7691
 0019 7692
 0020 7693
 0021 7694
 0022 7695
 0023 7696
 0024 7697
 0025 7698
 0026 7699
 0027 7700

*20
 START:

SAS
 CLL CTL
 CLL PAL
 ADD 4007
 OCA REGA
 TAD REGA
 TAD K6201
 OCA BEGIN0
 /
 /SET UP LOWER TEST ADDRESS 2230 FOR BANK 3 AND 000A FOR ALL OTHERS
 /
 TAD REGA
 SVA CLA K0240
 TAD
 OCA TALLY
 OCA DONVET
 /
 /FLOAT A SINGLE 1 BIT
 /
 BEGIN0: U000
 CLA CLL CML
 RAR
 OCA I TALLY
 TAD I TALLY
 ISZ DONVET
 JMP I=4
 TAD M4000
 SZA CLA GOOF
 JMP
 /
 /FLOAT A SINGLE 0 BIT
 /
 CLL CLA CMA
 RAR
 OCA I TALLY
 TAD I TALLY
 ISZ DONVET
 JMP I=4
 CMA
 SMA CLA
 JMP GOOF
 ISZ TALLY
 JMP BEGIN0
 PNTA:
 JMP START
 0047 7340
 0050 7010
 0051 3405
 0052 1405
 0053 2011
 0054 5050
 0055 7040
 0056 7700
 0057 5063
 0060 2005
 0061 5035
 0062 5020

/READ SWITCHES SW9, 17, 11
 /MOVE 9, 17, 11 INTO 6, 7, 9
 /NOPE
 /SAVE EXTENDED MEMORY BITS
 /STORE EXTENDED MEMORY DATA
 /SET SELECTED EXTENDED BANK
 /ADD CHANGE DATA FIELD (COP)
 /STORE AS FIRST INSTRUCTION IN DATA HANDLE

/GET EXTENDED MEMORY DATA
 /TEST FOR EXTENDED MEMORY
 /BANK 2
 /SET TALLY
 /CLEAR DONVET

/SET DATA FIELD
 /SET L=1 AC=0400
 /MOVE L=0 AC=4000
 /STORE IN TEST ADDRESS
 /FETCH IT
 /DOYE 4096 TIMES YET NO
 /DO YOYE
 /AC=4000
 /TEST OKAY
 /TEST FAILED TELL OPERATOR

/SET L=0 AC=7777
 /SET L=1 AC=3777
 /STORE IN TEST ADDRESS
 /FETCH IT
 /DONE 4096 TIMES YET
 /NOPE

/TEST FAILED TELL OPERATOR
 /UPDATE ADDRESS
 /TEST NEW ADDRESS
 /EXIT

/ERROR HANDLER

0063 7604 /READ SWITCHES
 0264 7500 /SR02=?
 0065 7402 /ERRCR HALT
 0266 7004 /MOVE SRC1 TO AC1
 0067 7500 /SRZ1=?
 0070 5075 /TYPE
 0071 7004 /MOVE SR02 TO AC1
 0072 7700 /SR02=?
 0073 5060 /GO
 0074 5061 /SCOPE LOOP

PNTB, SMA CLA
 JMP PNTA
 JMP PNTA+1

/TYPE OUT ROUTINE

0075 7300 /CLEAR ACL
 0076 6201 /RESTORE DATA FIELD
 0077 1010 TAD AUTO10 /GET AUTO10=0000 NEVER TYPED
 0100 7640 SZA CLA /=?
 0101 5111 JMP DATA /NO TYPE NUMERICS
 0102 TAD MESSA /GET POINTER
 0103 3010 DCA AUTO10 /STORE IN AUTO10
 0104 1410 TAD I AUTO10 /FETCH A CHARACTER
 0105 7450 SNA /DONE YET
 0106 5111 JMP *3 /YES
 0107 4152 JMS TYPE /TYPE IT
 0110 5104 JMP *4 /NO

/DATA TYPE OUT

0111 1005 /GET ADDRESS
 0112 4127 TAD TALLY /TYPE
 0113 1035 JMS OCTYP /GET DATA FIELD
 0114 3115 DCA BEGIN0 /STORE IT
 0115 0000 *1
 0116 1405 TAD I TALLY /SET DATA FIELD
 0117 4127 JMS OCTYP
 0120 1160 TAD K215
 0121 4152 JMS TYPE
 0122 1161 TAD K212
 0123 4152 JMS TYPE
 0124 7004 LAS
 0125 7006 RTL
 0126 5072 JMF PNTB
 0127 0000 PNTB
 0130 3015 DCA TEMP
 0131 1006 TAD K7774
 0132 3013 DCA REG8
 0133 1007 TAD K1026

OCTYP, 0

HERE, 0

