

IDENTIFICATION

PRODUCT CODE: MAINDEC-08-DHRKC-H-0
PRODUCT NAME: RK8E/RK8L DATA RELIABILITY PROGRAM
DATE RELEASED: FEBRUARY, 1977
MAINTAINER: DIAGNOSTIC ENGINEERING
AUTHOR: JOHN VROBEL/WILLIAM HEAVEY

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED UNDER A LICENSE AND MAY ONLY BE USED OR COPIED IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1972, 1975, 1976, 1977 BY DIGITAL EQUIPMENT CORPORATION

TABLE OF CONTENTS

1. ABSTRACT
2. RESTRICTIONS
- 2.1 HARDWARE
- 2.2 PROGRAM STORAGE
- 2.3 PRELIMINARY PROGRAMS
- 2.4 EXECUTION TIME
3. SWITCH REGISTER SETTINGS
4. OPERATOR AND/OR PROGRAM ACTION
- 4.1 STANDARD TEST PROCEDURE
- 4.2 RK05J DRIVE CARTRIDGE MOUNTING PROCEDURE
- 4.3 RK05F DRIVE MOUNTING PROCEDURE
- 4.4 RK0E/RK0L DATA RELIABILITY (ACCEPT MODE)
- 4.5 RK0E DATA RELIABILITY (MANUAL INTERVENTION MODE)
- 4.6 CHANGE PROGRAM IOT CODES
5. ERRORS
- 5.1 USEFUL INFORMATION
- 5.2 ERROR HALTS
- 5.3 ERROR TYPEOUTS
- 5.4 ERROR RECOVERY AND ERROR DISCONNECT
- 5.5 STATUS COMPLETE TYPEOUT AND PASS COMPLETE DISCONNECT
- 5.6 TYPICAL ERROR TYPEOUTS
6. RESTRICTIONS
7. TROUBLE SHOOTING INFORMATION
8. PROGRAM DESCRIPTION (ACCEPT MODE)
9. CONSOLE PACKAGE ADDENDUM
10. APT-8 HOOKS
11. PROGRAM LISTING

1.

ABSTRACT

THE RK8E/RK8L DATA RELIABILITY PROGRAM IS DESIGNED PRIMARILY AS AN ACCEPTANCE TEST TO VERIFY DISK DATA TRANSFERS WITHIN THE DISK SYSTEM.

THE "ACCEPT MODE" OF OPERATION VERIFIES THE CAPABILITY OF TRANSFERRING A TOTAL 3 X 10⁹ BITS OF DATA TO AND FROM EACH INDIVIDUAL DISK DRIVE ON THE DISK SYSTEM.

THE "MANUAL INTERVENTION MODE" IS AVAILABLE AS A HARDWARE DEBUGGING AID TO ALLOW THE OPERATOR TO SELECT DATA PATTERNS, TRANSFER LENGTHS, AND ADDRESSING.

(NOTE: LOCATION 0 CONTAINS REVISION LEVEL (IN ASCII) OF PROGRAM ON PROGRAM LOAD).

2.

RESTRICTIONS

THE RK8L CONTROL, WHICH CAN CONTROL UP TO 8 DRIVES, WILL NOT RUN WITH THE DW8E BUS ADAPTER. THE REASON FOR THIS STATEMENT IS THAT THE RK8L CONTROL USES IOT8 FOR EXTENDED DRIVES 4-7 WHICH IS NOT AVAILABLE ON THE DW8E.

2.1

HARDWARE

A. PDP-8/A, 8/E, 8/F, OR 8/M COMPUTER OR OTHER FAMILY OF 8 COMPATIBLE COMPUTER WITH NECESSARY DW8E BUS ADAPTER.

B. AT LEAST 4K OF READ/WRITE MEMORY. AT LEAST 8K OF MEMORY IS NECESSARY FOR OPERATION OF THE CONSOLE PACKAGE.

C. ASR-33 TELETYPE OR EQUIVALENT

D. RK8E OR RK8L DISK CONTROL

E. RK05J OR RK05F DISK DRIVE(S)

F. FORMATTED 2200 DPI-16 SECTOR PACK(S).

NOTE: THE RK05F DISK DRIVE IS CONSIDERED AS TWO SEPARATE UNITS. WHEN ANSWERING ALL QUESTIONS THE SEPARATE DRIVES MUST BE SPECIFIED. DSK07, DSK17, DSK27, ETC.

2.2

PROGRAM STORAGE

THE PROGRAM OCCUPIES OR UTILIZES LOCATION 0000 TO LOCATION 7577 OF FIELD 0. ALL EXTENDED MEMORY LOCATIONS, IF AVAILABLE, ARE UTILIZED FOR TESTING.

2.3

PRELIMINARY PROGRAMS

THIS PROGRAM REQUIRES A FORMATTED CARTRIDGE ON ALL DRIVES TO BE TESTED.

ALL BASIC AND EXTENDED MEMORY DIAGNOSTICS SHOULD BE RUN PRIOR TO RUNNING THIS PROGRAM.

RK8E CONTROL: RUN THE RK8E DISKLESS CONTROL TEST AND THE RK8E/RK8L DISK FORMATTER IF THIS DIAGNOSTIC FAILS TO OPERATE PROPERLY.

RK8L CONTROL: RUN THE RK8L INSTRUCTION TEST AND THE RK8E/RK8L FORMATTER IF THIS DIAGNOSTIC FAILS TO OPERATE PROPERLY.

2.4 EXECUTION TIME -----

THE PROGRAM EXECUTION TIME (I.E., PASSING 3×10^9 BITS OF DATA ON A DISK DRIVE), IS APPROX. 4 HOURS PER DISK DRIVE ON A 4K MEMORY SYSTEM OR APPROX. 3.5 HOURS PER DISK DRIVE ON SYSTEMS WITH EXTENDED MEMORY.

3. SWITCH REGISTER SETTINGS -----

SWR0#1 LOOP ON WRITE SEQUENCE.
SWR1#1 LOOP ON READ SEQUENCE.
SWR2#1 INHIBIT ALL ERROR TIMEOUTS
SWR3#1 TYPE "STATUS-COMplete" REPORT.
SWR4#1 PROGRAM STOP ON HALT.
SWR5#1 DRIVE DISCONNECT AFTER PASS COMPLETION.
SWR6#1 PERFORM ONLY "OVERLAP SEEKS", DO NOT EXECUTE DATA BREAKS.

4. OPERATOR AND/OR PROGRAM ACTION -----

4.1 STANDARD TEST PROCEDURE -----

- A. START AS SPECIFIED THROUGHOUT THIS DOCUMENTATION IS KEY CLEAR AND THEN KEY CONTINUE ON PDP8/E, PDP8/M, AND PDP8/F COMPUTERS.
- B. LOAD THE PROGRAM INTO MEMORY FIELD 0 USING THE STANDARD BINARY LOADER TECHNIQUE.
- C. IF IT IS DESIRED TO CHANGE THE IOT CODES WITHIN THE PROGRAM, FOLLOW THE PROCEDURE IN SECTION 4.6.
- D. RUN THE ACCEPTANCE MODE OF DATA RELIABILITY WITH ALL DRIVES AND MEMORY AVAILABLE BY FOLLOWING THE PROCEDURE

IN SECTION 4.4.

E. THE MANUAL INTERVENTION MODE, SECTION 4.5, MAY BE USED FOR TROUBLE SHOOTING, IF DESIRED.

F. IF POSSIBLE SWR4#1 SHOULD ALWAYS BE USED TO STOP THE PROGRAM.

G. IF THE PROGRAM HAS BEEN STOPPED DUE TO SWR4#1, THE PROGRAM CAN BE RESTARTED, AND THE INITIAL STARTUP QUESTIONS BYPASSED, BY USING 0205 AS THE RESTART ADDRESS.

H. FOR THE ABSOLUTE LOCATIONS OF ALL KNOWN HALTS IN THIS PROGRAM, ACCESS PAGE 1-22 OF THE PROGRAM LISTING.

4.2

RK05J DRIVE CARTRIDGE MOUNTING PROCEDURE

THE FOLLOWING IS THE CORRECT CARTRIDGE MOUNTING PROCEDURE FOR THE RK05J DISK DRIVE. ANY DEVIATION ENCOUNTERED DURING THIS PROCEDURE WILL BE CONSIDERED AN ERROR CONDITION.

A. SET SWITCH LABELED "RUN/LOAD" TO THE "LOAD" POSITION.

B. TURN AC POWER TO DISK DRIVE ON.

C. VERIFY THAT THE LIGHT LABELED "PWR" IS ON.

D. WAIT FOR THE LIGHT LABELED "LOAD" TO COME ON.

E. VERIFY THAT THE LIGHTS LABELED "RDY", "ON CYL", "FAULT", "WT", AND "RD" ARE OFF.

F. OPEN ACCESS DOOR.

G. INSERT CARTRIDGE.

H. CLOSE ACCESS DOOR.

I. SET SWITCH LABELED "RUN/LOAD" TO THE "RUN" POSITION.

J. WAIT FOR THE LIGHTS LABELED "RDY" AND "ON CYL" TO COME ON.

K. TOGGLE SWITCH LABELED "WT PROT" AND VERIFY THAT THE LIGHT LABELED "WT PROT" GOES ON AND OFF.

L. TOGGLE SWITCH LABELED "WT PROT" UNTIL THE LIGHT LABELED "WT PROT" IS OFF.

M. VERIFY THAT LIGHTS LABELED "FAULT", "WT", "RD", AND "LOAD" ARE OFF.

4.3

RK05F DRIVE SETUP PROCEDURE

THE FOLLOWING IS THE CORRECT SETUP PROCEDURE

FOR THE RK05F DISK DRIVE. ANY DEVIATION ENCOUNTERED DURING THIS PROCEDURE WILL BE CONSIDERED AN ERROR CONDITION.

- A. SET SWITCH LABELED "RUN/LOAD" TO THE "LOAD" POSITION.
- B. TURN AC POWER ON.
- C. VERIFY THAT LIGHT LABELED "PWR" IS ON.
- D. WAIT FOR LIGHT LABELED "LOAD" TO COME ON.
- E. VERIFY THAT LIGHTS LABELED "RDY", "ON CYL", "FAULT", "WT", AND "RD" ARE OFF.
- F. SET SWITCH LABELED "RUN/LOAD" TO THE "RUN" POSITION.
- G. WAIT FOR LIGHTS LABELED "RDY" AND "ON CYL" TO COME ON.
- H. TOGGLE SWITCH LABELED "WT PROT" AND VERIFY THAT THE LIGHT LABELED "WT PROT" GOES ON AND OFF.
- I. TOGGLE SWITCH LABELED "WT PROT" UNTIL LIGHT LABELED "WT PROT" GOES OFF.
- J. VERIFY THAT LIGHTS LABELED "FAULT", "WT", "RD", AND "LOAD" ARE OFF.

4.4

RK0E/RK0L DATA RELIABILITY (ACCEPT MODE)

- A. MAKE READY ALL DRIVES TO BE TESTED USING THE RK05J DRIVE CARTRIDGE MOUNTING PROCEDURE SECTION 4.2 OR THE RK05F DRIVE PROCEDURE IN SECTION 4.3.
- B. SET SWITCH LABELED "RUN/LOAD" TO THE "LOAD" POSITION ON ALL DRIVES NOT BEING TESTED.
- C. VERIFY THAT AC POWER IS ON, ON ALL DRIVES NOT BEING TESTED.
- D. SET THE SWITCH REGISTER TO 0200 AND PRESS LOAD ADDRESS.
- E. SET THE SWITCH REGISTER TO 0000 AND PRESS START.
- F. THE OPERATOR MAY SET SWRS=1 IF IT IS DESIRED TO HAVE THE PROGRAM AUTOMATICALLY DISCONNECT EACH DISK DRIVE AS EACH MAKE THEIR PASS COMPLETION. (NOTE: IF SWRS=0, ALL DISK DRIVES WILL CONTINUE TO RUN AFTER THEIR PASS COMPLETION)
- G. THE TTY WILL PRINT THE FOLLOWING PROGRAM NAME AND QUESTION.

RK0E/RK0L DATA RELIABILITY
EXTENDED R/W MEMORY (0-7)?

THE OPERATOR SHOULD THEN TYPE THE AMOUNT OF EXTENDED READ/ WRITE MEMORY BANKS NUMBERED SEQUENTIALLY FROM BANK 0, AS INDICATED BY THE TTY QUESTION.

- H. THE TTY WILL PRINT THE FOLLOWING QUESTION(S), ASKING THE

DESIRED DISK DRIVE(S) TO BE USED IN TESTING.

EXERCISE DISK07
EXERCISE DISK17
EXERCISE DISK27
EXERCISE DISK37
EXERCISE DISK47
EXERCISE DISK57
EXERCISE DISK67
EXERCISE DISK77

FOR THE QUESTION(S) ABOVE, TYPE Y FOR YES, IF IT IS DESIRED TO TEST THE DISK DRIVE IN QUESTION, OTHERWISE, TYPE N FOR NO.

I. THE TTY WILL PRINT THE FOLLOWING QUESTION.

ACCEPT MODE?

THE OPERATOR SHOULD THEN TYPE Y FOR YES TO RUN THE ACCEPTANCE MODE OF OPERATION.

J. THE TTY WILL PRINT THE FOLLOWING QUESTION.

ARE YOU SURE?

IF THE OPERATOR IS CERTAIN OF THE AMOUNT OF MEMORY, THE DISK DRIVE(S) SELECTED, AND THE MODE OF OPERATION, TYPE Y FOR YES. TYPING N FOR NO WILL RESULT IN A REPEAT OF ALL MESSAGES AND QUESTIONS ENCOUNTERED THUS FAR.

K. THE PROGRAM SHOULD START TESTING THE DISK DRIVE(S) AND MEMORY SELECTED.

L. THE "STATUS=COMPLETE" TYPEOUT SHOULD OCCUR UPON PASS COMPLETION OF EACH DISK DRIVE. ALL OTHER TYPEOUTS OR HALTS WILL BE CONSIDERED AS AN ERROR CONDITION. SEE SECTION 5.5 FOR "STATUS=COMPLETE" TYPEOUT.

M. A SUCCESSFUL PASS COMPLETE ON A DISK DRIVE WILL BE CONSIDERED AS NO "HARD" ERRORS AND NO MORE THAN ONE (1) "SOFT" ERROR PER PASS COMPLETE.

N. IF ANY ERRORS DO OCCUR, THE OPERATOR SHOULD ACCESS SECTION 5 IN THIS DOCUMENTATION.

4.5

RK8E/RK8L DATA RELIABILITY (MANUAL INTERVENTION MODE)

THE MANUAL INTERVENTION MODE IS AVAILABLE AS A TROUBLE SHOOTING AID AND SHOULD ONLY BE USED FOR SUCH PURPOSES, IF DESIRED.

A. MAKE READY ALL DISK DRIVES TO BE TESTED USING THE RK85J DRIVE CARTRIDGE MOUNTING PROCEDURE SECTION 4.2. OR THE RK85F DRIVE PROCEDURE SECTION 4.3.

B. SET SWITCH LABELED "RUN/LOAD" TO THE "LOAD" POSITION ON

ALL DRIVES NOT BEING TESTED.

- C. VERIFY THAT AC POWER IS ON, ON ALL DRIVES NOT BEING TESTED.
- D. SET THE SWITCH REGISTER TO 0200 AND PRESS LOAD ADDRESS.
- E. SET THE SWITCH REGISTER TO 0000 AND PRESS START.
- F. THE TTY WILL PRINT THE FOLLOWING PROGRAM NAME AND QUESTION.

RK0E/RK0L DATA RELIABILITY
EXTENDED R/W MEMORY (0-7)?

THE OPERATOR SHOULD THEN TYPE THE AMOUNT OF EXTENDED READ/
WRITE MEMORY BANKS NUMBERED SEQUENTIALLY FROM BANK 0, AS
INDICATED BY THE TTY QUESTION.

- G. THE TTY WILL PRINT THE FOLLOWING QUESTION(S), ASKING THE
DESIRED DISK DRIVE(S) TO BE USED IN TESTING.

EXERCISE DISK0?
EXERCISE DISK1?
EXERCISE DISK2?
EXERCISE DISK3?
EXERCISE DISK4?
EXERCISE DISK5?
EXERCISE DISK6?
EXERCISE DISK7?

FOR THE QUESTION(S) ABOVE, TYPE Y FOR YES, IF IT IS DESIRED
TO TEST THE DISK DRIVE IN QUESTION, OTHERWISE, TYPE N FOR
NO.

- H. THE TTY WILL PRINT THE FOLLOWING QUESTION.

ACCEPT MODE?

THE OPERATOR SHOULD THEN TYPE N FOR NO TO RUN THE MANUAL
INTERVENTION MODE OF OPERATION.

- I. THE TTY WILL THEN PRINT THE FOLLOWING QUESTION, ASKING
IF THE OPERATOR DESIRES TO SELECT A CONSTANT MEMORY FIELD,
RATHER THAN THE NORMAL RANDOM FIELD SELECTION.

FIELD?

IF THE OPERATOR DESIRES TO SELECT A CONSTANT FIELD,
TYPE Y FOR YES, OTHERWISE, TYPE N FOR NO. IF Y WAS TYPED THE
TTY WILL SPACE OUT ONCE AND WAIT FOR THE OPERATOR TO TYPE
THE DESIRED FIELD IN OCTAL (0-7).

- J. THE TTY WILL PRINT THE FOLLOWING QUESTION, ASKING IF THE
OPERATOR DESIRES TO SELECT A CONSTANT TRACK, RATHER THAN
THE NORMAL RANDOM TRACK SELECTION.

TRACK?

IF THE OPERATOR DESIRES TO SELECT A CONSTANT TRACK, TYPE Y FOR YES, OTHERWISE, N FOR NO. IF Y WAS TYPED, THE TTY WILL SPACE OUT ONCE AND WAIT FOR THE OPERATOR TO INPUT THE DESIRED TRACK ADDRESS (00000-14537).

- K. THE TTY WILL PRINT THE FOLLOWING QUESTION, ASKING IF THE OPERATOR DESIRES TO SELECT HALF BLOCK OR FULL BLOCK TRANSFERS, RATHER THAN THE NORMAL RANDOM SELECTION.

BLOCK LENGTH?

IF THE OPERATOR DESIRES TO CHANGE THE BLOCK LENGTH, TYPE Y FOR YES, OTHERWISE, N FOR NO. IF Y WAS TYPED THE TTY WILL SPACE OUT ONCE AND WAIT FOR THE OPERATOR TO TYPE THE BLOCK LENGTH DESIRED (0=256 WORD BLOCK OR 1=128 WORD BLOCK).

- L. THE TTY WILL PRINT THE FOLLOWING QUESTION, ASKING IF THE OPERATOR DESIRES TO SELECT A CONSTANT NUMBER OF SECTORS TO BE TRANSFERED, RATHER THAN THE NORMAL RANDOM SECTOR SELECTION.

EXTRA SECTORS?

IF THE OPERATOR DESIRES TO SELECT A CONSTANT AMOUNT OF SECTORS, TYPE Y FOR YES, OTHERWISE, N FOR NO. IF Y WAS TYPED THE TTY WILL SPACE OUT ONCE, AND WAIT FOR THE OPERATOR TO TYPE IN THE EXTRA SECTORS DESIRED (00-17). (NOTE: IF THE FIELD AND THE BLOCK LENGTH PREVIOUSLY SELECTED WAS 0, THE AMOUNT OF EXTRA SECTORS WILL BE LIMITED TO 07. OTHERWISE THE MAXIMUM AMOUNT IS LIMITED TO 17.)

- M. THE TTY WILL PRINT THE FOLLOWING QUESTION, ASKING IF THE OPERATOR DESIRES TO SELECT A DATA PATTERN, RATHER THAN NORMAL RANDOM DATA SELECTION.

DATA?

IF THE OPERATOR DESIRES TO SELECT A DATA PATTERN, TYPE Y FOR YES, OTHERWISE, N FOR NO. IF Y WAS TYPED, THE TTY WILL DO A "CRLF" AND WAIT FOR THE OPERATOR TO TYPE IN 12 OCTAL DATA WORDS TO BE USED IN TESTING.

- N. THE TTY WILL PRINT THE FOLLOWING QUESTION.

ARE YOU SURE?

IF THE OPERATOR IS CERTAIN OF THE INFORMATION SELECTED, TYPE Y FOR YES, TYPING N FOR NO WILL RESULT IN A REPEAT OF ALL MESSAGES AND QUESTIONS ENCOUNTERED THUS FAR.

- P. THE PROGRAM SHOULD START EXECUTING THE OPERATIONS SELECTED.

- R. IF ERRORS ARE ENCOUNTERED, ACCESS SECTION 5 IN THIS DOCUMENTATION.

THE PROGRAM NORMALLY RECOGNIZES DEVICE IOT CODE X74X. TO CHANGE THE DEVICE IOT CODES WITHIN THE PROGRAM:

- A. SET THE SWITCH REGISTER TO 0204 AND PRESS LOAD ADDRESS.
- B. SET THE SWITCH REGISTER TO 0000, SET SWITCH REGISTER BITS 3-8 TO THE DESIRED DEVICE IOT CODE, AND PRESS START.
- C. THE PROGRAM WILL CHANGE THE DEVICE IOT CODES WITHIN THE PROGRAM AND THEN HALT.
- D. PRESSING KEY CONTINUE WILL START THE PROGRAM AT LOCATION 0200 (SEE SECTIONS 4.4 OR 4.5 FOR OPERATION INSTRUCTIONS).

5. ERRORS

5.1 USEFUL INFORMATION

ALL STATUS ERRORS WILL BE REPORTED AS STATUS ERRORS. ALL DATA ERRORS WILL BE REPORTED AS DISK DATA ERRORS.

WHEN DATA IS BEING READ OFF THE DISK AND A CRC ERROR OCCURS THE PROGRAM WILL REPORT THE ERROR AS A READ STATUS ERROR. THE PROGRAM WILL THEN CHECK THE DATA READ FOR DATA ERRORS. IF DATA ERRORS EXIST THEY WILL BE REPORTED AS DISK DATA ERRORS.

5.2 ERROR HALTS

ERROR HALTS FOR WHICH THERE ARE NO ERROR TYPEOUTS ARE LISTED AND DEFINED AS FOLLOWS.

BIGSTP	MASTER ERROR HALT FOR ALL OF THE FOLLOWING ERROR STOPS. WHEN THE COMPUTER HALTS THE AC REGISTER WILL INDICATE THE PC OF THE FAILING ERROR STOP.
INTER1	NO DISK INTERRUPT
ERHLT0	SKIP TRAP FOR IOT "DLSC"
ERHLT2	SKIP TRAP FOR IOT "OCLR"
ERHLT3	SKIP TRAP FOR IOT "DLAG"
ERHLT5	SKIP TRAP FOR IOT "DRST"
ERHLT6	SKIP TRAP FOR IOT "DLDC"
BADHLT	CHECKSUM FAILED BUT WORD-BY-WORD COMPARE WORKED

NODSKS

NO DISKS AVAILABLE TO RUN

FLDHLT

PROGRAM WILL ONLY RUN IN FIELD 0

FOR THE ABSOLUTE LOCATIONS OF THE HALTS LISTED ABOVE,
ACCESS PAGE 1-22 OF THE PROGRAM LISTING.

5,3

ERROR TYPEOUTS

WHEN AN ERROR OCCURRES THE PROGRAM WILL PRINT AN
"ERROR HEADER" WHICH WILL SPECIFY THE PARTICULAR TYPE
OF ERROR FOUND AT THE TIME OF THE FAILURE.

POSSIBLE "ERROR HEADERS" ARE AS FOLLOWS.

WRITE STATUS ERROR
READ STATUS ERROR
DISK DATA ERROR
RECALIBRATE STATUS ERROR

AFTER THE "ERROR HEADER" MENTIONED ABOVE IS TYPED, THE
PROGRAM WILL PRINT THE FOLLOWING ERROR INFORMATION
FOUND AT THE TIME OF THE FAILURE, PERTAINING TO THE
FAILURE. POSSIBLE TYPEOUTS ARE AS FOLLOWS.

PC: PROGRAM LOCATION OF THE ACTUAL FAILURE.
ST: CONTENTS OF THE STATUS REGISTER.
EX: EXTENDED DRIVE BIT
CM: SOFTWARE COMMAND REGISTER.
IA: INITIAL SOFTWARE DISK ADDRESS REGISTER OR THE
CYLINDER, SURFACE, AND SECTOR BITS.
DA: FINAL SOFTWARE DISK ADDRESS REGISTER OR THE
CYLINDER, SURFACE, AND SECTOR BITS.
CA: SOFTWARE INITIAL CURRENT ADDRESS
WC: SOFTWARE INITIAL WORD COUNT
FW: SOFTWARE FINAL WORD COUNT
AS: SECTOR IN ERROR ON THE PARTICULAR CYLINDER
AND SURFACE IN QUESTION,
WA: WORD ADDRESS WITHIN THE SECTOR IN ERROR
AD: BREAK ADDRESS OF DATA BREAK IN COMPUTER.
DG: EXPECTED DATA
DB: DATA FOUND DURING DATA BREAK.

5.4

ERROR RECOVERY AND ERROR DISCONNECT

WHEN A READ, WRITE, OR DISK DATA ERROR OCCURS (SEE SECTION 5.3), THE PROGRAM WILL TRY TO REPEAT THE FAILING SEQUENCE FOUR (4) TIMES. IF THE ERROR HAS OCCURRED FOUR (4) TIMES SIMULTANEOUSLY, THE ERROR WILL BE CONSIDERED AS A NON-RECOVERABLE ERROR, THE "ERROR HEADER" WILL BE CHANGED TO INDICATE "NON-RECOVERABLE" ERROR, ANOTHER DISK ADDRESS WILL BE SELECTED FOR TESTING, IF A "SOFT" ERROR SHOULD OCCUR ON A TRACK, THE PROGRAM WILL RETRY THE READ SEQUENCE (64) TIMES BEFORE SELECTING ANOTHER TRACK FOR TESTING. (NOTE: THIS 64 RETRY ON "SOFT" ERRORS WILL BE TERMINATED ON A "HARD" ERROR).

POSSIBLE NON-RECOVERABLE ERROR HEADERS ARE AS FOLLOWS.

NON-RECOVERABLE READ STATUS ERROR
NON-RECOVERABLE WRITE STATUS ERROR
NON-RECOVERABLE DISK DATA ERROR

IF A NON-RECOVERABLE READ OR WRITE ERROR SHOULD OCCUR, THE DISK IN QUESTION WILL THEN BE RECALIBRATED (RESTORED TO CYLINDER 0). IF THE RECALIBRATE SEQUENCE FAILS, THE DISK DRIVE IN ERROR WILL BE DISCONNECTED BY THE PROGRAM AND NO LONGER BE TESTED.

THE FOLLOWING "DISCONNECT" AND "STATUS-COMPLETE" TYPEOUTS SHOULD OCCUR.

RECALIBRATE ERROR DISCONNECT!
DISK X DISCONNECTED!
DSK HARD SOFT COMP
X 0030 0010 0001
X 0240 5670 0001

IF ALL DISKS ON THE SYSTEM HAVE BEEN DISCONNECTED DO TO RECALIBRATE ERRORS THE FOLLOWING TYPEOUT WILL OCCUR AND THE PROGRAM WILL HALT.

DISK SYSTEM SHUT DOWN, NO DISKS TO RUN!

5.5

STATUS-COMPLETE TYPEOUT AND PASS COMPLETE DISCONNECT

ALL ERRORS AND PASS COMPLETES ARE TALLIED BY THE PROGRAM PER DISK DRIVE.

THE FOLLOWING IS AN EXAMPLE OF THE "STATUS-COMPLETE" TYPEOUT THAT WILL OCCUR WHEN SWR3=1 INDICATING TYPE THIS REPORT, A PASS COMPLETE OCCURS ON A DRIVE UNDER TEST, OR A DRIVE IS DISCONNECTED DO TO A RECALIBRATE ERROR.

DSK HARD SOFT COMP
X XXXX XXXX XXXX
X XXXX XXXX XXXX
X XXXX XXXX XXXX

X XXXX XXXX XXXX

THE TYPEOUT AS MENTIONED ABOVE IS DESCRIBED AS FOLLOWS.

DSK DISK DRIVE IN QUESTION.
HARD ALL ERRORS OTHER THAN THAT DEFINED AS A SOFT ERROR.
SOFT A READ CRC STATUS ERROR WITH BAD DATA PER TRANSFER WITH RECOVERY POSSIBLE WITHIN FOUR (4) RETRYs. (NOTE: FOUR (4) CONSECUTIVE RETRYs WILL BE CONSIDERED AS A NON-RECOVERABLE ERROR OR A "HARD" ERROR).
COMP PASS COMPLETES. <3 X 10(9) BITS>

IF SWR5=1 INDICATING "DISCONNECT ON PASS COMPLETION", AND A DISK DRIVE UNDER TEST MAKES A PASS COMPLETION, THE FOLLOWING TYPEOUT WILL OCCUR AND THE DRIVE WILL BE DISCONNECTED.

DISK X PASS COMPLETE!
DISK X DISCONNECTED!
DSK HARD SOFT COMP
X XXXX XXXX XXXX
X XXXX XXXX XXXX

IF SWR5=0 INDICATING DON'T "DISCONNECT ON PASS COMPLETION", AND A DISK DRIVE UNDER TEST MAKES A PASS COMPLETION, THE FOLLOWING TYPEOUT WILL OCCUR AND THE DRIVE WILL CONTINUE TO RUN.

DISK X PASS COMPLETE!
DSK HARD SOFT COMP
X XXXX XXXX XXXX
X XXXX XXXX XXXX

IF SWR5=1 AND ALL DRIVES HAVE MADE THEIR PASS COMPLETION AND HAVE BEEN DISCONNECTED, THE FOLLOWING TYPEOUT WILL OCCUR AND THE COMPUTER WILL HALT.

DISK SYSTEM SHUT DOWN, NO DISKS TO RUN!

5.6

TYPICAL ERROR TYPEOUTS

THE FOLLOWING IS AN EXAMPLE OF AN "ERROR HEADER" AND ERROR TYPEOUT THAT COULD HAVE OCCURRED ON A WRITE STATUS ERROR. (NOTE CRC IN THE STATUS INDICATOR "ST!")

WRITE STATUS ERROR
PC:2371 ST:4010 EX:0001 CM:4000 IA:0001 DA:0002
CA:3600 WC:7000 FW:0000

THE FOLLOWING IS AN EXAMPLE OF AN ERROR TYPEOUT THAT COULD HAVE OCCURRED IF THE STATUS REGISTER FAILED ON A SEEK ONLY FUNCTION.

SEEK STATUS ERROR
PC:2076 ST:4002 EX:0001 CM:3000 DA:4007

THE FOLLOWING IS A TYPICAL EXAMPLE OF AN "ERROR HEADER"
AND ERROR TYPEOUT THAT COULD HAVE OCCURRED ON A DISK
DATA ERROR. (NOTE: ADDITION DATA ERRORS IN BUFFER)

DISK DATA ERROR
PC:1674 ST:4010 EX:0001 CM:1432 IA:1035 DA:1021
CA:0001 WC:5000 FW:7400
AS:0015 WA:0007 AD:0010 DG:0537 DB:0536
AS:0015 WA:0077 AD:0100 DG:7777 DB:7776
AS:0016 WA:0002 AD:0405 DG:6167 DB:6166

6. RESTRICTIONS

ALL DISK DRIVES SHOULD BE SET TO THE LOAD POSITION
THAT ARE NOT BEING TESTED.

7. TROUBLE SHOOTING INFORMATION

IOT	FUNCTION
---	-----
6740 DLSC	LOAD SECTOR COUNTER AND EXTENDED DRIVE BIT FOR RK6L.
AC	
--	
0-3	LOAD THE DESIRED AMOUNT OF SECTORS TO BE TRANSFERRED WITH THE BINARY VALUE IN AC BITS 0-3.
4	EXTENDED DRIVE BIT FOR DRIVES 4-7
6741 DSKP	"SKIP" SKIP IF TRANSFER DONE FLAG OR ERROR FLAG IS SET.
6742 DCLR	"CLEAR" FUNCTION IS REGULATED BY AC BITS 10 AND 11. THE AC IS THEN CLEARED.
AC10	AC11
----	----
0	0
0	1
	CLEAR THE AC AND STATUS REGISTER.
	CLEAR THE AC, CONTROL, AND MAJOR REGISTERS. THIS INSTRUCTION WILL STOP THE CONTROL EVEN IF IT IS WRITING A HEADER. THIS IS THE ONLY INSTRUCTION THAT CLEARS MAINTENANCE MODE.

1	0	CLEAR AC, RECALIBRATE DISK DRIVE, AND CLEAR STATUS REGISTER.
6743	DLAG	"LOAD DISK ADDRESS AND GO" LOAD THE DISK CYLINDER, SURFACE, AND SECTOR FROM THE AC, CLEAR THE AC, AND DO THE COMMAND IN THE COMMAND REGISTER.
AC	--	
0-6		CYLINDER
7		SURFACE (1=UPPER) (0=LOWER)
8-11		SECTOR
6744	DLCA	"LOAD CURRENT ADDRESS" LOAD THE CURRENT ADDRESS FROM AC. THE AC IS THEN CLEARED.
AC	--	
0-11		CURRENT ADDRESS
6745	DRST	"READ STATUS" CLEAR THE AC AND READ THE CONTENTS OF THE STATUS REGISTER INTO THE AC.
AC	--	
0		TRANSFER DONE
1		READY TO SEEK, READ, OR WRITE.
2		NOT USED
3		SEEK FAIL
4		DISK FILE READY
5		CONTROL BUSY ERROR
6		TIME OUT ERROR
7		WRITE LOCK ERROR
8		CRC ERROR
9		DATA RATE ERROR
10		DRIVE STATUS ERROR
11		CYLINDER ADDRESS ERROR
6746	DLDC	"LOAD COMMAND" LOAD THE COMMAND REGISTER FROM AC, CLEAR THE AC, AND CLEAR THE STATUS REGISTER.
AC	--	
0-2#0		READ DATA
0-2#1		READ ALL
0-2#2		WRITE LOCK
0-2#3		SEEK ONLY
0-2#4		WRITE DATA

0-205	WRITE ALL
0-206	NOT USED
0-207	NOT USED
3	ENABLE INTERRUPT
4	ENABLE SET TRANSFER DONE ON SEEK DONE
5	HALF BLOCK 120 WORDS
6	EXTENDED MEMORY ADDRESS
7	EXTENDED MEMORY ADDRESS
8	EXTENDED MEMORY ADDRESS
9	UNIT SELECT
10	UNIT SELECT
11	EXTENDED CYLINDER ADDRESS

6747 DMAN

"MAINTENANCE IOT" LOAD THE MAINTENANCE REGISTER FROM THE AC, THE FUNCTION IS REGULATED BY THE AC BITS. MAINTENANCE MODE CAN ONLY BE CLEARED BY DCLK "CLEAR CONTROL".

AC
--

0	ENTER MAINTENANCE MODE
1	ENABLE SHIFT TO LOWER BUFFER
2	AC BIT 10, CRC REGISTER, AND THE LOWER DATA BUFFER ARE CONNECTED AS A SHIFT REGISTER. AC BIT 10 DATA SHIFTS TO THE CRC, THE CRC SHIFTS TO THE LOWER DATA BUFFER.
3	SHIFT COMMAND REGISTER TO THE LOWER DATA BUFFER.
4	SHIFT THE SURFACE AND SECTOR REGISTER TO THE LOWER DATA BUFFER.
5	SHIFT AC 10 DATA TO THE UPPER DATA BUFFER. THE UPPER BUFFER SHOULD SINK IN THE SILO WHEN FULL.
6	ONE SINGLE CYCLE BREAK REQUEST. DIRECTION IS REGULATED BY FUNCTION IN THE COMMAND REGISTER.
7	CLEAR AC THEN READ THE LOWER DATA BUFFER TO THE AC.
8	NOT USED.
9	NOT USED.
10	USED AS DATA WITH OTHER BITS IN THE MAINTENANCE MODE.
11	NOT USED

8.

PROGRAM DESCRIPTION (ACCEPT MODE)

THE FOLLOWING IS BRIEF DESCRIPTION OF THE STEPS TAKEN BY THE PROGRAM WHEN RUNNING THE ACCEPT MODE.

A. A RANDOM FIELD IS GENERATED. IF FIELD GENERATED IS A NON-EXISTING FIELD, THE MAXIMUM FIELD AVAILABLE WILL BE USED.

- B. A RANDOM BLOCK LENGTH IS GENERATED (128 OR 256 WORD SECTORS).
- C. A RANDOM AMOUNT OF SEQUENTIAL SECTORS TO TRANSFER IS GENERATED. IF THE FIELD PREVIOUSLY SELECTED WAS AN EXTENDED FIELD OR IF HALF BLOCK TRANSFERS WERE SELECTED (128 WORD SECTORS), THE AMOUNT OF SECTORS WILL BE LIMITED TO 17(8). IF THE FIELD SELECTED WAS FIELD 0 AND IF FULL BLOCK TRANSFERS WERE SELECTED (256 WORD SECTORS), THE AMOUNT OF SECTORS WILL BE LIMITED TO 7(8).
- D. A RANDOM STARTING SECTOR WILL BE GENERATED. THE RANDOM AMOUNT OF EXTRA SECTORS PREVIOUSLY GENERATED WILL BE ADDED TO THIS STARTING SECTOR, DETERMINING THE ACTUAL LENGTH OF THE DATA TRANSFER. IF THE STARTING SECTOR WAS 14 AND THE AMOUNT OF EXTRA SECTORS WAS 6, SECTORS 14, 15, 16, 17, 00, 01, AND 02 WILL BE USED FOR TRANSFERING DATA.
- E. AN INITIAL SOFTWARE WORD COUNT WILL BE CALCULATED.
- F. AN INITIAL RANDOM CURRENT ADDRESS WILL BE GENERATED. IF THE FIELD PREVIOUSLY GENERATED WAS FIELD 0, THE CURRENT ADDRESS WILL BE LIMITED WITHIN THE END OF THE PROGRAM +4000 LOCATIONS.
- G. THE BUFFER SELECTED WILL BE FILLED WITH RANDOM DATA, CHECKSUMMED, AND THE CHECKSUM SAVED. (NOTE: BUFFER IS DEPENDENT ON FIELD, WORD COUNT, BLOCK LENGTH, AND CURRENT ADDRESS PREVIOUSLY SELECTED.)
- H. THE PROGRAM WILL THEN POLE THE DISK DRIVES, DRIVE SELECTION IS SEQUENTIAL, THAT IS DISK0, DISK1, DISK2, ETC.
- I. DATA WILL BE WRITTEN ON THE SELECTED DISK DRIVE TO COMPLETE THE SEEK OPERATION USING THE RANDOM PARAMETERS GENERATED ABOVE. AS DATA IS WRITTEN, A BACK GROUND PROGRAM WILL CLEAR THE BUFFER AREA ALREADY WRITTEN ON THE DISK.
- J. WHEN THE WRITE AND CLEAR IS COMPLETE, DATA WILL BE READ OFF THE CURRENT DRIVE INTO THE BUFFER AREA. AS DATA IS READ, A BACK GROUND PROGRAM WILL CHECKSUM THE BUFFER INFORMATION ALREADY READ OFF THE DISK.
- K. WHEN THE READ AND CHECKSUM IS COMPLETE, THE CHECKSUM FOUND WILL BE COMPARED TO THE CHECKSUM SAVED PREVIOUS TO THE WRITE OPERATION. IF CHECKSUMS DO NOT COMPARE OR IF A CRC ERROR HAS OCCURRED, A WORD BY WORD COMPARE WILL BE MADE TO DETERMINE AND TYPE OUT THE BAD DATA FOUND.
- L. STEPS A-H WILL BE REPEATED AND THE DRIVE POLE WILL BE STARTED AT THE CURRENT DRIVE +1.
- M. FOR ALL POSSIBLE ERRORS, SEE SECTION 5 IN THIS DOCUMENT.

9.

CONSOLE PACKAGE ADDENDUM

9.1. DESCRIPTION

THE CONSOLE PACKAGE HAS BEEN ADDED TO THIS DIAGNOSTIC TO ALLOW THE PROGRAM TO RUN WITH NO HARDWARE SWITCH REGISTER AND TO HAVE COMMUNICATIONS WITH THE DIAGNOSTIC VIA A TERMINAL. THE DIAGNOSTIC CAN BE RUN IN TWO MODES WITH THE CONSOLE PACKAGE . 1) RUNNING WITH THE CONSOLE PACKAGE ACTIVE - THIS ALLOWS THE OPERATOR CONTROL OF THE DIAGNOSTIC THROUGH THE TERMINAL. THE DIAGNOSTIC WILL ASK FOR THE VALUE OF THE PSEUDO SWITCH REGISTER, BEFORE CONTINUING WITH EXECUTION OF THE DIAGNOSTIC. ALL ERRORS AND PASS COMPLETES WILL BE PRINTED AT THE TERMINAL. NO HALTS WILL BE EXECUTED. 2) CONSOLE PACKAGE NOT ACTIVE-THIS WILL RESULT IN THE NORMAL STANDALONE OPERATION OF THE PROGRAM AS DISCRIBED IN SECTIONS 1 THROUGH 8 OF THIS DUCUMENT,

9.2 RESTRICTIONS

- 1) RUNNING THE CONSOLE PACKAGE REQUIRES THAT THE PSEUDO SWITCH REGISTER BE USED.
- 2) ONCE RUNNING THE CONSOLE PACKAGE NONACTIVE AND NOW DESIRE TO RUN IT ACTIVE, ONE MUST RELOAD THE DIAGNOSTIC AND INITILIZE FOR A ACTIVE CONSOLE PACKAGE.

9.3 INITIALIZATION

FOR A ACTIVE CONSOLE PACKAGE

- 1.) SET LOCATION 21 BIT0=0 TO INDICATE USE PSEUDO SWITCH REGISTER.
- 2.) SET LOCATION 22 BITS=1 TO INDICATE CONSOLE PACKAGE ACTIVE.

FOR A NON ACTIVE CONSOLE PACKAGE

- 1.) SET LOCATION 21 BIT0=1 TO INDICATE NOT TO USE PSEUDO SWITCH REGISTER, BUT TU USE HARDWARE SWITCHES.
- 2.) SET LOCATION 22 BITS=0 TO INDICATE CONSOLE PACKAGE NOT ACTIVE.

9.4 CONTROL CHARACTERS

CONTROL CHARACTERS ARE USED TO GIVE THE OPERATOR THE

ABILITY TO PERFORM THE FOLLOWING FUNCTIONS.
NOTE: THE PROGRAM WILL RESPOND TO THE CONTROL
CHARACTER IN FIVE (5) SECONDS OR LESS.

CONTROL C

THIS WILL START THE LOADER THAT IS
IN LOCATION 7600.

CONTROL R

THIS WILL RESTART THE PROGRAM AND
REASK THE SWITCH REGISTER QUESTION AS
DESCRIBED IN SECTION 9.6.

CONTROL E

THIS WILL CONTINUE THE PROGRAM FROM
AN ERROR IF ALLOWED BY THE DIAGNOSTIC
OR FROM A WAITING STATEMENT.

CONTROL L

THIS WILL SWITCH THE TERMINAL MESSAGES
FROM THE DISPLAY TO A LINE PRINTER.
TO RESTORE THE MESSAGES ON THE TERMINAL
CONTROL L MUST BE TYPED AGAIN. IF
NO PRINTER IS AVAILBLE AND CONTROL L
IS TYPED THE RESULT WILL BE THAT THE
CONSOLE PACKAGE WILL WAIT FOR CONTROL C OR R.
THE CONTROL L WILL OUTPUT TO THE LINE
PRINTER AND THE PROGRAM WILL
ATTEMPT TO CONTINUE AS IF A CONTROL E
WAS TYPED IN.

CONTROL D

THIS WILL ALLOW THE ABILITY TO CHANGE
THE SWITCH REGISTER DURING PROGRAM
OPERATION. TYPING THIS CHARACTER WILL RESULT
IN AN INTERIGATION OF THE SWITCH REGISTER
QUESTION AS DESCRIBED IN SECTION 9.6.

CONTROL S

THIS WILL STOP PROGRAM EXECUTION AND WAIT IN A
LOOP FOR A CONTINUE. THE ONLY WAY TO CONTINUE
WILL BE TO TYPE A CONTROL Q, R OR C .
THIS IS A NONPRINTING CHARACTER.

CONTROL Q

THIS IS TO CONTINUE A PROGRAM AFTER A CONTROL
S IS TYPED. THIS IS A NONPRINTING CHARACTER.

9.5

WAITING MESSAGE

THE WAITING MESSAGE IS USED TO ALLOW THE OPERATOR TIME
TO MAKE A DECISION AS TO WHAT CONTROL CHARACTER
TO TYPE. THIS MESSAGE MAY APPEAR AT THE END
OF PASS MESSAGE IF THE HALT ON PASS BIT IS SET. THE CONTROL
CHARACTERS MAY NOW BE USED TO PERFORM THE NEEDED FUNCTION.

THE WAITING MESSAGE MAY BE PRINTED AFTER A ERROR MESSAGE IF THE HALT ON ERROR BIT IS SET, HERE AGAIN THE CONTROL CHARACTERS MAY BE USED. THE WAITING MESSAGE MAY BE PRINTED IF OPERATOR INTERVENTION IS REQUIRED.

9.6 SWITCH REGISTER MESSAGE

THIS MESSAGE IS USED TO SETUP THE PSEUDO SWITCH REGISTER BEFORE PROGRAM EXECUTION TAKES PLACE. THE SWITCH REGISTER IS SETUP WHEN THE FOURTH CHARACTER IS ENTERED OR A CARRIAGE RETURN IS TYPED

SR=0000 4000

UNDER SCORING INDICATES OPERATOR RESPONSE

9.7 END OF PASS

THE NORMAL PASS COMPLETE TYPEOUT AS DESCRIBED IN SECTION 5.5 IS USED.

9.8 ERRORS

THE STANDARD ERROR REPORTS AS DESCRIBED IN SECTION 5 OF THIS DOCUMENT WILL BE USED.

9.9 SWITCH REGISTER SETTINGS

THE STANDARD SWITCH SETTINGS AS DESCRIBED IN SECTION 3 OF THIS DOCUMENT WILL BE USED.

9.10 PARAMETER CONTROL WORDS

THE CONSOLE PACKAGE USES THE LUCATIONS 20 21 22 FOR THE FOLLOWING PURPOSES.

LOCATION 20
PSEUDO SWITCH REGISTER

LOCATION 21
HARDWARE IDENTIFIER 1

LOCATION 22

HARDWARE IDENTIFIER 2

LOCATION 0021

BIT ---	OCTAL VALUE	FUNCTION WHEN 0	FUNCTION WHEN 1
0	4000	USE PSEUDO SWITCHES	USE HARDWARE SWITCHES
1	2000	NO OPTION 1	HAS OPTION 1
2	1000	NO OPTION 2	HAS OPTION 2
3	400	NO 8A SIMULATOR	HAS 8A SIMULATOR
4	200	NO OPTION SIMULATOR	HAS OPTION SIMULATOR
5	100	NOT ON 8A XOR	ON 8A XOR
6	40	NOT PDP8-E TYPE CPU	PDP8-E TYPE CPU

7-11

8A MEMORY SIZE EX. 1K=00
2K=01
7K=06

32K=31

LOCATION 0022

BIT ---	OCTAL VALUE	FUNCTION WHEN 0	FUNCTION WHEN 1
0	4000	NOT ON ACT 8A LINE	ON ACT 8A LINE
1	2000	NOT ON ACT 8E LINE	ON ACT 8E LINE
2	1000	NOT YET DEFINED	
3	400	DEACTIVE CONSOLE PACKAGE	ACTIVE CONSOLE PACKAGE

9.11

LOCATION CHANGES
.....

THE FOLLOWING FIELD 1 LOCATIONS CAN BE CHANGED TO MEET THE SPECIFIC NEED FOR MODIFICATION OF THE DIAGNOSTIC.

0246

IS THE LOCATION FOR THE VALUE OF THE NUMBER OF PROGRAM PASSES NEED TO PRINT THE END OF PASS MESSAGE.

1037

IS THE LOCATION SET FOR THE NUMBER OF FILLER CHARACTERS AFTER A CRLF SET TO FOUR (4)

10.

APT-8 HOOKS
.....

10.1 DESCRIPTION

TWO INTERFACES HAVE BEEN PROVIDED WHICH ALLOW THIS DIAGNOSTIC TO RUN UNDER THE STANDARD APT-8 SYSTEM. THESE INTERFACES ARE:

1. TIMING INTERFACE
2. ERROR INTERFACE

EACH WILL BE EXPLAINED IN DETAIL.

10.2 SETUP

THE FOLLOWING INFORMATION MUST BE INDICATED DURING THE INITIAL PROGRAM START UP.

1. SINGLE OR MULTIPLE DRIVE TESTING.
2. DRIVE OR DRIVES TO BE TESTED.
3. DIAGNOSTIC RUNNING UNDER APT-8.
4. THE AMOUNT OF MEMORY IN 1K INCREMENTS.

IF SINGLE DRIVE TESTING BIT 5 OF ADDRESS 22 MUST BE SET TO A ONE (1) WITH BITS 6-11 CONTAINING THE DRIVE TO BE TESTED. IF MULTIPLE DRIVES ARE TO BE DONE BIT MUST BE SET TO A ZERO (0) AND BIT 6-11 CONTAINING THE HIGHEST NUMBER DRIVE TO BE TESTED. WHEN MULTIPLE DRIVE TESTING ONLY A SPECIFIC NUMBER OF DRIVES CAN BE INDICATED. THE PROGRAM ASSUMES THE DRIVES ARE TO BE DONE BEGINNING WITH DRIVE ZERO (0) AND FINISHING WITH THE HIGHEST DRIVE INDICATED. IF MULTIPLE DRIVES OTHER THAN CONSECUTIVELY NUMBERED DRIVES BEGINNING WITH DRIVE ZERO (0) ARE TO BE DONE, THEY MUST BE DONE AS SINGLE DRIVES AND TESTED INDEPENDANTLY.

THE PROGRAM ALLOWS DRIVES 0-7 TO BE SELECTED. USER SHOULD NOT EXCEED 0-3 DRIVES FOR THE MK8E CONTROL.

BIT ZERO OF ADDRESS 22 MUST BE SET TO A ONE TO INDICATE THAT THE PROGRAM WILL RUN UNDER APT-8.

NOTE: IT SHOULD BE NOTED AT THIS TIME THAT WHILE RUNNING UNDER APT-8 THE HARDWARE SWITCH REGISTER IS INOPERATIVE. ONLY THE HALT AND SINGLE STEP SWITCH WILL EFFECT THE PROGRAM RUN.

AMOUNT OF MEMORY IN 1K INCREMENTS SHOULD BE STORED IN BITS 7-11 OF LOCATION 21. AN ADDITION OF 1 TO THE NUMBER OF BITS IN 7-11 INCREASES MEMORY SIZE BY 1K. EX, 4K=3/8K=7. REMEMBER TO RETAIN STATUS OF BITS WHEN MODIFYING LOCATION 21.

APT-8 INTERFACES:

10.3.1. TIMING

APT-8 IS NOTIFIED OF PROGRAM RUN BETWEEN .2 SEC AND 2.0 SEC ON A 1.2 MICROSECOND MEMORY CYCLE. THIS WILL ALLOW THE DIAGNOSTIC TO RUN WITHOUT CAUSING AN APT-8 TIMEOUT ERROR IF THE DIAGNOSTIC IS TO BE RUN ON ON THE SLOWER MOS MEMORY.

10.3.2. ERRORS

ONLY THE DRIVE IN ERROR IS REPORTED TO APT-8 SYSTEM, SYSTEM. ERRORS WHICH CAUSE A PROGRAMMED HALT CAUSE A TIMEOUT ERROR, IF A PROGRAMMED HALT SHOULD OCCUR, THE ERROR PC WILL APPEAR IN THE AC ON THE DEVICE UNDER TEST. PROGRAMMED HALTS ARE EXPLAINED EARLIER IN THIS DOCUMENT.

11. PROGRAM LISTING

```

/RK8E/RK8L DATA RELIABILITY PROGRAM: MU=88-DHRKC=M
/
/MAINDEC=88-DHRKC=M-L
/COPYRIGHT 1972,1975,1976,1977 DIGITAL EQUIP. CORP.
/
/MAYNARD, MASS. 01754
/
0001 FIELD 1
/
/CONSOL SRC=V2=RD= CONSOLE PACKAGE
/
/THE PROGRAM SHOULD CHECK FOR A CONTROL CHARACTER FROM THE TERMINAL
/EVERY FIVE(5) SECONDS OR SOONER.
/LUICATIONS THAT NEED TO BE SET UP FOR USING THE CONSOLE PACKAGE.
/
/CNTVAL IN XC8PASS THIS LOCATION DETERMINDS THE NUMBER OF
/PROGRAM COMPLETIONS THAT ARE NEEDED BEFORE THE PASS MESSAGE IS TYPED
/THE VALUE SHOULD PUT THE PASS MESSAGE OUT IN THE RANGE OF 1 TO 5 MINUTES.
/THIS SHOULD BE A POSITIVE NUMBER.
/
/C8BSTRY THIS IS FOUND IN CNTRL ROUTINE CONTROL R PART
/IT IS THE RETURN WHEN CONTROL R IS ENTERED (RESTART PROGRAM)
/THE RETURN JUMPS TO X888H WHICH CONTAINS C8BSTRY SO PUT THE LABEL C8BSTRY
/WHERE YOU WANT TO RESTART THE PROGRAM.
/
/SETUP1 IN XC8ERR THIS IS THE MASK BIT FOR HALT ON ERROR
/PLACE THE CORRECT BIT IN THIS LOCATION FOR HALTING ON ERRORS.
/
/SETUP2 IN XC8PASS THIS IS THE MASK FOR HALT A END OF PASS.
/
/THE CALL TABLE IS A CONDITIONAL ASSEMBLY.
/TO ASSEMBLE THE CALL REMOVE THE / BEFORE CONSOL=0.
/IN COMBINING THE CONSOL PACKAGE TO A DIAGNOSTIC.
/THE CALL TABLE IS TO BE AT THE BEGINNING OF A PROGRAM.

```

```

0000 CONSOL=0
0001 PSKF= 0001
0002 PCLF= 0002
0003 PSKE= 0003
0004 PSTB= 0004
0005 PSIE= 0005
0006 GTF= 0006
0007 ACL= 7701
0007 CAF= 0007
0021 MQL= 7421
0021 MGA= 7501
/
0020 *20
/
0020 0000 F15HR, 0
0021 4000 F10P1, 4000

```

```

0022 0000 F10P2, 0
/
/IFDEF CONSOL <
/
0024 *24
/
0024 4424 C8PASS= JMS I . /C8 PASS COMPLETION ROUTINE
0200 XC8PAS
4425 C8CKSW= JMS I . /CHECK SW REG SETTING
0025 0262 XC8SW
4426 C8TTYI= JMS I . /FETCH CONSOL CHAR
0026 0272 XC8TTY
4427 C8CNTR= JMS I . /CHECK FOR CONTROL CHAR
0027 0400 XC8CNT
4430 C8PRNT= JMS I . /C8 PRINT A BUFFER
0030 0303 XC8PNT
4431 C8SWIT= JMS I . /SET UP PSEUDO SW, REG
0031 0656 XC8PSW
4432 C8OCTA= JMS I . /CONVERT TO ASCII AND PRINT
0032 1000 XC8OCT
4433 C8CRLF= JMS I . /OO A CARRIGE RETURN+ LINE FEED
0033 1023 XC8CRL
4434 C8ECHO= JMS I . /CHECK INPUT CHAR
0034 1063 XC8ECH
4435 C8TYPE= JMS I . /C8 PRINT ONE CHAR
0035 1077 XC8TYP
4436 C8ERR= JMS I . /C8 ERROR HANDLER
0036 1207 XC8ERR
4437 C8INQU= JMS I . /LOOK FOR OPERATOR INTERVENTION
0037 0635 XC8ING
4440 C8CKPA= JMS I . /CHECK IF CONTROL CHAR
0040 1041 XC8CKP
4441 C8PAUS= JMS I . /IF CONSOL PACKAGE RETURN CALL PLUS ONE
0041 0337 XC8PAU /IF NOT USING CONSOL REPLACE CALL WITH
/ A HLT AND THEN GO TO THE HALT
/
/*****
/*20 /PSEUDO SWITCH REGISTER
/
/*21 /HARDWARE INDICATORS
/4000=USE FRONT PANEL SWITCH REGISTER
/0000=USE THE PSEUDO SWITCH REGISTER LOC,20
/
/*22 /SYSTEM CONFIGURATION
/400=CONSOL PACKAGE SET ACTIVE
/0000=CONSULE PACKAGE SET DEACTIVE
/
/*23 /RESERVED FOR FUTURE USE
/
0200 *200
/
/*****
/C8PASS

```

```

/THIS IS CALLED AT THE END OF EACH PROGRAM COMPLETION
/THE VALUE OF** CNTVAL** WILL BE DETERMINED BY THE TIME IT TAKES
/THE PROGRAM TO COMPLETE THIS MANY C&PASS TO BE IN THE 1 TO 4 MINUTE
/RANGE
/ C&PASS=JMS XC&PAS
/EX. OF CALL C&PASS
/
/ JMS XC&PAS /MALT IF NON CONSOL PACKAGE
/ JMS START1 /CONTINUE RUNNING THIS PROGRAM

```

```

/RETURN TO LOCATION CALL PLUS ONE WITH THE AC=0 IF NON CONSOL PACKAGE AND HLT
/IF CONTINUE TO RUN THEN RETURN TO CALL PLUS2 AC=0
/THE LOCATION SETUP2 IS THE MASK BIT FOR THE MALT AT END OF PASS
/CHECK THAT IT IS CORRECT FOR THE CURRENT PROGRAM

```

/CALLS USED BY XC&PAS ARE CHKCLA=XC&CCLF=XC&OCTA=XC&SW=XC&PNT=XC&INO=

```

0200 0000 XC&PAS, 0
0201 7200 CLA
0202 4777 JMS CHKCLA /IS WORD 22 BIT 3 ACTIVE CONSOLE?
0203 5212 JMP DOPACK /IS CLASSIC
0204 4776 JMS C&GET /GET REGISTERS.
0205 4262 JMS XC&SW /DEACTIVE CONSOL CHECK SR SETTING
0206 0375 AND (400 /FOR MALT ON END OF C&PASS
0207 7640 SZA CLA /IS MALT 0 CONTINUE
0210 5000 JMP I XC&PAS /GO TO MALT
0211 5230 JMP C&BY1 /CONTINUE ON RUNNING PROGRAM
0212 4232 DOPACK, JMS CKCOUT /CLASS CHECK C&PASS COUNT
0213 5230 JMP C&BY1 /C&PASS COUNT NOT DONE REDO PROGRAM
0214 2250 ISZ P&CNT /C&PASS COUNT DONE SET C&PASS COUNT
0215 4774 JMS XC&CRLF
0216 4303 JMS XC&PNT /C&PNT BUFFER
0217 0253 M&SPAS
0220 1250 TAD P&CNT /GET NUMBER
0221 4773 JMS XC&OCTA /CONVERT IT TO ASCII
0222 4774 JMS XC&CRLF /DO A CARRIAGE RETURN
0223 4776 JMS C&GET /GET REGISTERS.
0224 4262 JMS XC&SW /CHECK A MALT AT END OF C&PASS
0225 0375 SETUP2, AND (400 /MASK BIT
0226 7640 SZA CLA /MALT 01 NO SKIP CONTINUE =0
0227 4772 JMS XC&INO /MALT 01 NO SKIP CONTINUE =0
0230 2200 C&BY1, ISZ XC&PAS /STOP PROGRAM EXECUTION-LOOK FOR INPUT
0231 5000 JMP I XC&PAS /BUMP RETURN
0232 0000 CKCOUT, 0
0233 1251 TAD DO&ET /CHECK IF SET UP NEEDED
0234 7640 SZA CLA /SET UP C&PASS COUNT VALUE
/IS C&PASS COUNT VALUE OK
/C&PASS COUNT VALUE ON
/GET COUNT VALUE FOR THIS PROG
/SET TO NEGATIVE
/STORE IN HERE
/INDICATE VALUE SET UP
/COUNT THE NUMBER OF PASSES
/EXIT FOR ANOTHER PASS
0235 5242 JMP NO&ET
0236 1252 TAD CNTVAL
0237 7040 CMA
0240 3247 DCA DO&NT
0241 2251 ISZ DO&ET
0242 2247 NO&ET, ISZ DO&NT
0243 5230 JMP C&BY1

```

```

0244 3251 DCA DO&ET /SET TO C&PNT C&PASS
0245 2232 ISZ CKCOUT /BUMP RETURN FOR
0246 5632 JMP I CKCOUT /C&PASS C&TYPE OUT
0247 0000 DO&NT, 0
0250 0000 P&CNT, 0
0251 0000 DO&ET, 0
0252 0000 CNTVAL, 0
0253 0410 M&SPAS, TEXT "DHRKCH PASS "
0254 2213
0255 0310
0256 4040
0257 2001
0260 2323
0261 4000

```

```

/C&CKSW
/THIS ROUTINE CAN BE USED INPLACE OF A READ THE SWITCHES LAS.
/ROUTINE THAT WILL CHECK WHERE TO READ THE
/C& SWITCHES FROM IE. FROM PANEL OR P&SUDD SWITCH REGISTER
/THE SELECTION IS DETERMINED BY THE STATE OF BIT 0 IN LOCATION 21.

```

```

/C&CKSW= JMS XC&SW
/EX. JMS XC&SW /READ THE C&SWIT REGISTER
/RETURN WITH THE CONTENTS OF SWITCH REGISTER

```

/RETURN TO NEXT LOCATION FOLLOWING CALL WITH THE AC= TO VALUE OF C&SWIT SETTING

/CALLS USED ARE=XC&CKPA=

```

0262 0000 XC&SW, 0
0263 4771 JMS XC&CKPA /GO CHECK THE IF ANY CONTRL
0264 7000 NOP
0265 1021 TAD 21 /GET MU FOR INDICATOR
0266 7710 SPA CLA /CHECK IF FROM PANEL 4000
0267 7614 7614 /DO LAS AND SKIP GET FROM PANEL WITH LAS
0270 1020 TAD 20 /P&SUDD SWITCH
0271 5662 JMP I XC&SW /EXIT WITH STATUS BIT IN AC.

```

```

/C&TTY1
/THIS ROUTINE WILL LOOK FOR A INPUT FROM THE TERMINAL
/AND REMOVE ANY PARITY BITS, THEN MAKE IT 8 BIT ASCII.
/ C&TTY1= JMS XC&TTY1
/EX. JMS XC&TTY1 /READ CHAR FROM THE CONSOL DEVICE
/RETURN TO CALL PLUS ONE AC CONTAINS THE CHAR

```

/CALLS USED=NONE- BUT C8CHAR IS OFF PAGE AND IN ROUTINE CALLED XC8ECHO

```

/
/
0272 0000 XC8TTY, 0
0273 0031 KSF /LOOK FOR KEYBOARD FLAG
0274 5273 JMP =-1
0275 0036 KRB /GET CHAR
0276 0370 AND (177 /MASK FOR 7 BITS
0277 1307 TAD (200 /ADD THE EIGHTH BIT
0300 3706 DCA C8CHAR /STORE IT
0301 1706 TAD C8CHAR
0302 5672 JMP I XC8TTY /EXIT

```

/C8PNT

/THIS ROUTINE WILL TYPE THE CONTENTS OF THE C8 PRINT BUFFER, THE LOCATION /OF THE BUFFER WILL BE IN THE ADDR8 FOLLOWING THE CALL, PRINTING OF THE BUFFER /WILL STOP WHEN A 00 CHAR IS DETECTED, CHARACTERS ARE PACKED 2 PER WORD.

/ C8PNT= JMS XC8PNT

/EX. JMS XC8PNT /C8PNT THE CONTENTS OF THE FOLLOWING BUFFER
/ MESS77 /LOCATION OF C8PNT BUFFER

/C8PNT WILL USE THE LOCATION FOLLOWING THE CALL AS THE POINTER FOR THE /C8PNT ROUTINE, RETURN TO CALL PLUS TWO WITH AC= 0

/CALLS USED ARE=XC8TYPE=XC8PNT

```

0303 0000 XC8PNT, 0
0304 7300 CLA CLL
0305 1703 TAD I XC8PNT /GET C8PNT BUFFERS STARTING LOCATION
0306 3336 DCA PT8TOR /STORE IN PT8TOR
0307 2303 ISZ XC8PNT /BUMP RETURN
0310 1736 C8D01, TAD I PT8TOR /GET DATA WORD
0311 0365 AND (7700 /MASK FOR LEFT BYTE
0312 7450 SNA /CHECK IF 00 TERMINATE
0313 5703 JMP I XC8PNT /EXIT
0314 7500 SMA /IS AC MINUS
0315 7020 CML /MAKE CHAR A 300 AFTER ROTATE
0316 7001 IAC /MAKE CHAR A 200 AFTER ROTATE
0317 7012 RTR
0320 7012 RTR
0321 7012 RTR
0322 4704 JMS XC8TYPE /PUT CHAR IN BITS 4-11 MAKE IT 8 BIT ASCII
0323 1736 TAD I PT8TOR /C8PNT IT ON CONSOLE
/GET DATA WORD

```

```

0324 0303 AND (0077 /MASK FOR RIGHT BYTE
0325 7450 SNA /CHECK IF 00 TERMINATOR
0326 5703 JMP I XC8PNT //EXIT
0327 1302 TAD (3740 /ADD FUDGE FACTOR TO DETERMINE IF 200
0330 7500 SMA /OR 300 IS TO BE ADD TO CHAR
0331 1301 TAD (100 /ADD 100
0332 1300 TAD (240 /ADD 200
0333 4704 JMS XC8TYPE /C8TYPE ONLY BITS 4-11
0334 2336 ISZ PT8TOR /BUMP POINTER FOR NEXT WORD
0335 5310 JMP C8D01 /DO AGAIN
0336 0000 PT8TOR, 0 /STOP FOR C8PNT BUFFER

```

/C8PAUS

/THIS ROUTINE WILL CHECK IF THE CONSOL PACKAGE IS ACTIVE, IF ACTIVE /IT WILL RETURN TO CALL PLUS ONE AC= 0, AND DO THAT INSTRUCTION, /IF THE CONSOL PACKAGE IS NOT ACTIVE THE CALL WILL BE REPLACED /WITH A 7402 HALT AND THEN RETURN TO THE HALT.

/ C8PAUS= JMS XC8PAU

/EX. JMS XC8PAUS /CHECK IF ON ACTIVE CONSOL IF NOT HALT HERE
/ ANYTHING /RETURN HERE IF ON ACTIVE CONSOL

/CALLS USED ARE=CHKCLA=

```

0337 0000 XC8PAU, 0
0340 7300 CLA CLL
0341 4777 JMS CHKCLA /CHECK LOC 22 BIT 3 CONSOLE BIT
0342 5350 JMP C8D03 /GO DO CONSOL PART RETURN CALL+1
0343 7040 CMA /DEACTIVE CONSOL PACKAGE PUT MLT IN CALL
0344 1337 TAD XC8PAU /GET CURRENT RETURN ADDR8
0345 3337 DCA XC8PAU /SET UP RETURN
0346 1357 TAD (7402 /GET CODE FOR MLT
0347 3737 DCA I XC8PAU /PUT HALT IN CALL LOCATION
0350 5737 C8D03, JMP I XC8PAU /GO TO HALT OR RETURN TO NEXT LOCATION

```

- 0357 7402
- 0360 0240
- 0361 0100
- 0362 3740
- 0363 0077
- 0364 1077
- 0365 7700
- 0366 1075
- 0367 0200
- 0370 0177
- 0371 1041

0372 0635
0373 1000
0374 1023
0375 0400
0376 0624
0377 1200
0400

PAGE

/*****

/C0CNTM

/THIS ROUTINE WILL CHECK FOR THE PRESENCE OF CONTROL CHARACTERS
/IT WILL CHECK FOR THE FOLLOWING CHAR C-N-U-L-S
/C0CNTM JMS XC0CNT

/EX. JMS XC0CNT /CHECK FOR CONTROL CHARACTER
/ JMS ANYTHING /LOC FOLLOWING CALL IS FOR CONTINUING THE PROGRAM
/ JMS ANYTHING /LOC. IS FOR RETURN IF INMODE SET AND NOT CNTRL CHAR

/RETURN IS TO CALL PLUS ONE IF CONTINUE
/RETURN IS TO CALL PLUS TWO IF INMODE SET AND NOT CONTROL CHAR
/RETURN IS TO CALL PLUS TWO IF INMODE IS NOT SET AND NO
/CNTRL CHAR .,THIS WILL PRINT THE CHARACTER AND A ?
/CLEAR THE AC AND RETURN CALL+2.

/CALLS USED ARE-CMKCLA=XC0TYPE=XC0CRLF=C0GET=UPARON=XC0TYI=XC0PSW=

0400 0000 XC0CNT, 0
0401 3777* DCA ACSAVE /SAVE THE AC
0402 4776* JMS CMKCLA /CHECK LOC.22 BITS FOR CONSOLE BIT
0403 5206 JMP ,+3 /ON ACTIVE CONSOLE
0404 1777* TAD ACSAVE /DEACTIVE CONSOLEGET AC FOR RETURN
0405 5600 JMP I XC0CNT /EXIT NOT ON ACTIVE CONSOLE
0406 6004 GTF
0407 3775* DCA FLSAVE
0410 7501 MGA
0411 3774* DCA MGSAVE /SAVE THE M0
0412 3255 DCA INDEXA /SET DISPLACEMENT INTO TABLE 0
0413 1257 TAD XTABLA /GET ADDR OF TABLE A
0414 3256 DCA GETDAT /CONTAINS POINTER TO CONTROL CHAR
0415 1656 REDDA, TAD I GETDAT /GET CONTROL CHAR FROM TABLE
0416 7450 SNA /CHECK FOR A 0 END OF TABLE
0417 5226 JMP DONEA /END OF TABLE NO CONTROL CHAR
0420 1773* TAD C0CHAR /COMPARE CHAR TO CONTROL CHAR
0421 7650 SNA CLA /0 IF MATCH
0422 5243 JMP GOITA /MATCH
0423 2255 ISZ INDEXA /NO MATCH NOT END OF TABLE REDD
0424 2256 ISZ GETDAT /BUMP INDEX FOR EXIT WHEN CONTROL FOUND
0425 5215 JMP REDDA /BUMP GETDAT FOR COMPARE OF NEXT CNTRL CHAR.
0426 1772* DONEA, TAD INMODE /CHECK IF PROGRAM EXPECTS CHAR
0427 7640 SZA CLA /1=CHAR EXPECTED 0= NO CHAR EXPECTED
0430 5240 JMP EXITA /CHAR EXPECTED

0431 1773* TAD C0CHAR /GET CHAR= NOT CONTROL+ NOT EXPECTED
0432 4771* JMS XC0TYPE /C0PMNT CHAR
0433 1370 TAD (277 /GET CODE FOR "7"
0434 4771* JMS XC0TYPE
0435 4767* JMS XC0CRLF
0436 2200 ISZ XC0CNT /BUMP RETURN
0437 5600 JMP I XC0CNT /EXIT CALL+2
0440 2200 EXITA, ISZ XC0CNT /BUMP RETURN FOR MAIN PROGRAM CHECK OF CHAR
0441 1773* TAD C0CHAR /PUT CHAR IN AC.
0442 5600 JMP I XC0CNT /EXIT
0443 1773* GOITA, TAD C0CHAR /GET THE CONTENTS OF CHAR
0444 1366 TAD (100 /ADD 100 TO FORM A GOOD ASCII CHARACTER
0445 3773* DCA C0CHAR /RESTORE COFFECT CHAR
0446 1260 TAD XTABLB /GET START OF TABLE B
0447 1255 TAD INDEXA /GET NUM F \ INTO TABLE
0450 3254 DCA GOT0A /STORE IT
0451 1654 TAD I GOT0A /GET THE ROUTINE STARTTING ADDRESS
0452 3254 DCA GOT0A /STORE IT IN HERE
0453 5654 JMP I GOT0A /GOTO CONTROL CHAR ROUTINE
0454 0000 GOT0A, 0000 /ADD OF CNTRL ROUTINE TO EXECUTE
0455 0000 INDEXA, 0000 /DISPLACEMENT INTO CNTRL TABLE
0456 0000 GETDAT, 0000 /LOCATION OF ADDR OF CONTROL CHAR.
0457 0461 XTABLA, TABLA /ADDMS OF TABLEA
0460 0471 XTABLB, TABLB /ADDMS OF TABLEB
0461 7575 TABLA, 7575 /CNTRL C BACK TO MONITOR 203
0462 7564 7564 /CNTRL L SWITCH ERROR PRINTTING DEVICE 214
0463 7557 7557 /CNTRL R START DISPLAYING CHAR, AGAIN 221
0464 7556 7556 /CNTRL R BACK TO BEGINNING OF PROGRAM 222
0465 7555 7555 /CNTRL S STOP SENDING CHAR TO DISPLAY WAIT FOR CNTRL Q 223
0466 7573 7573 /CNTRL E CONTINUE WITH PROGRAM 205
0467 7574 7574 /CNTRL D CHANGE SWITCH REGISTER ON FLY
0470 0000 0000

0471 0551 TABLB, CNTRL C
0472 0537 CNTRL L
0473 0500 CNTRL R
0474 0511 CNTRL S
0475 0521 CNTRL E
0476 0545 CNTRL D
0477 0600 CNTRL D

/CNTRL Q
/START SENDING CHAR. TO THE DISPLAY
/THIS WILL RETURN CONTROL TO CALL THAT WAS SET BY
/THE CALL FOR CONTROL S.

0500 3772* CNTRLQ, DCA INMODE /SET SUFT FLAG FOR UNEXPECTED CHAR
0501 1335 TAD C0SETS /CHECK IF CONTROL S TYPED IN
0502 7640 SZA CLA
0503 5306 JMP BYRETR /CNTRL S TYPED IN
0504 4765* JMS C0GET /NO CNTRL S TYPED PREVIOUSLY
0505 5600 JMP I XC0CNTM /LEAVE VIA CNTR ENTRY ADDRESS
0506 3335 BYRETR, DCA C0SETS /CLEAR THE SUFT FLAG
0507 4765* JMS C0GET /RESTORE REGISTERS
0510 5736 JMP I C0METR /EXIT TO ADDRESS SET BY CONTROL S

```

/
/CONTROL R
/GO TO THE QUESTION C8SWIT
0511 3764* CNTRLR, DCA TTYLPT /CLEAR THE TYPE FLAG SET TO TTY
0512 3335 DCA C88ETS /CLEAR SOFT FLAG FOR CNTRL S
0513 3772* DCA INMODE
0514 4763* DCA UPAROW /PRINT THE " AND C8CHAM
0515 3762* C8BY4, DCA C88WST /CLEAR FLAG FOR CNTRL D OR R
0516 6203 CIF CDF 0
0517 5720 JMP I XDUSH /GO TO ADDRS OF C8SWIT
0520 0200 XDUSH, BGN /DUSH IS LABEL FOR C8SWIT QUESTION
/
/
/CONTROL S
/STOP SENDING CHAR, TO DISPLAY UNTIL A "Q IS RECEIVED
/
/
0521 1335 CNTRL8, TAD C88ETS /IF1 DO NOT STORE IN C8RETR
0522 7640 SZA CLA
0523 5327 JMP C8D07 /DONT SET UP C8RETR
0524 7001 IAC /MAKE RETURN CALL PLUS 2
0525 1200 TAD XC8CNT /GET RETURN FOR THIS CALL
0526 3336 DCA C8RETR /STORE IT HERE FOR USE BE CNTRL Q
0527 2335 C8D07, ISZ C88ETS /SET FLAG TO SAVE CALL
0530 4761* JMS XC8TTYI /LOOK FOR THE INPUT
0531 4765* JMS C8GET /GE: REGISTERS
0532 4200 JMS XC8CNTR /CHECK FOR THE CONTROL CHAR
0533 7200 CLA
0534 5321 JMP CNTRL8 /IF NOT A CNTRL Q R C REASK
0535 0000 C88ETS, 0
0536 0000 C8RETR, 0
/
/SWITCH OUTPUT FROM ONE OUTPUT DEVICE TO ANOTHER- THE TWO OUTPUTS ARE THE
/CONSOLE AND THE PRINTER WITH DEVICE CODE 66.
/
/
0537 1764* CNTRL8, TAD TTYLPT /GET PRESENT C8SWIT INDICATOR
0540 7000 CMA /COMPLEMENT IT
0541 3764* DCA TTYLPT /STORE NEW C8SWIT
0542 4763* JMS UPAROW /C8PNT " AND CHAR ON NEW DEVICE
0543 4765* JMS C8GET /RESTORE THE REGISTERS
0544 5000 JMP I XC8CNT /EXIT
/
/CONTROL E
/CONTINUE RUNNING FROM A INQUIRE OR ERROR
/
/
0545 4763* CNTRL8, JMS UPAROW /PRINT THE CONTROL CHAR
0546 3762* DCA C88WST /CLEAR ENTRY FLAG.
0547 4765* JMS C8GET /GET THE REGISTERS
0550 5000 JMP I XC8CNT /RETURN TO CALL PLUS ONE
/
/CONTROL C

```

```

/RETURN TO MONITOR CONTROL C
0551 3764* CNTRLC, DCA TTYLPT /CLEAR THE LPT FLAG TO PRINT ON DISPLAY
0552 3762* DCA C88WST /CLEAR ENTRY FLAG.
0553 4763* JMS UPAROW /C8PNT " AND LETTER IN CHAR
0554 6203 CDF CIF /GO TO 0 FLD
0555 6007 CAF /CLEAR THE WORLD
0556 5700 JMP I (7000) /GO TO DIAGNOSTIC MONITOR
/
/*****
/
/
0560 7000
0561 0272
0562 0745
0563 0615
0564 1121
0565 0624
0566 0100
0567 1023
0570 0277
0571 1077
0572 1076
0573 1075
0574 1346
0575 1347
0576 1200
0577 1345
0600 0600 PAGE
/
/CONTROL D
/CHANGE THE SWITCH REGISTER ANYTIME CNTRL D AND RETURN TO
/THE PROGRAM RUNNING.
/
0600 4215 CNTRLD, JMS UPAROW
0601 1213 TAD C88ETD /CHECK IF THE RETURN ADDRS IS SAFE
0602 7640 SZA CLA
0603 5207 JMP C8D011 /DO NOT CHANGE THE RETURN ADDRS
0604 1777* TAD XC8CNT /GET THE RETURN ADDRS AND SAVE IT
0605 3214 DCA C88ETD /SAVE THE RETURN HERE
0606 2213 C8D011, ISZ C88ETD /INDICATE RETURN SAVED DONT DESTROY
0607 4256 JMS XC8PSW /GO CHANGE THE SWITCH REGISTER
0610 3213 DCA C88ETD /CLEAR THE FLAG
0611 4224 JMS C8GET /RESTORE THE AC HQ LINK ETC
0612 5614 JMP I C88ETD /RETURN TO THE PROGRAM
/
0613 0000 C88ETD, 0
0614 0000 C88ETD, 0
/
/THIS WILL TYPE A UP ARROW AND THE CHAM IN C8CHAM.
0615 0000 UPAROW, 0 /C8PNT THE "" AND THE CHAM C8TYPED IN

```



```

0715 0000 TSTCHA, 0
0716 7041 CIA
0717 1356 TAD (215 /CMPL CHAR IN AC
0720 7650 SNA CLA (215 /TEST IF IT IS A CARRIAGE RETURN
0721 5342 JMP ENDIT /SKIP IN NOT CR,
0722 1774 TAD C0CHAR /WAS CARRIAGE RETURN
0723 1355 TAD (-260 /NOT CR, GET CHAR
0724 7710 SPA CLA (-260 /CHECK IF IT IS IN RANGE
0725 5336 JMP ERR1 /IF NOT POSITIVE CBERR CHAR SMALLER THEN 260
0726 1774 TAD C0CHAR /CBERR= CHAR TOO SMALL
0727 1354 TAD (-270 /GET CHAR
0730 7700 SNA CLA (-270 /GET A=270+ CHECK IF IT IS LARGER THEN 7
0731 5336 JMP ERR1 /SKIP IF LESS THEN 7
0732 1774 TAD C0CHAR /CBERR ON CHAR NOT IN RANGE
0733 0353 AND (7 /GET CHAR
0734 3774 DCA C0CHAR /MASK FOR RIGHT BYTE
0735 5715 JMP I TSTCHA /STONE IN CHAR
0736 1352 ERN1, TAD (277 /GET CHAR IN AC
0737 4775 JMS XC0TYPE /EXIT
0740 4773 JMS XC0CRLF /C0PNNT
0741 5266 JMP C0R0PS /
0742 4773 ENDIT, JMS XC0CRLF /EXIT+ ASK AGAIN
0743 3345 DCA C0HWST /DO A CR LF
0744 5656 JMP I XC0PSW /CLEAR THE PSW ENTRY FLAG
0745 0000 C0HWST, 0 /EXIT ROUTINE

0746 0000 TPCNT, 0
0747 2322 MESA, TEXT "SR= "
0750 7540
0751 0000

```

```

0752 0277
0753 0007
0754 7510
0755 7520
0756 0215
0757 7775
0760 1063
0761 1076
0762 0040
0763 1000
0764 0515
0765 0272
0766 0303
0767 1200
0770 1345
0771 1347
0772 1346
0773 1023
0774 1075
0775 1077
0776 0336
0777 0400

```

```

1000 PAGE
/C00CTA
/OCTAL TO ASCII CONVERSION
/THIS ROUTINE WILL TAKE THE OCTAL NUMBER IN THE AC AND CONVERT IT TO ASCII
/THE RESULT WILL BE PRINTED ON THE CONSOLE TERMINAL
/ C00CTA= JMS XC00CT
/
/EX. JMS XC00CTA /AC CONTAINS NUMBER TO BE CHANGE
/ RETURN IS TO CALL PLUS ONE AC=0
/
/CALLS USED ARE=XC0TYPE=

1000 0000 XC00CT, 0
1001 7106 CLL RTL
1002 7006 RTL /POSITION THE FIRST CHAR FOR PRINTING
1003 3221 DCA C0TMP1 /SAVE CORRECT POSITIONED WORD HERE
1004 1377 TAD (=4
1005 3222 DCA C0CKP /STONE COUNTER IN HERE
1006 1221 C0D04, TAD C0TMP1 /GET FIRST NUMBER
1007 0376 AND (0007 /MASK
1010 1375 TAD (260 /ADD THE PRINT CONSTANT
1011 4277 JMS XC0TYPE /TYPE THE NUMBER
1012 1221 TAD C0TMP1 /
1013 7006 RTL
1014 7004 RAL
1015 3221 DCA C0TMP1 /PUT NEXT NUMBER IN POSITION
1016 2222 ISZ C0CKP /STONE IT
1017 5206 JMP C0D04 /DONE YET WITH FOUR NUMBERS
1020 5600 JMP I XC00CT /NOT YET UU MORE
1021 0000 C0TMP1, 0 /DONE WITH FOUR
1022 0000 C0CKP, 0

/*****
/C0CRLF
/C0TYPE CR AND LF WITH FILLERS FOLLOWING EACH LF AND CR
/
/ C0CRLF= JMS XC0CRL
/
/EX. JMS XC0CRLF /C0PNNT A CR AND LF WITH FILL
/ /RETURN TO CALL PLUS ONE AC =0
/CALLS USED ARE=XC0TYPE=

1023 0000 XC0CRLF, 0
1024 7300 CLA CLL
1025 1374 TAD (215 /GET CODE FOR CR
1026 4277 JMS XC0TYPE
1027 1237 TAD FILLER
1030 7040 CMA
1031 3240 DCA FILCNT /STONE FILLER IN HERE

```

```

1032 1373      TAD      (212      /GET CODE FOR LF
1033 4277      C000R, JMS      XC8TYPE
1034 2240      ISZ      FILCNT      /CHECK ON FILLER CHAR
1035 5233      JMP      C0002      /TYPE A NON PRINTING CHAR
1036 5623      JMP I     XC8CRL      /EXIT
1037 0004      FILLER, 0004      /FILLER SET FOR 4 CHAR
1040 0000      FILCNT, 0      /COUNTER FOR FILL

```

```

/*****
/C8CKPA
/THIS ROUTINE WILL CHECK IF A CHARACTER WAS ENTERED FROM THE
/TERMINAL. IF THE FLAG IS SET AND THE CONSOLE PACKAGE IS
/ACTIVE A CHECK IS MADE TO DETERMINE IF IT IS A CONTROL CHAR.
/IF IT WAS A CONTROL CHAR THEN ITS CONTROL FUNCTION IS PERFORMED.
/IF NOT A CONTROL CHARACTER OR A CONTROL E-D-L-O- IT WILL DO
/THE CONTROL FUNCTION AND RETURN TO CALL PLUS 2.
/IF A NON CONTROL CHARACTER WILL BE PRINTED AND A "3" IT WILL RETURN TO
/CALL PLUS 2.
/IF NO FLAG IS SET OR THE CONSOLE IS NOT ACTIVE THE RETURN IS TO
/CALL PLUS 1.

```

```

/      C8CKPA= JMS      XC8CKP

```

```

/EX,      JMS      XC8CKPA      /CALL TO CHECK IF CONTROL CHAR SET
/      ANYTHING(SKIP)      /RETURN IF NOT FLAG OR NOT CONSOLE ACTIVE
/      ANYTHING(JMP EXIT SKIP CHAIN)      /RETURN IF NOT CONTROL OR CONTINUE CONTROL

```

```

/CALLS USED ARE=XC8TTYI=XC8CNTN=C00EY=

```

```

1041 0000      XC8CKP, 0
1042 3772*     DCA      AC0AVE      /SAVE THE AC
1043 0004      GTF      /SAVE THE FLAG
1044 3771*     DCA      FL0AVE      /SAVE THE FLAG
1045 7501      MQA      /PUT MD IN AC
1046 3770*     DCA      M00AVE      /SAVE THE MD
1047 0031      K0F      /CHECK THE KEYBOARD FLAG
1050 5261      JMP      C00Y3      /EXIT TO CALL PLUS 1
1051 4767*     JMS      C0KCLA      /CHECK LOC 20 BIT 3 CONSOLE BIT
1052 7410      SKP      /ACTIVE CONSOLE PACKAGE
1053 5261      JMP      C00Y3      /EXIT TO CALL PLUS 1
1054 4766*     JMS      XC8TTYI      /GET THE CHAR
1055 4765*     JMS      C00EY      /GET THE FLAG
1056 4764*     JMS      XC8CNTN      /CHECK IF CONTROL CHAR.
1057 7000      NOP      /RETURN IF A CONTINUE CHAR.
1060 2241      ISZ      XC8CKP      /BUMP RETURN FOR CALL PLUS 2
1061 4765*     C00Y3, JMS      C00EY      /GET REGISTERS
1062 5641      JMP I     XC8CKP      /BAY GOOD BY

```

```

/*****

```

```

/C8ECHO
/THIS ROUTINE WILL LOOK FOR A CHAR FROM THE KEYBOARD. STORE IT IN LOCATION CHAR
/CHECK IF IT WAS A CONTROL CHARACTER= SET INMODE= PRINT CHARACTER

```

```

/      C8ECHO =      JMS XC8ECH
/EX,      JMS      XC8ECHO      /LOOK FOR CONSOLE CHAR & PRINT IT
/      /RETURN CALL PLUS ONE AC @ CHAR C0TYPED IN

```

```

/CALLS USED ARE=XC8TTYI=XC8CNTN=C00EY=XC8ECH=XC8TYP=

```

```

/
XC8ECH, 0
1063 0000      JMS      XC8TTYI      /WAIT FOR CHAR FROM KEYBOARD
1064 4766*     JMS      C00EY      /RESTORE THE REGISTERS
1065 4765*     ISZ      INMODE      /SET INMODE IDENTIFYING THIS AS A EXPECTED CHAR
1066 2276      JMS      XC8CNTN      /GO CHECK IF IT IS A CONTROL CHAR
1067 4764*     JMP I     XC8ECH      /WAS A CONTROL CHAR= CONTINUE RUNNING
1070 5663      JMS      XC8TYP      /NOT A CONTROL CHAR & PRINT IT
1071 4277      DCA      INMODE      /CLEAR FLAG THAT CHAR EXPECTED
1072 3276      TAD      C0CHAR      /GET CHAR IN AC
1073 1275      JMP I     XC8ECH      /EXIT
1074 5663      C0CHAR, 0
1075 0000      INMODE, 0

```

```

/*****

```

```

/C8TYP=
/THIS ROUTINE WILL & PRINT ON THE CONSOLE OR THE LPT WITH DEVICE CODE 66.
/

```

```

/      C8TYP= JMS XC8TYP

```

```

/EX,      JMS      XC8TYP      /& PRINT THE CHAR IN THE AC.
/      /RETURN CALL PLUS ONE AC @0000
/      /DO NOT CLEAR THE LINK IN THIS ROUTINE NEEDED BY C00CT

```

```

/CALLS USED ARE=C0MANG=XC8CNTN=XC8PNT=XC8CHLP=XC8INQU=

```

```

1077 0000      XC8TYP, 0
1100 3320      DCA      PNTBUF      /STORE CHAN
1101 1321      TAD      TTYLPT      /CHECK 0=TTY 7777=LPT
1102 7640      SZA      CLA
1103 5312      JMP      XDULPT      /DO OUT PUT ON LPT
1104 1320      TAD      PNTBUF
1105 0046      TLS
1106 0041      T0F
1107 5306      JMP      -=1
1110 0042      TCF
1111 5316      JMP      C00Y5
1112 1320      XDULPT, TAD      PNTBUF      /GET CHAR
1113 0006      PST0      PCLF      /& PRINT IT
1114 4322      JMS      C0MANG      /CHECK KEYBOARD IF HUNG
1115 0002      PCLF      /CLEAR THE FLAG
1116 7600      C00Y5, 7600      /CLEAR THE AC

```



```

1117 5677      JMP I   XC8TYP      /EXIT
1120 0000      PNTBUF, 0
1121 0000      TTYLPT, 0

1122 0000      C0MANG, 0
1123 7200      CLA
1124 1316      TAD          C0B55      /GET CONSTANT 7600
1125 3320      OCA          PNTBUF      /PNTBUF IS NOW A COUNTER
1126 6661      PSKF
1127 7410      SKP
1130 5722      JMP I   C0MANG      /$AN FLAG DONE
1131 2345      ISZ          C0CONT      /FIRST COUNTER FAST ONE
1132 5326      JMP          =-4        /CHECK IF FLAG SET YET
1133 2320      ISZ          PNTBUF      /MADE 4096 COUNTS ON FAST COUNTER
1134 5331      JMP          =-5        /KEEP IT UP FOR 5 SEC
1135 1764*     TAD          XC0CNTR      /GET THE RETURN ADDRESS IN CONTROL
1136 3322      OCA          C0MANG      /SAVE IT IN MANG
1137 3321      OCA          TTYLPT      /ALLOW PRINTING ON TTY
1140 4763*     JMS          XC0PNT
1141 1146      MESMANG
1142 4223      JMS          XC0CRLF      /LPT ERROR
1143 4762*     JMS          XC0INQU      /PRINT WAITING
1144 5722      JMP I   C0MANG      /CONTINUE TO SAVE ADDRESS
1145 0000      C0CONT, 0
1146 1420      MESMANG,TEXT "LPT ERROR"
1147 2440
1150 0522
1151 2217
1152 2200

1162 0635
1163 0303
1164 0400
1165 0624
1166 0272
1167 1200
1170 1346
1171 1347
1172 1345
1173 0212
1174 0215
1175 0260
1176 0007
1177 7774
1200

```

PAGE

/THIS ROUTINE WILL CHECK LOCATION 22 THE HARD WARE CONFIG WORD,
/TO SEE IF THE CONSOLE BIT 3 (400) IS SET IF SET THEN RETURN
/TO CALL PLUS TWO FOR A ACTIVE CONSOLE PACKAGE AC=0
/IF NOT SET THEN TO CALL PLUS ONE FOR A ULACTIVE CONSOLE PACKAGE.

```

1200 0000      CHKCLA, 0
1201 7200      CLA
1202 1022      TAD          22          /GET THE CONTENTA OF LOCATION 22
1203 0377      AND          (400)       /MASK FOR BIT 3 (400)
1204 7650      SNA CLA
1205 2200      ISZ          CHKCLA      /
1206 5600      JMP I   CHKCLA      /ACTIVE CONSOLE PACKAGE RETURN
                                      /CALL PLUS ONE (1) FOR ACTIVE
                                      /DEACTIVE CONSOLE PACKAGE RETURN
                                      /CALL PLUS TWO (2)

/C0ERR
/THIS ROUTINE WILL DETERMINE WHAT TO DO WHEN A C0ERR IS ENCOUNTERED
/WILL CHECK IF CLASSIC SYSTEM, WILL CHECK C0SWIT REGISTERS.
/ C0ERR= JMS XC0ERR
/Ex. JMS XC0ERR /GO TO C0ERR CALL IF NOT CONSOLE
/ /RETURN IS CALL PLUS ONE AC =0000

/CALLS USED ARE=CHKCLA-XC0CRLF=XC0S#-XC0INQU=XC0PNT=XC0OCTA=

1207 0000      XC0ERR, 0
1210 0002      IOF
1211 3345      DCA          ACSAVE      /SAVE AC
1212 0004      GTF
1213 3347      DCA          PLSAVE      /SAVE THE FLAGS
1214 7501      MGA
1215 3346      DCA          MQSAVE      /SAVE THE MD
1216 7340      CLA CLL CMA          /SUBTRACT A 1 FOR TRUE LOCATION
1217 1207      TAD          XC0ERR      /GET RETURN LOCATION
1220 3344      DCA          PCSAVE      /SAVE ADD OF C0ERR CALL
1221 6201      CDF
1222 7340      CLA CLL CMA
1223 1776      TAD I   (CLASIK)      /GET REAL PC.
1224 3316      DCA          REALPC      /SAVE IT.
1225 6211      CDF          10
1226 4200      JMS          CHKCLA      /CHECK LOC,22 BIT 3 CONSOLE BIT
1227 7410      SKP
1230 5270      JMP          NTCLAS      /ACTIVE CONSOLE PACKAGE
1231 4775*     JMS          C0GET       /NOT CLASSIC SYSTEM
1232 4774*     JMS          XC0S#       /GET REGISTERS.
                                      /CHECK SWITCH REG FOR BIT THAT INDICATES
                                      /NO ERROR MESSAGE
1233 0373      SETUP1, AND          10000 /MASK FOR BIT FOR NO ERROR PRINTING
                                      /IF THIS ERROR MESSAGE IS TO ALWAYS
                                      /BE PRINTED LEAVE AND VALUE AT 0000
1234 7640      SZA CLA
1235 3262      JMP          C0U010      /SKIP IF BIT IS 0 PRINT ERROR MESSAGE
1236 4772*     JMS          XC0CRLF      /DO NOT PRINT
1237 4771*     JMS          XC0PNT
1240 1320      ERRMES
1241 4771*     JMS          XC0PNT      /PRINT THE ERROR MESSAGE
1242 1330      MESPC
1243 1316      TAD          REALPC      /PRINT THE PC STATEMENT
1244 4770*     JMS          XC0OCTA     /GET PC
1245 4771*     JMS          XC0PNT      /CONVERT 4 DIGIT PC TO ASCII
1246 1333      MESAC

```

```

1247 1345      TAD      AC8AVE
1250 4770*    JMS      XC8OCTA
1251 4771*    JMS      XC8PNT
1252 1336      MESMQ
1253 1346      TAD      MQ8AVE
1254 4770*    JMS      XC8OCTA
1255 4771*    JMS      XC8PNT
1256 1341      MESFL
1257 1347      TAD      FL8AVE
1260 4770*    JMS      XC8OCTA
1261 4772*    JMS      XC8CRLF
1262 4775*    C80010, JMS      C8GET
1263 4774*    JMS      XC8SW
1264 7610      SKP      CLA
1265 5300      JMP      C8BY2
1266 4767*    JMS      XC8INQ
1267 5300      JMP      C8BY2
1270 4775*    NTCLAS, JMS      C8GET
1271 4774*    JMS      XC8SW
1272 7610      SKP      CLA
1273 5607      JMP      I      XC8ERR
1274 1366      TAD      (7402
1275 3744      DCA      I      PC8AVE
1276 4775*    JMS      C8GET
1277 5744      JMP      I      PC8AVE
1300 4775*    C8BY2, JMS      C8GET
1301 5607      JMP      I      XC8ERR
/
1302 7402      /ROVINS, HLT
1303 7000      NOP
1304 3317      DCA      MYAC
1305 6201      CDF      0
1306 1020      TAD      SWR
1307 3765      DCA      I      (SWR)
1310 1776      TAD      I      (CLASIK)
1311 3315      DCA      CLRTRN
1312 1317      TAD      MYAC
1313 6202      CDF      0
1314 5715      JMP      I      CLRTRN
/
1315 0000      CLTRN, 0
1316 0000      REALPC, 0
1317 0000      MYAC, 0
/
1320 0410      /ERMES, TEXT "DMRKC FAILED "
1321 2213
1322 0310
1323 4040
1324 0001
1325 1114
1326 0504
1327 4000
1330 4040      MESPC, TEXT " PC:"

```

```

1331 2003
1332 7200
1333 4040      MESAC, TEXT " AC:"
1334 0103
1335 7200
1336 4040      MESMQ, TEXT " MQ:"
1337 1521
1340 7200
1341 4040      MESFL, TEXT " FL:"
1342 0614
1343 7200
1344 7777      PC8AVE, 7777
1345 7777      AC8AVE, 7777
1346 7777      MQ8AVE, 7777
1347 7777      FL8AVE, 7777
/
1365 0020
1366 7402
1367 0635
1370 1000
1371 0303
1372 1023
1373 0000
1374 0262
1375 0624
1376 1514
1377 0400
0000
FIELD 0

```

0000	00000000	00000000	11101111	11111111	11000000	00000000	00000000	00000000
0100	00000000	00000000	00000000	00000000	00000000	00000000	00000000	00000000
0200	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
0300	11111111	11111111	11111111	11111111	11111111	10000001	11111111	11111111
0400	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
0500	11111111	11111111	11111111	11111111	11111111	11111110	11111111	11111111
0600	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
0700	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
1000	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
1100	11111111	11111111	11111111	11111111	11111111	11100000	00111111	11111111
1200	11111111	11111111	11111111	11111111	11111111	11111111	11111111	11111111
1300	11111111	11111111	11111111	11111111	11111111	00000000	00000111	11111111

1400
1500
1600
1700

2000
2100
2200
2300
2400
2500
2600
2700

3000
3100
3200
3300
3400
3500
3600
3700

4000
4100
4200
4300
4400
4500
4600
4700

5000
5100
5200
5300
5400
5500
5600
5700

6000
6100
6200
6300
6400
6500
6600
6700

7000
7100
7200
7300
7400
7500
7600
7700

```

/NOTE: LOCATION 0 CONTAINS THE REVISION
/LEVEL (IN ASCII) ON PROGRAM LOAD.
/
/ALL KNOWN HALTS
/
1400 0556 ERHLT0 /SKIP TRAP DLSC
1401 0563 ERHLT2 /SKIP TRAP DCLR
1402 2561 ERHLT3 /SKIP TRAP DLAG
1403 2544 ERHLT5 /SKIP TRAP DRST
1404 0547 ERHLT6 /SKIP TRAP DLDC
1405 3130 INTER1 /NO DISK INTERRUPT
1406 2362 INTER2 /UNDEFINED INTERRUPT
1407 0206 FLDHLT /PROGRAM WILL ONLY RUN IN FIELD 0
1410 2702 NDDSK0 /NO DISKS AVAILABLE TO RUN
1411 0603 STPHLT /PROGRAM STOP FROM SHR4=1
1412 2755 CHNHLT /I/O CHANGE HALT
1413 1707 BADHLT /COMPUTER MUST BE DOWN, CHECKSUM FAILED
/BUT MURD=MY=WORD COMPARE WORKED.
/STOP FOR ALL ERROR HALTS.
/
1414 3136 BIGSTP
/
6740 DLSC=6740 /LOAD SECTOR COUNTER
6741 DSKP=6741 /SKIP ON TRANSFER DONE OR ERROR
6742 DCLR=6742 /CLEAR DISK CONTROL LOGIC
6743 DLAG=6743 /LOAD ADDRESS AND GO
6744 DLCA=6744 /LOAD CURRENT ADDRESS
6745 DRST=6745 /READ STATUS REGISTER
6746 DLDC=6746 /LOAD COMMAND REGISTER
/
4406 LAB=JMS I XLAS
4407 CLASIC=JMS I XCLAS
4427 RANDAT=JMS I XRNWRD
4430 DISCON=JMS I XDUMP
4431 SPACE=JMS I XSPAC
4432 ONEIN=JMS I XOCT1
4433 FORIN=JMS I XOCT4
4434 SETGEN=JMS I XSTGEN
/
4435 SETFLD=JMS I XSTFLD
4437 YESNO=JMS I XCHKYN
/
4436 SELCHK=JMS I XCKPOT
4440 RANGEN=JMS I XRNDOO
4442 REBRAN=JMS I XRBRAN
4441 DISKGO=JMS I XDSKGO
4443 RECAL=JMS I XRESTR
4444 RECEIV=JMS I XWAIT
4446 ERROR=JMS I XERR0
4447 RDSTAT=JMS I XRDST
4453 LADD=JMS I XLADD
4450 DSKBKP=JMS I XSKBP

```

```

4451 LDCM=JMS I XLDCM
4452 LDCUR=JMS I XLDCA
4454 CLRALL=JMS I XCLDR
4455 PRNTER=JMS I XPRN
4456 OCTEL=JMS I XPROCT
4445 TYPE=JMS I XPRINT
4457 CRLF=JMS I XCRLF
4426 GENDAT=JMS I XGN DAT
4424 CHK22=JMS I XCMK22
4425 KTICK=JMS I XKTCK
/
0000 *0
/
0000 0310 310 /REVISION "H" INTERRUPT SERVICE RETURN
0001 5001 5001 /DCA SAVAC SAVE AC AT INT.
0002 0002 0002 /RAL SHIFT LINK AT TIME OF INT.
0003 0003 0003 /DCA SVLNK SAVE LINK AT TIME OF INT.
0004 0004 0004 /JMP I 5 RETURN TO INT, SERVICE
0005 0005 0005 /RETURN POINTER
/
0006 1546 XLAS, MYLAB
0007 1514 XCLAS, CLASIK
/
0010 *10
/
0010 0000 AUTO10, 0
/
0011 0000 AUTO11, 0
/
0012 0000 AUTO12, 0
/
0013 0004 K0004, 0004
0014 0070 K0070, 0070
0015 0100 K0100, 0100
0016 0200 K0200, 0200
0017 0400 K0400, 0400
/
0020 *20
/
0020 0000 SWK, 0
0021 4000 DP1, 4000
0022 0000 DP2, 0
/
0023 2156 KAERR0, AERROR
0024 0523 XCMK22, CMK22
0025 1154 XKTCK, KXTICK
0026 1737 XGN DAT, GNDAT
0027 2600 XRNWRD, RNWRD
0030 2637 XDUMP, DUMP
0031 1506 XSPAC, SPAC
0032 2400 XOCT1, OCT1
0033 2430 XOCT4, OCT4
0034 1753 XSTGEN, STGEN
0035 2703 XSTFLD, STFLD

```

```

0036 2060 XCKPOT, CMK POT
0037 2035 XCHKYN, CMKYN
0040 1715 XRNDOM, RANDOM
0041 2200 XDSKGO, DSKGO
0042 1761 XRSRAN, RSRAN
0043 3052 XRESTR, RESTOR
0044 2000 XWAIT, WAIT
0045 2620 XPRINT, PRINT
0046 1200 XERRD, ERRD
0047 2541 XRDST, RDST
0050 0751 XSDKP, SDKP
0051 0542 XLDCM, LDGM
0052 2550 XLDCA, LDCA
0053 2554 XLDDA, LDDA
0054 0560 XCLDR, CLDR
0055 1450 XPRN, PRN
0056 1426 XFROCT, FROCT
0057 1414 XCMLF, UPONE
0060 0000 AMOUNT, 0
0061 0001 K0001, 0001
0062 0003 K0003, 0003
0063 0006 K0006, 0006
0064 0007 K0007, 0007
0065 0010 K0010, 0010
0066 0017 K0017, 0017
0067 0260 K0260, 0260
0070 0277 K0277, 0277
0071 0770 K0770, 0770
0072 7007 K7007, 7007
0073 4000 K4000, 4000
0074 4100 K4100, 4100
0075 1000 K1000, 1000
0076 1777 K1777, 1777
0077 7700 K7700, 7700
0100 7760 K7760, 7760
0101 7777 K7777, 7777
0102 0077 K0077, 0077
0103 6201 K6201, 6201
0104 7400 K7400, 7400
/
DECIMAL
/
0105 7764 M12, -12
/
OCTAL
/
0106 7774 M4, -4
0107 7770 M10, -10
0110 7775 K7775, 7775
/
0111 0000 TRASH1, 0
0112 0000 TRASH2, 0
0113 0000 TRASH3, 0
0114 0000 UPDATE, 0
0115 0000 POLD8K, 0

```

```

0116 0000 OPMTAL, 0
0117 0000 BUFTAL, 0
0120 0000 PCREG, 0
0121 0000 STRREG, 0
0122 0000 EXREG, 0
0123 0000 CMREG, 0
0124 0000 INTDA, 0
0125 0000 DAREG, 0
0126 0000 CAREG, 0
0127 0000 WCAREG, 0
0130 0000 FWMREG, 0
0131 0000 ASREG, 0
0132 0000 WAREG, 0
0133 0000 ADREG, 0
0134 0000 DGREG, 0
0135 0000 DBREG, 0
0136 0000 INTCM, 0
0137 0000 STATRY, 0
0140 0000 DATTRY, 0
0141 0000 CMKSAV, 0
0142 0000 FNDSUM, 0
0143 0000 MAXFLD, 0
0144 7607 MAXTIM, 7607
0145 3240 MAXTRK, 3240
0146 3600 BGNBUF, STRBUF
0147 0000 CONSEC, 0
0150 7777 CLKCNT, -1
/
0151 0756 DATPOT, DAT1
0152 3522 TIMPOT, OBTM1
0153 3537 STAPOT, D8HRD=3
0154 3512 RUNPOT, D8K00
/
0155 0000 CRCNT, 0
0156 0000 CRCFLG, 0
0157 0000 DATFLG, 0
0160 0000 SPFLD, 0
0161 0000 SPTRK1, 0
0162 0000 SPTRK2, 0
0163 0000 SPSEC, 0
0164 0000 SPBLK, 0
0165 0000 ERPLG, 0
0166 0000 SAVAC, 0
0167 0000 SVLNA, 0
0170 0000 FINTIM, 0
0171 0000 TRTCNT, 0
0172 3213 XTEXT, TEXPC
0173 3142 PRNDAT, TYPDAT
0174 0000 SAVCM, 0
0175 0000 CLNBK, 0
/
0176 1131 BGMILT, BIGHLT
0200
/
/

```

```

/START OF PROGRAM BY OPERATOR!
/AT 0200, TTY INTERGATION!
/AT 0201, CHANGE IOT DEVICE CODES!
/AT 0202, RESTART AT SEEK ROUTINE!
/
0200 4777* BGN, JMS APT8 /TO REGULAR TEST
0201 5776* JMP CHANG /CHANGE IOT ROUTINE
0202 5775* JMP RUN
0203 3156 DCA CRCFLG /CLEAR CRC FLAG
0204 0224 RIF
0205 7440 SZA /FIELD 07???
0206 4576 FLDMLT, JMS I 06MLT /WILL ONLY RUN IN FIELD 07???
0207 1103 TAD KCDF
0210 3211 DCA ,+1
0211 7402 HLT /MAKE DF=IF
/
/SETUP INTERRUPT SERVICE!
/
0212 1362 TAD ACUCA
0213 3001 DCA 1 /SETUP AC DCA
0214 1250 TAD KRUT
0215 3002 DCA 2 /SETUP ROTATE LINK
0216 1361 TAD LNKDCA
0217 3003 DCA 3 /SETUP SAVE LINK
0220 1360 TAD K5405
0221 3004 DCA 4 /SETUP JMP RETURN
0222 1363 TAD BRKRET
0223 3005 DCA 5 /RETURN POINTER
/
/CLEAR DATA INFORMATION TABLE
/AT END OF PROGRAM!
/
0224 1077 STRTEX, TAD K7700
0225 3111 DCA TRASH1 /CLEAR COUNTER
0226 1774* TAD RANJMS
0227 3773* DCA SWDAT /SET INSTRUCTION SWITCH
0230 7340 CLA CLL CMA
0231 1152 TAD TIMPDT
0232 3010 DCA AUTO10 /LOCATION POINTER
0233 3410 DCA I AUTO10 /CLEAR
0234 2111 ISZ TRASH1
0235 5233 JMP ,=2 /MURE TO CLEAR
0236 3157 DCA DATFLG
0237 5775* SKPNOP, JMP RUN
/
/PRINT PROGRAM NAME AND
/ASK OPERATOR ABOUT AMOUNT
/OF MEMORY!
/
0240 4457 CRLF
0241 4455 PRNTER /PRINT "RK8E/RK8L DATA RELIABILITY"
0242 3307 MES1
0243 4455 PRNTER /PRINT "AMOUNT OF MEMORY"
0244 3346 MES5

```

```

0245 4432 ONEIN
0246 0070 0070 /RECEIVE ONE OCTAL
0247 5243 JMP ,=4 /LIMITS
0250 7004 KRUT, RAL /INPUT ERROR
0251 7006 RTL
0252 7040 CMA /COMPLEMENT
0253 3143 DCA MAXFLD /MAXIMUM FIELD POINTER
0254 4772* JMS CLAFLD /CHECK FOR CLASSIC.
0255 3111 ALLAGN, DCA TRASH1
0256 1107 TAD M10
0257 3112 DCA TRASH2
0260 3060 DCA AMOUNT /A FEW POINTERS
/
/ASK OPERATOR ABOUT DISK(S) TO TEST!
/
0261 1111 NEXT, TAD TRASH1
0262 1154 TAD RUNPOT
0263 3113 DCA TRASH3 /SAVE RUN POINTER
0264 4455 PRNTER /PRINT "EXERCISE"
0265 3325 MES2
0266 7340 CLA CLL CMA
0267 4455 PRNTER /PRINT " DISK"
0270 3332 MES3
0271 1067 TAD K0260
0272 1111 TAD TRASH1 /ADD IN DISK NUMBER
0273 4445 TYPE /TYPE DISK NUMBER
0274 1070 TAD K0277
0275 4445 TYPE /TYPE ?
0276 4444 RECEIV /RECEIVE KEY INPUT
0277 4437 YESNO /WAS IT YES OR NO
0300 5255 JMP ALLAGN /NEITHER
0301 5304 JMP ,+3 /WAS A NO
0302 0060 ISZ AMOUNT /AMOUNT OF DISK FOUND
0303 7340 CLA CLL CMA /AC TO 7777 FOR EXISTING DISK
0304 3513 DCA I TRASH3 /SETUP RUN POINTER
0305 2111 ISZ TRASH1
0306 2112 ISZ TRASH2
0307 5261 JMP NEXT /ASK ABOUT NEXT DISK
/
/ASK IF ACCEPT MODE!
/
0310 1060 TAD AMOUNT /GET AMOUNT FOUND
0311 7650 SNA CLA /WERE ANY FOUND
0312 5224 JMP STRTEX /OPERATOR ERROR NO DISK INPUT
0313 4455 PRNTER /PRINT "ACCEPT MODE?"
0314 3363 MES6
0315 4444 RECEIV /RECEIVE INPUT
0316 4437 YESNO /YES OR NOT???
0317 5313 JMP ,=4 /NEITHER ALL AGAIN
0320 7610 SKP CLA /MANUAL TEST
0321 5771* JMP ASKSUR /ASK "ARE YOU SURE"
/
/IF ACCEPT MODE, INTERGATE

```

```

/ABOUT CONSTANT FIELD1
/
0322 4455 MANUAL, PRNTER /PRINT "FIELD?"
0323 3404 MESS
0324 4444 RECEIV /RECEIVE Y OR N
0325 4437 YESNO /CHECK FOR Y OR N
0326 5322 JMP MANUAL /NEITHER Y OR N
0327 5345 JMP ASKNX1 /WAS A N, ASK ABOUT NEXT
0330 4431 SPACE /SPACE OUT ONE
0331 4432 ONEIN /GET 1 OCTAL
0332 0070 0070 /LIMITS
0333 5322 JMP MANUAL /INPUT ERROR ASK AGAIN
0334 7104 CLL RAL
0335 7006 RTL
0336 3160 DCA SPFLD /SAVE INPUT
0337 1100 TAD SPFLD
0340 1143 TAD MAXFLD /COMPARE TO MAXIMUM
0341 7700 SMA CLA /U.K.?
0342 5322 JMP MANUAL /INPUT ERROR
0343 7340 CLA CLL CMA
0344 3770 DCA FLOFLG /SETUP FIELD FLAG
/
/INTERIGATE ABOUT CONSTANT TRACK1
/
0345 4455 ASKNX1, PRNTER /PRINT "TRACK?"
0346 3410 MESS9
0347 4444 RECEIV /RECEIVE Y OR N
0348 4437 YESNO /CHECK FOR Y OR N
0351 5345 JMP ASKNX1 /ERROR, ASK AGAIN
0352 5767 JMP ASKNX2 /N, ASK ABOUT NEXT
0353 4431 SPACE
0354 4432 ONEIN /RECEIVE 1 IN OCTAL
0355 0010 0010 /LIMITS
0356 5345 JMP ASKNX1 /ERROR, ASK AGAIN
0357 5766 JMP SAVE1 /TU SAVE SOME ROOM,
/
0360 5405 K5405, 5405
0361 3167 LNKDCA, DCA SVLNK
0362 3166 ACUDCA, DCA SAVAC
0363 2304 BRKRET, RETURN
/
0366 0400
0367 0406
0370 3572
0371 0513
0372 1404
0373 2601
0374 0522
0375 0600
0376 2730
0377 2070
0400
PAGE
/
/

```

```

/INTERIGATE ABOUT CONSTANT
/BLOCK LENGTH1
/
0400 3161 SAVE1, DCA SPTRK1 /SAVE EXTENDED TRACK BIT
0401 4433 FORIN /GET FOUR IN OCTAL.
0402 5777 JMP ASKNX1 /ERROR, ASK AGAIN
0403 3162 DCA SPTRK2 /SAVE CYL., SURFACE, AND SECTOR
0404 7340 CLA CLL CMA
0405 3776 DCA TRKFLG /SETUP TRACK FLAG
/
0406 4455 ASKNX2, PRNTER /PRINT "BLOCK LENGTH?"
0407 3424 MESS11
0410 4444 RECEIV /RECEIVE INPUT
0411 4437 YESNO /CHECK FOR Y OR N
0412 5206 JMP ASKNX2 /ERROR, ASK AGAIN
0413 5225 JMP ASKNX3 /N, ASK ABOUT NEXT
0414 4431 SPACE /N, ASK ABOUT NEXT
0415 4432 ONEIN /Y, SPACE OUT 1
0416 0010 0010 /RECEIVE 1 IN OCTAL
0417 5206 JMP ASKNX2 /LIMITS
0420 7640 SZA CLA /ERROR, ASK AGAIN
0421 7340 CLA CLL CMA /SET HALF BLOCK?
0422 3164 DCA SPBLK /YES
0423 7340 CLA CLL CMA /SETUP BLOCK NUMBER
0424 3775 DCA MLPFLG /SETUP BLOCK FLAG
/
/INTERIGATE ABOUT CONSTANT
/SECTORS1
/
0425 4455 ASKNX3, PRNTER /PRINT "EXTRA SECTORS?"
0426 3414 MESS10
0427 4444 RECEIV /RECEIVE INPUT
0430 4437 YESNO /CHECK FOR Y OR N
0431 5225 JMP ASKNX3 /INPUT ERROR
0432 5204 JMP ASKNX5 /N, ASK ABOUT NEXT
0433 4431 SPACE /SPACE OUT 1
0434 4432 ONEIN /REVEIVE 1 IN OCTAL
0435 0010 0010 /LIMITS
0436 5225 JMP ASKNX3 /ERROR, ASK AGAIN
0437 7104 CLL RAL
0440 7006 RTL
0441 3163 DCA SPSEC /SAVE IT
0442 4432 ONEIN /RECEIVE 1 IN OCTAL
0443 0070 0070 /LIMITS
0444 5225 JMP ASKNX3 /INPUT ERROR, ASK AGAIN
0445 1163 TAD SPSEC /ADD IN LAST
0446 3163 DCA SPSEC /SAVE ALL
0447 1164 TAD SPBLK
0450 7640 SZA CLA /BLOCK LENGTH 0????
0451 5254 JMP .+5 /NO LIMIT IS 17.
0452 1160 TAD SPFLD
0453 7640 SZA CLA /FIELD 0?????
0454 1065 TAD K0010 /LIMIT IS 17.
0455 1064 TAD K0007

```

```

0456 7140      CLL CMA
0457 1163      TAD      SPSEC          /COMPARE SECTOR INPUT;
0460 7630      BZL CLA          /IN LIMITS???
0461 3225      JMP      ASKNX3         /NO, INPUT ERROR
0462 7340      CLA CLL CMA
0463 3774*     DCA      SECFLG        /SETUP SECTOR FLAG
/
/
/INTERIGATE ABOUT "OPERATOR
/SELECT DATA"
0464 4455     ASKNX5, PRNTR          /PRINT "DATA?"
0465 3433     MES13
0466 1322     TAD      RANJMS
0467 3773*     DCA      SWDAT        /SET INSTRUCTION SWITCH
0470 4444     RECEIV
0471 4437     YESNO          /RECEIVE INPUT
0472 5264     JMP      ASKNX5         /Y OR N
0473 5313     JMP      ASKSR        /ERROR, ASK AGAIN
0474 1346     TAD      KSKP          /ASK "ARE YOU SURE"
0475 3773*     DCA      SWDAT        /SET INSTRUCTION SWITCH
0476 1105     TAD      M12
0477 3111     DCA      TRASH1       /SETUP WORD COUNTER
0500 7340     CLA CLL CMA
0501 1151     TAD      DATPOT       /GET POT POINTER
0502 3010     DCA      AUTO10
0503 4457     CRLF
0504 4433     FORIN          /RECEIVE 4 IN OCTAL
0505 5264     JMP      ASKNX5         /INPUT ERROR, ASK AGAIN
0506 3410     DCA I  AUTO10         /SAVE DATA
0507 2111     ISZ      TRASH1       /UPDATE COUNTER
0510 5303     JMP      L=5          /GET NEXT
0511 7340     CLA CLL CMA
0512 3157     DCA      DATPLG       /SETUP DATA FLAG
/
/ASK IF HE'S SURE;
0513 4455     ASKSR, PRNTR          /PRINT "ARE YOU SURE"
0514 3436     MES14
0515 4444     RECEIV
0516 4437     YESNO          /GET INPUT
0517 5313     JMP      ASKSR        /Y OR N
0520 5772*     JMP      STRTEX       /INPUT ERROR
0521 5771*     JMP      RUN          /ALL AGAIN
0522 4426     RANJMS, GENDAT       /START DATA TESTING
/
/THIS ROUTINE TESTS FOR BEING ON APT,
/IF ON APT RETURN IS PLUS ONE, IF NOT RETURN IS PLUS TWO.
/
0523 0000     CHEK22, 0
0524 1022     TAD      22
0525 7700     BMA CLA          /ON APT?
0526 2323     ISZ      CHEK22       /NO, UPDATE RETURN.
0527 5723     JMP I  CHEK22         /AND RETURN.

```

```

/ROUTINE TO NOTIFY APT.
/
0530 0000     KTIME, 0
0531 4424     CHK22
0532 7410     SKP
0533 5730     JMP I  KTIME          /ON APT.
0534 6002     IOF              /NOT ON APT, GO ABOUT NORMAL RUN.
0535 6201     CDF      00        /TURN INTERRUPT SYSTEM OFF
/                                     /DATA FIELD SHOULD ALWAYS
/                                     /BE ZERO IN PROGRAM RUN.
/CHANGED TO CURRENT DATA FIELD.
0536 6272     CIF      70
0537 4741     JMS I  K6500
0540 5730     JMP I  KTIME          /RETURN,
/
0541 6500     K6500, 6500
/
/SUBROUTINE TO LOAD COMMAND REGISTER
/
0542 0000     LOCM, 0
0543 3123     DCA      CMREG
0544 1123     TAD      CMREG
0545 6746     IOT6, DLDC          /LOAD COMMAND REGISTER
0546 7610     KSKP, SKP CLA
0547 4576     ERHLT6, JMS I  BGMLT
0550 1122     TAD      EXREG
0551 7110     CLL RAK
0552 7630     BZL CLA
0553 1016     TAD      K0200
0554 6740     IOT6, DLSC          /LOAD EXT. DRIVE
0555 7610     SKP CLA
0556 4576     ERHLT6, JMS I  BGMLT /SKIP TRAP IOT6
0557 5742     JMP I  LOCM         /EXIT
/
/SUBROUTINE TO ISSUE "DCLR" CLEAR IOT
0560 0000     CLDR, 0
0561 6742     IOT2, DCLR          /DCLR "CLEAR IOT"
0562 5760     JMP I  CLDR         /EXIT
0563 4576     ERHLT2, JMS I  BGMLT /ERRR SKIP TRAP
/
0571 0000
0572 0224
0573 2601
0574 3574
0575 3575
0576 3573
0577 0345
0600     PAGE
/
/
/SETUP ADDRESSING, COMMAND,
/AND DATA PARAMETERS;

```



```

/MAKE FIELD1
/
0600 4406 RUN, LAS /GET THE SWITCHES,
0601 0016 AND /MASK MALT SW,
0602 7640 SZA CLA K0200 /TIME TO HALT?
0603 7402 STPHLT, MLT /MALT FROM SWR4=1,
0604 1777* TAD PLDFLG /GET FIELD FLAG
0605 7650 SNA CLA /WAS IT SET?
0606 5211 JMP ,+3 /NO, USE RANDOM FIELD
0607 1160 TAD SPFLD /YES, GET OPERATOR FIELD
0610 5230 JMP HNPLD /GO
0611 7301 CLA CLL IAC
0612 1143 TAD MAXFLD /GET MAXIMUM FIELD POINTER
0613 7650 SNA CLA /ANY FIELDS THERE
0614 5230 JMP HNPLD /NO EXTENDED FIELDS TO USE
0615 4440 RANGEN /YES, GET A RANDOM FIELD
0616 0014 AND K0070 /MASK
0617 7450 SNA /COULD BE 0
0620 5230 JMP HNPLD /WAS DON'T HAVE TO CHECK LIMITS
0621 3136 DCA INTCH /SAVE FIELD FOUND
0622 1136 TAD INTCH
0623 1143 TAD MAXFLD /ADD IN MAXIMUM FIELD POINTER
0624 7710 SPA CLA /IN LIMITS????
0625 5231 JMP RNPLD+1 /YES, USE IT
0626 1143 TAD MAXFLD /NO, USE MAXIMUM IN THE MACHINE
0627 7040 CMA
0630 3136 RNPLD, DCA INTCH
/MAKE BLOCK LENGTH1
/
0631 1776* TAD MLFFLG /GET BLOCK FLAG
0632 7650 SNA CLA /WAS IT SET????
0633 4440 RANGEN /NO, USE RANDOM
0634 1164 TAD SPBLK /MASK
0635 0015 AND K0100 /INITIAL HALF BLOCK BIT ****
0636 1136 TAD INTCH
0637 3136 DCA INTCH
0640 1136 TAD INTCH
0641 0015 AND K0100 /MASK
0642 7640 SZA CLA /HALF BLOCK SET????
0643 1016 TAD K0200 /YES, SETUP WC POINTER
0644 1104 TAD K7400
0645 3112 DCA TRASH2 /WC BUILDER
0646 1112 TAD TRASH2
0647 7041 CIA
0650 3114 DCA UPDATE /UPDATER FOR FWREG
0651 1136 TAD INTCH
0652 0390 AND A0170 /MASK FIELD BITS
0653 7640 SZA CLA /WERE THERE ANY
0654 1065 TAD K0010 /YES
0655 1064 TAD K0007 /MAKE MAXIMUM SECTOR POINTER
0656 3111 DCA TRASH1 /SAVE IT
/MAKE AMOUNT OF SECTORS
/TO TRANSFER1

```

```

/
0657 1775* TAD SECFLG /GET SECTOR FLAG
0660 7650 SNA CLA /WAS IT SET????
0661 4440 RANGEN /USE RANDOM
0662 1163 TAD SPSEC /GET OPERATOR INPUT
0663 0111 AND TRASH1 /MASK OUT
0664 3147 DCA CONSEC /SAVE
0665 1147 TAD CONSEC
0666 7040 CMA
0667 3111 DCA TRASH1 /CONSECUTIVE TO DO
/MAKE WORD COUNT1
/
0670 1112 TAD TRASH2 /COMPUTE INITIAL WC
0671 2111 ISZ TRASH1
0672 5270 JMP ,+2 /UPDATE BY BUILDER
0673 3127 DCA WCNEG /INITIAL WORD COUNT ****
/MAKE CURRENT ADDRESS1
/
0674 4440 RANGEN /GENERATE RANDOM CA
0675 3126 DCA CAREG /SAVE IT
0676 1136 TAD INTCH
0677 0014 AND K0070 /MASK FIELD BITS
0700 7640 SZA CLA /EXTENDED FIELD????
0701 5317 JMP FILLUP /INITIAL CA 0,K,****
0702 1146 TAD BGNBUF
0703 7140 CMA CLL
0704 1126 TAD CAREG
0705 7620 SNL CLA /GREATER THAN PROGRAM+1
0706 5315 JMP CONCUR /NO, USE CONSTANT VALUE
0707 1127 TAD WCREG /GET WORD COUNT
0710 7041 CIA
0711 1126 TAD CAREG /ADD IN CA
0712 1016 TAD K0200
0713 7630 SZL CLA /WITHIN BOUNDS????
0714 5317 JMP FILLUP /YES, INITIAL CA 0,K,****
0715 1146 CONCUR, TAD BGNBUF /NO, USE PROGRAM+1
0716 3126 DCA CAREG /SAVE IT
/ROUTINE TO FILL AND CHECK SUM BUFFER
/
0717 4425 FILLUP, KTICK /NOTIFY APT IF NEED BE.
0720 4434 SETGEN /SETUP AND SAVE GENERATOR
0721 1106 TAD M4
0722 3137 DCA STATRY /SETUP TRY COUNTER
0723 4435 REFILL, SETFLD /FIELD+ BUFLD+ AUTO 11+ 12
0724 3325 DCA ,+1 /FIELD TO BUFFER IN AC
0725 7402 MLT /CDF TO BUFFER
0726 3141 DCA CHMSAV /START WITH 0
0727 4427 NEWRD, RANDAT /GENERATE DATA
0730 3111 DCA TRASH1 /SAVE OUTPUT WORD
0731 1111 TAD TRASH1 /GET BACK WORD
0732 3411 DCA I AUTO11 /STONE IN BUFFER
0733 7100 CLL

```

```

0734 1111 TAD TRASH1 /GET BACK WORD
0735 1141 TAD CHKSAV /ADD IN LAST
0736 7430 BZL /LINK SET??
0737 7001 IAC /ADD IT IN
0740 3141 DCA CHKSAV /SAVE FOR NEXT
0741 2117 ISZ BUPTAL /UPDATE BUFFER TALLY
0742 5327 JMP NEWRD /MORE WORDS TO GO
0743 6201 CDF @
0744 1165 TAD ERPLG
0745 7650 BNA CLA /EHRDR FLAG SET????
0746 5774* JMP POLNEX /POLE DRIVES
0747 5773* JMP REWRT /YES, MUST BE A WRITE ERROR

```

```

0750 0170 AB170, 0170
/
/SUBROUTINE TO ISSUE "DSKP" DISK SKIP IOT
/

```

```

0751 0000 BDKP, 0
0752 6741 IOT1, DSKP /DISK SKIP IOT
0753 7410 SKP /DID NOT SKIP
0754 2351 ISZ BDKP
0755 5751 JMP I BDKP /EXIT

```

```

/PLACE FOR DATA IN MANUAL MODE
/

```

```

0756 0000 DAT1, 0000
0757 0000 DAT2, 0000
0760 0000 DAT3, 0000
0761 0000 DAT4, 0000
0762 0000 DAT5, 0000
0763 0000 DAT6, 0000
0764 0000 DAT7, 0000
0765 0000 DAT8, 0000
0766 0000 DAT9, 0000
0767 0000 DAT10, 0000
0770 0000 DAT11, 0000
0771 0000 DAT12, 0000
/

```

```

0773 1047
0774 1000
0775 3574
0776 3575
0777 3572
1000

```

```

PAGE
/

```

```

/ROUTINE TO SELECT DRIVE NO.
/SEQUENTIAL SELECTION 0,1,2,3,0,1,ETC.
/

```

```

1000 2115 POLNEX, ISZ POLDISK /UPDATE POLE POINTER
1001 1115 TAD POLDISK /GET POINTER
1002 4436 SELCHK /CHECK IF DISK ON SYSTEM.
1003 5200 JMP POLNEX /NO, TRY NEXT DRIVE
1004 1115 TAD POLDISK
1005 7112 CLL RTN
1006 0061 AND K0001

```

```

1007 3122 DCA EXREG /SET EXT, DRIVE BIT
/

```

```

/DRIVE COMPLETED, START
/WRITE SEQUENCE
/SELECT DISK ADDRESS.
/

```

```

1010 1115 GOTIT, TAD POLDISK /GET DRIVE NO.
1011 0062 AND K0003 /MASK
1012 7104 CLL RAL /MOVE TO 9-10.
1013 1136 TAD INTCM /ADD IN OTHER.
1014 3136 DCA INTCM /SAVE INITIAL COMMAND.
1015 1777* TAD TRKFLG /GET TRACK FLAG
1016 7650 BNA CLA /WAS IT SET????
1017 4440 RANGEN /GET RANDOM DA.
1020 1161 TAD SPTRK1 /GET OPERATOR CONSTANT INPUT.
1021 0061 AND K0001 /MASK EXT, BIT.
1022 1136 TAD INTCM /ADD IN OTHER.
1023 3136 DCA INTCM /SAVE COMPLETE INITIAL COMMAND.
1024 1777* TAD TRKFLG /GET TRACK FLAG
1025 7650 BNA CLA /WAS IT SET????
1026 4440 RANGEN /USE RANDOM
1027 1162 TAD SPTRK2 /GET INPUT
1030 3124 DCA INTDA /SAVE INITIAL DA.
1031 1777* TAD TRKFLG
1032 7640 BZA CLA /INPUT BY OPERATOR?
1033 5247 JMP REWRT /LET HIM FAIL??
1034 1136 TAD INTCM
1035 7010 RAR
1036 7620 BNL CLA /EXT BIT SET?
1037 5247 JMP REWRT /NO, DON'T LIMIT DA.
1040 1145 TAD MAXTRK
1041 1124 TAD INTDA
1042 7630 SZL CLA /BEOND MAXIMUM LIMIT?
1043 5247 JMP REWRT /NO, DONT LIMIT.
1044 1124 TAD INTDA
1045 7040 CMA
1046 3124 DCA INTDA /YES, SET TO LEGAL LIMIT.
/

```

```

/WRITE INFORMATION
/CLEAR BUFFER ON THE FLY
/

```

```

1047 4441 REWRT, DISKGO /GO WRITE
1050 4400 4400 /WRITE DATA POINTER
1051 5263 JMP REREAD /WRITE O.K.
1052 7340 CLA CLL CMA
1053 3165 DCA ERPLG /SET WRITE ERROR FLAG
1054 4442 RESRAN /RESET GENERATOR
1055 2137 ISZ STATRY /UPDATE WRITE ME-TRY
1056 5776* JMP REFILL /TRY AGAIN
/

```

```

/CHECK FOR LOOP ON WRITE
/

```

```

1057 4406 LAS /GET SWITCH 0
1060 7710 TRYTIM, SPA CLA /LOOP ON WRITE????
1061 5775* JMP REFILL-2 /YES, TRY WRITE AGAIN

```

```

1062 5351      JMP      STRREL      /RESHARE ALL UNIVES ON ERROR
1063 1260      REREAD, TAD      TRYTIM
1064 3171      DCA      TRYCNT      /SETUP FOR SOFT ERROR RETRY
1065 3165      DCA      ERFLG      /CLEAR ERROR FLAG
1066 1106      TAD      M4
1067 3137      DCA      STATRY      /SETUP TRY COUNTER
1070 1106      TAD      M4
1071 3140      DCA      DATTRY      /SETUP TRY COUNTER
1072 3155      DCA      CRCCNT      /CLEAR CRC COUNTER!!!!

/
/READ INFORMATION;
/CHECK BUFFER UN TME FLY;
/

1073 4441      RDRY,   DISKGO      /READ DATA
1074 0400      0400      /READ DATA POINTER
1075 7610      SKP CLA      /DATA READ O.K.
1076 5305      JMP      RDSTA      /STATUS ERROR
1077 3155      DCA      CRCCNT      /CLEAR CRC COUNTER;

/
/CHECK DATA ON NO STATUS ERRORS;
/

1100 4774*     JMS      DTCHK      /CHECK DATA
1101 5324      JMP      RERUN      /DATA O.K.
1102 2140      ISZ      DATTRY      /UPDATE READ RE=TRY
1103 5273      JMP      RDRY      /TRY AGAIN
1104 5323      JMP      RERUN-1  /TRY TO SEEK IT
1105 1121      RDSTA,  TAD      STREG      /GET STATUS READ
1106 0065      AND      R0010      /MASK CRC
1107 7450      0NA      /CMC ERROR????
1110 5320      JMP      UPRY      /NO, TRY READ AGAIN
1111 3156      DCA      CRCFLG      /YES, SET FLAG
1112 2155      ISZ      CRCCNT      /UPDATE CRC POINTER

/
/CHECK DATA AFTER CRC ERROR;
/

1113 4774*     JMS      DTCHK      /CHECK DATA
1114 7610      SKP CLA      /IS A HARD ERROR;
1115 7340      CLA CLL CMA      /SET RETRY COUNTER;
1116 3165      DCA      ERFLG      /SETUP FOR 64 RETRY IF AC=7777
1117 7410      SKP      /CHECK ON RETRY!!!!
1120 3155      UPRY,   DCA      CRCCNT
1121 2137      ISZ      STATRY      /UPDATE TRY POINTER
1122 5273      JMP      RDRY      /TRY AGAIN
1123 3165      DCA      ERFLG      /IS A HARD ERROR
1124 3155      RERUN,  DCA      CRCCNT      /CLEAR CRC COUNT
1125 3156      DCA      CRCFLG      /CLEAR CRC FLAG
1126 4773*     JMS      CKTIM      /CHECK TIME POINTERS
1127 1165      TAD      ERFLG
1130 7650      SNA CLA      /IS IT 64 RETRY FOR SOFT ERROR?
1131 5334      JMP      +3      /NO DON'T BOTHER
1132 2171      ISZ      TRYCNT      /YES, UPDATE RETRY COUNTER
1133 5266      JMP      REREAD+3  /TRY AGAIN

/
/CHECK FOR LOOP ON READ;
/

```

```

1134 4406      LAS      /GET SWITCH 1
1135 7104      CLL RAL
1136 7710      SPA CLA      /LOOP????
1137 5263      JMP      REREAD      /YES, LOOP
1140 1137      TAD      STATRY      /TEST FOR HARD ERROR
1141 7650      SNA CLA
1142 5351      JMP      STRREL      /YES
1143 3165      DCA      ERFLG      /CLEAR ERROR FLAG

/
/CHECK FOR TYPE STATUS
/REPORT;
/

1144 4406      LAS      /MASK
1145 0017      AND      R0400      /TYPE STATUS REPORT????
1146 7640      SZA CLA
1147 4772*     JMS      TPSTA      /YES
1150 5771*     JMP      RUN      /DU NEXT DRIVE

/
/RESTORE DRIVE AFTER ERROR
/

1151 1123      STRREL, TAD      CMREG      /GET DRIVE NO.
1152 4443      RECAL      /RESTORE
1153 5771*     JMP      RUN      /START NEXT DRIVE

/
/ROUTINE TO DETERMINE IF TIMING NEEDS TO BE FOR APT SYSTEM.
/

1154 0000      XKTICK, 0
1155 4424      CHK22      /TEST FOR APT
1156 7410      SKP      /NO, RETURN TO NORMAL RUN
1157 5754      JMP I   XKTICK
1160 6201      CDF      0
1161 2150      ISZ      CLKCNT      /LONG COUNTER FOR APT
1162 5366      JMP      EXTICK      /NORMAL RETURN
1163 1100      TAD      R7700      /INIT COUNTER
1164 3150      DCA      CLKCNT
1165 4770*     JMS      KTIME      /NOTIFY APT
1166 6201      EXTICK,  CDF 0
1167 5754      JMP I   XKTICK
1170 0530
1171 0600
1172 3000
1173 2450
1174 1600
1175 0721
1176 0723
1177 3573

PAGE
1200 0000      ERNO,  0
1201 7001      IAC      /UPDATE AC FLAG

```

```

1202 3374          DCA  PCNTR2          /SAVE NON-RECOVERABLE POINTER;
/
/COMPUTE WAY TO "HARD"/"SOFT" TALLYS;
/
1203 1377          TAD  K7773
1204 3375          DCA  PCNTR3          /LINE COUNTER
1205 1123          TAD  CMREG          /GET LAST COMMAND
1206 0063          AND  K0006          /MASK DRIVE NUMBER
1207 7170          CLL  CML  CMA  RAR
1210 3373          DCA  PCNTR1          /SETUP COUNTER
1211 1062          TAD  K0003
1212 2373          ISZ  PCNTR1
1213 5211          JMP  ,+2          /COMPUTE WAY TO BUFFER
1214 1153          TAD  STAPOT
1215 3373          DCA  PCNTR1          /PINTER TO BUFFER
/
/DETERMINE IF ERROR IS "HARD" OR "SOFT";
/
1216 1156          TAD  CRCPLG          /GET CRC FLAG
1217 7650          SNA  CLA          /CRC ERROR???
1220 5251          JMP  NTSOFT          /NO, WAS DEFINITELY A HARD ERROR;
1221 1600          TAD  I  ERRO          /GET ERROR POINTER;
1222 7650          SNA  CLA          /WAS IT FIRST TIME?
1223 5255          JMP  NTERR          /NO ERROR, ADDITIONAL CRC DATA;
1224 1125          TAD  DAREG          /COMPARE FAILING SECTOR TO
1225 0066          AND  K0017          /SECTOR WHERE DATA ERROR
1226 7041          CIA
1227 1131          TAD  ASREG          /OCCURRED;
1230 7640          SZA  CLA          /SAME SECTOR?
1231 5251          JMP  NTSOFT          /NO, "HARD" ERROR
1232 7340          CLA  CLL  CMA
1233 1155          TAD  CRCCNT          /GET CRC COUNTER
1234 7450          SNA
1235 5245          JMP  SOFT          /WAS THIS FIRST POSSIBLE "SOFT"?
1236 1110          TAD  K7775          /YES, UPDATE "SOFT" TALLY;
1237 7650          SNA  CLA          /CHECK IF NONRECOVERABLE "SOFT";
1240 2373          ISZ  PCNTR1          /WAS IT?
1241 1773          TAD  I  PCNTR1          /NO, DUMP "SOFT" TALLY;
1242 7440          SZA
1243 1101          TAD  K7777          /OTHERWISE DUMP "HARD" TALLY;
1244 5254          JMP  NTERR-1          /DONT GO BACK WAROS!!!!!!
1245 1101          TAD  K7777          /DUMP APPROPRIATE TALLY!!
1246 1773          TAD  I  PCNTR1          /DUMP IT;
1247 3773          DCA  I  PCNTR1          /REDUCE HARD ERROR COUNT
1250 2373          ISZ  PCNTR1          /YES, UPDATE POINTER
1251 1101          NTSOFT, TAD  K7777
1252 2773          ISZ  I  PCNTR1          /UPDATE ERROR COUNT
1253 7610          SKP  CLA
1254 3773          DCA  I  PCNTR1          /HOLD AT 7777
/
/CHECK INHIBIT SW;
/
1255 4423          NTERR, JMS  I  KERRRO          /REPORT ERROR TO APT IF REQUIRED
1256 4406          LAR
1257 7106          CLL  RTL
    
```

```

1260 7710          SPA  CLA          /INHIBIT ERRORS????
1261 5356          JMP  ERROEX+1          /YES
/
/CHECK FOR NO HEADER ON SECOND DATA ERROR;
/
1262 1600          DOMEAU, TAD  I  ERRO          /GET TEXT POINTER
1263 7650          SNA  CLA          /DATA ERROR?
1264 5355          JMP  ERROEX          /EXIT
/
/TYPE ERROR MESSAGE;
/
1265 4457          CRLF
1266 4457          CRLF
1267 1374          TAD  PCNTR2          /GET NON-RECOV. FLAG
1270 7640          SZA  CLA          /WAS IT SET
1271 5275          JMP  ,+4          /NO DON'T TYPE IT
1272 7340          CLA  CLL  CMA
1273 4455          PRNTR          /PRINT "NON-RECOVERABLE "
1274 3335          MES4
1275 1600          TAD  I  ERRO          /GET TEXT POINTER;
1276 1376          TAD  HEUTAD          /MAKE ERROR HEADER POINTER;
1277 3120          DCA  PCREG          /SAVE POINTER;
1300 1520          TAD  I  PCREG          /GET CORRECT TEXT;
1301 3304          OCA  ,+3
1302 7340          CLA  CLL  CMA
1303 4455          PRNTR          /PRINT HEADER
1304 7402          HLT
1305 7340          CLA  CLL  CMA
1306 4455          PRNTR          /PRINT "ERROR"
1307 3303          MES0
1310 4457          CRLF
1311 1200          TAD  ERRO
1312 3120          DCA  PCREG          /SAVE PC
1313 2200          ISZ  ERRO
1314 1600          TAD  I  ERRO
1315 3371          OCA  ESAYE
1316 2200          ISZ  ERRO          /UPDATE FOR RETURN
1317 1172          TAD  XTEXT
1320 3374          OCA  PCNTR2
1321 1372          TAD  XREG
1322 3010          DCA  AUTO10
1323 1105          TAD  M12
1324 3373          DCA  PCNTR1          /COUNTER FOR # OF HEADS
1325 1371          STNAUT, TAD  ESAYE          /GET TEXT POINTER
1326 7500          SNA
1327 5363          JMP  NOTEX          /NOT THIS ONE
1330 7104          CLL  RAL
1331 3371          DCA  ESAYE
1332 2375          ISZ  PCNTR3          /UPDATE LINE FILL COUNTER
1333 7610          SKP  CLA          /NO CRLF
1334 4457          CRLF
1335 1374          TAD  PCNTR2          /GET TEXT MESSAGE POINTER
1336 2374          ISZ  PCNTR2
1337 2374          ISZ  PCNTR2
1340 3343          DCA  ,+3          /STONE FOR PRINTER
    
```

```

1341 7340      CLA CLL CMA
1342 4455      PRNTR
1343 7402      MLT
1344 1410      TAD I  AUTO10
1345 4456      UCTEL
1346 2373      AGAIN, ISZ  PCNTR1
1347 5325      JMP  STHAUT
1350 1520      TAD I  PCNEG
1351 1106      TAD  M4
1352 7650      SNA CLA
1353 4573      JMS I  PRNDAT
1354 5360      JMP  .+4
1355 4573      ERROEX, JMS I  PRNDAT
1356 2200      ISZ  ERMO
1357 2200      ISZ  ERMO
1360 7301      CLA CLL IAC
1361 4454      CLRALL
1362 5600      JMP I  ERMO
1363 7104      NOTEX, CLL RAL
1364 3371      DCA  ESAVE
1365 2374      ISZ  PCNTR2
1366 2374      ISZ  PCNTR2
1367 2010      ISZ  AUTO10
1370 5346      JMP  AGAIN

```

```

/
1371 0000      ESAVE, 0
1372 0117      XREG, PCREG-1
1373 0000      PCNTR1, 0
1374 0000      PCNTR2, 0
1375 0000      PCNTR3, 0
1376 1377      HEDTAD, BUFPNT=1
1377 7773      K7773, 7773

```

```

/
1400 1400      PAGE
/
/POINTERS FOR TEXT INFORMATION:
/
1400 3247      BUFPNT, ERTX1
1401 3255      ERTX2
1402 3264      ERTX3
1403 3276      ERTX4

```

```

/ROUTINE TO CHECK FOR CLASSIC AND LIMIT
/TRANSFERS TO FIELD 0 IF AVAILABLE.
/

```

```

1404 0000      CLAFLD, 0
1405 1022      TAD  22
1406 0017      AND  K0400
1407 7650      SNA CLA
1410 5604      JMP I  CLAFLD
1411 7340      CLA CLL CMA
1412 3143      DCA  MAXFLD
1413 5604      JMP I  CLAFLD

```

```

/ROUTINE TO DO CRLF

```

```

/
1414 0000      UPONE, 0
1415 7300      CLA CLL
1416 1224      TAD  K0215
1417 4445      TYPE
1420 1225      TAD  K0212
1421 4445      TYPE
1422 4445      TYPE
1423 5614      JMP I  UPONE

```

```

/
1424 0215      K0215, 0215
1425 0212      K0212, 0212
/ROUTINE TO PRINT FOUR OCTAL
/

```

```

1426 0000      PROCT, 0
1427 7006      RTL
1430 7006      RTL
1431 3214      DCA  UPONE
1432 1106      TAD  M4
1433 3250      DCA  PRN
1434 1214      TAD  UPONE
1435 0064      AND  K0007
1436 1067      TAD  K0260
1437 4445      TYPE
1440 1214      TAD  UPONE
1441 7006      RTL
1442 7004      RAL
1443 3214      DCA  UPONE
1444 2250      ISZ  PRN
1445 5234      JMP  .+11
1446 4431      SPACE
1447 5626      JMP I  FRUCT

```

```

/SUBROUTINE TO PRINT TEXT
/
1450 0000      PRN, 0
1451 7650      SNA CLA
1452 4457      CRLF
1453 1650      TAD I  PRN
1454 2250      ISZ  PRN
1455 3226      DCA  FRUCT

```

```

1456 7300      MKPRN, CLA CLL
1457 1626      TAD I  FRUCT
1460 0077      AND  K7700
1461 7450      SNA
1462 5304      JMP  EXIT
1463 7500      SNA
1464 7020      CML
1465 7001      IAC
1466 7012      RTR
1467 7012      RTR

```

```

1470 7012      RTR
1471 4445      TYPE
1472 1626      TAD I   FROCT
1473 0102      AND     K0077
1474 7450      SNA
1475 5304      JMP     EXIT
1476 1313      TAD     K3740
1477 7500      SNA
1500 1074      TAD     K4100
1501 4431      SPACE           /SPACE OUT 1
1502 2226      ISZ     FROCT
1503 5256      JMP     MRPRN     /MORE TO PRINT
1504 7300      EXIT,  CLA CLL
1505 5650      JMP I   PRN

/
/ROUTINE TO SPACE OUT 1
/
1506 0000      SPAC,  0
1507 1312      TAD     K0240
1510 4445      TYPE
1511 5706      JMP I   SPAC

/
1512 0240      K0240, 240
1513 3740      K3740, 3740

/
/THIS ROUTINE WILL BE A SKIP INSTRUCTION FOR SYSTEMS WITHOUT CLASSIC
/OTHERWISE IT WILL EXECUTE THE NEXT INSTRUCTION IN FIELD 0 AND THEN
/SKIP THE INSTRUCTION AFTER THAT ONE.
/
1514 0000      CLASIK, 0
1515 3345      DCA     SAVEAC           /SAVE CURRENT AC.
1516 1714      TAD I   CLASIK           /GET INSTRUCTION TO EXECUTE,
1517 3344      DCA     ROUTHMP          /SAVE IT.
1520 2314      ISZ     CLASIK
1521 1022      TAD     UP2
1522 0017      AND     K0400
1523 7640      SZA CLA           /ARE WE ON CLASSIC?
1524 5327      JMP     ,+3             /YES.
1525 1345      TAD     SAVEAC           /NO, THEN
1526 5714      JMP I   CLASIK           /EXIT.
1527 2314      ISZ     CLASIK
1530 6211      COF     10
1531 1020      TAD     SWR
1532 3777      DCA I   (SWR)           /SAVE SWITCH REGISTER.
1533 1021      TAD     UP1
1534 3776      DCA I   (OP1)           /SAVE CONTROL 1.
1535 1022      TAD     OP2
1536 3775      DCA I   (OP2)
1537 1344      TAD     ROUTHMP
1540 3774      DCA I   (ROUTINS)       /SAVE ROUTINE IN FIELD 1.
1541 1345      TAD     SAVEAC           /GET BACK AC.
1542 6212      CIF     10
1543 5774      JMP I   (ROUTINS)       /GO AND EXECUTE INSTRUCTION,

/
1544 0000      ROUTHMP, 0

```

```

1545 0000      SAVEAC, 0
/
/ROUTINE TO GET THE SWITCHES.
/
1546 0000      MYLAS, 0
1547 4407      CLASIK           /CHECK FOR CLASSIC,
1550 4425      C0CKSW          /GET SWITCHES.
1551 7604      TAD     7604
1552 5746      JMP I   MYLAS           /EXIT.

/
/ROUTINE TO RESET REGISTERS FOR ERROR PRINTER
/
1553 0000      SETREG, 0
1554 1073      TAD     K0000           /GET STATUS
1555 3121      DCA     STMEG           /SAVE FOR ERROR PRINTER
1556 7340      CLA CLL CMA           /DECREASE BY 1
1557 1111      TAD     TRASH1          /GET SECTOR POINTER
1560 0066      AND     K0017
1561 1112      TAD     TRASH2          /ADD IN ADDRESS
1562 3125      DCA     DAMEG           /SAVE FOR ERROR PRINTER
1563 1170      TAD     FIXTIM          /CHECK IF FIRST SECTOR?
1564 7640      SZA CLA           /IF 80, DON'T UPDATE COMMAND!
1565 5753      JMP I   SETREG          /NO, DON'T!
1566 1174      TAD     SAVCH           /GET COMMAND REG.
1567 3123      DCA     CMREG           /SAVE FOR ERROR PRINTER
1570 5753      JMP I   SETREG          /RETURN

/
1574 1302
1575 0022
1576 0021
1577 0020
1600          PAGE

/
/ROUTINE TO CHECK DATA READ
/
1600 0000      DTCHK, 0
1601 1156      TAD     CRCFLG          /GET CRC FLAG
1602 7640      SZA CLA           /WAS IT SET?
1603 5212      JMP     WRDCHK          /YES, THEN WORD BY WORD CHECK!!!
1604 1142      TAD     FNDSUM          /GET CHECK SUM FOUND
1605 7041      CIA
1606 1141      TAD     CHKSAV          /COMPARE TO GOOD VALUE SAVED
1607 7650      SNA CLA           /WERE THEY THE SAME
1610 5000      JMP I   DTCHK          /YES, DATA O.K.
1611 7340      CLA CLL CMA
1612 3446      WRDCHK, DCA I XEMRO     /SETUP CHECKSUM ERROR FLAG
1613 1123      TAD     CMREG

/
1614 0015      AND     K0100
1615 7640      SZA CLA           /HALT BLOCK SET??
1616 1016      TAD     K0200          /YES!
1617 1104      TAD     K7400
1620 3112      DCA     TRASH2
1621 1112      TAD     TRASH2
1622 7040      CMA

```

```

1623 3314 DCA MSKER
1624 7340 CLA CLL CMA
1625 3142 DCA FNDSUM /SET FIRST TIME FLAG
1626 4442 RESRAN /NO, SETUP RANDOM GENERATOR
1627 1130 TAD FWREG /GET FINAL WC
1630 4435 SETFLD /GET AUTO11+ BUFTAL+ FIELD
1631 3246 DCA GOCDF /SAVE FIELD CDF
1632 1112 TAD TRASH2
1633 3361 DCA RSRAN
1634 1124 TAD INTDA
1635 3353 DCA STGEN
1636 1361 DTRI, TAD RSRAN
1637 0314 AND MSKER
1640 3132 DCA WAREG
1641 1353 TAD STGEN
1642 0066 AND K0017
1643 3131 DCA ASREG
1644 4427 RANDAT /GENERATE DATA
1645 3134 DCA DGREG /SAVE GOOD DATA POINTER
1646 7402 GOCDF, HLT/CDP /CDF TO BUFFER FIELD
1647 1411 TAD I AUTO11 /GET BAD DATA WORD
1650 0201 CDF 0 /HOLD OF
1651 3135 DCA DMREG /SAVE BAD WORD
1652 1011 TAD AUTO11 /GET ADDRESS
1653 3133 DCA ADREG /SAVE FOR PRINTER
1654 1135 TAD DBREG /GET DATA READ
1655 7041 CIA
1656 1134 TAD DGREG /COMPARE TO GOOD VALUE
1657 7650 SNA CLA /WERE THEY THE SAME
1660 5272 JMP NOERR /YES, NO ERROR
1661 2142 ISZ FNDSUM /FIRST TIME PRINT????
1662 5310 JMP NTRKS /NO, JUST ADDRESS AND DATA
1663 1156 TAD CRCFLG /GET CRC FLAG
1664 7650 SNA CLA /IF SET NO NON-RECOVERABLE.
1665 1140 TAD DATTRY /NO, GET NON-RECOVERABLE FLAG.
1666 2200 ISZ DTCHK /UPDATE FOR ERROR RETURN
1667 4446 ERROR /ENRDR DATA
1670 0004 0004 /PUNTER
1671 7760 7760 /PUNTER
1672 2361 NOERR, ISZ RSRAN
1673 5300 JMP .+5
1674 2353 ISZ STGEN
1675 7000 NOP
1676 1112 TAD TRASH2
1677 3361 DCA RSRAN
1678 2117 ISZ BUFTAL /UPDATE BUFFER TALLY
1679 5236 JMP DTM1 /MORE WORDS TO CHECK
1682 1446 TAD I XENRD /GET ERROR INDICATOR!
1683 7650 SNA CLA /WAS THERE AN ERROR?
1684 3155 DCA CRCCNT /NO, CLEAR CRC COUNTER
1685 2446 ISZ I XENRD /CHECK FOR COMPUTER ERROR?
1686 5600 JMP I DTCHK /ALL O.K.
1687 4576 BADHLT, JMS I SGMLT /COMPUTER MUST BE DOWN, CHECKSUM
1688 4446 NTRKS, ERROR /OTHER ERRORS IN BUFFER
1711 0000 0000

```

```

1712 0000 0000
1713 5272 JMP NOERR /CHECK REST OF BUFFER
1714 0000 MSKER, 0
/ROUTINE TO GENERATE RANDOM NUMBERS
/
1715 0000 RANDOM, 0
1716 7301 CLA CLL IAC
1717 1373 TAD RAD1
1720 1374 TAD RAD2
1721 1375 TAD RAD3
1722 3373 DCA RAD1
1723 7004 RAL
1724 1373 TAD RAD1
1725 1374 TAD RAD2
1726 1375 TAD RAD3
1727 3374 DCA RAD2
1730 7004 RAL
1731 1373 TAD RAD1
1732 1374 TAD RAD2
1733 1375 TAD RAD3
1734 3375 DCA RAD3
1735 1375 TAD RAD3
1736 5715 JMP I RANDOM /EXIT, RANDOM NUMBER IN AC
/
/GENERATOR FOR RANDOM DATA
/
1737 0000 GNDAT, 0
1740 7301 CLA CLL IAC
1741 1367 TAD RAN1
1742 1370 TAD RAN2
1743 7106 CLL RTL
1744 3367 DCA RAN1
1745 1370 TAD RAN2
1746 7012 RTH
1747 1367 TAD RAN1
1750 3370 DCA RAN2
1751 1370 TAD RAN2
1752 5737 JMP I GNDAT
/
/ROUTINE TO SAVE RANDOM GENERATOR
/
1753 0000 STGEN, 0
1754 1367 TAD RAN1
1755 3371 DCA SAV1
1756 1370 TAD RAN2
1757 3372 DCA SAV2
1760 5733 JMP I STGEN
/
/ROUTINE TO RESET RANDOM GENERATOR
/
1761 0000 RSRAN, 0
1762 1371 TAD SAV1
1763 3367 DCA RAN1

```

```

1764 1372      TAD      SAV2
1765 3370      DCA      RAN2
1766 5761      JMP I   RSMAN
/
1767 1234      RAN1,   1234
1770 5670      RAN2,   5670
/
1771 0000      SAV1,   0
1772 0000      SAV2,   0
1773 1234      RAD1,   1234
1774 5670      RAD2,   5670
1775 4321      RAD3,   4321
/
/
2000          PAGE
/
/ROUTINE TO WAIT FOR KEY FROM OPERATOR.
/
2000 0000      WAIT,   0
2001 6032      KCC
2002 6031      KBF
2003 5202      JMP     , -1
2004 6036      KRB
2005 0234      AND     K177
2006 1016      TAD     K0200
2007 3235      DCA     CHKN
/SAVE CHARACTER
2010 1022      TAD     22
/CHECK FOR CLASSIC
2011 0017      AND     K0400
/MASK CLASSIC BIT
2012 7650      SNA    CLA
/CLASSIC=NON ZERO
2013 5226      JMP     WAIT1
2014 1235      TAD     CHKN
/RESTORE CHAR. FOR CLASSIC
2015 6211      CDF     10
2016 3777*     DCA     C0CHAR
/SAVE CHARACTER,
2017 2776*     ISZ     INMODE
2020 1777*     TAD     C0CHAR
/GET BACK AC,
2021 6201      CDF     0
2022 4407      CLASIC
/CHECK FOR CLASSIC,
2023 4427      C0CNTR
/ROUTINE TO EXECUTE,
2024 7000      NOP
2025 7300      CLA    CLL
/CLEAR CLASSIC AC RETURN
2026 1235      WAIT1,  TAD     CHKN
/RESTORE CHARACTER
2027 6046      TLF
2030 6041      TBF
2031 5230      JMP     , -1
2032 6042      TCF
2033 5600      JMP I   WAIT
/EXIT
/
2034 0177      K177,  0177
/
/ROUTINE TO CHECK FOR YES OR NU
/
2035 0000      CHKN,   0
2036 3200      DCA     WAIT
/SAVE POINTER
2037 1235      TAD     CHKN
/GET PC STORED
2040 3260      DCA     CHKPOT
/SAVE IT

```

```

2041 1200      TAD     WAIT
2042 2235      ISZ     CHKN
2043 7041      CIA
2044 1257      TAD     K0316
2045 7650      SNA    CLA
/NO WAS IT A NO
2046 5635      JMP I   CHKN
/YES
2047 1200      TAD     WAIT
2050 2235      ISZ     CHKN
2051 7041      CIA
2052 1256      TAD     K0331
2053 7650      SNA    CLA
/NO WAS IT A YES
2054 5635      JMP I   CHKN
/YES
2055 5600      JMP I   CHKPOT
/NO WAS NEITHER
/
/
2056 0331      K0331, 0331
2057 0316      K0316, 0316
/
/ROUTINE TO CHECK DISK RUN POINTERS
/
2060 0000      CHKPOT, 0
2061 0064      AND     K0007
2062 1154      TAD     MNPOT
2063 3200      DCA     WAIT
2064 1600      TAD I   WAIT
/GET RUN POINTER
2065 7640      SZA    CLA
/RUN THIS DRIVE
2066 2260      ISZ     CHKPOT
/NO
2067 5600      JMP I   CHKPOT
/EXIT
/
/ROUTINE TO TEST FOR APT AND SET UP APPROPRIATE
/REGISTERS IN UN THE SYSTEM.
/
2070 0000      APT0,   0
2071 4424      CHK22
/TEST FOR APT
2072 5301      JMP     , +7
/YES
2073 4407      CLASIC
2074 4431      C0SWIT
2075 7000      NOP
2076 1355      TAD     K7000
2077 3775*     DCA     SKPNOP
2100 5351      JMP     EXIT0
/EXIT
2101 1022      TAD     OP2
2102 0354      AND     K7577
/NO CONSOLE PACKAGE
2103 3022      DCA     UP2
2104 1355      TAD     K7000
2105 3774*     DCA     MYLAS+3
/NO SWITCH REGISTER
/NO OPERATOR INTERVENTION ALLOWED
2106 1022      TAD     OP2
2107 0064      AND     K0007
/GET # OF DRIVES
2110 3111      DCA     TRASH1
2111 1022      TAD     OP2
2112 0015      AND     K0100
2113 7650      SNA    CLA
/NO SINGLE DRIVE = NON ZERO AC
2114 5325      JMP     M0USKS
/NO

```



```

2115 7301      CLL CLA IAC
2116 3000      DCA AMOUNT          /ONLY ONE DRIVE
2117 1111      TAD TRASH1      /GET DRIVE NUMBER
2120 1154      TAD MUNPOT
2121 3111      DCA TRASH1
2122 7340      CLL CLA CMA
2123 3511      DCA I TRASH1      /DU THIS DRIVE
2124 5342      JMP MEMSET
2125 1111      MODSKS, TAD TRASH1
2126 7040      CMA
2127 3112      DCA TRASH2      /SAVE THE NUMBER OF DRIVES
2130 3111      DCA TRASH1
2131 1111      TAD TRASH1
2132 1154      TAD MUNPOT      /ESTABLISH DRIVE
2133 3113      DCA TRASH3
2134 7340      CLL CLA CMA
2135 3513      DCA I TRASH3      /DU THIS DRIVE
2136 2111      ISZ TRASH1
2137 2000      ISZ AMOUNT
2140 2112      ISZ TRASH2      /DONE?
2141 5331      JMP MODSKS+4      /MORE TO DO
2142 1021      MEMSET, TAD Z1
2143 7012      RTR
2144 0004      AND K0007
2145 7104      CLL RAL
2146 7006      RTL
2147 7040      CMA          /NEGATIVE AMOUNT OF FIELDS.
2150 3143      DCA MAXFLD
2151 2270      EXAPTS, ISZ APT8
2152 2270      ISZ APT8
2153 5670      JMP I APT8
/
2154 7377      K7377, 7377
2155 7000      K7000, 7000
/
/THIS ROUTINE WILL NOTIFY APT OF AN ERROR.
/ONLY THE DRIVE IN ERROR IS ESTABLISHED.
/
2156 0000      AERROR, 0
2157 4424      CHK2          /CHECK FOR APT=0.
2160 7410      SKP
2161 5756      JMP I AERROR      /EXIT
2162 6002      IOF
2163 7200      CLA
2164 1115      TAD POLD8K      /DRIVE NUMBER
2165 0004      AND K0007
2166 6201      CDF 00
2167 6272      CIF 70
2170 5772      JMP I K6520      /NOTIFY APT
2171 7402      MLT          /SOMETHING WENT WRONG IF IT GETS HERE
/
2172 6520      K6520, 6520

```

```

2177 1075      PAGE
2178 2200
/
/ROUTINE TO WRITE OR READ SECTORS SELECTED
/
2200 0000      DSKGO, 0
2201 7340      CLA CLL CMA
2202 3170      DCA FINTIM      /SETUP FIRST TIME POINTER
2203 3156      DCA CRCFLG      /CLEAR CRC FLAG
2204 1126      TAD CAREG      /GET INITIAL CURRENT ADDRESS
2205 4452      LOCUR          /LOAD CURRENT ADDRESS
2206 1127      TAD WCREG
2207 3130      DCA FWREG      /SETUP FINAL WC
2210 1124      TAD INTDA      /GET INITIAL STARTING SECTOR
2211 3111      DCA TRASH1      /SAVE
2212 1124      TAD INTDA      /GET DISK ADDRESS
2213 0100      AND K7760      /MASK
2214 3112      DCA TRASH2      /SAVE
2215 1136      TAD INTCM      /GET INITIAL COMMAND
2216 1000      TAD I DSKGO      /GET READ OR WRITE
2217 4451      LOCMD          /LOAD COMMAND
2220 1123      TAD CMREG
2221 1075      TAD K1000      /MAKE READ ALL OR WRITE ALL
2222 3174      DCA SAYCM      /SAVE FOR SWITCH TO CONSECUTIVE MODE
2223 1111      TAD TRASH1      /SECTOR TO DO
2224 0006      AND K0017      /MASK
2225 1112      TAD TRASH2      /ADD TO TRACK
2226 4453      LDADD          /LOAD AND GO
2227 6001      ION          /TURN INTERRUPT ON
/
/ROUTINE TO CLEAR OR CHECK SUM BUFFER UN THE FLY
/
2230 3777*     GODAK, DCA TIMER2      /CLEAR LONG TIMER
2231 3142      DCA FNDSUM      /CLEAR SUM CHECK
2232 4435      SETFLD      /GET FIELD TO BUFFER
2233 3254      DCA CHNCFD      /SAVE CDF
2234 1170      TAD FINTIM
2235 7650      SNA CLA          /TIME TO GO
2236 5241      JMP STRWRK      /YES!!!!
2237 4776*     JMP TIME          /WAIT FOR FIRST INTERRUPT
2240 5234      JMP           =4      /NOT HERE YET
2241 1117      STRWRK, TAD BUPTAL
2242 7041      CIA
2243 1130      TAD FWREG      /COMPARE TO SOFTWARE FINAL
2244 7450      SNA           /WAIT FOR DISK???
2245 5274      JMP WRKDON      /YES!!!!
2246 7041      CIA
2247 3175      DCA CLNBAK      /SAVE DIFFERENCE
2250 1175      TAD CLNBAK
2251 7041      CIA
2252 1117      TAD BUPTAL
2253 3117      DCA BUPTAL      /UPDATE BUFFER TALLY
2254 7402      CHNCFD, MLT      /CDF TO BUFFER FIELD
2255 1123      TAD CMREG
2256 7700      SNA CLA          /READ OR WRITE

```

```

2257 5264      JMP      WASRD      /WAS A READ!!
2260 3411      GOCLR, DCA I  AUTO11  /WAS A WRITE, CLEAR BUFFER
2261 2175      ISZ      CLNBAK  /UPDATE TALLY
2262 5260      JMP      GOCLR      /MORE TO CLEAR
2263 5274      JMP      WRKDON    /DONE WITH SOME
2264 1142      WASRD, TAD      FNDSUM
2265 7100      GDCHK, CLL
2266 1411      TAD I  AUTO11  /GET WORD
2267 7430      SZL
2270 7001      IAC
2271 2175      ISZ      CLNBAK  /UPDATE CLEAR POINTER
2272 5265      JMP      GDCHK      /MORE TO CHECKSUM
2273 3142      DCA      FNDSUM  /SAVE IT
2274 6201      WRKDON, CDF      0
2275 1117      TAD      BUPTAL
2276 7650      SNA CLA  /LAST WORD DONE????
2277 5302      JMP      DSKEK  /EXIT
2300 4776      JMS     TIME   /TIME AND WAIT
2301 5241      JMP     STRHRK  /WAIT FOR INT, OR DONE!!!!
2302 2200      DSKEK, ISZ   DSKGO
2303 5600      JMP I  DSKGO  /EXIT

/
/INTERUPT SERVICE
/
2304 6741      RETURN, DSKP      /DISK SKIP IOT
2305 5353      JMP      NODSKP  /NOT THE DISK
2306 2111      ISZ      TRASH1  /UPDATE SECTOR NUMBER
2307 7000      NOP
2310 1114      TAD      UPVATE  /IT WON'T WORK WITHOUT IT!
2311 1130      TAD      FWREG
2312 3130      DCA      FWREG  /UPDATE WORD COUNT
2313 6745      STATUS, DRST
2314 1073      TAD      K4000
2315 7440      SZA
2316 5337      JMP      STATER  /ONLY DONE FLAG?
2317 1130      TAD      FWREG  /STATUS ERROR
2320 7650      SNA CLA  /LAST TRANSFER?
2321 5365      JMP      TRDONE  /TRANSFER IS DONE
2322 3170      DCA      FINTIM  /CLEAR FIRST TIME POINTER!
2323 1174      TAD SAVCM  /GET READ OR WRITE COMMAND
2324 6746      RDLWRL, DLDC  /LOAD COMMAND REGISTER
2325 1111      TAD      TRASH1  /GET SECTOR TO DO
2326 0064      AND      K0017  /MASK OFF
2327 1112      TAD      TRASH2  /ADD IN TRACK
2330 6743      LODGO, DLAG  /LOAD DISK ANFD GO
2331 1107      RETRN, TAD   SVLNK  /GET LINK
2332 7110      CLL RAM
2333 1106      TAD      SAVAC
2334 6244      RMF
2335 6001      ION
2336 5400      JMP I  0
2337 4775      STATER, JMS  SETREG  /SETUP REGISTERS!
2340 1123      TAD      CMREG
2341 7710      SPA CLA
2342 7001      IAC
/WRITE OR READ
/WRITE

```

```

2343 7001      IAC
2344 3347      DCA      +-3
2345 1137      TAD      STATRY  /MODIFY HEADER POINTER
2346 4446      ERROR  /GET TRY POINTER
2347 0000      0000  /PRINT MESSAGE
2350 7770      7770  /MODIFIED HEADER POINTER
2351 2200      ISZ      DSKGO  /MESSAGE POINTER
2352 5302      JMP      DSKEK  /UPDATE FOR ERROR
2353 3374      NODSKP, DCA  TIMER3  /EXIT
2354 2374      ISZ      TIMER3
2355 5354      JMP      -=1
2356 4407      CLASIC  /WAIT FOR DISK TO STOP.
2357 4440      CCKCPA  /CHECK FOR CLASSIC.
2360 7000      NOP  /ROUTINE TO EXECUTE.
2361 6031      K8F
2362 4576      INTER2, JMS I  00MLT  /KEYBOARD FLAG??
2363 6032      KCC  /ILLEGAL INTERRUPT
2364 5331      JMP      RETRN
2365 4775      TRDONE, JMS  SETREG  /EXIT BACK.
2366 3170      DCA      FINTIM  /SETUP REGISTERS!
2367 1167      TAD      SVLNK  /CLEAR FIRST TIME POINTER!
2370 7110      CLL RAM
2371 1106      TAD      SAVAC  /REPLACE LINK
2372 6244      RMF  /REPLACE AC
2373 5400      JMP I  0  /RESTORE MEMORY FIELDS+ FLAGS
/RETURN TO BACK GROUND
/
2374 0000      TIMER3, 0
/
2375 1553
2376 3123
2377 3141
2400      PAGE
/
/ROUTINE TO GET ONE IN OCTAL
/
2400 0000      OCT1, 0
2401 4444      RECEIV  /RECEIVE
2402 3354      DCA      LOAD  /SAVE IT
2403 1600      TAD I  OCT1  /GET LIMITS
2404 0064      AND      K0007  /GET LIMITS
2405 1067      TAD      K0260  /MASK
2406 7141      CLL CIA
2407 1354      TAD      LOAD  /GET INPUT
2410 7620      SNL CLA  /IN LIMITS????
2411 5226      JMP      INERR  /NO, ERROR EXIT
2412 1600      TAD I  OCT1  /GET LIMITS
2413 0014      AND      K0070  /GET LIMITS
2414 7110      CLL RAM  /MASK
2415 7012      RTR
2416 1067      TAD      K0260
2417 7040      CMA
2420 1354      TAD      LOAD  /GET INPUT
2421 7630      SZL CLA  /IN LIMITS????
2422 5226      JMP      INERR  /NO, ERROR
2423 1354      TAD      LOAD  /GET INPUT

```

```

2424 0064 AND K0007 /MASK
2425 2200 ISZ OCT1
2426 2200 INERK, ISZ OCT1
2427 5600 JMP I OCT1 /GOOD EXIT
/
/Routine TO RECEIVE FOUR OCTAL
/
2430 0000 OCT4, 0
2431 1106 TAD M4
2432 3341 DCA RDST /SETUP COUNTER
2433 3350 DCA LDCA /START WITH 0
2434 4432 ONEIN /RECEIVE ONE OCTAL
2435 0070 0070 /LIMITS
2436 5630 JMP I OCT4 /ENRUR EXIT
2437 1350 TAD LDCA /GET LAST
2440 2341 ISZ RDST /UPDATE COUNTER
2441 7410 SKP
2442 5246 JMP ,+4 /EXIT
2443 7004 HAL
2444 7006 RTL
2445 5233 JMP OCT4+3
2446 2230 ISZ OCT4
2447 5630 JMP I OCT4 /EXIT OCTAL IN AC
/
/Routine TO UPDATE AND CHECK FOR PASS COMPLETE
/

```

```

2450 0000 CKTIM, 0
2451 1115 TAD POLOSK
2452 0064 AND K0007 /SETUP CURRENT DRIVE #
2453 3341 DCA RDST /POINTER
2454 1341 TAD RDST
2455 1152 TAD TIMPOT /GET TIME POINTER
2456 3354 DCA LDAD /SAVE IT
2457 7301 CLA CLL IAC /ONE FOR 0
2460 1147 TAD CONSEC /GET AMOUNT DONE
2461 1754 TAD I LDAD /ADD IN AMOUNT COMPLETED SO FAR
2462 3754 DCA I LDAD /SAVE IT
2463 7620 SNL CLA /LINK UP????
2464 5650 JMP I CKTIM /NO, EXIT
2465 4440 RANGEN /GET RANDOM NUMBER
2466 3777 DCA RAN1 /RE-PRIME GENERATOR
2467 4440 RANGEN /GET RANDOM NUMBER
2470 3776 DCA RAN2 /RE-PRIME GENERATOR
2471 7100 CLL
2472 1354 TAD LDAD
2473 1013 TAD K0004
2474 3354 DCA LDAD /SECOND TIME POINTER
2475 2754 ISZ I LDAD /UPDATE IT
2476 1754 TAD I LDAD /GET COUNT
2477 1144 TAD MAXTIM /ADD IN FUDGE FACTOR
2500 7620 SNL CLA /PASS COMPLETE????
2501 5650 JMP I CKTIM /NO, EXIT
2502 3754 DCA I LDAD /ZERU SECCOUND COUNTER
2503 1341 TAD RDST
2504 7040 CMA

```

```

2505 3341 DCA RDST /SETUP COUNTER
2506 1362 TAD CMPPOT /ADD IN POINTER
2507 1062 TAD K0003
2510 2341 ISZ RDST /COMPUTE BUFFER
2511 5307 JMP ,+2
2512 3341 DCA RDST /SAVE ADDRESS POINTER
2513 7340 CLA CLL CMA
2514 2741 ISZ I RDST /UPDATE PASS COMPLETE POINTER
2515 7610 SKP CLA
2516 3741 DCA I RDST /HOLD AT 7777
2517 4457 CRLP
2520 4455 PRNTER /PRINT "DISK"
2521 3477 MES17
2522 1115 TAD PULDSK /GET DISK POLE NUMBER
2523 0064 AND K0007 /MASK
2524 1067 TAD K0260
2525 4445 TYPE /TYPE DISK NO.
2526 7340 CLA CLL CMA
2527 4455 PRNTER /PRINT "PASS COMPLETE"
2530 3502 MES18
2531 4406 LAS
2532 0015 AND K0100 /MASK
2533 7650 SNA CLA /PASS COMPLETE DISCONNECT????
2534 5337 JMP ,+3 /NO WAY!!!!
2535 4430 DISCON /DUMP DRIVE
2536 5775 JMP RUN /MORE TO TEST!!!!
2537 4774 JMS TPSTA /STATUS=COMPLETE TYPEOUT
2540 5650 JMP I CKTIM /EXIT
/
/SUBROUTINE TO READ STATUS REGISTER
/

```

```

2541 0000 RDST, 0
2542 6745 IOTS, DRST /READ STATUS IOT
2543 7410 SKP
2544 4576 ERMLTS, JMS I 0GMLT /SKIP TRAP
2545 3121 DCA STREG /SAVE RESULTS
2546 1121 TAD STNEG
2547 5741 JMP I RDST /EXIT
/
/SUBROUTINE TO LOAD CURRENT ADDRESS REGISTER
/

```

```

2550 0000 LDCA, 0
2551 6744 IOT4, ULCA /LOAD CURRENT ADDRESS IOT
2552 4425 KTICK /NOTIFY APT
2553 5750 JMP I LDCA /EXIT
/
/SUBROUTINE TO LOAD TRACK ADDRESS REGISTER
/

```

```

2554 0000 LDAD, 0
2555 3125 DCA DANEK
2556 1125 TAD DANEK
2557 6743 IOTS, DLG /LOAD DISK ADDRESS REGISTER
2560 5754 JMP I LDAD /EXIT
2561 4576 ERMLTS, JMS I 0GMLT /ENRUR SKIP TRAP

```

```

2562 3541 / CMPPQT, DUCHMP-3
2574 3000
2575 0000
2576 1770
2577 1767
2600 PAGE
/ /ROUTINE TO GET RANDOM OR OPERATOR DATA
/
2600 0000 RNWRD, 0
2601 7402 SWDAT, MLT /MODIFIED SWITCH
2602 5600 JMP I RNWRD /EXIT
2603 6201 CDF 0 /HUMC CDF
2604 1412 TAD I AUTO12 /GET DATA
2605 7402 RECDF, MLT /BUFFER CDF
2606 2116 ISZ OPMTAL /UPDATE TALLY
2607 5600 JMP I RNWRD /EXIT
2610 3220 DCA PRINT /SAVE WORD
2611 1105 TAD M12
2612 3116 DCA OPMTAL /REPLACE TALLY
2613 7340 CLA CLL CMA
2614 1151 TAD DATPQT
2615 3012 DCA AUTO12 /REPLACE AUTO INDEX
2616 1220 TAD PRINT /GET SAVED WORD
2617 5600 JMP I RNWRD /EXIT

/ /ROUTINE TO TYPE
/
2620 0000 PRINT, 0
2621 3237 DCA DUMP /STORE AC VALUE
2622 4424 CHK22 /SEE IF ON APT
2623 5235 JMP PREXIT /NO. EXIT
2624 1237 TAD DUMP /RETURN AC.
2625 4407 CLASIC /CHECK FOR CLASSIC.
2626 4435 C8TYPE /ROUTINE TO EXECUTE.
2627 7410 SKP
2630 5620 JMP I PRINT /EXIT.
2631 6046 TLF
2632 6041 TSF
2633 5232 JMP ,=-1
2634 6042 TCF
2635 7200 PREXIT, CLA
2636 5620 JMP I PRINT

/ /ROUTINE TO DUMP AND REPORT DISK STATUS
/
2637 0000 DUMP, 0
2640 4424 CHK22 /CHECK FOR APT
2641 5637 JMP I DUMP
2642 4455 PRNTER /PRINT "DISK "
2643 3477 MES17
2644 1115 TAD POLOSK
2645 0064 AND K0007 /SETUP CURRENT DRIVE #
2646 3200 DCA RNWRD /SAVE

```

```

2647 1200 TAD RNWRD /GET DISK NUMBER
2650 1067 TAD K0260
2651 4445 TYPE /TYPE DISK NUMBER
2652 7340 CLA CLL CMA
2653 4455 PRNTER /PRINT "DISCONNECTED!"
2654 3445 MES15
2655 4777 JMS TPSTA /TYPE STATUS REPORT
2656 1200 TAD RNWRD
2657 1154 TAD RUNPQT
2660 3200 DCA RNWRD /SAVE POINTER ADDRESS
2661 3600 DCA I RNWRD /CLEAR RUN POINTER
2662 3200 DCA RNWRD
2663 1106 TAD M6
2664 3220 DCA PRINT /CHECK FOR MORE POINTER
2665 1200 TAD RNWRD
2666 4436 SELCHK /CHECK SELECT POINTERS
2667 7610 SKP CLA /DISK NOT HERE
2670 5637 JMP I DUMP /MORE AVAILABLE
2671 2200 ISZ RNWRD
2672 2220 ISZ PRINT /UPDATE POINTERS
2673 5265 JMP ,=6
2674 4457 CRLF
2675 4455 PRNTER /PRINT "DISK"
2676 3477 MES17
2677 7340 CLA CLL CMA
2700 4455 PRNTER /PRINT "SYSTEM DOWN"
2701 3455 MES16
2702 4576 NOOSKS, JMS I BGHLT /ERROR, NO DISK AVAILABLE

/
/ROUTINE TO SETUP FIELD TO BUFFER+ AUTO11+ BUFFER TALLY
/
2703 0000 STFLD, 0
2704 7041 CIA
2705 1127 TAD WCMEG
2706 3117 DCA BUPTAL
2707 7340 CLA CLL CMA
2710 1126 TAD CAREG /GET INITIAL CA
2711 3011 DCA AUTO11 /SAVE
2712 1157 TAD DATFLG /GET DATA FLAG
2713 7650 SNA CLA /WAS IT SET???
2714 5322 JMP ,+6 /NO, USE REGULAR
2715 1105 TAD M12
2716 3116 DCA OPMTAL /SETUP SPECIAL TALLY
2717 7340 CLA CLL CMA
2720 1151 TAD DATPQT
2721 3012 DCA AUTO12 /SETUP SPECIAL AUTO INDEX
2722 1136 TAD INTCM /GET LAST COMMAND
2723 0014 AND K0070 /MASK FIELD BITS
2724 1103 TAD KCDF /MAKE BUFFER CDF
2725 3205 DCA RECDF /SETUP SPECIAL CDF
2726 1205 TAD RECDF /GET BACK CDF
2727 5703 JMP I STFLD /EXIT, FIELD IN AC

/
/ROUTINE TO CHANGE DEVICE IOT CODES
/

```

```

2730 4407  CHANG, CLASSIC /CHECK FOR CLASSIC.
2731 4431  C88WIT /ROUTINE TO EXECUTE.
2732 7000  NOP
2733 4406  LAS /GET SWITCHES
2734 0071  AND A0770 /MASK 3=0
2735 3776' DCA LDCM /SAVE DESIRED CODE
2736 1360  TAD CHNPOT /POINTER
2737 3111  DCA TRASH1 /ADDRESS POINTER
2740 1357  TAD CCNTR1 /AMOUNT TO DO
2741 3112  DCA TRASH2 /SETUP COUNTER
2742 1511  CHANGR, TAD I TRASH1 /GET ADDRESS POINTER
2743 3113  OCA TRASH3 /SAVE ADDRESS
2744 1513  TAD I TRASH3 /GET OLD CODE
2745 0072  AND A7007 /MASK OFF OLD CODE
2746 1776' TAD LDCM /ADD IN DESIRED CODE
2747 3513  DCA I TRASH3 /RESTORE
2750 2111  ISZ TRASH1 /UPDATE POINTER
2751 2112  ISZ TRASH2 /UPDATE CHANGE COUNTER
2752 5342  JMP CHANGR /MORE TO CHANGE
2753 4407  CLASSIC /CHECK FOR CLASSIC.
2754 4436  C88R /ROUTINE TO EXECUTE.
2755 7402  CHNHLT, HLT /IOTS CHANGED, HIT CONTINUE DR
2756 5775' JMP BGN /IF ON CONSOLE PACKAGE
/CONTROL E TO START PROGRAM,

```

```

2757 7765  /CCNTR1, 7765
/

```

```

2760 2761  /CHNPOT, CHNPOT*1
2761 2304  RETURN
2762 2313  STATUS
2763 2324  RDLWRL
2764 2330  LODGO
2765 0554  IOT0
2766 0752  IOT1
2767 0561  IOT2
2770 2557  IOT3
2771 2551  IOT4
2772 2542  IOT5
2773 0545  IOT6
/

```

```

2775 0200
2776 0542
2777 3000
3000 3000

```

```

PAGE
/
/ROUTINE TO TYPE STATUS REPORT
/

```

```

3000 0000  TPSTA, 0
3001 4424  CHK22
3002 5600  JMP I TPSTA
3003 4457  CRLF
3004 4455  PRNTR /PRINT "OSK HARD SOFT COMP"
3005 3372  MEBY
3006 1107  TAD MIB
3007 3245  DCA TSAVE1 /MAXIMUM TO DO

```

```

3010 3246  DCA TSAVE2
3011 3247  DCA TSAVE3 /CLEAR SOME COUNTERS
3012 1246  CHKRES, TAD TSAVE2
3013 1062  TAD K0003
3014 3246  DCA TSAVE2
3015 1246  TAD TSAVE2
3016 1153  TAD STAPOT
3017 3251  DCA TSAVE5 /LOCATION OF DISK STATUS
3020 1247  TAD TSAVE3
3021 4436  SELCHK /CHECK RUN POINTER
3022 5241  JMP NOTSTA /DISK NOT RUNNING
3023 4457  CRLF
3024 4431  SPACE /SPACE OUT ONE
3025 1247  TAD TSAVE3
3026 1067  TAD K0260 /GET DISK NO.
3027 4445  TYPE
3030 4431  SPACE /SPACE OUT ONE
3031 4431  SPACE /SPACE OUT ONE
3032 7346  CLA CLL CHA RTL
3033 3250  DCA TSAVE4
3034 1651  TAD I TSAVE5 /COUNTER FOR FOUR WORDS
3035 4456  OCTEL /GET STATUS
3036 2251  ISZ TSAVE5 /TYPE IT
3037 2250  ISZ TSAVE4
3040 5234  JMP ,=4
3041 2247  NOTSTA, ISZ TSAVE3 /UPDATE DRIVE NUMBER
3042 2245  ISZ TSAVE1
3043 5212  JMP CHKRES /MORE TO REPORT
3044 5000  JMP I TPSTA /EXIT

```

```

3045 0000  TSAVE1, 0
3046 0000  TSAVE2, 0
3047 0000  TSAVE3, 0
3050 0000  TSAVE4, 0
3051 0000  TSAVE5, 0
/
/ROUTINE TO RECALIBRATE SELECTED DRIVE
/OISCONNECT DRIVE ON ERROR!
/

```

```

3052 0000  RESTOR, 0
3053 0063  AND K0006
3054 3200  DCA TPSTA /SAVE DRIVE NUMBER
3055 1077  TAD K7700
3056 3341  DCA TIMER2 /SETUP COUNTER
3057 2340  ISZ TIMER1
3060 5257  JMP ,=1
3061 2341  ISZ TIMER2 /WAIT FOR DISK TO COOL OFF!
3062 5257  JMP ,=3
3063 1200  TAD TPSTA /CURRENT DRIVE
3064 4451  LDCM /LOAD COMMAND
3065 7326  CLA CLL CHL RTL /ENABLE RECALIBRATE BIT
3066 4454  CLRALL /"RECALIBRATE"
3067 4450  DBKSKP /DISK SKIP IOT
3070 5267  JMP ,=1 /WAIT FOR FINST DONE FLAG
3071 4447  R0STAT /MEAD STATUS

```

```

3072 7500          SMA
3073 5311          JMP      RESERR          /DONE FLAG SET????
3074 0076          AND      K1777          /NO, ERROR
3075 7640          SZA CLA          /MASK OTHER ERROR BITS
3076 5311          JMP      RESERR          /ANY SET????
3077 4454          RESTA, CLRALL          /YES, ERROR
3100 1016          TAD      K0200          /CLEAR STATUS
3101 1200          TAD      TPSTA          /ENABLE SET SECOND DONE FLAG
3102 4451          LDCMD          /ORIGINAL COMMAND
3103 4450          DSKSKP          /LOAD COMMAND
3104 5303          JMP      .-1          /DISK SKIP IOT
3105 4447          RDBSTAT          /WAIT FOR SECOND DONE
3106 1073          TAD      K4000          /READ STATUS
3107 7650          SNA CLA          /HAS IT ONLY DONE FLAG
3110 5652          JMP I      RESTOR          /YES, RETURN
3111 7300          RESERR, CLA CLL
3112 4446          ERROR          /ERROR
3113 0003          0003
3114 7500          7500
3115 4457          CRLF
3116 4457          CRLF
3117 4455          PRNTER          /PRINT"RECALIBRATE ERROR DISCONNECT"
3120 3174          MEB19
3121 4430          DISCON          /DISCONNECT DISK
3122 5652          JMP I      RESTOR          /MORE DISK AVAILABLE
/
/Routine TO TIME AND WAIT
/
3123 0000          TIME, 0
3124 2340          ISZ      TIMER1
3125 5723          JMP I      TIME          /EXIT
3126 2341          ISZ      TIMER2
3127 5723          JMP I      TIME          /EXIT
3130 4576          INTER1, JMS I 00HLT          /NO INTERRUPT OCCURRED, I GUESS!
/
/Routine TO COMBINE ERROR HALTS,
/WHEN THE COMPUTER HALTS THE AC
/Will EQUAL THE PC ON THE FAILING
/HALT INSTRUCTION.
/
3131 0000          BIGHLT, 0
3132 7300          CLA CLL
3133 1331          TAD      BIGHLT          /LOAD AC WITH PC.
3134 4407          CLASIC          /CHECK FOR CLASSIC.
3135 4436          C0ERR          /ROUTINE TO EXECUTE.
3136 7402          BIGHTP, HLT          /AC=PC.
3137 5332          JMP      .-5          /NON-RECOVERABLE.
/
3140 0000          TIMER1, 0
3141 0000          TIMER2, 0
/
/Routine TO TYPE OUT DATA INFORMATION
/
3142 0000          TYPDAT, 0
3143 4455          PRNTER          /PRINT "A81"

```

```

3144 3235          TEXAS
3145 1131          TAD      ASREG
3146 4456          OCTEL
3147 7340          CLA CLL CMA
3150 4455          PRNTER          /PRINT "WAI"
3151 3237          TEXWA
3152 1132          TAD      WAREG
3153 4456          OCTEL
3154 7340          CLA CLL CMA
3155 4455          PRNTER          /PRINT "AD1"
3156 3241          TEXAD
3157 1133          TAD      ADREG
3160 4456          OCTEL
3161 7340          CLA CLL CMA
3162 4455          PRNTER          /PRINT "DG1"
3163 3243          TEXDG
3164 1134          TAD      DGREG
3165 4456          OCTEL
3166 7340          CLA CLL CMA
3167 4455          PRNTER          /PRINT "DB1"
3170 3245          TEXDB
3171 1135          TAD      DBREG
3172 4456          OCTEL
3173 5742          JMP I      TYPDAT
/
MEB19, TEXT      "RECALIBRATE ENRROR DISCONNECT!"
3174 2205
3175 0301
3176 1411
3177 0222
3200 0124
3201 0540
3202 0522
3203 2217
3204 2240
3205 0411
3206 2303
3207 1716
3210 1005
3211 0324
3212 4100
/
3213 2003          TEXPC, TEXT      "PC1"
3214 7200
3215 2324          TEXST, TEXT      "ST1"
3216 7200
3217 0530          TEXEX, TEXT      "EX1"
3220 7200
3221 0315          TEXCM, TEXT      "CM1"
3222 7200
3223 1101          TEXIA, TEXT      "IA1"
3224 7200
3225 0401          TEXDA, TEXT      "DA1"
3226 7200
3227 0301          TEXCA, TEXT      "CA1"
3230 7200

```

3231	2703	TEXWC,	TEXT	"WCI"
3232	7200			
3233	0627	TEXFW,	TEXT	"FWI"
3234	7200			
3235	0123	TEXAS,	TEXT	"ASI"
3236	7200			
3237	2701	TEXWA,	TEXT	"WAI"
3240	7200			
3241	0104	TEXAD,	TEXT	"ADI"
3242	7200			
3243	0407	TEXDG,	TEXT	"DGI"
3244	7200			
3245	0402	TEXDB,	TEXT	"DBI"
3246	7200			
		/		
3247	2205	ERTX1,	TEXT	"READ STATUS"
3250	0104			
3251	4023			
3252	2401			
3253	2425			
3254	2300			
3255	2722	ERTX2,	TEXT	"WRITE STATUS"
3256	1124			
3257	0540			
3260	2324			
3261	0124			
3262	2523			
3263	0000			
3264	2205	ERTX3,	TEXT	"RECALIBRATE STATUS"
3265	0301			
3266	1411			
3267	0222			
3270	0124			
3271	0540			
3272	2324			
3273	0124			
3274	2523			
3275	0000			
3276	0411	ERTX4,	TEXT	"DISK DATA"
3277	2313			
3300	0004			
3301	0124			
3302	0100			
		/		
3303	0005	MESS,	TEXT	" ERROR"
3304	2222			
3305	1722			
3306	0000			
3307	2213	MESS1,	TEXT	"MK06/RK0L DATA RELIABILITY"
3310	7005			
3311	5722			
3312	1370			
3313	1440			
3314	0401			
3315	2401			

3316	4022			
3317	0514			
3320	1101			
3321	0211			
3322	1411			
3323	2431			
3324	0000			
3325	0530	MESS2,	TEXT	"EXERCISE"
3326	0522			
3327	0311			
3330	2305			
3331	0000			
3332	4004	MESS3,	TEXT	" DISK"
3333	1123			
3334	1300			
3335	1617	MESS4,	TEXT	"NON-RECOVERABLE "
3336	1655			
3337	2205			
3340	0317			
3341	2605			
3342	2201			
3343	0214			
3344	0540			
3345	0000			
3346	0530	MESS5,	TEXT	"EXTENDED R/W MEMORY(0-7)?"
3347	2405			
3350	1604			
3351	0504			
3352	4022			
3353	5727			
3354	4015			
3355	0515			
3356	1722			
3357	3150			
3360	6055			
3361	6751			
3362	7700			
3363	0103	MESS6,	TEXT	"ACCEPT MODE?"
3364	0305			
3365	2024			
3366	4015			
3367	1704			
3370	0577			
3371	0000			
3372	0423	MESS7,	TEXT	"DSK HARD SOFT COMP"
3373	1340			
3374	1001			
3375	2204			
3376	4023			
3377	1706			
3400	2440			
3401	0317			
3402	1520			

3403 0000
 3404 0611 MESSAGE, TEXT "FIELD?"
 3405 0514
 3406 0477
 3407 0000
 3410 2422 MESSAGE9, TEXT "TRACK?"
 3411 0103
 3412 1377
 3413 0000
 3414 0530 MESSAGE10, TEXT "EXTRA SECTORS?"
 3415 2422
 3416 0140
 3417 2305
 3420 0324
 3421 1722
 3422 2377
 3423 0000
 3424 0214 MESSAGE11, TEXT "BLOCK LENGTH?"
 3425 1703
 3426 1340
 3427 1405
 3430 1607
 3431 2410
 3432 7700
 3433 0401 MESSAGE13, TEXT "DATA?"
 3434 2401
 3435 7700
 3436 0122 MESSAGE14, TEXT "ARE YOU SURE?"
 3437 0540
 3440 3117
 3441 2540
 3442 2325
 3443 2205
 3444 7700
 3445 4004 MESSAGE15, TEXT "DISCONNECTED!"
 3446 1123
 3447 0317
 3450 1416
 3451 0503
 3452 2405
 3453 0441
 3454 0000
 3455 2331 MESSAGE16, TEXT "SYSTEM SHUT DOWN, NO DISKS TO RUN!"
 3456 2384
 3457 0515
 3460 4023
 3461 1025
 3462 2440
 3463 0417
 3464 2716
 3465 5440
 3466 1617
 3467 4004
 3470 1123
 3471 1323

3472 4024
 3473 1740
 3474 2225
 3475 1641
 3476 0000
 3477 0411 MESSAGE17, TEXT "DISK "
 3500 2313
 3501 4000
 3502 4020 MESSAGE18, TEXT "PASS COMPLETE!"
 3503 0123
 3504 2340
 3505 0317
 3506 1520
 3507 1405
 3510 2405
 3511 4100

3512 0000 DSK00, 0
 3513 0000 DSK10, 0
 3514 0000 DSK20, 0
 3515 0000 DSK30, 0
 3516 0000 DSK40, 0
 3517 0000 DSK50, 0
 3520 0000 DSK60, 0
 3521 0000 DSK70, 0

3522 0000 D0TM1, 0
 3523 0000 D1TM1, 0
 3524 0000 D2TM1, 0
 3525 0000 D3TM1, 0
 3526 0000 D4TM1, 0
 3527 0000 D5TM1, 0
 3530 0000 D6TM1, 0
 3531 0000 D7TM1, 0
 3532 0000 D0TM2, 0
 3533 0000 D1TM2, 0
 3534 0000 D2TM2, 0
 3535 0000 D3TM2, 0
 3536 0000 D4TM2, 0
 3537 0000 D5TM2, 0
 3540 0000 D6TM2, 0
 3541 0000 D7TM2, 0

3542 0000 D0HRD, 0
 3543 0000 D0SOP, 0
 3544 0000 D0CHP, 0
 3545 0000 D1HRD, 0
 3546 0000 D1SOP, 0
 3547 0000 D1CHP, 0
 3550 0000 D2HRD, 0
 3551 0000 D2SOP, 0
 3552 0000 D2CHP, 0

4000
4100

4200
4300

4400
4500

4600
4700

5000
5100

5200
5300

5400
5500

5600
5700

6000
6100

6200
6300

6400
6500

6600
6700

7000
7100

7200
7300

7400
7500

7600
7700

AB170	0750	CBGET	0624	CONCUR	0715	DAT3	0760
AB770	0071	CBHANG	1122	CONSEC	0147	DAT4	0761
A7007	0072	CBINDU	4437	CONSOL	0000	DAT5	0762
ACDCA	0362	CBQCTA	4432	CRCENT	0155	DAT6	0763
ACL	7701	CBPASS	4424	CRCPLG	0136	DAT7	0764
ACSAVE	1345	CBPAUS	4441	CRLF	4437	DAT8	0765
ADREG	0133	CBPRNT	4430	DBCMP	3544	DAT9	0766
AERROR	2156	CBRDP3	0606	DBHRU	3542	DATFLG	0157
AGAIN	1346	CBRETD	0614	DBSOP	3543	DATPDT	0151
ALLAGN	0255	CBRETR	0536	DOTM1	3522	DATTRY	0140
AMOUNT	0060	CBRETD	0613	DOTM2	3532	DBREG	0135
APT6	2270	CBRETS	0535	DICMP	3547	OCLR	6742
ASKNX1	0345	CBSWIT	4431	DIMRU	3545	DGREG	0134
ASKNX2	0406	CBWST	0745	DISOP	3546	DISCON	4430
ASKNX3	0425	CBTMP1	1021	DITM1	3523	DISKGO	4441
ASKNX5	0464	CBTTYI	4426	DITM2	3533	DLAG	6743
ASKSUR	0513	CBTYPE	4435	DZCMP	3552	DLCA	6744
ASREG	0131	CAF	6007	U2HRU	3550	DLDC	6746
AUTO10	0010	CAREG	0126	DZSOP	3551	DLSC	6740
AUTO11	0011	CBNTR1	2757	O2TM1	3524	DOCNT	0247
AUTO12	0012	CHANG	2750	O2TM2	3534	DOHEAD	1262
BADHLT	1707	CHANGR	2742	U3CMP	3555	DONEA	0426
BGHLT	0176	CHEK22	0523	U3HRU	3553	DOPACK	0212
BGN	0200	CHK22	4424	D3SOP	3554	DOSBT	0251
BGNBUF	0146	CHKCLA	1200	D3TM1	3525	DRST	6745
BIGHLT	3131	CHKPOT	2060	D3TM2	3535	DSK00	3512
BIGSTP	3136	CHKRES	3012	D4CMP	3560	DSK10	3513
BRKRET	0363	CHKJAV	0141	D4HRU	3556	DSK20	3514
BUFFNT	1400	CHKYF	2035	D4SOP	3557	DSK30	3515
BUFTAL	0117	CHNCDF	2254	O4TM1	3526	DSK40	3516
BYRETR	0506	CHNHLT	2755	O4TM2	3536	DSK50	3517
CB0Y1	0230	CHNPOT	2760	USCMP	3563	DSK60	3520
CB0Y2	1300	CKCOT	0232	D5HRU	3561	DSK70	3521
CB0Y3	1061	CKTIM	2450	D5SOP	3562	DSKEX	2302
CB0Y4	0515	CLAFLD	1404	D5TM1	3527	DSKGO	2200
CB0Y5	1116	CLASIC	4407	U5TM2	3537	DSKP	6741
CB0CHAR	1075	CLASIK	1514	U6CMP	3566	DSKSKP	4450
CB0CKP	1022	CLDR	0560	DBHRU	3564	DTCHK	1600
CB0CKPA	4440	CLKCNT	0130	D6SOP	3565	UTR1	1636
CB0CKSW	4425	CLRALL	4454	O6TM1	3530	DUMP	2637
CB0CNTR	4427	CLRBK	0175	O6TM2	3540	ENDIT	0742
CB0CONT	1145	CLRTRN	1315	U7CMP	3571	ERFLG	0165
CB0CRLF	4433	CHPOT	2562	D7HRU	3567	ERHLT0	0556
CB0D01	0310	CHREG	0123	D7SOP	3570	ERHLT2	0563
CB0D010	1262	CNTRLC	0531	U7TM1	3531	ERHLT3	2561
CB0D011	0607	CNTRLD	0600	U7TM2	3541	ERHLT5	2544
CB0D02	1033	CNTRLE	0545	UARE6	0125	ERHLT6	0547
CB0D03	0350	CNTRLL	0537	DAT1	0756	ERR1	0736
CB0D04	1006	CNTRLQ	0500	DAT10	0767	ERRM25	1520
CB0D07	0527	CNTRLW	0511	DAT11	0770	ERR0	1200
CB0ECHO	4434	CNTRLS	0521	DAT12	0771	ERRDEX	1355
CB0ERR	4436	CNTVAL	0252	DAT2	0757	ERROR	4446

ERTX1	3247	K0001	0061	M12	0105	NTWKK5	1710
ERTX2	3255	K0003	0062	M4	0106	OCT1	2400
ERTX3	3264	K0004	0013	MANUAL	0322	OCT4	2430
ERTX4	3276	K0006	0063	MAXFLD	0143	OCTEL	4456
ESAVE	1371	K0007	0064	MAYTIM	0144	ONEIN	4432
EXAPT8	2151	K0010	0065	MAYTNK	0145	OP1	0021
EXIT	1504	K0017	0066	MEMSET	2142	OP2	0022
EXITA	0440	K0070	0014	MES0	3303	OPRTAL	0116
EXREG	0122	K0077	0102	MES1	3307	PASCNT	0250
XYICK	1166	K0100	0015	MES10	3414	PCLF	6662
F1OP1	0021	K0200	0016	MES11	3424	PCNTR1	1373
F1OP2	0022	K0212	1425	MES13	3433	PCNTR2	1374
F10HR	0020	K0215	1424	MES14	3436	PCNTR3	1375
FILCNT	1040	K0240	1512	MES15	3445	PCREG	0120
FILLER	1037	K0260	0067	MES16	3455	PCSAVE	1344
FILLUP	0717	K0277	0070	MES17	3477	PNTBUF	1120
FIRTIM	0170	K0316	2057	MES18	3502	POLD5K	0115
FIDFLG	3372	K0331	2056	MES19	3174	POLNEX	1000
FIDMLT	0206	K0400	0017	MES2	3325	PREXIT	2635
FLSAVE	1347	K1000	0075	MES3	3332	PRINT	2620
FNDSUM	0142	K177	2034	MES4	3335	PRN	1450
FORIN	4433	K1777	0076	MES5	3346	PRNDAT	0173
FRDCT	1426	K3740	1513	MES6	3363	PRNTER	4455
FRREG	0130	K4000	0073	MES7	3372	P8IE	6665
GENDAT	4426	K4100	0074	MES8	3404	P8KE	6663
GETCHI	0703	K5405	0360	MES9	3410	P8KF	6661
GETDAT	0456	K6500	0541	MES10	0747	P8TB	6664
GN DAT	1737	K6520	2172	MES10	1553	PTSTOR	0536
GOBAK	2230	K7000	2155	MESFL	1541	RAD1	1773
GOCDF	1646	K7377	2154	MESHAN	1146	RAD2	1774
GOCHK	2265	K7400	0104	MESM0	1336	RAD3	1775
GOCLR	2260	K7700	0077	MESPAS	0253	RAN1	1767
GOITA	0443	K7760	0100	MESPC	1330	RAN2	1770
GOTIT	0110	K7773	1377	MODSKS	2125	RANDAT	4427
GOTOA	0454	K7775	0110	MOA	7501	RANDOM	1715
GTF	0004	K7777	0101	MGL	7421	RANGEN	4440
HEDTAD	1376	KAERRO	0023	MOSAVE	1346	RANJMS	0522
HLFFLG	3375	KCDF	0103	MRPRN	1456	RDLNRL	2324
INDEXA	0455	KROT	0250	M8KEN	1714	ROST	2541
INERR	2426	K8PK	0546	MYAC	1317	ROSTA	1105
INMODE	1076	KTICK	4425	MYLAB	1546	ROSTAT	4447
INTCM	0136	KTIME	0530	NEWRU	0727	ROTRY	1073
INTDA	0124	LAB	4406	NEXT	0261	REALPC	1316
INTER1	3130	LOAD	2554	NODSKP	2353	RECAL	4443
INTER2	2362	LOADD	4453	NODSKS	2702	RECFD	2605
IOT0	0554	L0CA	2550	NOERR	1672	RECEIV	4444
IOT1	0752	LDCM	0542	NOSET	0242	REDOA	0415
IOT2	0561	LDCMO	4451	NOTEX	1363	REFILL	0723
IOT3	2557	LDCUR	4452	NOTSTA	3041	REREAD	1063
IOT4	2551	LNKDCA	0361	NTCLAS	1270	RERUN	1124
IOT5	2542	LDDGO	2330	NTERN	1255	RESERR	3111
IOT6	0545	M10	0107	NTSOFT	1251	RESRAN	4442

RESTA	3077	TABLB	0471	XCBCNL	1023		
RESTOR	3052	TEXAD	3241	XCBECH	1063		
RETRN	2331	TEXAS	3235	XCBEKR	1207		
RETURN	2304	TEXCA	3227	XCBOCT	0055		
REWRT	1047	TEXCH	3221	XCBOCT	1000		
RNFLD	0630	TEXDA	3225	XCOPAS	0200		
RNRWD	2600	TEXDG	3245	XCOPAU	0337		
ROUINS	1302	TEXDG	3243	XCOPNT	0303		
ROUTMP	1544	TEXEX	3217	XCOPSW	0656		
RSRAN	1761	TEXFW	3233	XCBSW	0262		
RUN	0000	TEXIA	3223	XCBTY	0272		
RUNPOT	0154	TEXPC	3213	XCBTYP	1077		
SAV1	1771	TEXST	3215	XCHKZ2	0024		
SAV2	1772	TEXWA	3237	XCHKYN	0037		
SAVAC	0166	TEXWC	3231	XCKPUT	0056		
SAVCM	0174	TIME	3123	XCLAS	0007		
SAVE1	0400	TIMER1	3140	XCLUK	0034		
SAVEAC	1545	TIMER2	3141	XCRLT	0057		
SDPK	0751	TIMER3	2374	XDDLWT	1112		
SECFLG	3374	TIMPOT	0152	XDSW	0520		
SELCHK	4436	TMPCNT	0746	XDSKWD	0041		
SEYFLD	4435	TPSTA	3000	XDUMP	0030		
SETGEN	4434	TRASH1	0111	XERRU	0046		
SETREG	1553	TRASH2	0112	XFROCT	0056		
SETUP1	1233	TRASH3	0113	XGNDAT	0026		
SETUP2	0225	TRDONE	2365	XKTCK	0025		
SKPNOP	0237	TRKFLG	3573	XKTICK	1154		
SOFT	1245	TRYCNT	0171	XLAB	0006		
SPAC	1506	TRYTIM	1060	XLOAD	0053		
SPACE	4431	TSAVE1	3045	XLOCA	0052		
SPBLK	0164	TSAVE2	3046	XLOCM	0051		
SPFLD	0160	TSAVE3	3047	XOCT1	0052		
SPSEC	0163	TSAVE4	3050	XOCT4	0053		
SPTRK1	0161	TSAVE5	3051	XPRINT	0045		
SPTRK2	0162	TSTCHA	0715	XPRN	0055		
STAPOT	0153	TYLPT	1121	XRDST	0047		
STATER	2337	TYPDAT	3142	XREG	1372		
STATRY	0137	TYPE	4445	XRESTR	0043		
STATUS	2313	UPAROW	0615	XRNDDM	0040		
STFLD	2703	UPDATE	0114	XRNHMD	0027		
STGEN	1753	UPONE	1414	XRSRAN	0042		
STPHLT	0403	UPTRY	1120	XSDPK	0050		
STRAUT	1325	WAIT	2000	XSPAC	0051		
STRBUF	3600	WAIT1	2026	XSTFLD	0055		
STREG	0121	WAREG	0132	XSTGEN	0034		
STRREL	1151	WARSD	2204	XTABLA	0057		
STRTEX	0224	WATMES	0051	XTABLB	0060		
STRWRK	2241	WCREG	0127	XTEXT	0172		
SVLNK	0167	WRDCHK	1612	XWAIT	0044		
SWDAT	2601	WRKDON	2274	YESNU	4437		
SWR	0020	XCCKP	1041				
TABLA	0461	XCOCNT	0400				

ERRORS DETECTED: 0
LINKS GENERATED: 163
RUN-TIME: 6 SECONDS
3K CORE USED