IDENTIFICATION

PRODUCT CODE: MAINDEG-08+DHRKC-H-D

PRODUCT NAME: RKSE/RKSL DATA RELIABILITY PROGRAM

DATE RELEASED: FEBRUARY, 1977

MAINTAINER: DIAGNOSTIC ENGINEERING

AUTHOR: JOHN VHOBEL/WILLIAM HEAVEY

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A CUMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED UNDER A LICENSE AND MAY ONLY BE USED OR COPIED IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE.

DIGITAL EQUIPMENT CORPURATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFIWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1972, 19/5, 1976,1977 BY DIGITAL EQUIPMENT CORPORATION

		·	

TABLE UF CONTENTS

1. ABSTRACT 3. RESTRICTIONS 2.1 HARDWARE 2.2 PROGRAM STORAGE 2.3 PRELIMINARY PROGRAMS 2.4 EXECUTION TIME 3. SWITCH REGISTER SETTINGS 4. OPERATOR AND/OR PROGRAM ACTION 4.1 STANDARD TEST PROCEDURE 4.2 RK95J DRIVE CARTRIDGE MOUNTING PROCEDURE 4.3 RK05F DRIVE MOUNTING PROCEDURE 4.4 RKSE/RKSL DATA RELIABILITY (ACCEPT MODE) 4.5 RKSE DATA RELIABILITY (MANUAL INTERVENTION MODE) 4.6 CHANGE PROGRAM IOT CODES 5, ERRORS 5.1 USEFUL INFORMATION 5.2 ERROR HALTS. 5.3 ERROR TYPEDUTS ERROR RECOVERY AND ERROR DISCONNECT 5,4 5,5 STATUS COMPLETE TYPEOUT AND PASS COMPLETE DISCONNECT 5.6 TYPICAL ERROR TYPEOUTS 6, RESTRICTIONS 7. TROUBLE SHOOTING INFORMATION **4.** PROGRAM DESCRIPTION (ACCEPT MODE) 9. CONSOLE PACKAGE ADDENDUM 10. APT-8 HOOKS

11.

PROGRAM LISTING

1. ABSTRACT

THE RKSE/RKSL DATA RELIABILITY PROGRAM IS DESIGNED PRIMARILY AS AN ACCEPTANCE TEST TO VERIFY DISK DATA TRANSFERS WITHIN THE DISK SYSTEM.

THE "ACCEPT MODE" OF OPERATION VERIFIES THE CAPABILITY OF TRANSFERRING A TOTAL: 3 X 18(9) BITS OF DATA TO AND FROM EACH INDIVIDUAL DISK DRIVE ON THE DISK SYSTEM.

THE "MANUAL INTERVENTION MODE" IS AVAILABLE AS A MARDWARE DEBUGGING AID TO ALLOW THE OPERATOR TO SELECT DATA PATTERNS, TRANSFER LENGTHS, AND ADDRESSING.

(NOTE: LOCATION & CONTAINS REVSION LEVEL (IN ASCII) OF PROGRAM ON PROGRAM LOAD).

2. RESTRICTIONS

THE RKGL CONTROL, WHICH CAN CONTROL UP TO 8 DRIVES, WILL NOT RUN WITH THE DWSE BUS ADAPTER, THE REASON FOR THIS STATEMENT IS THAT THE RKGL CONTROL USES JOTS FOR EXTENDED DRIVES 4-7 WHICH IS NOT AVAILABLE ON THE DWSE.

2.1 HARDWARE

- A. PDP-8/A, 8/E, 8/F, OR 8/M COMPUTER OR OTHER FAMILY OF & COMPATIBLE COMPUTER WITH NECCESSARY DWSE SUS ADAPTER.
- B. AT LEAST 4K OF READ/HRITE HEMORY. AT LEAST SK OF MEMORY IS NECESSARY FOR OPERATION OF THE CONSOLE PACKAGE.
- C. ASR-33 TELETYPE OR EQUIVALENT
- D. RKSE OR RKSL DISK CONTROL
- E. RKOSJ OR RKOSP DISK DRIVE(S)
- F. FORMATTED 2200 SPI-16 SECTOR PACK(S).

NOTE: THE REGSF DISK DRIVE IS CONSIDERED AS TWO SEPARATE UNITS, WHEN ANSWERING ALL QUESTIONS THE SEPARATE SRIVES HUST BE SPECIFIED, DSK87, DSK87, ETC.

2.2 PROGRAM STORAGE

THE PROGRAM OCCUPIES OR UTILIZES LOCATION SOES TO LOCATION 7577 OF FIELD S. ALL EXTENDED MEMORY LOCATIONS, IF AVAILABLE, ARE UTILIZED FOR TESTING.

2,3 PRELIMINARY PROGRAMS

THIS PROGRAM REQUIRES A FORMATTED CARTRIDGE ON ALL DRIVES TO BE TESTED.

ALL BASIC AND EXTENDED MEMORY DIAGNOSTICS SHOULD BE RUN PRIOR TO RUNNING THIS PROGRAM.

RKSE CONTROL: RUN THE RESE DISKLESS CONTROL TEST AND THE RESE/RESL DISK FORMATTER IF THIS DIAGNOSTIC FAILS TO OPERATE PROPERLY.

RK&L CONTROL: RUN THE RESL INSTRUCTION TEST AND THE RKSE/RKSL FORMATTER IF THIS DIAGNOSTIC FAILS TO OPERATE PROPERLY.

2,4 EXECUTION TIME

SWROOT

THE PROGRAM EXECUTION TIME (I.L. PASSING 3 X 10(9) BITS OF DATA ON A DISK DRIVE), IS APROX. 4 HOURS PER DISK DRIVE ON A 4K MEMORY SYSTEM OR APROX. 3.5 HOURS PER DISK DRIVE ON SYSTEMS WITH EXTENDED MEMORY.

3. SWITCH REGISTER SETTINGS

LOOP ON WRITE SEQUENCE. SWR1#1 LOOP ON READ SEQUENCE. 8WR2#1 INHIBIT ALL ERNOR TYPEOUTS SWR3#1 TYPE "STATUS-CUMPLETE" REPORT. PROGRAM STOP ON HALT. SWR4#1 SWR5#1 DRIVE DISCONNECT AFTER PASS COMPLETION.

PERFORM ONLY "UVERLAP SEEKS", DO NOT SWR6#1 EXECUTE DATA BREAKS.

OPERATOR AND/OR PROGRAM ACTION 4.

4.1 STANDARD TEST PROCEDURE

- A. START AS SPECIFIED THROUGH OUT THIS DOCUMENTATION IS KEY CLEAR AND THEN KEY CUNTINUE ON PDP8/E, PDP8/M, AND PDPS/F COMPUTERS.
- B. LOAD THE PROGRAM INTO MEMORY FIELD & USING THE STANDARD BINARY LOADER TECHNIQUE.
- C. IF IT IS DESIRED TO CHANGE THE IOT CODES WITHIN THE PROGRAM, FOLLOW THE PROCEDURE IN SECTION 4.6.
- D. RUN THE ACCEPTANCE MODE OF DATA RELIABILITY WITH ALL DRIVES AND MEMORY AVAILABLE BY FOLLOWING THE PROCEDURE