

IDENTIFICATION

Product Code: MAINDEC 08-D02B-D

Product Name: PDP-8 Instruction Test Part 2B

Date Created: January 12, 1968

Maintainer: Diagnostic Group

1. ABSTRACT

This program is a test of the 2s complement add (TAD) and rotate logic (RAL, RTL, RAR, RTR). Random numbers are used in the Twos Add portion of the test and sequential numbers are used in the Rotate portion. Program control depends on operator manipulation of four switches in the SWITCH REGISTER (bits 0, 1, 2, 3). Error information is normally printed out on the keyboard printer.

2. REQUIREMENTS

Storage

Memory locations 20_8 - 4177_8 .

Subprograms and/or Subroutines

High RIM Loader, High Binary Loader.

Equipment

PDP-8 Processor-Keyboard Reader

3. USAGE

3.1 Loading

If the Binary Loader beginning at 7777_8 is in memory, load the Instruction Test - Part 2b.

Otherwise, the RIM Loader beginning at 7756_8 and/or the Binary Loader must be loaded into memory.

PDP-8 Instruction Test - Part 2B (Maindec 801-2B) may now be loaded as follows:

Set 7777_8 in the SWITCH REGISTER.

Press LOAD ADDRESS key.

Place Instruction Test-Part 2B in the keyboard reader.

Press START key on the operator console.

Engage the keyboard reader.

3.2 Switch Settings

When starting at the TAD portion (200_8) of the test, set switches 0 and 2 to the 1 state. This switch configuration allows the program to print any error message and halt on the error condition. After the TAD portion has run for a minimum of 10 minutes, set switch 3 to a 1 to enter the Rotate Test.

When starting at the rotate portion (2000_8) set switches 0 and 2 to the 1 state as above. This switch configuration allows the program to print any error message and halt on the error condition.

Switch 0	Stop on error (406_8 for TAD or 2433_8 for Rotate Test).
Switch 1	Scope mode (repeat loop causing the error).
Switch 2	Print error.
Switch 3	Leave the Twos Add test and start the Rotate Test.

- Switch 0 and 1 Scope mode and stop on error.
- Switch 0 and 2 Print error and halt.
- Switch 1 and 2 Scope and print error.

3.3 Start-Up and/or Entry

The starting address of the TAD portion of the test is 0200_8 . The starting address of the Rotate portion of the test is 2000_8 . If bit 3 of the SWITCH REGISTER is set, it automatically causes an exit from the Twos Add portion of the test to the Rotate portion of the test.

Set either 0200_8 in the SWITCH REGISTER to start at the Twos Add portion of the test, or set 2000_8 in the SWITCH REGISTER to start at the Rotate portion of the test.

Press the LOAD ADDRESS key.

Press the START key.

3.4 Errors in Usage

The error halt for TAD Test is 406_8 .

The error halt for Rotate Test is 2433_8 .

Error printouts from both tests would appear as follows:

TWOS ADD ERROR PRINTOUT:

Good	Bad	X ARG	Y ARG
0 000000000001	0 000000000000	0 000000000000	0 000000000001

Indicating loss of a 1 bit in AC bit 11.

ROTATE ERROR PRINTOUTS:

PAT 0	000000000001	(original pattern)
RAL 0	0000000000010	(pattern after RAL inst.)
RAR 0	0000000000000	(pattern after RAR inst.)

Indicating loss of a 1 bit in AC bit 11 as a result of an RAR.

PAT 0	000000100000
RTR 0	0000000000000
RTL 0	0000000000000

Indicating loss of a 1 bit in AC bit 8 as a result of an RTR.

3.5 Recovery from such Errors

The program may be continued after it halts on an error, by pressing the CONTINUE key. The program continues to the next test, unless scope mode (bit 1) is requested.

Set the state of AC switch 1 to 1 to repeat the loop causing the error (scope mode).

Reference 4.3 for other switch variations.

4. RESTRICTIONS

This test should be run only after a successful run of the Instruction Test 2A to provide maximum reliability of the module repair table.

5. DESCRIPTION

5.1 Discussion

The PDP-8 Instruction Test-Part 2B tests the 2s ADD and ROTATE logic.

The 2s ADD logic is tested by the addition of pseudo random numbers. Two pseudo random numbers are generated and 2s added by a logical (simulated) adder. The same two numbers are added by the 2s add logic (TAD). The results are compared, and if an equality exists, two new random numbers are generated and the sequence is re-executed. If an inequality exists, the computer halts and/or types the error condition depending on the switch settings.

5.2 Examples and/or Applications

The error printout will contain the correct answer, the incorrect answer, and the two random numbers used.

Visual inspection of these patterns will determine the cause of the error. A lookup table is provided for rapid repair which will give all of the information shown in section 4.6.

Exit from TAD Test to the Rotate portion is accomplished by setting bit 3 in the SWITCH REGISTER. This switch also causes the program to print "ADD OK."

The Rotate Test generates 8192 patterns to be tested on two pairs of rotate instructions. The first pair of rotate instructions to be tested is RAL and RAR. The test pattern is rotated left once, then the result is rotated right once. The following items are compared:

The result of the RAR should equal the test pattern and original link.

The result of the link after the RAL should equal bit 0 of the test pattern.

If the RAR results and link equals the test pattern and link, the RAL and RAR instructions have operated correctly.

If an error occurs and an error printout is requested, the test pattern and the results of both the RAL and RAR instructions are printed. Visual inspection of these patterns will determine the probable cause of the error.

The second pair of rotate instructions to be tested is RTR and RTL. The test pattern is rotated right twice, then the result is rotated left twice. The following items are compared:

The result of the RTL should equal the test pattern and original link.

The result of the link after the RTR should equal pattern bit 1 of the test pattern.

If the RTL results and link equal the test pattern and link, the RTR and RTL, instructions have operated correctly.

If an error occurs and an error printout is requested, the test pattern and the results of both the RTR and RTL instructions are printed. Visual inspection of these patterns will determine the probable cause of the error.

After a complete pass through the Rotate Test, the computer will print ROT.

A printout of "2B" indicates the completion os a complete pass through the entire set of tests, after which the test begins again.

6. METHODS

See description section 5.

7. EXECUTION TIME

The TAD section takes 1 second for one complete pass; it will cycle continuously unless AC switch 3 is set. The Rotate portion takes 3 seconds for one complete pass.

8. PROGRAM LISTING

/PDP-8 INSTRUCTION TEST PART 2B ADD-ROTATE

0000	0000	*0	0000
0000	0000		JMP 1
0001	5001		2
0002	0002		3
0003	0003		
		*0020	
0020	0000	PRXLOP,	0 /PRINT LOOP
0021	6046		TLS
0022	6041	LPXX,	TSF
0023	5022		JMP LPXX
0024	7200		CLA
0025	5420		JMP I PRXLOP
		CRLFLF,	0
0026	0000		CLA CMA
0027	7240		AND CR /CR
0030	0104		JMS PRXLOP
0031	4020		CLA CMA
0032	7240		AND LF /LF
0033	0103		JMS PRXLOP
0034	4020		CLA CMA
0035	7240		AND LF /LF
0036	0103		JMS PRXLOP
0037	4020		JMP I CRLFLF
0040	5426		
		CRLF,	0
0041	0000		CLA CMA
0042	7240		AND CR /CR
0043	0104		JMS PRXLOP
0044	4020		CLA CMA
0045	7240		AND LF /LF
0046	0103		JMS PRXLOP
0047	4020		JMP I CRLF
0050	5441		
		PAT,	0 /GENERATOR PATTERN
0051	0000	RALRTL,	0 /ROTATE LEFT PATTERNS
0052	0000	LFTLNK,	0 /ROTATE LEFT LINK PATTERNS
0053	0000	RARRTR,	0 /ROTATE RIGHT PATTERNS
0054	0000	RITLNK,	0 /ROTATE RIGHT LINK PATTERNS
0055	0000	TST1,	0 /TEST FLAG
0056	0000		

		PROUT,	0	/PRINT OUT LOCATION
0057	0000	K4000,	4000	/MASK LIST
0060	4000	K2000,	2000	
0061	2000	K1000,	1000	
0062	1000	K0400,	0400	
0063	0400	K0200,	0200	
0064	0200	K0100,	0100	
0065	0100	K0040,	0040	
0066	0040	K0020,	0020	
0067	0020	K0010,	0010	
0070	0010	K0004,	0004	
0071	0004	K0002,	0002	
0072	0002	K0001,	0001	
0073	0001	XPROUT,	PROUT	
0074	0057	R,	0322	/R
0075	0322	A,	0301	/A
0076	0301	L,	0314	/L
0077	0314	T,	0324	/T
0100	0324	P,	0320	/P
0101	0320	SP,	0240	/SP
0102	0240	LF,	0212	/LF
0103	0212	CR,	0210	/CR
0104	0215	ZERO,	0060	/ZERO
0105	0060	OVE,	0061	/ONE
0106	0061	O,	0317	/U ALPHA
0107	0317	K,	0313	/K
0110	0313	COUNT,	7764	/MINUS 11
0111	7764	STRUNT,	0	
0112	0000	TWO,	0262	/2
0113	0262	B,	0302	/B
0114	0302	WD1,	0	
0115	0000	WD2,	0	
0116	0000	BW1,	0	
0117	0000	CRY,	0	
0120	0000	TOTAL,	0	
0121	0000	SUM,	0	
0122	0000	CNTR,	0	
0123	0000	HEADER,	0	
0124	0000	BITSTR,	0	
0125	0000	SPACD6,	7776	/MINUS 1
0126	7776	SPACST,	0	
0127	0000	G,	0307	/G
0130	0307	D,	0304	/D
0131	0304	X,	0330	/X
0132	0330	Y,	0331	/Y
0133	0331	LINK,	0	/LINK
0134	0000	XARG,	0	/XARG
0135	0000	YARG,	0	/YARG
0136	0000	COUNTX,	7763	
0137	7763	LNKSTR,	0	
0140	0000	K7377,	7377	
0141	7377			

39<2 0000 0
0143 7240 CLA CMA
0144 0140 AND Z LNKSTR
0145 7440 SZA
0146 5150 JMP SL
0147 5152 JMP CL
0150 7360 SL, CLA CMA STL
0151 5542 JMP I CX
0152 7340 CL, CLL CLA CMA
0153 5542 JMP I CX

*4000

4000	7200	RAND2,	CLA	
4001	1417	TAD I 0017		
4002	3135	DCA XARG	/STORE FIXED PAT	
4003	1417	TAD I 0017		
4004	3136	DCA YARG	/STORE FIXED PAT	
4005	2216	ISZ RCNT		
4006	5647	JMP I XSTRXY	/EXIT TO TEST	
4007	1215	TAD LISTX		
4010	3017	DCA 0017		
4011	1214	TAD M144		
4012	3216	DCA RCNT		
4013	5647	JMP I XSTRXY	/EXIT TO TEST	
4014	7634	M144, -144		
4015	4177	LISTX, LIST-1		
4016	0000	RCNT, 0000		
4017	0000	ODEVEN, 0000		
4020	7300	RAND, CLL CLA	/FIXED PATTERN	
4021	2217	ISZ ODEVEN	/RANDOM PATTERN	
4022	7000	NOP		
4023	1217	TAD ODEVEN		
4024	7010	RAR		
4025	7630	SZL CLA		
4026	5230	JMP RAND1		
4027	5200	JMP RAND2		
4030	7604	RAND1, CLA OSR		
4031	0063	AND Z K0400		
4032	7000	NOP		
4033	7440	SZA		
4034	5650	JMP I ADDX	/SW 3 EQUALS A ONE TO EXIT	
4035	7240	CLA CMA		
4036	0121	AND Z TOTAL		
4037	7000	NOP		
4040	3135	DCA Z XARG		
4041	7040	CMA		
4042	0121	AND Z TOTAL		
4043	7001	IAC		
4044	1410	TAD I Z 10		
4045	3136	DCA Z YARG		
4046	5647	JMP I XSTRXY		
4047	0225	XSTRXY, STRXY		
4050	0312	ADDX, PADDOK		

*0017

0017 4177 LIST-1

*4051

4051	7240	FCOMP,	CLA CMA	/COMPARE SUM AND TOTAL
4052	0121	AND Z TOTAL		
4053	7040	CMA		
4054	0122	AND Z SUM		
4055	3275	DCA CXM		
4056	7240	CLA CMA		
4057	0122	AND Z SUM		
4060	7040	CMA		
4061	0121	AND Z TOTAL		
4062	3274	DCA CXN		
4063	7240	CLA CMA		
4064	0275	AND CXM		
4065	7440	SZA		
4066	5676	JMP I ERX		/ERROR
4067	7240	CLA CMA		
4070	0274	AND CXN		
4071	7440	SZA		
4072	5676	JMP I ERX		/ERROR
4073	5277	JMP LCOMP		
4074	0000	CXN,	0	
4075	0000	CXM,	0	
4076	0400	ERX,	ERROR	
4077	7240	LCOMP,	CLA CMA	/COMPARE CRY AND LINK
4100	0134	AND Z LINK		/LINK BIT IN BIT 11
4101	7040	CMA		
4102	0120	AND Z CRY		
4103	3322	DCA LRX		
4104	7240	CLA CMA		
4105	0120	AND Z CRY		
4106	7040	CMA		
4107	0134	AND Z LINK		
4110	3323	DCA LRY		
4111	7240	CLA CMA		
4112	0322	AND LRX		
4113	7440	SZA		
4114	5676	JMP I ERX		/ERROR
4115	7240	CLA CMA		
4116	0323	AND LRY		
4117	7440	SZA		
4120	5676	JMP I ERX		
4121	5724	JMP I NOERX		/ERRROR
4122	0000	LRX,	0	
4123	0000	LRY,	0	
4124	0407	NOERX,	NOERR	

*4200

4200	7777	LIST,	7777	4262	7777	7777
4201	7777		7777	4263	0001	0001
4202	7776		7776	4264	7777	7777
4203	7777		7777	4265	0002	0002
4204	7775		7775	4266	7777	7777
4205	7777		7777	4267	0004	0004
4206	7773		7773	4270	7777	7777
4207	7777		7777	4271	0010	0010
4210	7767		7767	4272	7777	7777
4211	7777		7777	4273	0020	0020
4212	7757		7757	4274	7777	7777
4213	7777		7777	4275	0040	0040
4214	7737		7737	4276	7777	7777
4215	7777		7777	4277	0100	0100
4216	7677		7677	4300	7777	7777
4217	7777		7777	4301	0200	0200
4220	7577		7577	4302	7777	7777
4221	7777		7777	4303	0400	0400
4222	7377		7377	4304	7777	7777
4223	7777		7777	4305	1000	1000
4224	6777		6777	4306	7777	7777
4225	7777		7777	4307	2000	2000
4226	5777		5777	4310	7777	7777
4227	7777		7777	4311	4000	4000
4230	3777		3777	4312	0001	0001
4231	7777		7777	4313	7777	7777
4232	7777		7777	4314	0002	0002
4233	7777		7777	4315	7777	7777
4234	7776		7776	4316	0004	0004
4235	7777		7777	4317	7777	7777
4236	7775		7775	4320	0010	0010
4237	7777		7777	4321	7777	7777
4240	7773		7773	4322	0200	0200
4241	7777		7777	4323	7777	7777
4242	7767		7767	4324	0400	0400
4243	7777		7777	4325	7777	7777
4244	7757		7757	4326	0100	0100
4245	7777		7777	4327	7777	7777
4246	7737		7737	4330	0200	0200
4247	7777		7777	4331	7777	7777
4250	7677		7677	4332	0400	0400
4251	7777		7777	4333	7777	7777
4252	7577		7577	4334	1000	1000
4253	7777		7777	4335	7777	7777
4254	7377		7377	4336	2000	2000
4255	6777		6777	4337	7777	7777
4256	7777		7777	4340	4000	4000
4257	5777		5777	4341	7777	7777
4260	7777		7777			
4261	3777		3777			

*0200

0200	7240	ARITHT,	CLA CMA
0201	3124	DCA Z HEADER	
0202	7240	CLA CMA	
0203	3135	DCA XARG	
0204	7240	CLA CMA	
0205	3136	DCA YARG	
0206	7240	CLA CMA	
0207	3121	DCA TOTAL	
0210	3134	DCA Z LINK	
0211	3115	DCA Z WD1	
0212	5223	JMP INCR	
0213	3120	DCA Z CRY	
0214	7340	ADD,	CLA CMA CLL
0215	0135	AND Z XARG	
0216	1136	TAD Z YARG	
0217	3122	DCA Z SUM	/STORE SUM OF REAL ADD
0220	7004	RAL	
0221	3134	DCA Z LINK	/STORE LINK OF REAL ADD AT BIT 11
0222	5737	JMP I XFCOMP	/COMPARE SUM AND TOTAL
0223	5624	INCR,	JMP I INCRX
0224	4020	INCRX,	RAND
0225	7240	STRXY,	CLA CMA
0226	0135	AND Z XARG	
0227	3115	DCA Z WD1	/XARG EQUALS WD2
0230	7240	CLA CMA	
0231	0136	AND Z YARG	
0232	3116	DCA Z WD2	/YARG EQUALS WD2
0233	4235	JMS ADDISM	/JMS TO FAKE ADD
0234	5214	JMP ADD	

0235	0000	ADDISM, 0	/FAKE ADD
0236	7300	CLA CLL	
0237	3121	DCA Z TOTAL	
0240	3120	DCA Z CRY	
0241	7040	CMA	
0242	0111	AND Z COUNT	/MINUS 11
0243	3123	DCA Z CNTR	
0244	7040	AISM, CMA	
0245	0115	AND Z WD1	
0246	7010	RAR	
0247	3115	DCA Z WD1	
0250	7004	RAL	
0251	3117	DCA Z BW1	
0252	7040	CMA	
0253	0116	AND Z WD2	
0254	7010	RAR	
0255	3116	DCA Z WD2	
0256	7040	CMA	
0257	0117	AND BW1	
0260	7420	SNL	
0261	5302	JMP DISM	
0262	7450	SNA	
0263	5305	JMP CISM	
0264	7300	CLL CLA	
0265	7040	AXISM, CMA	
0266	0120	AND Z CRY	
0267	7010	RAR	
0270	7040	CMA	
0271	0117	AND Z BW1	
0272	3120	BISM, DCA Z CRY	
0273	7040	CMA	
0274	0121	AND Z TOTAL	
0275	7010	RAR	
0276	3121	DCA Z TOTAL	
0277	2123	ISZ Z CNTR	
0300	5244	JMP AISM	
0301	5635	JMP I ADDISM	
0302	7450	DISM, SNA	
0303	5265	JMP AXISM	
0304	7220	CML CLA	
0305	7040	CISM, CMA	
0306	0120	AND Z CRY	
0307	7440	SZA	
0310	7100	CLL	
0311	5272	JMP BISM	

0312	4041	PADDOK,	JMS Z CRLF	/CR LF
0313	7240	CLA CMA		
0314	0076	AND Z A		/A
0315	4020	JMS Z PRXLOP		
0316	7240	CLA CMA		
0317	0131	AND Z D		/D
0320	4020	JMS Z PRXLOP		
0321	7240	CLA CMA		
0322	0131	AND Z D		/D
0323	4020	JMS Z PRXLOP		
0324	7240	CLA CMA		
0325	0102	AND Z SP		/SP
0326	4020	JMS Z PRXLOP		
0327	7240	CLA CMA		
0330	0107	AND Z O		/O
0331	4020	JMS Z PRXLOP		
0332	7240	CLA CMA		
0333	0110	AND Z K		/K
0334	4020	JMS Z PRXLOP		
0335	5736	JMP I ROTATE		/EXIT ADD TEST
0336	2000	ROTATE, GEN1		
0337	4051	XFCOMP, FCOMP		

*0400
 0400 7604 ERROR, CLA OSR /READ IN SR
 0401 7106 CLL RTL
 0402 7510 SPA /SW2 EQUALS A ONE TO PRINT
 0403 4216 JMS PRINT /JMS TO PRINT ROUTINE
 0404 7604 CLA OSR
 0405 7510 SPA /SW0 EQUALS A ONE TO HALT
 0406 7402 HLT /HALT ON ERROR
 0407 7604 NOERR, CLA OSR
 0410 7104 CLL RAL /SW1 EQUALS A ONE TO SCOPE MODE
 0411 7510 SPA /SCOPE MODE
 0412 5614 JMP I SXY
 0413 5615 JMP I INCRT /CONTINUE MODE
 0414 0225 SXY, STRXY
 0415 0223 INCRT, INCR
 0416 0000 PRINT, 0
 0417 7240 CLA CMA
 0420 0124 AND Z HEADER /HEADER FLAG
 0421 7440 SZA
 0422 4321 JMS PRHEAD /JMS TO PRINT HEADER ROUTINE
 0423 7000 PRERR, NOP
 0424 4041 JMS Z CRLF /CR LF
 0425 4020 JMS Z PRXLOP
 0426 7240 CLA CMA
 0427 0120 AND Z CRY
 0430 4635 JMS I XONZER /TEST FAKE LINK FOR SEX AND
 /PRINT A ONE OR ZERO
 0431 7240 CLA CMA
 0432 0102 AND Z SP /PRINT SP
 0433 4020 JMS Z PRXLOP
 0434 5236 JMP PTOTAL /PRINT CONTENTS OF FAKE ADD
 0435 2637 XONZER, ONZER

```

0436 7240 PTOTAL, CLA CMA
0437 0121 AND Z TOTAL /STORE CONTENTS OF FAKE ADD
0440 3125 DCA Z BITSTR
0441 4266 JMS MESSG
0442 7240 CLA CMA
0443 0134 AND Z LINK /TEST REAL LINK FOR SEX AND
0444 4635 JMS I XONZER /PRINT A ONE OR ZERO

0445 7240 CLA CMA
0446 0102 AND Z SP / PRINT SP
0447 4020 JMS Z PRXLOP
0450 5251 JMP XTOTAL

0451 7240 XTOTAL, CLA CMA
0452 0122 AND Z SUM
0453 3125 DCA Z BITSTR /STORE CONTENTS OF REAL ADD
0454 4266 JMS MESSG
0455 7240 CLA CMA
0456 0135 AND Z XARG
0457 3125 DCA Z BITSTR /STORE XARG
0460 4266 JMS MESSG
0461 7240 CLA CMA
0462 0136 AND Z YARG
0463 3125 DCA Z BITSTR /STORE Y ARG
0464 4266 JMS MESSG
0465 5616 JMP I PRINT /EXIT TO SWITCH ROUTINE

```

```

0466 0000 MESSG,      0
0467 7240 CLA CMA
0470 0137 AND Z COUNTX
0471 3112 DCA Z STRCNT
0472 2112 NBIT,      ISZ Z STRCNT
0473 7410 SKP
0474 5312 JMP PRSPAC           /12 COUNTS FINISHED
0475 7240 CLA CMA
0476 0125 AND Z BITSTR
0477 7100 CLL
0500 7004 RAL
0501 3125 DCA Z BITSTR       /STORE ROTATED WORD
0502 7430 SZL
0503 5306 JMP PRONE
0504 4764 PRZERO,     JMS I XZEROR   /PRINT ZERO
0505 5272 JMP NBIT
0506 7240 PRONE,      CLA CMA
0507 0106 AND Z ONE
0510 4020 JMS Z PRXLOP       /PRINT ONE
0511 5272 JMP NBIT
0512 7240 PRSPAC,     CLA CMA
0513 0102 AND Z SP
0514 4020 JMS Z PRXLOP       /SP
0515 7240 CLA CMA
0516 0102 AND Z SP
0517 4020 JMS Z PRXLOP       /SP
0520 5666 JMP I MESSG
0521 0000 PRHEAD,      0
0522 7200 CLA
0523 3124 DCA Z HEADER      /CLEAR HEADER FLAG
0524 7240 CLA CMA
0525 0126 AND Z SPAC06
0526 3127 DCA Z SPACST       /STORE SPACE COUNT
0527 4041 JMS Z CRLF        /PRINT CR LF

```

0530	7240	SPA06,	CLA CMA
0531	0102	AND Z SP	
0532	4020	JMS Z PRXLOP	/PRINT 6 SPACES
0533	2127	ISZ Z SPACST	
0534	5330	JMP SPA06	
0535	7240	CLA CMA	
0536	0130	AND Z G	/G
0537	4020	JMS Z PRXLOP	
0540	7240	CLA CMA	
0541	0107	AND Z O	/O ALPHA
0542	4020	JMS Z PRXLOP	
0543	7240	CLA CMA	
0544	0107	AND Z O	/O ALPHA
0545	4020	JMS Z PRXLOP	
0546	7240	CLA CMA	
0547	0131	AND Z D	/D
0550	4020	JMS Z PRXLOP	
0551	4762	JMS I MANYSP	/JMP TO PRINT 12 SPACES
0552	7240	CLA CMA	
0553	0114	AND Z B	/B
0554	4020	JMS Z PRXLOP	
0555	7240	CLA CMA	
0556	0076	AND Z A	/A
0557	4020	JMS Z PRXLOP	
0560	5761	JMP I CONHED	
0561	0600	CONHED, HEDCON	
0562	0626	MANYSP, TWELVE	
0563	5721	HEDRJ, JMP I PRHEAD	/EXIT HEADER ROUTINE
0564	2702	XZEROR, ZEROR	

*0600

0600	7240	HEDCON,	CLA CMA	
0601	0131	AND Z D		/D
0602	4020	JMS Z PRXLOP		
0603	4226	JMS TWELVE		/12 SPACES
0604	7240	CLA CMA		
0605	0132	AND Z X		/X
0606	4020	JMS Z PRXLOP		
0607	7240	CLA CMA		
0610	0102	AND Z SP		/SP
0611	4020	JMS Z PRXLOP		
0612	4240	JMS ARGXXX		/ARG
0613	4226	JMS TWELVE		/12 SPACES
0614	7240	CLA CMA		
0615	0133	AND Z Y		/Y
0616	4020	JMS Z PRXLOP		
0617	7240	CLA CMA		
0620	0102	AND Z SP		/SP
0621	4020	JMS Z PRXLOP		
0622	4240	JMS ARGXXX		/ARG
0623	4041	JMS Z CRLF		/CR LF
0624	5625	JMP I RJHED		/JUMP TO EXIT HEADER ROUTINE
0625	0563	RJHED, HEDRJ		
0626	0000	TWELVE, 0		
0627	7240	CLA CMA		
0630	0111	AND Z COUNT		
0631	3127	DCA Z SPACST		/STORE MINUS 12
0632	7240	SPA12, CLA CMA		
0633	0102	AND Z SP		/SP
0634	4020	JMS Z PRXLOP		/PRINT 12 SPACES
0635	2127	ISZ Z SPACST		
0636	5232	JMP SPA12		
0637	5626	JMP I TWELVE		
0640	0000	ARGXXX, 0		
0641	7240	CLA CMA		
0642	0076	AND Z A		/A
0643	4020	JMS Z PRXLOP		
0644	7240	CLA CMA		
0645	0075	AND Z R		/R
0646	4020	JMS Z PRXLOP		
0647	7240	CLA CMA		
0650	0130	AND Z G		/G
0651	4020	JMS Z PRXLOP		
0652	5640	JMP I ARGXXX		

*2000

2000	4316	GEN1,	JMS HSEKP	
2001	4142	CONT1,	JMS Z CX	
2002	0051	AND Z PAT		
2003	7001	IAC		
2004	3051	DCA Z PAT		/STORE INCREMENTED PATTERN
2005	7420	SNL		
2006	5215	JMP CLRLNK		/JMP TO CLEAR LNKSTR
2007	1060	TAD K4000		
2010	3140	DCA Z LNKSTR		/SET LNKSTR TO 4000
2011	4352	PT1EX, JMS EX		
2012	7440	SZA		
2013	5220	JMP ROT1		
2014	5274	JMP GEN2		/EXIT ROT1
2015	7200	CLRLNK, CLA		
2016	3140	DCA Z LNKSTR		
2017	5211	JMP PT1EX		
2020	7240	ROT1, CLA CMA		
2021	3056	DCA Z TST1		/SET TST1 FLAG
2022	7340	CLL CLA CMA		
2023	0140	AND Z LNKSTR		
2024	7440	SZA		
2025	5272	JMP SETLINK		
2026	7140	CLL CMA		/CLEAR LINK
2027	0051	REROT1, AND Z PAT		/BRING UP PATTERN
2030	7004	RAL		
2031	3052	DCA Z RALRTL		/STORE RAL PATTERN
2032	7430	SZL		/SKIP IF LINK EQUALS A ZERO
2033	1060	TAD Z K4000		/SET RAL LINK STORE
2034	3053	DCA Z LFTLNK		/CLEAR RAL LINK STORE
2035	7240	CLA CMA		
2036	0052	AND Z RALRTL		
2037	7010	RAR		
2040	3054	DCA Z RARRTR		/STORE RAR PATTERN
2041	7430	SZL		/SKIP IF LINK EQUALS A ZERO
2042	1060	TAD Z K4000		/SET RAR LINK STORE
2043	3055	DCA Z RITLNK		/CLEAR RAR LINK STORE

2044	7340	CLL CLA CMA	
2045	0054	AND Z RARRTR	/RARRTR SHOULD EQUAL PAT
2046	7040	CMA	
2047	1051	TAD Z PAT	/COMPARE RARTR WITH PAT
2050	7040	CMA	/AC SHOULD EQUAL ZERO
2051	7450	SNA	
2052	7430	SZL	
2053	5715	JMP I ERSWIX	/JUMP TO ERROR SWITCHES
2054	1060	TAD K4000	
2055	0051	AND Z PAT	/MASK BIT 0 OF PAT
2056	7040	CMA	
2057	1053	TAD Z LFTLNK	/COMPARE LFTLNK WITH PAT
2060	7040	CMA	/BIT 0
2061	7440	SZA	
2062	5715	JMP I ERSWIX	/JUMP TO ERROR SWITCHES
2063	1055	TAD Z RITLNK	
2064	7040	CMA	
2065	1140	TAD Z LNKSTR	/COMPARE PAT LINK WITH RITLNK
2066	7040	CMA	
2067	7440	SZA	
2070	5715	JMP I ERSWIX	
2071	5751	JMP I SXOKX1	
2072	7360	SETLNK, CLA CMA STL	/SET LINK
2073	5227	JMP REROT1	
2074	4316	GEN2, JMS HSEKP	
2075	4142	CONT2, JMS Z CX	
2076	0051	AND Z PAT	
2077	7001	IAC	
2100	3051	DCA Z PAT	/STORE INCREMENTED PATTERN
2101	7420	SNL	
2102	5311	JMP CLLINK	/JUMP TO CLEAR LNKSTR
2103	1060	TAD K4000	
2104	3140	DCA Z LNKSTR	/SET LNKSTR TO 4000
2105	4363	PT1EXX, JMS EX1	
2106	7440	SZA	
2107	5714	JMP I ROT2X	
2110	5332	JMP ROTOK	/EXIT ROTATE TESTS

2111 7200 CLLINK, CLA
 2112 3140 DCA Z LNKSTR
 2113 5305 JMP PT1EXX

 2114 2200 ROT2X, ROT2
 2115 2400 ERSWIX, ERRSW1
 2116 0000 HSEKP, 0
 2117 7300 CLA CLL
 2120 3051 DCA Z PAT
 2121 3052 DCA Z RALRTL
 2122 3054 DCA Z RARRTR
 2123 3053 DCA Z LFTLNK
 2124 3055 DCA Z RITLNK
 2125 3140 DCA Z LNKSTR
 2126 7000 NOP
 2127 7000 NOP
 2130 7000 NOP
 2131 5716 JMP I HSEKP
 2132 7200 ROTOK, CLA
 2133 4041 JMS Z CRLF /CRLF
 2134 1075 TAD Z R /R
 2135 4020 JMS Z PRXLOP
 2136 1107 TAD Z O /O
 2137 4020 JMS Z PRXLOP
 2140 1100 TAD Z T /T
 2141 4020 JMS Z PRXLOP
 2142 4041 JMS Z CRLF /CRLF
 2143 1113 TAD Z TWO /2
 2144 4020 JMS Z PRXLOP
 2145 1114 TAD Z B /B
 2146 4020 JMS Z PRXLOP
 2147 5750 JMP I ARITH
 2150 0200 ARITH, ARITHT
 2151 2521 SXOKX1, SWOKX1
 2152 0000 EX, 0
 2153 1140 TAD Z LNKSTR
 2154 7440 SZA
 2155 7410 SKP
 2156 5220 JMP ROT1
 2157 7240 CLA CMA
 2160 0051 AND Z PAT
 2161 7040 CMA
 2162 5752 JMP I EX
 2163 0000 EX1, 0
 2164 1140 TAD Z LNKSTR
 2165 7440 SZA
 2166 7410 SKP
 2167 5714 JMP I ROT2X
 2170 7240 CLA CMA
 2171 0051 AND Z PAT
 2172 7040 CMA
 2173 5763 JMP I EX1

*2200

2200	7300	ROT2,	CLA CLL	
2201	3056	DCA Z TST1	/CLEAR TEST FLAG	
2202	7340	CLL CLA CMA		
2203	0140	AND Z LNKSTR		
2204	7440	SZA		
2205	5250	JMP STLNK		
2206	7140	CLL CMA		
2207	0051	REROT2, AND Z PAT	/BRING UP PATTERN	
2210	7012	RTR		
2211	3054	DCA Z RARRTR	/STORE RTR PATTERN	
2212	7430	SZL	/SKIP IF LINK EQUALS A ZERO	
2213	1072	TAD Z K0002	/SET RTR LINK STORE	
2214	3055	DCA Z RITLNK	/CLEAR RTR LINK STORE	
2215	1054	TAD Z RARRTR		
2216	7006	RTL		
2217	3052	DCA Z RALRTL	/STORE RTL PATTERN	
2220	7430	SZL		
2221	1060	TAD Z K4000	/SET RTL LINK STORE	
2222	3053	DCA Z LFTLNK	/CLEAR RTL LINK STORE	
2223	7100	CLL		
2224	1052	TAD Z RALRTL	/RALRTL SHOULD EQUAL PAT	
2225	7040	CMA		
2226	1051	TAD Z PAT	/COMPARE RALRTL WITH PAT	
2227	7040	CMA		
2230	7440	SZA		
2231	5652	JMP I ERSW2X	/JMP TO ERROR SWITCHES	
2232	1072	TAD Z K0002	/COMPARE ROTLNK WITH PAT BIT 10	
2233	0051	AND Z PAT	/MASK BIT 10 OF PAT	
2234	7040	CMA		
2235	1055	TAD Z RITLNK		
2236	7040	CMA		
2237	7440	SZA		
2240	5652	JMP I ERSW2X		
2241	1053	TAD Z LFTLNK	/LFT LINK SHOULD EQUAL LNKSTR	
2242	7040	CMA		
2243	1140	TAD Z LNKSTR	/COMPARE LFTLNK WITH LNKSTR	
2244	7040	CMA		
2245	7440	SZA		
2246	5652	JMP I ERSW2X	/JUMP TO ERROR SWITCHES	
2247	5653	JMP I SXOKX2		
2250	7360	STLNK, CLA CMA STL		
2251	5207	JMP REROT2		
2252	2406	ERSW2X, ERSW2		
2253	2525	SXOKX2, SWOKX2		

*2400

2400	7200	ERRSW1,	CLA	
2401	1244	TAD	ROTX1	
2402	3215	DCA	ERIN	/SCOPE MODE RJMP ADDRESS
2403	1245	TAD	CONTX1	
2404	3214	DCA	CONTX	/CONTINUE MODE RJMP ADDRESS
2405	5216	JMP	ERSW	
2406	7200	ERRSW2,	CLA	
2407	1250	TAD	ROTX2	
2410	3215	DCA	ERIN	/SCOPE MODE RJMP ADDRESS
2411	1251	TAD	CONTX2	
2412	3214	DCA	CONTX	/CONTINUE MODE RJMP ADDRESS
2413	5216	JMP	ERSW	
2414	0000	CONTX,	0	
2415	0000	ERIN,	0	
2416	7604	ERSW,	CLA OSR	/READ IN SWITCHES
2417	0062	AND Z	K1000	/MASK BIT 2
2420	7040	CMA		
2421	1062	TAD Z	K1000	
2422	7040	CMA		
2423	7450	SNA		/TEST BIT 2 SWITCH
2424	4255	JMS	ROPR	
2425	7604	CLA	OSR	
2426	0060	AND Z	K4000	/MASK BIT 0
2427	7040	CMA		
2430	1060	TAD Z	K4000	
2431	7040	CMA		
2432	7450	SNA		/TEST BIT 0 SWITCH
2433	7402	HLT		/ERROR HALT
2434	7604	SWOK,	CLA OSR	
2435	0061	AND Z	K2000	/MASK BIT 1
2436	7040	CMA		
2437	1061	TAD Z	K2000	
2440	7040	CMA		
2441	7450	SNA		/TEST BIT 1 SWITCH
2442	5615	JMP I	ERIN	/JMP TO SCOPE MOD
2443	5614	JMP I	CONTX	/JMP TO CONTINUE MODE

2444	2020	ROTX1,	ROT1	
2445	2001	CONTX1,	CONT1	
2446	2000	GEN1X1,	GEN1	
2447	2074	GEN2X2,	GEN2	
2450	2200	ROTX2,	ROT2	
2451	2075	CONTX2,	CONT2	
2452	2464	TWOROX,	TWORO	
2453	2465	FINPRX,	FINPR	
2454	2650	RARPRX,	RARPR	
2455	0000	ROPR,	0	/RJMP TO SWITCH ROUTINE
2456	4026	JMS Z CRLF		/PRINT CR LF LF
2457	4714	JMS I PATPRX		/PRINT PAT
2460	7200	CLA		
2461	1056	TAD Z TST1		
2462	7440	SZA		
2463	5266	JMP ROT1PR		/PRINT ROTATE ONE PATTERN
2464	4715	TWORO,	JMS I ROT2PX	/PRINT ROTATE TWO PATTERN
2465	5655	FINPR,	JMP I ROPR	
2466	7200	ROT1PR,	CLA	
2467	1254	TAD RARPRX		
2470	3714	DCA I PATPRX		
2471	4041	JMS Z CRLF		/PRINT CR LF
2472	7200	CLA		
2473	1075	TAD Z R		/R
2474	4020	JMS Z PRXLOP		
2475	1076	TAD Z A		/A
2476	4020	JMS Z PRXLOP		
2477	1077	TAD Z L		/L
2500	4020	JMS Z PRXLOP		
2501	1102	TAD Z SP		/SP
2502	4020	JMS Z PRXLOP		
2503	1053	TAD Z LFTLNK		
2504	7440	SZA		
2505	5716	JMP I LN0NER		/LEFT LINK PRINT ONE
2506	4717	JMS I ZERORX		/LEFT LINK PRINT ZERO
2507	1102	RO1X, TAD Z SP		
2510	4020	JMS Z PRXLOP		/SP
2511	1052	TAD Z RALRTL		
2512	3057	DCA Z PROUT		
2513	5720	JMP I COUNXX		/PRINT RALRTL CONTENTS
2514	2600	PATPRX,	PATPR	
2515	2732	ROT2PX,	ROT2PR	
2516	2676	LN0NER,	LNONE	
2517	2702	ZERORX,	ZEROR	
2520	2616	COUNXX,	COUNPR	
2521	7200	SWOKX1,	CLA	
2522	1245	TAD CONTX1		
2523	3214	DCA CONTX		
2524	5234	JMP SWOK		
2525	7200	SWOKX2,	CLA	
2526	1251	TAD CONTX2		
2527	3214	DCA CONTX		
2530	5234	JMP SWOK		

*2600

2600	0000	PATPR,	0	
2601	1101	TAD Z P		/P
2602	4020	JMS Z PRXLOP		
2603	1076	TAD Z A		/A
2604	4020	JMS Z PRXLOP		
2605	1100	TAD Z T		/T
2606	4020	JMS Z PRXLOP		
2607	1102	TAD Z SP		/SP
2610	4020	JMS Z PRXLOP		
2611	4361	JMS PLINK		
2612	1102	TAD Z SP		
2613	4020	JMS Z PRXLOP	/SP	
2614	1051	TAD Z PAT		
2615	3057	DCA Z PROUT		/STORE GENERATED PATTERN
2616	4231	COUNPR, JMS MINDEX		/JMS TO MASK INDEX ROUTINE
2617	0137	AND Z COUNTX		
2620	3112	DCA Z STRCNT		
2621	2112	LSTBIT, ISZ Z STRCNT		
2622	7410	SKP		
2623	5600	JMP I PATPR		/12 COUNTS FINISHED
2624	7200	CLA		
2625	1057	TAD Z PROUT		
2626	0410	AND I Z 10		
2627	4237	JMS ONZER		
2630	5221	JMP LSTBIT		
2631	0000	MINDEX, 0		
2632	7200	CLA		
2633	1074	TAD Z XPROUT		/INDEX STARTING ADDRESS
2634	3010	DCA Z 10		/STORE INDEX ADDRESS
2635	7240	CLA CMA		
2636	5631	JMP I MINDEX		

2637 0000 ONZER, 0
 2640 7440 SZA
 2641 5244 JMP ONEP /JMP TO PRINT ONE
 2642 4302 JMS ZEROR
 2643 5637 JMP I ONZER
 2644 7240 ONEP, CLA CMA
 2645 0106 AND Z ONE
 2646 4020 JMS Z PRXLOP /PRINT ONE
 2647 5637 JMP I ONZER

 2650 7200 RARPR, CLA
 2651 1273 TAD FINPRN
 2652 3200 DCA PATPR
 2653 4041 JMS Z CRLF /CR LF
 2654 7200 CLA
 2655 1075 TAD Z R /R
 2656 4020 JMS Z PRXLOP
 2657 1076 TAD Z A /A
 2660 4020 JMS Z PRXLOP
 2661 4323 JMS RSPACE /R SP
 2662 1055 TAD Z RITLNK
 2663 7440 SZA
 2664 5307 JMP LN0NEX /RIT LINK EQUALS A ONE
 2665 4302 JMS ZEROR
 2666 1102 R01XX, TAD Z SP /SP
 2667 4020 JMS Z PRXLOP
 2670 1054 TAD Z RARRTR
 2671 3057 DCA Z PROUT
 2672 5216 JMP COUNPR /PRINT RARR TR CONTENTS

 2673 2465 FINPRN, FINPR
 2674 2507 R01XR, R01X
 2675 2744 RTLPRX, RTLPR

2676 7240 LNONE, CLA CMA
2677 0106 AND Z ONE
2700 4020 JMS Z PRXLOP /PRINT LINK
2701 5674 JMP I R01XR

2702 0000 ZEROR, 0
2703 7240 CLA CMA
2704 0105 AND Z ZERO
2705 4020 JMS Z PRXLOP /PRINT 0 LINK
2706 5702 JMP I ZEROR

2707 7200 LNONE, CLA
2710 1106 TAD Z ONE
2711 4020 JMS Z PRXLOP
2712 5266 JMP R01XX

2713 0000 RTCRLF, 0
2714 7200 CLA
2715 4041 JMS Z CRLF /CR LF
2716 1075 TAD Z R /R
2717 4020 JMS Z PRXLOP
2720 1100 TAD Z T /T
2721 4020 JMS Z PRXLOP
2722 5713 JMP I RTCRLF

2723 0000 RSPACE, 0
2724 7200 CLA
2725 1075 TAD Z R /R
2726 4020 JMS Z PRXLOP
2727 1102 TAD Z SP /SP
2730 4020 JMS Z PRXLOP
2731 5723 JMP I RSPACE

2732	7200	ROT2PR,	CLA	
2733	1275	TAD RTLPRX		
2734	3200	DCA PATPR		
2735	4313	JMS RTCRLF	/CR LF RT	
2736	4323	JMS RSPACE	/R SP	
2737	1055	TAD Z RITLNK		
2740	7440	SZA		
2741	5307	JMP LN0NEX	/RIGHT LINK EQUALS A ONE	
2742	4302	JMS ZEROR	/PRINT Ø LINK	
2743	5266	JMP R01XX	/PRINT SP AND RARRTR CONTENTS	
2744	7200	RTLPR,	CLA	
2745	1273	TAD FINPRN		
2746	3200	DCA PATPR		
2747	4313	JMS RTCRLF	/CR LF RT	
2750	1077	TAD Z L	/L	
2751	4020	JMS Z PRXLOP		
2752	1102	TAD Z SP	/SP	
2753	4020	JMS Z PRXLOP		
2754	1053	TAD Z LFTLNK		
2755	7440	SZA		
2756	5276	JMP LN0NE	/PRINT 1 LINK	
2757	4302	JMS ZEROR	/PRINT Ø LINK	
2760	5674	JMP I R01XR		
2761	0000	PLINK,	Ø	
2762	1140	TAD Z LNKSTR	/PRINT PAT LINK	
2763	4237	JMS ONZER		
2764	5761	JMP I PLINK		

@A	0076	K	0110
ADD	0214	K0001	0073
ADDISM	0235	K0002	0072
ADDX	4050	K0004	0071
AISM	0244	K0010	0070
ARGXXX	0640	K0020	0067
ARITH	2150	K0040	0066
ARITHT	0200	K0100	0065
AXISM	0265	K0200	0064
B	0114	K0400	0063
BISM	0272	K1000	0062
BITSTR	0125	K2000	0061
BW1	0117	K4000	0060
CISM	0305	K7377	0141
CL	0152	L	0077
CLLINK	2111	LCOMP	4077
CLRLNK	2015	LF	0103
CNTR	0123	LFTLNK	0053
CONHFD	0561	LINK	0134
CONTX	2414	LIST	4200
CONTX1	2445	LISTX	4015
CONTX2	2451	LNKSTR	0140
CONT1	2001	LNONF	2676
CONT2	2075	LNONFR	2516
COUNPR	2616	LNONFX	2707
COUNT	0111	LPXX	0022
COUNTX	0137	LRX	4122
COUNXX	2520	LRY	4123
CR	0104	LSTBIT	2621
CRLF	0041	MANYSP	0562
CRLFLF	0026	MESSG	0466
CRY	0120	MINDFX	2631
CX	0142	M144	4014
		NBIT	0472
CXM	4075	NOERR	0407
CXN	4074		
U	0131	NOERX	4124
UISM	0302	O	0107
ERIN	2415	ODEVFN	4017
ERROR	0400	UNE	0106
ERRSW1	2400	UNEP	2644
ERRSW2	2406	ONZER	2637
ERSW	2416	P	0101
ERSWIX	2115	PADDOK	0312
ERSW2X	2252	PAT	0051
ERX	4076	PATPR	2600
EX	2152	PATPRX	2514
EX1	2163	PLINK	2761
FCOMP	4051	PRERR	0423
FINPR	2465	PRHEAD	0521
FINPRN	2673	PRINT	0416
FINPRX	2453	PRONF	0506
G	0130	PROUT	0057
GEN1	2000	PRSPAC	0512
GEN1X1	2446	PRXLOP	0020
GEN2	2074	PRZERO	0504
GEN2X2	2447	PTOTAL	0436
HEADER	0124	PT1EX	2011
HEDCON	0600	PT1EXX	2105
HEDRJ	0563	R	0075
HSEKP	2116	RALRTL	0052
INCR	0223	RAND	4020
INCRT	0415	RAND1	4030
INCRX	0224	RAND2	4000

RARPR	2650	SWOK	2434
RARPRX	2454	SWOKX1	2521
RARRTR	0054	SWOKX2	2525
RCNT	4016	SXOKX1	2151
REROT1	2027	SXOKX2	2253
REROT2	2207	SXY	0414
RITLNK	0055	T	0100
RJHED	0625	TOTAL	0121
ROPR	2455	TST1	0056
ROTATE	0336	TWELVE	0626
ROTOPK	2132	TWO	0113
ROTX1	2444	TWORO	2464
ROTXP	2450	TWOROX	2452
ROT1	2020	WD1	0115
ROT1PR	2466	WD2	0116
ROT2	2200	X	0132
ROT2PR	2732	XARG	0135
ROT2PX	2515	XFCOMP	0337
ROT2X	2114	XONZFR	0435
RO1X	2507	XPROUT	0074
RO1XR	2674	XSTRXY	4047
RO1XX	2666	XTOTAL	0451
RSPACE	2723	XZEROR	0564
RTCRLF	2713	Y	0133
RTLPR	2744	YARG	0136
RTLPRX	2675	ZERO	0105
SETLNK	2072	ZEROR	2702
SL	0150	ZERORX	2517
SP	0102)	
SPAC06	0126		
SPACST	0127		
SPA06	0530		
SPA12	0632		
STLNK	2250		
STRCNT	0112		
STRXY	0225		
SUM	0122		