

MAINDEC-08-DO5B-D

IDENTIFICATION

Product Code: MAINDEC-08-DO5B-D
Product Name: Random JMP-JMS Test
Date Created: December 28, 1967
Maintainer: Diagnostic Group
Author: R. Green

1. ABSTRACT

This is a diagnostic program to test the JMS instruction of the PDP-8. Random FROM and TO addresses are selected for each test. The JMP instruction is tested in that each test requires a JMP to reach the JMS.

2. REQUIREMENTS

2.1 Equipment

PDP-8 equipped with Teletype.

2.2 Storage

Locations 0000 - 0574

The Binary Loader must be stored in the last memory page.

2.3 Preliminary Programs

It is assumed that MAINDEC 08-D01(n), 08-D02(n), 08-D03(n), and 08-D04(n) have been run successfully.

3. LOADING PROCEDURE

3.1 Method

Use the standard Binary Loader

4. STARTING PROCEDURE

4.1 Control Switch Settings

- SR0 Halt on error.
- SR2 Hold the FROM address constant (1).
Select random FROM addresses (0).
- SR3 Hold the TO address constant (1).
Select random TO addresses (0).

4.2 Starting Address

0200

Restart Address - 0215

4.3 Operator Action

- a. Set SR to 0200 and press LOAD ADDRESS.
- b. If it is desired to set either SR2 or SR3, the FROM or TO address may be specified by entering the address into the locations shown below.

FROM = Location 130

TO = Location 126

If SR2 or SR3 is set after the program has been started, the last address taken from the random number generator is used repeatedly.

- c. Push START.

5. OPERATING PROCEDURE

Same as section 4.

6. ERRORS

6.1 Error Halts

All unused memory locations are loaded with HLT instructions. If the program executes one of these background HLTs, it is probable that the interrupt failed to occur following the JMS instruction. The FROM and TO address may be checked at any time to locate the test JMS instructions.

6.2 Error Printouts

F xxxx TO yyyy

(TO) = mmmm

(nnnn) = rrrr

6.2.1 Explanation

(FROM) F xxxx: xxxx = address of JMS instruction being tested.

(TO) TO yyyy: yyyy = address that the JMS instruction is going to.

(TO) = mmmm; mmmm = the contents of the address TO. This should equal xxxx + 1.

(nnnn) = rrrr: nnnn is the address minus one that was stored in location 0000 during the interrupt. rrrr is the content of address nnnn.

6.2.2 Examples

a. The following is a forced error printout where no error occurred.

```
F 5236 TO 6354
(TO) = 5237
(6354) = 5237
```

The test JMS instruction was in location 5236. The JMS was trying to jump to location 6354. The contents of TO (location 6354) was 5237. This is correct since the PC is stored on a JMS instruction.

To gain any knowledge from the third line of the printout, the user must understand the sequence of events when a JMS instruction is followed by an interrupt. As an end result of this sequence, the address of the location following the cell where the PC is stored is placed into cell 0. To derive this third line of the printout, the address in cell 0 is decremented by one and printed on the Teletype; then the contents of that address are printed.

b. The following is a typical error printout.

```
F 5236 TO 6354
(TO) = 7402
(4354) = 5237
```

Line 1 is simply a statement of the problem. Line 2 says that the contents of location 6354 are not 5237 as they should be, but are 7402 instead. 7402 is a HLT instruction. Since memory is filled with a background of HLT orders, it is evident that the PC was not stored in location 6354 during the JMS.

Line 3 of the printout reveals where the PC was stored. Since on the interrupt 4355 was stored in location zero and (4354) contains the correctly stored PC, 5237, it is apparent that a jump error occurred. The JMS instruction should have jumped to 6354, but it actually jumped to 4354. Bit 1 was lost.

c. The following is another typical error printout.

```
F 5236 TO 6354
(TO) = 7237
(6354) = 7237
```

Line 1 is again simply a statement of the problem. Line 2 says that the contents of location 6354 are not 5237 as expected, but are instead 7237. Since the contents are not a HLT order, 7402, it is evident that the PC was stored here, but the number stored was wrong. Comparing the good (5237), and the bad (7237), it is apparent that bit 1 was "picked up" during the store PC operation of the JMS instruction.

6.3 Error Recovery

The program continues testing following an error printout. When enough information has been gathered from the error printouts, a FROM and TO address is selected for use in the scope mode loop. Enter the chosen addresses into proper locations (see section 4.3.b). Enter 5531 into location 1 and restart the program with SR2 and SR3 set.

The scope mode loop is:

| <u>Location</u> | <u>Coding</u> |
|-----------------|---------------|
| 0000 | |
| 0001 | JMP 1 FROM 1 |
| xxxx | A, ION |
| xxxx | JMS 1 TO |
| 0131 | FROM 1 A |

To discontinue the scope mode loop, restore the original contents (7200) of location 1 and restart.

7. RESTRICTIONS

(None)

8. MISCELLANEOUS

8.1 Execution Time

4,726 random tests/second

9. PROGRAM DESCRIPTION

The JMS instruction is checked through use of the interrupt function. A random number generator selects a FROM and a TO address. An ION instruction is then placed at FROM -1 and the JMS instruction at FROM. The program jumps to the address specified by TO. After executing the ION and JMS instructions, an interrupt occurs starting the program counter at location 1. A checking routine located here verifies that the operation was successful before starting the next test.

Random addresses are restricted as follows: $0600 < \text{random address} < 7600$.

The area between 0600 and 7600 is filled with HLT instructions in case the interrupt fails.

"05" is printed after every 61,000 tests.

```

0200
*200
/RANDOM JMP=JMS TEST
/SR0=HALT ON ERROR
/SR2=FIXED FROM
/SR3=FIXED TO
/SPREAD HALTS THROUGH MEMORY
/BETWEEN THE LIMLO AND LIMHI
/LIMITS

0200 4154 BEGIN, JMS PATCH /CLA
0201 1135 TAD LIMLO
0202 7041 CIA
0203 3126 DCA TO
0204 1152 GON, TAD HALT
0205 3526 DCA I TO
0206 1126 TAD TO
0207 7001 IAC
0210 3126 DCA TO
0211 1126 TAD TO
0212 1136 TAD LIMHI
0213 7640 SEA CLA
0214 5204 JMP GON
0215 1042 TAD M15
0216 3041 DCA CT1
0217 3040 DCA CT

/CHECK FOR FIXED FROM

0220 7604 LOOP, LAS
0221 7004 RAL
0222 7006 RTL
0223 7630 SEL CLA
0224 5246 JMP LOOP1=6

/GET RANDOM FROM

0225 1133 GETRAN, TAD RANUM
0226 7104 RAL CLL
0227 7430 SEL
0230 1134 TAD THREE
0231 3133 DCA RANUM
0232 1133 TAD RANUM
0233 7510 SPA
0234 5241 JMP ,+5
0235 1135 TAD LIMLO
0236 7710 SPA CLA
0237 5225 JMP GETRAN
0240 5244 JMP ,+4
0241 1136 TAD LIMHI
0242 7700 SMA CLA
0243 5225 JMP GETRAN

0244 1133 TAD RANUM
0245 3130 DCA FROM

```

0246 1130
0247 7001
0250 3132
0251 7040
0252 1130
0253 3131

TAD FROM
IAC
DCA FRMP1
CMA
TAD FROM
DCA FROM1

/CHECK FOR FIXED TO

0254 7604
 0255 7006
 0256 7006
 0257 7630
 0260 5302

LOOP1, LAS
 RTL
 RTL
 S&L CLA
 JMP CRSCK-3

/GET RANDOM TO

0261 1133
 0262 7104
 0263 7430
 0264 1134
 0265 3133
 0266 1133
 0267 7510
 0270 5275
 0271 1135
 0272 7710
 0273 5261
 0274 5300
 0275 1136
 0276 7700
 0277 5261
 0300 1133
 0301 3126
 0302 1126
 0303 7001
 0304 3127
 0305 1130
 0306 7041
 0307 1126
 0310 7650
 0311 5220

GTRAN1, TAD RANUM
 RAL CLL
 S&L
 TAD THREE
 DCA RANUM
 TAD RANUM
 SPA
 JMP ,+5
 TAD LIMLO
 SPA CLA
 JMP GTRAN1
 JMP ,+4
 TAD LIMHI
 SMA CLA
 JMP GTRAN1
 TAD RANUM
 DCA TO
 TAD TO
 IAC
 DCA TOP1
 CRSCK, TAD FROM
 CIA
 TAD TO
 SNA CLA
 JMP LOOP

/BRING UP THE FLAG

0312 7040
 0313 6041
 0314 6046
 0315 6041
 0316 5315

CMA
 TSF
 TLS
 TSF
 JMP , -1

/PLACE THE INSTRUCTIONS

| | | |
|------|------|-------------|
| 0317 | 7200 | CLA |
| 0320 | 1137 | TAD ITON |
| 0321 | 3531 | DCA I FROM1 |
| 0322 | 1153 | TAD JMP1 |
| 0323 | 3530 | DCA I FROM |
| 0324 | 3000 | DCA 0 |

/GO DO IT

| | | |
|------|------|-------------|
| 0325 | 5531 | JMP I FROM1 |
| 0326 | 7402 | HLT |

/PRINTOUT SUBROUTINE

| | | |
|------|------|-------------|
| 0327 | 0000 | TYPAC, 0 |
| 0330 | 3143 | DCA SAVE+3 |
| 0331 | 1143 | TAD SAVE+3 |
| 0332 | 7012 | RTR |
| 0333 | 7010 | RAR |
| 0334 | 3142 | DCA SAVE+2 |
| 0335 | 1142 | TAD SAVE+2 |
| 0336 | 7012 | RTR |
| 0337 | 7010 | RAR |
| 0340 | 3141 | DCA SAVE+1 |
| 0341 | 1141 | TAD SAVE+1 |
| 0342 | 7012 | RTR |
| 0343 | 7010 | RAR |
| 0344 | 3140 | DCA SAVE |
| 0345 | 5727 | JMP I TYPAC |

/SUCCESS PRINTOUT

| | | |
|------|------|---------------|
| 0346 | 1041 | SUP, TAD CT1 |
| 0347 | 7001 | IAC |
| 0350 | 3041 | DCA CT1 |
| 0351 | 1041 | TAD CT1 |
| 0352 | 7640 | SEA CLA |
| 0353 | 5437 | JMP I ALOOP |
| 0354 | 1373 | TAD AMSG2 |
| 0355 | 3124 | DCA WORK |
| 0356 | 1124 | LP1, TAD WORK |
| 0357 | 7001 | IAC |
| 0360 | 3124 | DCA WORK |
| 0361 | 1524 | TAD I WORK |
| 0362 | 6046 | TLS |
| 0363 | 6041 | TSE |
| 0364 | 5363 | JMP ,=1 |
| 0365 | 1043 | TAD M265 |
| 0366 | 7640 | SEA CLA |
| 0367 | 5356 | JMP LP1 |
| 0370 | 1042 | TAD M15 |
| 0371 | 3041 | DCA CT1 |

1/11/68 3:28,22

PAGE 3-1

03/2 5437

JMP I ALDOP

0373 0373
 0374 0215
 0375 0212
 0376 0260
 0377 0265

AMSG2, .
 215 /CR
 212 /LF
 260 /0
 265 /5

0000 0000

*0

0000 0000

0 /FOR SCOPE MODE INSERT

0001 5001

JMP 1 /JMP I FROM 1 (5531) IN LOC1

0002 0002

2 /GET STORED ADDRESS

0003 0003

3

0004 1132

TAD FRMP1

0005 7640

SZA CLA

0006 5546

JMP I AER

/ADDRESS STORED IN (TO) WRONG

0007 1127

TAD TOP1

0010 7041

CIA

0011 1000

TAD 0

0012 7640

SZA CLA

0013 5546

JMP I AER

/ADDRESS STORED IN (0) WRONG

0014 1152

RETURN, TAD HALT

0015 3530

DCA I FROM

0016 1152

TAD HALT

0017 3526

DCA I TO

0020 7040

CMA

0021 1000

TAD 0

0022 3000

DCA 0

0023 1152

TAD HALT

0024 3400

DCA I 0

0025 1152

TAD HALT

0026 3531

DCA I FROM1

0027 7001

IAC

0030 1040

TAD CT

0031 3040

DCA CT

0032 1040

TAD CT

0033 7640

SZA CLA

0034 5437

JMP I ALOOP

0035 5436

JMP I ,+1

0036 0346

SUP

0037 0220

ALOOP, LOOP

0040 0000

CT, 0

0041 0000

CT1, 0

0042 7763

M15, -15

0043 7513

M265, -265

| | | | | |
|------|------|--------|------|-------------------------------|
| 0044 | 0215 | MSG1, | 215 | /CR |
| 0045 | 0212 | | 212 | /LF |
| 0046 | 0212 | | 212 | /LF |
| 0047 | 0306 | | 306 | /F = FROM |
| 0050 | 0240 | | 240 | /SPACE |
| 0051 | 0000 | INS1, | 0 | /X ADDRESS OF JMS INSTRUCTION |
| 0052 | 0000 | INS2, | 0 | /X |
| 0053 | 0000 | INS3, | 0 | /X |
| 0054 | 0000 | INS4, | 0 | /X |
| 0055 | 0240 | | 240 | /SPACE |
| 0056 | 0324 | | 324 | /T |
| 0057 | 0317 | | 317 | /U |
| 0060 | 0240 | | 240 | /SPACE |
| 0061 | 0000 | INS5, | 0 | /X |
| 0062 | 0000 | INS6, | 0 | /X |
| 0063 | 0000 | INS7, | 0 | /X |
| 0064 | 0000 | INS8, | 0 | /X |
| 0065 | 0215 | | 215 | /CR |
| 0066 | 0212 | | 212 | /LF |
| 0067 | 0377 | | 377 | /RUBOUT |
| 0070 | 0250 | | 250 | /C |
| 0071 | 0324 | MSG2, | 324 | /T |
| 0072 | 0317 | | 317 | /U |
| 0073 | 0251 | | 251 | /) |
| 0074 | 0240 | | 240 | /SPACE |
| 0075 | 0275 | | 275 | /= |
| 0076 | 0240 | | 240 | /SPACE |
| 0077 | 0000 | INS9, | 0 | /X STORED ADDRESS |
| 0100 | 0000 | INS10, | 0 | /X S/B FRMP1 |
| 0101 | 0000 | INS11, | 0 | /X |
| 0102 | 0000 | INS12, | 0 | /X |
| 0103 | 0215 | | 215 | /CR |
| 0104 | 0212 | | 212 | /LF |
| 0105 | 0377 | | 377 | /RUBOUT |
| 0106 | 0250 | | 250 | /C |
| 0107 | 0000 | MSG3, | 0 | /X ADDRESS=1 STORED |
| 0110 | 0000 | INS13, | 0 | /X IN LOC 0 AT INTERRUPT |
| 0111 | 0000 | INS14, | 0 | /X |
| 0112 | 0000 | INS15, | 0 | /X |
| 0113 | 0251 | | 251 | /) |
| 0114 | 0240 | | 240 | /SPACE |
| 0115 | 0275 | | 275 | /= |
| 0116 | 0240 | | 240 | /SPACE |
| 0117 | 0000 | INS16, | 0 | /X CONTENTS OF ABOVE |
| 0120 | 0000 | INS17, | 0 | /X ADDRESS |
| 0121 | 0000 | INS18, | 0 | /X |
| 0122 | 0000 | INS19, | 0 | /X |
| 0123 | 0207 | | 207 | /END MARK |
| 0124 | 0000 | WORK, | 0 | |
| 0125 | 7571 | M207, | -207 | |

/CONSTANTS

| | | | |
|------|------|--------|----------|
| 0126 | 0000 | TO, | 0 |
| 0127 | 0000 | TOP1, | 0 |
| 0130 | 0000 | FROM, | 0 |
| 0131 | 0000 | FROM1, | 0 |
| 0132 | 0000 | FRMP1, | 0 |
| 0133 | 2525 | RANUM, | 2525 |
| 0134 | 0003 | THREE, | 3 |
| 0135 | 7200 | LIMLO, | -600 |
| 0136 | 0200 | LIMHI, | -7600 |
| 0137 | 6001 | ITON, | ION |
| 0140 | 0000 | SAVE, | 0 |
| 0141 | 0000 | | 0 |
| 0142 | 0000 | | 0 |
| 0143 | 0000 | | 0 |
| 0144 | 0007 | MSK7, | 7 |
| 0145 | 0260 | TW6, | 260 |
| 0146 | 0400 | AER, | ER |
| 0147 | 0327 | ATYP, | TYPAC |
| 0150 | 0330 | ATYP1, | TYPAC+1 |
| 0151 | 0044 | AMSG1, | MSG1 |
| 0152 | 7402 | HALT, | HLT |
| 0153 | 4526 | JMP1, | JMS I TO |

| | | | | |
|------|------|--------|-------------|-----------------------|
| 0154 | 0000 | PATCH, | 0 | /RESTORE THEN GO AWAY |
| 0155 | 3000 | | DCA 0 | |
| 0156 | 1167 | | TAD X1 | |
| 0157 | 3001 | | DCA 1 | |
| 0160 | 1170 | | TAD X2 | |
| 0161 | 3002 | | DCA 2 | |
| 0162 | 1171 | | TAD X3 | |
| 0163 | 3003 | | DCA 3 | |
| 0164 | 1172 | | TAD X4 | |
| 0165 | 3573 | | DCA I X5 | |
| 0166 | 5554 | | JMP I PATCH | |
| 0167 | 7200 | X1, | 7200 | |
| 0170 | 1526 | X2, | 1526 | /TAD I TO |
| 0171 | 7041 | X3, | 7041 | |
| 0172 | 7200 | X4, | CLA | |
| 0173 | 0200 | X5, | 200 | |

| | | | |
|------|------|------|-------------|
| 0400 | 1204 | *400 | TAD ,+4 |
| 0401 | 3547 | ER, | DCA I ATYP |
| 0402 | 1130 | | TAD FROM |
| 0403 | 5550 | | JMP I ATYP1 |
| 0404 | 0405 | | ,+1 |
| 0405 | 1140 | | TAD SAVE |
| 0406 | 0144 | | AND MSK7 |
| 0407 | 1145 | | TAD TW6 |
| 0410 | 3051 | | DCA INS1 |
| 0411 | 1141 | | TAD SAVE+1 |
| 0412 | 0144 | | AND MSK7 |
| 0413 | 1145 | | TAD TW6 |
| 0414 | 3052 | | DCA INS2 |
| 0415 | 1142 | | TAD SAVE+2 |
| 0416 | 0144 | | AND MSK7 |
| 0417 | 1145 | | TAD TW6 |
| 0420 | 3053 | | DCA INS3 |
| 0421 | 1143 | | TAD SAVE+3 |
| 0422 | 0144 | | AND MSK7 |
| 0423 | 1145 | | TAD TW6 |
| 0424 | 3054 | | DCA INS4 |
| 0425 | 1231 | | TAD ,+4 |
| 0426 | 3547 | | DCA I ATYP |
| 0427 | 1126 | | TAD TO |
| 0430 | 5550 | | JMP I ATYP1 |
| 0431 | 0432 | | ,+1 |
| 0432 | 1140 | | TAD SAVE |
| 0433 | 0144 | | AND MSK7 |
| 0434 | 1145 | | TAD TW6 |
| 0435 | 3061 | | DCA INS5 |
| 0436 | 1141 | | TAD SAVE+1 |
| 0437 | 0144 | | AND MSK7 |
| 0440 | 1145 | | TAD TW6 |
| 0441 | 3062 | | DCA INS6 |
| 0442 | 1142 | | TAD SAVE+2 |
| 0443 | 0144 | | AND MSK7 |
| 0444 | 1145 | | TAD TW6 |
| 0445 | 3063 | | DCA INS7 |
| 0446 | 1143 | | TAD SAVE+3 |
| 0447 | 0144 | | AND MSK7 |
| 0450 | 1145 | | TAD TW6 |
| 0451 | 3064 | | DCA INS8 |
| 0452 | 1256 | | TAD ,+4 |
| 0453 | 3547 | | DCA I ATYP |
| 0454 | 1526 | | TAD I TO |
| 0455 | 5550 | | JMP I ATYP1 |
| 0456 | 0457 | | ,+1 |

0457 1140
 0460 0144
 0461 1145
 0462 3077
 0463 1141
 0464 0144
 0465 1145
 0466 3100
 0467 1142
 0470 0144
 0471 1145
 0472 3101
 0473 1143
 0474 0144
 0475 1145
 0476 3102
 0477 7040
 0500 1000
 0501 3000

0502 1306
 0503 3547
 0504 1000
 0505 5550
 0506 0507
 0507 1140
 0510 0144
 0511 1145
 0512 3107
 0513 1141
 0514 0144
 0515 1145
 0516 3110
 0517 1142
 0520 0144
 0521 1145
 0522 3111
 0523 1143
 0524 0144
 0525 1145
 0526 3112
 0527 1333
 0530 3547
 0531 1400
 0532 5550
 0533 0534
 0534 1140
 0535 0144
 0536 1145
 0537 3117
 0540 1141
 0541 0144
 0542 1145
 0543 3120
 0544 1142

TAD SAVE
 AND MSK7
 TAD TW6
 DCA INS9
 TAD SAVE+1
 AND MSK7
 TAD TW6
 DCA INS10
 TAD SAVE+2
 AND MSK7
 TAD TW6
 DCA INS11
 TAD SAVE+3
 AND MSK7
 TAD TW6
 DCA INS12
 CMA
 TAD 0
 DCA 0

TAD ,+4
 DCA I ATYP
 TAD 0
 JMP I ATYP1
 ,+1
 TAD SAVE
 AND MSK7
 TAD TW6
 DCA MSG3
 TAD SAVE+1
 AND MSK7
 TAD TW6
 DCA INS13
 TAD SAVE+2
 AND MSK7
 TAD TW6
 DCA INS14
 TAD SAVE+3
 AND MSK7
 TAD TW6
 DCA INS15
 TAD ,+4
 DCA I ATYP
 TAD I 0
 JMP I ATYP1
 ,+1
 TAD SAVE
 AND MSK7
 TAD TW6
 DCA INS16
 TAD SAVE+1
 AND MSK7
 TAD TW6
 DCA INS17
 TAD SAVE+2

0545 0144
0546 1145
0547 3121
0550 1143
0551 0144
0552 1145
0553 3122

AND MSK7
TAD TW6
DCA INS18
TAD SAVE+3
AND MSK7
TAD TW6
DCA INS19

| | | | | | |
|------|------|-------|-----|--------|----------------|
| 0554 | 1151 | | TAD | AMSG1 | |
| 0555 | 3124 | | DCA | WORK | |
| 0556 | 1524 | TYPE, | TAD | I WORK | |
| 0557 | 6046 | | TL5 | | |
| 0560 | 6041 | | TSF | | |
| 0561 | 5360 | | JMP | :=1 | |
| 0562 | 7201 | | CLA | IAC | |
| 0563 | 1124 | | TAD | WORK | |
| 0564 | 3124 | | DCA | WORK | |
| 0565 | 1524 | | TAD | I WORK | |
| 0566 | 1125 | | TAD | M207 | |
| 0567 | 7640 | | SZA | CLA | |
| 0570 | 5356 | | JMP | TYPE | |
| 0571 | 7604 | | LAS | | |
| 0572 | 7710 | | SPA | CLA | |
| 0573 | 7402 | | HLT | | /HALT ON ERROR |
| 0574 | 5014 | | JMP | RETURN | |

5

THERE ARE NO ERRORS

SYMBOL TABLE

| | |
|--------|------|
| AER | 0146 |
| ALOUP | 0037 |
| AMSG1 | 0151 |
| AMSG2 | 0373 |
| AIYP | 0147 |
| AIYP1 | 0150 |
| BEGIN | 0200 |
| CRSCK | 0305 |
| CT | 0040 |
| CT1 | 0041 |
| ER | 0400 |
| FRMP1 | 0132 |
| FROM | 0130 |
| FROM1 | 0131 |
| GETRAN | 0225 |
| GUN | 0204 |
| GTRAN1 | 0261 |
| HALT | 0152 |
| INS1 | 0051 |
| INS10 | 0100 |
| INS11 | 0101 |
| INS12 | 0102 |
| INS13 | 0110 |
| INS14 | 0111 |
| INS15 | 0112 |
| INS16 | 0117 |
| INS17 | 0120 |
| INS18 | 0121 |
| INS19 | 0122 |
| INS2 | 0052 |
| INS3 | 0053 |
| INS4 | 0054 |
| INS5 | 0061 |
| INS6 | 0062 |
| INS7 | 0063 |
| INS8 | 0064 |
| INS9 | 0077 |
| IION | 0137 |
| JMP1 | 0153 |
| LIMHI | 0136 |
| LIMLO | 0135 |
| LOOP | 0220 |
| LOOP1 | 0254 |
| LP1 | 0356 |
| MSG1 | 0044 |
| MSG2 | 0071 |
| MSG3 | 0107 |
| MSK7 | 0144 |
| M15 | 0042 |
| M207 | 0125 |
| M265 | 0043 |
| PATCH | 0154 |
| RANUM | 0133 |

SYMBOL TABLE

| | |
|--------|------|
| RETURN | 0014 |
| SAVE | 0140 |
| SUP | 0346 |
| THREE | 0134 |
| TU | 0126 |
| TUP1 | 0127 |
| TW6 | 0145 |
| TYPAC | 0327 |
| TYPE | 0556 |
| WORK | 0124 |
| X1 | 0167 |
| X2 | 0170 |
| X3 | 0171 |
| X4 | 0172 |
| X5 | 0173 |

SYMBOL TABLE

| | |
|--------|------|
| RETURN | 0014 |
| ALOOP | 0037 |
| CT | 0040 |
| CT1 | 0041 |
| M15 | 0042 |
| M265 | 0043 |
| MSG1 | 0044 |
| INS1 | 0051 |
| INS2 | 0052 |
| INS3 | 0053 |
| INS4 | 0054 |
| INS5 | 0061 |
| INS6 | 0062 |
| INS7 | 0063 |
| INS8 | 0064 |
| MSG2 | 0071 |
| INS9 | 0077 |
| INS10 | 0100 |
| INS11 | 0101 |
| INS12 | 0102 |
| MSG3 | 0107 |
| INS13 | 0110 |
| INS14 | 0111 |
| INS15 | 0112 |
| INS16 | 0117 |
| INS17 | 0120 |
| INS18 | 0121 |
| INS19 | 0122 |
| WORK | 0124 |
| M207 | 0125 |
| TU | 0126 |
| TUP1 | 0127 |
| FROM | 0130 |
| FROM1 | 0131 |
| FRMP1 | 0132 |
| RANUM | 0133 |
| THREE | 0134 |
| LIMLO | 0135 |
| LIMHI | 0136 |
| ITON | 0137 |
| SAVE | 0140 |
| MSK7 | 0144 |
| TW6 | 0145 |
| AER | 0146 |
| ATYP | 0147 |
| ATYP1 | 0150 |
| AMSG1 | 0151 |
| HALT | 0152 |
| JMP1 | 0153 |
| PATCH | 0154 |
| X1 | 0167 |
| X2 | 0170 |
| X3 | 0171 |

SYMBOL TABLE

| | |
|--------|------|
| X4 | 0172 |
| X5 | 0173 |
| BEGIN | 0200 |
| GUN | 0204 |
| LOOP | 0220 |
| GETRAN | 0225 |
| LOOP1 | 0254 |
| GTRAN1 | 0261 |
| CKSCK | 0305 |
| TYPAC | 0327 |
| SUP | 0346 |
| LP1 | 0356 |
| AMSG2 | 0373 |
| ER | 0400 |
| TYPE | 0556 |

(1)

(2)

(3)