

IDENTIFICATION

PRODUCT CODE: MAINDEC-W8-DHRKD-D-D
PRODUCT NAME: RK8E/RK8L DISK FORMATTER PROGRAM
DATE RELEASED: FEBRUARY, 1977
MAINTAINER: DIAGNOSTIC ENGINEERING
AUTHOR: JOHN VMOHEL/WILLIAM HEAVEY

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED UNDER A LICENSE AND MAY ONLY BE USED OR COPIED IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1972, 1976, 1977 BY DIGITAL EQUIPMENT CORPORATION

TABLE OF CONTENTS

1.	ABSTRACT
2.	RESTRICTIONS
2.1	HARDWARE
2.2	PROGRAM STORAGE
3.	PRELIMINARY PROGRAMS
4.	OPERATOR AND/OR PROGRAM ACTION
4.1	STANDARD TEST PROCEDURE
4.2	RK05J DRIVE CARTRIDGE MOUNTING PROCEDURE
4.3	RK05F DRIVE SETUP PROCEDURE
4.4	FORMAT PROGRAM
4.5	SWITCH REGISTER SETTINGS
5.	ERRORS
6.	PROGRAM DISCRIPTION
7.	APT-8 HOOKS
8.	PROGRAM LISTING
9.	CONSOLE PACKAGE ADDENDUM

1. ABSTRACT

THE RK8E/RK8L DISK FORMATTER PROGRAM IS DESIGNED TO WRITE
AND CHECK THE FORMAT OF THE COMPLETE DISK CARTRIDGE.

ONLY STANDARD DEC SURFACE FORMAT IS AVAILABLE (I.E. SEC-
TORS NUMBERED IN THE NORMAL NUMERICAL SEQUENCE 0, 1, 2, 3,
4, 5, ETC.).

2. RESTRICTIONS

THE RK8L CONTROL, WHICH CAN CONTROL UP TO 8 DRIVES, WILL NOT
RUN WITH THE DW8E BUS ADAPTER. THE REASON FOR THIS STATEMENT
IS THAT THE RK8L CONTROL USES IOT0 FOR EXTENDED DRIVES 4-7
WHICH IS NOT AVAILABLE ON THE DW8E.

2.1 HARDWARE

A. PDP-8/E, 8/F, 8/M OR 8/A COMPUTER
OTHER FAMILY OF 8 COMPATIBLE COMPUTER WITH NECESSARY
DW8E BUS ADAPTER FOR RK8E CONTROL ONLY.

B. AT LEAST 4K OF READ/WRITE MEMORY. AT LEAST 8K OF MEMORY
IS NEEDED FOR OPERATION OF THE CONSOLE PACKAGE.

C. ASR-33 TELETYPE OR EQUIVALENT

D. RK8E DISK CONTROL OR RK8L DISK CONTROL

E. RK05J OR RK05F DISK DRIVE(S)

NOTE: THE RK05F'S DRIVE IS CONSIDERED AS TWO SEPARATE
UNITS. WHEN ANSWERING ALL QUESTIONS EACH SEPARATE UNIT
MUST BE SPECIFIED: DSK07, DSK17, DSK27, ETC.

2.2 PROGRAM STORAGE

THE PROGRAM UTILIZES OR OCCUPIES LOCATIONS 0000 TO
4177 OF THE CURRENT FIELD.

3. PRELIMINARY PROGRAMS

THE FOLLOWING PROGRAMS SHOULD BE RUN IF THE FORMATTER PROGRAM
FAILS TO OPERATE CORRECTLY:

ALL BASIC AND EXTENDED MEMORY DIAGNOSTICS

FOR THE RK8E CONTROL, RUN THE RK8E DISKLESS CONTROL TEST
AND THE RK8E DRIVE CONTROL TEST.

FOR THE RK8L CONTROL, RUN THE RK8L INSTRUCTION TEST.

4. OPERATOR AND/OR PROGRAM ACTION

4.1 STANDARD TEST PROCEDURE

- A. LOAD THE PROGRAM INTO ANY R/W MEMORY BANK USING THE STANDARD BINARY LOADER TECHNIQUE.
- B. TO RUN THE FORMATTER PROGRAM, FOLLOW THE PROCEDURE IN SECTION 4.4.

4.2 RK05J DRIVE CARTRIDGE MOUNTING PROCEDURE

THE FOLLOWING IS THE CORRECT CARTRIDGE MOUNTING PROCEDURE FOR THE RK05J DISK DRIVE. ANY DEVIATION ENCOUNTERED DURING THIS PROCEDURE WILL BE CONSIDERED AN ERROR CONDITION.

- A. SET SWITCH LABELED "RUN/LOAD" TO THE "LOAD" POSITION.
- B. TURN AC POWER ON.
- C. VERIFY THAT LIGHT LABELED "PWR" IS ON.
- D. WAIT FOR LIGHT LABELED "LOAD" TO COME ON.
- E. VERIFY THAT LIGHTS LABELED "RDY", "ON CYL", "FAULT", "WT", AND "RD" ARE OFF.
- F. OPEN ACCESS DOOR.
- G. INSERT CARTRIDGE.
- H. CLOSE ACCESS DOOR.
- I. SET SWITCH LABELED "RUN/LOAD" TO THE "RUN" POSITION.
- J. WAIT FOR LIGHTS LABELED "RDY" AND "ON CYL" TO COME ON.
- K. TOGGLE SWITCH LABELED "WT PROT" AND VERIFY THAT THE LIGHT LABELED "WT PROT" GOES ON AND OFF.
- L. TOGGLE SWITCH LABELED "WT PROT" UNTIL LIGHT LABELED "WT PROT" GOES OFF.
- M. VERIFY THAT LIGHTS LABELED "FAULT", "WT", "RD", AND "LOAD" ARE OFF.

4.3 RK05F DRIVE SETUP PROCEDURE

THE FOLLOWING IS THE CORRECT DRIVE SETUP PROCEDURE FOR THE RK05F DISK DRIVE. ANY DEVIATION ENCOUNTERED DURING THIS PROCEDURE WILL BE CONSIDERED AN ERROR CONDITION.

- A. SET SWITCH LABELED "RUN/LOAD" TO THE "LOAD" POSITION.
- B. TURN AC POWER ON.

- C. VERIFY THAT LIGHT LABELED "PWR" IS ON.
- D. WAIT FOR LIGHT LABELED "LOAD" TO COME ON.
- E. VERIFY THAT LIGHTS LABELED "RDY", "ON CYL", "FAULT", "WT", AND "RD" ARE OFF.
- F. SET SWITCH LABELED "RUN/LOAD" TO THE "RUN" POSITION.
- G. WAIT FOR LIGHTS LABELED "RDY" AND "ON CYL" TO COME ON.
- H. TOGGLE SWITCH LABELED "WT PROT" AND VERIFY THAT THE LIGHT LABELED "WT PROT" GOES ON AND OFF.
- I. TOGGLE SWITCH LABELED "WT PROT" UNTIL LIGHT LABELED "WT PROT" GOES OFF.
- J. VERIFY THAT LIGHTS LABELED "FAULT", "WT", "RD", AND "LOAD" ARE OFF.

4.4 FORMAT PROGRAM -----

- A. MAKE READY ALL DRIVES TO BE FORMATTED:

 FOR RK05J DRIVES USE THE RK05 DRIVE MOUNTING PROCEDURE
 REFER TO SECTION 4.2.

 FOR RK05F DRIVES USE THE RK05 DRIVE SETUP PROCEDURE
 REFER TO SECTION 4.3.
- B. SET SWITCH LABELED "RUN/LOAD" TO THE "LOAD" POSITION ON ALL DRIVES NOT BEING FORMATTED.
- C. SET THE SWITCH REGISTER TO 0200 AND PRESS LOAD ADDRESS.
- D. SET THE SWITCH REGISTER TO 0000.
- E. IF IT IS DESIRED TO CHANGE THE IOT DEVICE CODES WITHIN THE PROGRAM (THEY ARE NORMALLY X74X), SET SWITCH REGISTER BIT 11 TO A "1".
- F. IF CHANGE IOT CODES WAS SELECTED, SET SWITCH REGISTER BITS 3 TO 8 TO THE DESIRED IOT DEVICE CODE.
- G. PRESS KEY START (KEY START IS KEY CLEAR AND THEN KEY CONTINUE ON A PDP8/E, PDP8/P, OR PDP8/M). IF SELECTING A PDP8/A (PRESS INIT AND THEN PRESS RUN). IF SELECTED, ALL IOT DEVICE CODES WITHIN THE PROGRAM WILL BE CHANGED. THE TTY WILL TYPE THE FOLLOWING PROGRAM NAME, INFORMATION, AND QUESTION.

RK05/RK06 DISK FORMATTER PROGRAM

FOR ALL QUESTIONS ANSWER Y FOR YES OR N FOR NO,
FORMAT DISK 0?

- H. IF THE OPERATOR DESIRES TO FORMAT DISK 0, TYPE Y FOR YES, OTHERWISE, N FOR NO, ON THE TTY KEYBOARD. THE FOLLOWING QUESTION WILL THEN BE TYPED ON THE TTY.

FORMAT DISK 1?

- I. IF THE OPERATOR DESIRES TO FORMAT DISK 1, TYPE Y FOR YES, OTHERWISE, N FOR NO, ON THE TTY KEYBOARD. THE FOLLOWING QUESTION WILL THEN BE TYPED ON THE TTY.

FORMAT DISK 2?

- J. IF THE OPERATOR DESIRES TO FORMAT DISK 2, TYPE Y FOR YES, OTHERWISE, N FOR NO, ON THE TTY KEYBOARD. THE FOLLOWING QUESTION WILL THEN BE TYPED ON THE TTY.

FORMAT DISK 3?

- K. IF THE OPERATOR DESIRES TO FORMAT DISK 3, TYPE Y FOR YES, OTHERWISE, N FOR NO, ON THE TTY KEYBOARD. THE FOLLOWING QUESTION WILL THEN BE TYPED ON THE TTY.

FORMAT DISK 4?

- L. IF THE OPERATOR DESIRES TO FORMAT DISK 4, TYPE Y FOR YES, OTHERWISE, N FOR NO, ON THE TTY KEYBOARD. THE FOLLOWING QUESTION WILL THEN BE TYPED ON THE TTY.

FORMAT DISK 5?

- M. IF THE OPERATOR DESIRES TO FORMAT DISK 5, TYPE Y FOR YES, OTHERWISE, N FOR NO, ON THE TTY KEYBOARD. THE FOLLOWING QUESTION WILL THEN BE TYPED ON THE TTY.

FORMAT DISK 6?

- N. IF THE OPERATOR DESIRES TO FORMAT DISK 6, TYPE Y FOR YES, OTHERWISE, N FOR NO, ON THE TTY KEYBOARD. THE FOLLOWING QUESTION WILL THEN BE TYPED ON THE TTY.

FORMAT DISK 7?

- O. IF THE OPERATOR DESIRES TO FORMAT DISK 7, TYPE Y FOR YES, OTHERWISE, N FOR NO, ON THE TTY KEYBOARD. THE FOLLOWING QUESTION WILL THEN BE TYPED ON THE TTY.

ARE YOU SURE?

- P. TYPING N FOR NO WILL RESULT IN REPEATING ALL THE PREVIOUS QUESTIONS. TYPING Y FOR YES, WILL RESULT IN EXECUTION OF THE OPERATION SELECTED.

- Q. PROGRAM EXECUTION IS APROX. 80 SECONDS PER DISK DRIVE. AFTER ALL DISKS SELECTED HAVE BEEN FORMATTED AND CHECKED THE TTY WILL TYPE THE FOLLOWING PASS COMPLETE MESSAGE AND

QUESTION,

RK8E/RK8L DISK FORMATTER PASS COMPLETE
FORMAT SAME DISK(S) AGAIN?

R. IF THE OPERATOR DESIRES TO REPEAT THE OPERATION SELECTED,
TYPE Y FOR YES. TYPING N FOR NO WILL RESULT IN A REPEAT
OF THE INITIAL START-UP QUESTIONS.

4,5 SWITCH REGISTER SETTINGS

SWR11=0 DO NOT CHANGE IOT DEVICE CODES

SWR11=1 CHANGE IOT DEVICE CODES

SWR3=8 DESIRED IOT DEVICE CODE.

5. ERRORS

WHEN A RECOVERABLE ERROR OCCURS THE TTY WILL PRINT
AN "ERROR HEADER" AND ERROR INFORMATION PERTAINING
TO THE FAILURE.

POSSIBLE ERROR HEADERS ARE AS FOLLOWS.

DISK DATA ERROR
READ STATUS ERROR
WRITE STATUS ERROR
RECALIBRATE STATUS ERROR

AFTER THE ERROR HEADER MENTIONED ABOVE IS TYPED THE TTY
WILL PRINT SOME OF THE FOLLOWING ERROR INFORMATION PER-
TAINING TO THE FAILURE.

PC: PROGRAM LOCATION OF FAILURE

GD: EXPECTED INFORMATION

EX: EXTENDED DRIVE BIT

CM: SOFTWARE COMMAND REGISTER

ST: CONTENTS OF STATUS REGISTER

DA: SOFTWARE CYLINDER, SURFACE, AND SECTOR REGISTER

CA: INITIAL CURRENT ADDRESS

AD: ADDRESS OF DATA BREAK

DT: DATA FOUND DURING DATA BREAK

AFTER THE ERROR INFORMATION IS TYPED THE TTY WILL TYPE ONE
OF THE FOLLOWING QUESTIONS ASKING THE ERROR RECOVERY DESIRED.

A. IF THE ERROR WAS A RECALIBRATE ERROR THE FOLLOWING QUESTION

WILL BE TYPED.

TRY TO RECALIBRATE SAME DISK AGAIN?

TYPING A Y FOR YES WILL RESULT IN A REPEAT OF THE RE-CALIBRATE SEQUENCE ON THE DISK IN ERROR. TYPING N FOR NO WILL RESULT IN PROGRESSING TO THE NEXT AVAILABLE DISK.

B. IF THE ERROR WAS A WRITE ERROR THE FOLLOWING QUESTION WILL BE TYPED.

TRY TO FORMAT SAME CYLINDER AGAIN?

TYPING Y FOR YES WILL RESULT IN A REPEAT OF THE WRITE SEQUENCE ON THE CURRENT CYLINDER. TYPING N FOR NO WILL WILL IN PROGRESSING TO THE NEXT SEQUENTIAL CYLINDER.

C. IF THE ERROR WAS A READ OR CHECK ERROR THE FOLLOWING QUESTION WILL BE TYPED.

TRY TO CHECK SAME CYLINDER AGAIN?

TYPING A Y FOR YES WILL RESULT IN A REPEAT IN THE READ AND CHECK SEQUENCE ON THE CURRENT CYLINDER. TYPING A N FOR NO WILL RESULT IN PROGRESSING TO THE NEXT SEQUENTIAL CYLINDER.

6. PROGRAM DISCRIPTION

THE FORMATTING IS ACTUALLY A FUNCTION OF THE RK8E OR RK8L CONTROL AND DRIVE LOGIC. THE PROGRAM SIMPLY WRITES DATA ON EVERY SECTOR IN THE "WRITE ALL" MODE, THEN CHECKS THE DATA IN SUCH A WAY IN THE "READ DATA" MODE AS TO VERIFY THAT THE HEADER WORDS WRITTEN ON EVERY SECTOR ARE ALSO CORRECT. THE "READ DATA MODE" AUTOMATICALLY PERFORMS A CHECK HEADER FUNCTION.

THE FIRST TWO WORDS OF EVERY SECTOR ARE SET TO THE ABSOLUTE DISK ADDRESS(I.E. COMMAND REGISTER BITS 9-11 AND CYLINDER, SURFACE, AND SECTOR BITS 0-11, RESPECTIVELY) AND THE REMAINDER OF THE DATA AREA TO ALL ZEROS WHEN THE DATA IS WRITTEN. ONLY THE FIRST TWO WORDS OF EVERY SECTOR(I.E. THE ADDRESSING INFORMATION) ARE CHECKED WHEN DATA IS READ IN THE "READ DATA" MODE.

7. APT-8 HOOKS

7.1 DESCRIPTION

TWO INTERFACES HAVE BEEN PROVIDED WHICH ALLOW THIS DIAGNOSTIC TO RUN UNDER THE STANDARD APT-8 SYSTEM. THESE INTERFACES ARE:

1. TIMING INTERFACE

2. ERROR INTERFACE

EACH WILL BE EXPLAINED IN DETAIL.

7.2 SETUP -----

ONLY HARDWARE CONFIGURATION WORD 2, ADDRESS 22, NEED BE ESTABLISHED. THE FOLLOWING INFORMATION MUST BE INDICATED:

1. SINGLE OR MULTIPLE DRIVE TESTING.
2. DRIVE OR DRIVES TO BE TESTED.
3. DIAGNOSTIC RUNNING UNDER APT-8.

IF SINGLE DRIVE TESTING BIT 5 OF ADDRESS 22 MUST BE SET TO A ONE (1) WITH BITS 6-11 CONTAINING THE DRIVE TO BE TESTED. IF MULTIPLE DRIVES ARE TO BE DONE BIT 5 MUST BE SET TO A ZERO (0) AND BIT 6-11 CONTAINING THE HIGHEST NUMBER DRIVE TO BE TESTED. WHEN MULTIPLE DRIVE TESTING ONLY A SPECIFIC NUMBER OF DRIVES CAN BE INDICATED. THE PROGRAM ASSUMES THE DRIVES ARE TO BE DONE BEGINNING WITH DRIVE ZERO (0) AND FINISHING WITH THE HIGHEST DRIVE INDICATED. IF MULTIPLE DRIVES OTHER THAN CONSECUTIVELY NUMBERED DRIVES BEGINNING WITH DRIVE ZERO (0) ARE TO BE DONE, THEY MUST BE DONE AS SINGLE DRIVES AND TESTED INDEPENDENTLY.

THE PROGRAM ALLOWS ONLY DRIVES ZERO (0) THROUGH SEVEN (7) TO BE TESTED AT THIS TIME.

BIT ZERO OF ADDRESS 22 MUST BE SET TO A ONE TO INDICATE THAT THE PROGRAM WILL RUN UNDER APT-8.

NOTE: IT SHOULD BE NOTED AT THIS TIME THAT WHILE RUNNING UNDER APT-8 THE HARDWARE SWITCH REGISTER IS INOPERATIVE, ONLY THE HALT AND SINGLE STEP SWITCH WILL EFFECT THE PROGRAM RUN.

7.3 APT-8 INTERFACES -----

7.3.1. TIMING -----

APT-8 IS NOTIFIED OF PROGRAM RUN BETWEEN .2 SEC AND 2.0 SEC ON A 1.2 MICROSECOND MEMORY CYCLE. THIS WILL ALLOW THE DIAGNOSTIC TO RUN WITHOUT CAUSING AN APT-8 TIMEOUT ERROR IF THE DIAGNOSTIC IS TO BE RUN ON THE SLOWER MUS MEMORY.

7.3.2. ERRORS -----

ONLY THE ERROR PC IS REPORTED TO APT-8 SYSTEM. ERRORS WHICH CAUSE A PROGRAMMED HALT CAUSE A TIMEOUT ERROR. IF A PROGRAMMED HALT SHOULD OCCUR, THE ERROR PC WILL APPEAR IN THE AC ON THE DEVICE UNDER TEST. PROGRAMMED HALTS ARE EXPLAINED EARLIER IN THIS DOCUMENT.

8. PROGRAM LISTING

9. CONSOLE PACKAGE ADDENDUM

9.1 DESCRIPTION

THE CONSOLE PACKAGE HAS BEEN ADDED TO THIS DIAGNOSTIC TO ALLOW THE PROGRAM TO RUN WITH NO HARDWARE SWITCH REGISTER AND TO HAVE COMMUNICATIONS WITH THE DIAGNOSTIC VIA A TERMINAL. THE DIAGNOSTIC CAN BE RUN IN TWO MODES WITH THE CONSOLE PACKAGE . 1) RUNNING WITH THE CONSOLE PACKAGE ACTIVE - THIS ALLOWS THE OPERATOR CONTROL OF THE DIAGNOSTIC THROUGH THE TERMINAL. THE DIAGNOSTIC WILL ASK FOR THE VALUE OF THE PSEUDO SWITCH REGISTER, BEFORE CONTINUING WITH EXECUTION OF THE DIAGNOSTIC. ALL ERRORS AND PASS COMPLETES WILL BE PRINTED AT THE TERMINAL. NO HALTS WILL BE EXECUTED. 2) CONSOLE PACKAGE NOT ACTIVE - THIS WILL RESULT IN THE NORMAL STANDALONE OPERATION OF THE PROGRAM AS DISCRIBED IN SECTIONS 1 THROUGH 8 OF THIS DUCUMENT.

9.2 RESTRICTIONS

- 1) RUNNING THE CONSOLE PACKAGE REQUIRES THAT THE PSEUDO SWITCH REGISTER BE USED.
- 2) ONCE RUNNING THE CONSOLE PACKAGE NONACTIVE AND NOW DESIRE TO RUN IT ACTIVE, ONE MUST RELOAD THE DIAGNOSTIC AND INITIALIZE FOR A ACTIVE CONSOLE PACKAGE.

9.3 INITIALIZATION

FOR A ACTIVE CONSOLE PACKAGE

- 1.) SET LOCATION 21 BIT0=0 TO INDICATE USE OF PSEUDO SWITCH REGISTER.
- 2.) SET LOCATION 22 BIT3=1 TO INDICATE CONSOLE PACKAGE ACTIVE.

FOR A NON ACTIVE CONSOLE PACKAGE

- 1.) SET LOCATION 21 BIT0=1 TO INDICATE NOT TO USE PSEUDO SWITCH REGISTER, BUT TO USE HARDWARE SWITCHES.
- 2.) SET LOCATION 22 BIT3=0 TO INDICATE CONSOLE PACKAGE NOT ACTIVE.

9.4 CONTROL CHARACTERS

CONTROL CHARACTERS ARE USED TO GIVE THE OPERATOR THE ABILITY TO PERFORM THE FOLLOWING FUNCTIONS.
NOTE: THE PROGRAM WILL RESPOND TO THE CONTROL CHARACTER IN FIVE (5) SECONDS OR LESS.

CONTROL C

THIS WILL START THE LOADER THAT IS IN LOCATION 7600.

CONTROL R

THIS WILL RESTART THE PROGRAM AND REASK THE SWITCH REGISTER QUESTION AS DESCRIBED IN SECTION 9.6.

CONTROL E

THIS WILL CONTINUE THE PROGRAM FROM AN ERROR IF ALLOWED BY THE DIAGNOSTIC OR FROM A WAITING STATEMENT.

CONTROL L

THIS WILL SWITCH THE TERMINAL MESSAGES FROM THE DISPLAY TO A LINE PRINTER. TO RESTORE THE MESSAGES ON THE TERMINAL CONTROL L MUST BE TYPED AGAIN. IF NO PRINTER IS AVAILABLE AND CONTROL L IS TYPED THE RESULT WILL BE THAT THE CONSOLE PACKAGE WILL WAIT FOR CONTROL C OR R. THE CONTROL L WILL OUTPUT TO THE LINE PRINTER AND THE PROGRAM WILL ATTEMPT TO CONTINUE AS IF A CONTROL E WAS TYPED IN.

CONTROL D

THIS WILL ALLOW THE ABILITY TO CHANGE THE SWITCH REGISTER DURING PROGRAM OPERATION. TYPING THIS CHARACTER WILL RESULT IN AN INTERIGATION OF THE SWITCH REGISTER QUESTION AS DESCRIBED IN SECTION 9.6.

CONTROL S

THIS WILL STOP PROGRAM EXECUTION AND WAIT IN A LOOP FOR A CONTINUE. THE ONLY WAY TO CONTINUE WILL BE TO TYPE A CONTROL Q, R OR C. THIS IS A NONPRINTING CHARACTER.

CONTROL Q

THIS IS TO CONTINUE A PROGRAM AFTER A CONTROL S IS TYPED. THIS IS A NONPRINTING CHARACTER.

9.5 WAITING MESSAGE -----

THE WAITING MESSAGE IS USED TO ALLOW THE OPERATOR TIME TO MAKE A DECISION AS TO WHAT CONTROL CHARACTER

TO TYPE. THIS MESSAGE MAY APPEAR AT THE END
OF PASS MESSAGE IF THE HALT ON PASS BIT IS SET. THE CONTROL
CHARACTERS MAY NOW BE USED TO PERFORM THE NEEDED FUNCTION.

THE WAITING MESSAGE MAY BE PRINTED AFTER A ERROR MESSAGE
IF THE HALT ON ERROR BIT IS SET. HERE AGAIN THE CONTROL
CHARACTERS MAY BE USED.
THE WAITING MESSAGE MAY BE PRINTED IF OPERATOR INTERVENTION
IS REQUIRED.

9.6 SWITCH REGISTER MESSAGE

THIS MESSAGE IS USED TO SETUP THE PSEUDO SWITCH REGISTER
BEFORE PROGRAM EXECUTION TAKES PLACE. THE SWITCH REGISTER
IS SETUP WHEN THE FOURTH CHARACTER IS ENTERED OR A CARRIAGE
RETURN IS TYPED

SR#0000 4000

UNDER SCORING INDICATES OPERATOR RESPONSE

9.7 END OF PASS

THE NORMAL PROGRAM PASS COMPLETE AS DESCRIBED IN SECTION
4.4 IS USED.

9.8 ERRORS

THE STANDARD ERROR REPORTS AS DESCRIBED IN SECTION 5
OF THIS DOCUMENT WILL BE USED.

9.9 SWITCH REGISTER SETTINGS

THE STANDARD SWITCH SETTINGS AS DESCRIBED IN SECTION 4.5
OF THIS DOCUMENT WILL BE USED.

9.10 PARAMETER CONTROL WORDS

THE CONSOLE PACKAGE USES THE LOCATIONS 20 21 22 FOR THE
FOLLOWING PURPOSES.

LOCATION 20
PSEUDO SWITCH REGISTER

LOCATION 21
HARDWARE IDENTIFIER 1

LOCATION 22
HARDWARE IDENTIFIER 2

LOCATION 0021

BIT ---	OCTAL VALUE -----	FUNCTION WHEN 0 -----	FUNCTION WHEN 1 -----
0	4000	USE PSEUDO SWITCHES	USE HARDWARE SWITCHES
1	2000	NO OPTION 1	HAS OPTION 1
2	1000	NO OPTION 2	HAS OPTION 2
3	400	NO 8A SIMULATOR	HAS 8A SIMULATOR
4	200	NO OPTION SIMULATOR	HAS OPTION SIMULATOR
5	100	NOT ON 8A XOR	ON 8A XOR
6	40	NOT PDP8-E TYPE CPU	PDP8-E TYPE CPU
7-11		8A MEMORY SIZE EX. 1K=00 2K=01 7K=06 32K=31	

LOCATION 0022

BIT ---	OCTAL VALUE -----	FUNCTION WHEN 0 -----	FUNCTION WHEN 1 -----
0	4000	NOT ON ACT8A LINE	ON ACT 8A LINE
1	2000	NOT ON ACT 8E LINE	ON ACT 8E LINE
2	1000	NOT YET DEFINED	
3	400	DEACTIVE CONSOLE PACKAGE	ACTIVE CONSOLE PACKAGE

9.11

LOCATION CHANGES

THE FOLLOWING LOCATIONS CAN BE CHANGED TO MEET THE SPECIFIC
NEED FOR MODIFICATION OF THE DIAGNOSTIC.

3637 IS THE LOCATION SET FOR THE NUMBER OF
FILLER CHARACTERS AFTER A CRLF SET TO FOUR (4)


```

/RK8E/RK8L DISK FORMATTER PROGRAM: MD=08-DHRKD=0
/MAINDEC=08-DHRKD=0=0
/
6740  DLSC=6740      /LOAD SECTOR COUNTER
6741  DSKP=6741      /SKIP UN TRANSFER DONE OR ERROR
6742  DCLR=6742      /CLEAR DISK CONTROL LOGIC
6743  DLAG=6743      /LOAD ADDRESS AND GO
6744  DLCA=6744      /LOAD CURRENT ADDRESS
6745  DRST=6745      /READ STATUS REGISTER
6746  DLDC=6746      /LOAD COMMAND REGISTER
6747  DMAN=6747      /LOAD MAINTENANCE
/
4446  LDSC=JMS I      XXLDC
4430  IOTCHN=JMS I    XCHANG
4431  LOUTRK=JMS I    XWTRK
4432  REDDSK=JMS I    XRDRK
4433  RECAL=JMS I    XRESTR
4434  RECEIV=JMS I    XWAIT
4435  KILBUF=JMS I    XKLBUF
4437  ERROR=JMS I    XERRO
4440  RDSTAT=JMS I    XRUST
4444  LDADD=JMS I    XLDAO
4441  DSKSKP=JMS I    XSDKP
4442  LDCMD=JMS I    XLDCM
4443  LDCUR=JMS I    XLUCA
4445  CLRALL=JMS I    XCLOD
4447  PRNTER=JMS I    XPHN
4450  OCTEL=JMS I    XFROCT
4451  TWUCT=JMS I    XTUCT
4436  TYPE=JMS I    XPHINT
4452  CRLF=JMS I    XCRLF
4424  APT8A=JMS I    XAPT8
4425  TIME=JMS I    XTIME
4427  TICK=JMS I    XTICK
4426  KAERRO=JMS I    XAERRO
/
0000  *0
/
0000  0304          304      /REV D
0001  5001          5001
0002  0002          0002
0003  0003          0003
/
0010  *10
/
0010  0000          AUTO10, 0
/
0011  0000          AUTO11, 0
/
0020  *20
/
0020  0000          0000      /PSEUDO SWITCH REGISTER
0021  4000          4000      /CONTRL WORD 1
0022  0000          0000      /CONTRL WORD 2
```

```

/RESERVED
0023  0000          0000
0024  1125          XAPT8, APT8
0025  1557          XTIME, KTIME
0026  1600          XAERRO, AERRO
0027  1530          XTICK, KTICK
0030  1463          XCHANG, CHANG
0031  0600          XWTRK, WTRK
0032  1000          XRDRK, REDTRK
0033  1400          XRESTR, RESTOR
0034  1327          XWAIT, WAIT
0035  0752          XKLBUF, KLBUF
0036  1312          XPRINT, PRINT
0037  0436          XERRO, ERRO
0040  0671          XRUST, RUST
0041  0740          XSDKP, SDKP
0042  0720          XLDCM, LDCM
0043  0700          XLUCA, LUCA
0044  0711          XLDAO, DAO
0045  0745          XCLOD, CLOR
0046  0733          XXLDC, XLDC
0047  1252          XPHN, PRN
0050  1227          XFROCT, FROCT
0051  1200          XTUCT, TUCT
0052  1215          XCRLF, UPONE
0053  2201          XLOTRK, LOTRK
0054  2200          XHITRK, HITRK
0055  2200          BGNBUFF, WRKBUFF
0056  0000          AMOUNT, 0
0057  0000          SWITCH, 0
0060  0003          K0003, 0003
0061  0004          K4, 4
0062  0007          K0007, 0007
0063  0040          K0040, 0040
0064  7465          M313, -313
0065  0277          K0277, 0277
0066  0200          K0200, 0200
0067  0260          K0260, 0260
0070  4000          K4000, 4000
0071  7735          K7735, 7735
0072  7760          K7760, 7760
0073  0400          K0400, 400
0074  0037          K0037, 0037
0075  6201          KCDF, CDF
0076  7774          M4, -4
0077  7770          M10, -10
0100  0000          DRIVNO, 0
0101  0000          CHAR, 0
0102  0000          LOWAD, 0
0103  0000          HIGHAD, 0
0104  0000          TRKCNT, 0
0105  0000          DSKCNT, 0
0106  0000          STCNT1, 0
0107  0000          STCNT1, 0
0110  0000          STCNT2, 0
0111  0000          STCNT3, 0
```

```

0112 0000 TCNTR1, 0
0113 0000 TCNTR2, 0
0114 0000 TCNTR3, 0
0115 0000 TCNTR4, 0
0116 0000 TCNTR5, 0
/
0117 0000 GOREG2, 0
0120 0000 EX0IT, 0
0121 0000 CMREG, 0
0122 0000 STREG, 0
0123 0000 DAREG, 0
0124 0000 CAREG, 0
0125 0000 ADREG, 0
0126 0000 DTREG, 0
0127 0263 BGNTRST, FRMDSK
0130 0000 HOMEHA, 0
0131 0000 DATCNT, 0
0132 7776 CLKCNT, =2
/
0133 1623 XMOVE, MOVE
0134 0000 LOC8ED, 0
0135 0424 XEND, ENDTST
0136 0000 SOFT, 0
0137 0140 ADPOT1, DSK0A
0140 0000 DSK0A, 0
0141 0000 DSK1A, 0
0142 0000 DSK2A, 0
0143 0000 DSK3A, 0
0144 0000 DSK4A, 0
0145 0000 DSK5A, 0
0146 0000 DSK6A, 0
0147 0000 DSK7A, 0
0150 0151 ADPOT2, DSK0B
0151 0000 DSK0B, 0
0152 0000 DSK1B, 0
0153 0000 DSK2B, 0
0154 0000 DSK3B, 0
0155 0000 DSK4B, 0
0156 0000 DSK5B, 0
0157 0000 DSK6B, 0
0160 0000 DSK7B, 0
0161 0000 PCOUNT, 0
/
0200 *200
/
0200 6224 BGN, RIF
0201 3130 DCA HOMEHA
0202 1130 TAD HOMEHA
0203 1075 TAD KCUF
0204 3205 DCA ,+1
0205 7402 HLT
/MAKE HOMEDF
/MAKE DF=IF
/NOV TEST FOR APT SYSTEM
/IF ON APT TERMINAL MESSAGES ARE SKIP
/TO AVOID TIMING PROBLEMS WITH THE SYSTEM
0206 4424 APT0A /TEST FOR APT SYSTEM
/USED ONLY IF ON APT

```

```

0207 4777 JMS XC0PSW /SET SR=.
0210 4430 IOTCMN /CHANGE DEVICE TO SWR3=0
0211 4452 CRLF
0212 4452 CRLF
0213 4447 PRNTER /PRINT "RK0E/RK0L DISK FORMATTER PROGRAM"
0214 2045 MES1 /MESSAGE 1 POINTER
0215 4452 CRLF
0216 4447 PRNTER /PRINT "FOR ALL QUESTIONS"
0217 2066 MES2 /MESSAGE POINTER 2
0220 1077 ALLAGN, TAD M10
0221 3107 DCA STCNT1
0222 3134 DCA LOC8ED
0223 3110 DCA STCNT2
0224 4452 SAMAGN, CRLF
0225 4447 PRNTER /PRINT "FORMAT DISK ? "
0226 2117 MES3 /MESSAGE POINTER 3
0227 1110 TAD STCNT2
0230 1067 TAD K0260
0231 4436 TYPE /TYPE DISK NUMBER
0232 1065 QUES1, TAD K0277
0233 4436 TYPE /TYPE ?
0234 1137 TAD ADPOT1
0235 1110 TAD STCNT2
0236 3111 DCA STCNT3
0237 4434 RECEIV /WAIT FOR CHARACTER
0240 5244 JMP NOTDSK /NO NOT THIS DISK
0241 5232 JMP QUES1 /NEITHER YES OR NO
0242 2134 WASDSK, ISZ LOC8ED
0243 7340 CLA CLL CHA
0244 3511 NOTDSK, DCA I STCNT3 /YES, WAS CLEAR DISK POINTER
0245 2110 ISZ STCNT2 /UPDATE POINTER
0246 2107 ISZ STCNT1 /COUNT DISKS
0247 5224 JMP SAMAGN /ASK ABOUT NEXT
/
0250 4452 DONE, CRLF
0251 4447 PRNTER /PRINT "ARE YOU SURE ?"
0252 2126 MES4 /MESSAGE POINTER 4
0253 4434 RECEIV /WAIT FOR CHARACTER
0254 5220 JMP ALLAGN /NO, START ALL OVER
0255 5230 JMP DONE /NEITHER TYPE ?
0256 1134 TAD LOC8ED
0257 7041 CIA
0260 7450 SNA /ANY DISKS
0261 5200 JMP BGN /NO, OPERATOR ERROR
0262 3134 DCA LOC8ED /YES, AMOUNT LOCATED
/
/FIRST RECALIBRATE AND FORMAT IN WRITE ALL MODE
/ALL DISK DRIVES SELECTED BY OPERATOR, MAKE THE FIRST
/TWO WORDS OF EVERY DISK SECTION EQUAL TO THE
/ABSOLUTE DISK ADDRESS.
/
0263 4533 FRMDSK, JMS I XMOVE /MOVE DISK POINTERS
0264 1134 TAD LOC8ED
0265 3056 DCA AMOUNT
0266 1056 TAD AMOUNT

```

```

0267 3105          OCA      DSKCNT      /COUNTER FOR AMOUNT OF DISKS
0270 3115          OCA      TCNTR4
0271 1150          TAD      ADPQT2
0272 3116          OCA      TCNTR5      /A FEW COUNTERS
0273 1516          TAD I    TCNTR5
0274 7640          SZA CLA      /FORMAT THIS DISK
0275 5302          JMP      FOMMAT      /YES, GO
0276 2116          NEXFRM, ISZ   TCNTR5      /NO, TRY NEXT
0277 2115          ISZ      TCNTR4
0300 5273          JMP      .-5
0301 7402          HLT                /WHAT HAPPENED???

/
0302 1115          FOMMAT, TAD    TCNTR4
0303 0060          AND      K0003      /MASK OUT
0304 7104          CLL RAL      /MAKE DISK NUMBER
0305 3100          OCA      DRIVNO
0306 1115          TAD      TCNTR4
0307 0061          AND      K4
0310 7640          SZA CLA
0311 1066          TAD      K0200
0312 3120          OCA      EXBIT      /SET EXTENDED DRIVE BIT
0313 4433          RECAL      /RECALIBRATE THIS DRIVE
0314 5335          JMP      NEXEX1      /RECALIBRATE NEXT EXISTING
0315 3102          OCA      LOWAD      /SETUP ADDRESS POINTER
0316 3103          OCA      HIGHAD     /SETUP ADDRESS POINTER
0317 1064          TAD      M313
0320 3104          OCA      TRKCNT      /COUNTER FOR AMOUNT OF TRACKS

/
0321 4427          WRTDSK, TICK      /TIMING FOR APT IF NEEDED.
0322 7774          =4              /OTHERWISE BOTH ARE SKIPPED
0323 4431          LODTRX           /FORMAT A TRACK
0324 5335          JMP      RENEX1    /TO NEXT DISK
0325 7300          CLA CLL
0326 1102          TAD      LOWAD
0327 1063          TAD      K0040
0330 3102          OCA      LOWAD      /UPDATE TO NEXT TRACK
0331 7630          SZA CLA      /SET EXTENDED BIT
0332 2103          ISZ      HIGHAD     /YES
0333 2104          ISZ      TRKCNT     /UPDATE TRACK COUNTER
0334 5321          JMP      WRTDSK     /DU NEXT TRACK
0335 2105          RENEX1, ISZ   DSKCNT  /UPDATE DISK COUNTER
0336 5276          JMP      NEXFRM     /DU NEXT DISK

/
/ROUTINE TO CHECK ADDRESSING INFORMATION ON THE DISK,
/THE FIRST TWO WORDS OF EVERY SECTOR SHOULD EQUAL
/THE ABSOLUTE DISK ADDRESS. ALL OTHER DATA IS
/NOT CHECKED.

/
0337 1056          CHKDSK, TAO     AMOUNT
0340 3105          OCA      DSKCNT      /AMOUNT OF DISKS
0341 3115          OCA      TCNTR4
0342 1150          TAD      ADPQT2
0343 3116          OCA      TCNTR5
0344 1516          TAD I    TCNTR5      /SOFTWARE INFORMATION

```

```

0345 7640          SZA CLA                /CHECK THIS DISK
0346 5353          JMP      CHKDAT        /CHECK THIS ONE
0347 2116          NEXCHK, ISZ      TCNTR5 /UPDATE FOR NEXT DISK
0350 2115          ISZ      TCNTR4
0351 5344          JMP      .-5
0352 7402          HLT                    /WHAT HAPPENED????

/
0353 1115          CHKDAT, TAD      TCNTR4
0354 0000          AND      K0003        /MASK OUT
0355 7104          CLL      RAL         /MAKE DRIVE NUMBER
0356 3100          DCA      DRIVNO
0357 1115          TAD      TCNTR4
0360 0001          AND      K4
0361 7640          SZA CLA
0362 1006          TAD      K0200
0363 3120          DCA      EX01T        /SET EXTENDED DRIVE BIT
0364 4433          RECAL              /RECALIBRATE
0365 5776          JMP      RENEX2      /TRY NEXT DRIVE
0366 3102          DCA      LOWAD
0367 3103          DCA      HIGHAD      /SETUP STARTING DISK ADDRESS
0370 1064          TAD      M313
0371 3104          DCA      TRKCNT
0372 5775          JMP      CHECK      /AMOUNT OF TRACKS TO DO

/
0375 0400
0376 0414
0377 3456
0400 0400          PAGE

/
0400 4427          CHECK, TICK        /TIMING FOR APT IF NEEDED,
0401 7774          =4                /SKIPPED IF NOT REQUIRED.
0402 4432          REDDSK            /READ AND CHECK ONE CYLINDER
0403 5214          JMP      RENEX2    /TO NEXT DISK
0404 7300          CLA CLL
0405 1102          TAD      LOWAD
0406 1063          TAD      K0040
0407 3102          DCA      LOWAD      /UPDATE TO NEXT CYLINDER
0410 7630          SZL CLA          /TIME TO SET EXTENDED BIT
0411 2103          ISZ      HIGHAD    /YES, SET IT
0412 2104          ISZ      TRKCNT    /UPDATE CYLINDER COUNTER
0413 5200          JMP      CHECK     /CHECK NEXT ONE
0414 2105          RENEX2, ISZ      DSKCNT /UPDATE DISK COUNTER
0415 5777          JMP      NEXCHK    /CHECK NEXT

/
/
0416 1022          TAD      Z2
0417 0070          AND      K4000      /TEST FOR APT
0420 7650          SNA CLA          /ARE WE?
0421 5224          JMP      ENDTST    /NO, NORMAL RUN
0422 2101          ISZ      PCOUNT    /INCREMENT PASS COUNT
0423 5776          JMP      FRMDSK    /LOOP PROGRAM
0424 4452          ENDTST, CRLF
0425 4447          PRNTR
0426 2021          TEXEND
0427 4452          CRLF

```

```

0430 4447      PRNTER      /PRINT "TRY SAME SEQUENCE"
0431 2135      MESS
0432 4434      RECEIV
0433 5775      JMP      ALLAGN      /WAIT FOR INPUT FROM OPERATOR
0434 5227      JMP      .+3      /NO, ASK AGAIN
0435 5776      JMP      PRMDSK      /TRY SAME SEQUENCE

/
/
/SUBROUTINE FOR "ERRORS," SCOPE LOOPS, AND
/ERROR TYPEOUTS.
/
0436 0000      ERRO, 0
0437 7301      CLA CLL IAC
0438 1236      TAD      ERRO
0439 3344      DCA      RETRN1      /GET PC STORED
0440 4426      KAERRO      /STORE FOR RETURN
0441 4452      CRLF      /NOTIFY APT OF ERROR IS NEEDED
0442 4452      CRLF
0443 1636      TAD I      ERRO      /GET TEXT POINTER
0444 0062      AND      K0007      /MASK 9-11
0445 1352      TAD      HEDTAD      /MAKE ERROR HEADER TAD
0446 3251      DCA      .+1
0447 7402      HLT
0448 3254      DCA      .+2      /MODIFIED HEADER TAD
0449 4447      PRNTER      /MODIFIED HEADER POINTER
0450 7402      HLT
0451 4452      CRLF
0452 4447      PRNTER      /PRINT PC:
0453 1642      TEXPC
0454 1236      TAD      ERRO      /GET PC POINTER
0455 4450      OCTEL      /PRINT PC STORED
0456 1636      TAD I      ERRO      /GET TEXT POINTER
0457 7104      CLL RAL
0458 7420      SNL
0459 5274      JMP      NTGD      /NOT GD: REGISTER
0460 3236      DCA      ERRO
0461 4447      PRNTER      /PRINT GD:
0462 1644      TEXGD
0463 1117      TAD      GONEG2
0464 4450      OCTEL      /PRINT FOUR OCTAL
0465 7610      SKP CLA
0466 3236      DCA      ERRO
0467 4447      PRNTER
0468 1646      TEXEX
0469 1120      TAD      EXBIT
0470 7640      SZA CLA
0471 7001      IAC
0472 4450      OCTEL
0473 1345      TAD      XTEXT
0474 3350      DCA      PCNTR2
0475 1346      TAD      XREG
0476 3010      UCA      AUTO10
0477 1357      TAD      K7771
0478 3347      DCA      PCNTR1      /COUNTER FOR # OF HEADS
0479 7344      CLA CLL CMA RAL

```

```

0512 3351      OCA      PCNTR3
0513 1236      STHAUT, TAD      ERRO      /GET TEXT POINTER
0514 7500      SMA
0515 5336      JMP      NOTEX      /NOT THIS ONE
0516 7104      CLL RAL
0517 3236      OCA      ERRO
0518 1350      TAD      PCNTR2
0519 2350      ISZ      PCNTR2      /GET TEXT MESSAGE POINTER
0520 2350      ISZ      PCNTR2
0521 3325      DCA      .+2
0522 4447      PRNTER      /STORE FOR PRINTER
0523 7402      HLT
0524 1410      TAD I      AUTO10
0525 4450      OCTEL      /PRINT XX:
0526 2351      ISZ      PCNTR3      /MODIFIED TEXT POINTER
0527 7610      SKP CLA
0528 4452      CRLF
0529 2347      AGAIN, ISZ      PCNTR1
0530 5313      JMP      STRAUT      /CHECK FOR NEXT XX:
0531 5744      JMP I      RETRN1      /RETURN TO QUESTION
0532 7104      NOTEX, CLL RAL
0533 3236      DCA      ERRO
0534 2350      ISZ      PCNTR2
0535 2350      ISZ      PCNTR2
0536 2010      ISZ      AUTO10
0537 5333      JMP      AGAIN

/
0544 0000      RETRN, 0
0545 1650      XTEXT, TEXCM
0546 0120      XREG, EXBIT
0547 0000      PCNTR1, 0
0548 0000      PCNTR2, 0
0549 0000      PCNTR3, 0
0550 1353      HEDTAD, TAD      MEOLST
0551 1664      HEDLST, ERTX1
0552 1675      ERTX2
0553 1705      ERTX3
0554 1717      ERTX4
0555 7771      K7771, 7771

/
0575 0220
0576 0263
0577 0347
0600

PAGE
/
/ROUTINE TO FORMAT CYLINDER
/MAKE FIRST TWO WORDS OF EVERY SECTOR
/EQUAL TO DISK ADDRESS.
/
0600 0000      WRTTRK, 0
0601 7330      CLA CLL CML RAR
0602 3117      DCA      GDREG2      /SETUP COMPARE REGISTER
0603 4435      KILBUF      /CLEAR BUFFER
0604 1071      TAD      K7735      /AMOUNT OF SECTORS TO GO
0605 3112      DCA      TCNTR1      /SETUP COUNTER

```

```

0606 3113      DCA      TCNTR2      /STARTING WITH 0
0607 1072      TAD      K7760        /STOPPER
0610 3114      DCA      TCNTR3      /SECTOR COUNTER POINTER STOP
0611 1113      LODR1, TAD      TCNTR2
0612 0074      AND      K0037        /MASK SECTOR BITS
0613 1102      TAD      LOWAD        /ADD IN CYLINDER
0614 3453      DCA I   XL0TRK        /SETUP TRACK WORD IN BUFFER
0615 1120      TAD      EX0IT        /ADD IN EXTENDED BIT
0616 1103      TAD      HIGHAD
0617 1100      TAD      DRIVNO        /ADD IN DRIVE NUMBER
0620 3454      DCA I   XMITRK        /SETUP TRACK WORD IN BUFFER
0621 1454      TAD I   XMITRK
0622 0270      AND      K7577
0623 1130      TAD      HOME0A
0624 1267      TAD      K5000        /CURRENT FIELD
0625 4442      LDCHD                /FUNCTION WRITE ALL
0626 1120      TAD      EX0IT        /LUAV COMMAND
0627 4446      LD8C                /LOAD EXTENDED DRIVE BIT
0630 7200      CLA                /CLEAR EXTENDED DRIVE BIT
0631 1055      TAD      BGN8BUF
0632 4443      LOCUR                /LOAD CURRENT ADDRESS
0633 1453      TAD I   XL0TRK
0634 4444      LDADD                /LOAD TRACK AND GO
0635 4441      DSKSKP                /SKIP ON FLAG
0636 5235      JMP      .-1          /WAIT FOR FLAG
0637 4440      RDSTAT                /READ STATUS
0640 1070      TAD      K4000
0641 7640      SZA CLA                /WAS STATUS 0?
0642 5254      JMP      LOUER        /ERROR, STATUS ON WRITE ALL
0643 2113      ISZ      TCNTR2
0644 2114      ISZ      TCNTR3
0645 7610      SKP CLA                /COUNT FIRST REVOLUTION
0646 3113      DCA      TCNTR2      /STILL IN FIRST REV.
0647 2113      ISZ      TCNTR2      /SETUP FOR SECTOR "1"
0650 2112      ISZ      TCNTR1
0651 5211      JMP      LODR1        /UPDATE SECTOR COUNTER
0652 2200      ISZ      WRITRK      /TRY NEXT SECTOR
0653 5600      JMP I   WRITRK
0654 4437      LODER, ERROR
0655 3602      JMP      WRITRK      /THIS CYLINDER DONE
0656 4433      /                  /ERROR, STATUS
0657 5600      RECAL                /TEXT POINTER
0658 4452      JMP I   WRITRK      /CLEAR CONTROL AND DRIVE
0659 4447      CRLF                /TO NEXT DISK
0660 1734      PRNTEH                /PRINT "TRY SAME AGAIN"
0661 4434      ERMES1
0662 5252      RECEIV                /WAIT FOR YES OR NO
0663 5250      JMP      LOUER=2      /WAS A NO TRY SAME CYLINDER
0664 5201      JMP      .-5          /WAS NEITHER ASK AGAIN
0665 5000      JMP      WRITRK +1    /YES, TRY NEXT
0666 7577      K5000, 5000
0667 7577      K7577, 7577
0668 7577      /
0669 7577      /
0670 7577      /SUBROUTINE TO READ STATUS REGISTER

```

```

0671 0000      /RDST, 0
0672 6745      IOT5, DRST                /HEAD STATUS IOT
0673 7410      SKP
0674 4777*     ERHLT5, JMS      XC0ERR    /SKIP TRAP ERROR.
0675 3122      DCA      STREG            /SAVE RESULTS
0676 1122      TAD      STREG
0677 5671      JMP I   RDST              /EXIT
0678 5671      /
0679 5671      /SUBROUTINE TO LOAD CURRENT ADDRESS REGISTER
0680 0000      /
0681 3125      LDCA, 0
0682 1125      DCA      ADREG            /SAVE IN ADDRESS
0683 3124      TAD      ADREG
0684 1125      DCA      CA0REG          /SETUP INITIAL CURRENT ADDRESS
0685 6744      TAD      ADREG
0686 5700      IOT4, ULCA                /LOAD CURRENT ADDRESS IOT
0687 4777*     ERHLT4, JMS      XC0ERR    /EXIT
0688 5307      JMP      .-1            /SKIP TRAP ERROR.
0689 5307      /
0690 5307      /SUBROUTINE TO LOAD TRACK ADDRESS REGISTER
0691 0000      /
0692 3123      LOAD, 0
0693 1123      DCA      DA0REG          /SAVE OUTBOUND DATA
0694 6743      TAD      DA0REG
0695 5711      IOT3, OLAG                /LOAD DISK ADDRESS REGISTER
0696 4777*     ERHLT3, JMS      XC0ERR    /EXIT
0697 5316      JMP      .-1            /SKIP TRAP ERROR.
0698 5316      /
0699 5316      /SUBROUTINE TO LOAD COMMAND REGISTER
0700 0000      /
0701 3121      LDCH, 0
0702 3776*     DCA      CMREG            /SAVE OUTBOUND DATA
0703 4775*     DCA      INMODE
0704 7200      JMS      XC0CKP          /CHECK FOR CONTROL CHARACTERS.
0705 7200      CLA
0706 7200      CLA
0707 1121      TAD      CMREG
0708 6746      IOT6, OLDC                /LOAD COMMAND REGISTER
0709 5720      JMP I   LDCH              /EXIT
0710 4777*     ERHLT6, JMS      XC0ERR    /SKIP TRAP ERROR.
0711 5331      JMP      .-1
0712 5331      /
0713 5331      /SUBROUTINE ISSUE "OLSC"
0714 0000      XL0SC, 0
0715 6740      IOT0, OLSC
0716 5733      JMP I   XL0SC
0717 4777*     ERHLT0, JMS      XC0ERR    /SKIP TRAP ERROR.
0718 5336      JMP      .-1

```

```

      /SUBROUTINE TO ISSUE "DSKP" DISK SKIP IOT
      /
0740 0000      SSKP, 0
0741 6741      IOT1, DSKP      /DISK SKIP IOT
0742 7410      SKP      /DID NOT SKIP
0743 2340      ISZ      SSKP
0744 5740      JMP I      SSKP      /EXIT

      /SUBROUTINE TO ISSUE "DCLR" CLEAR IOT
      /
0745 0000      CLDR, 0
0746 6742      IOT2, DCLR      /DCLR "CLEAR IOT"
0747 5745      JMP I      CLDR      /EXIT
0750 4777      ERHLT2, JMS      XCERR      /SKIP TRAP ERROR.
0751 5350      JMP      ,=-1

      /ROUTINE TO ZERO WORK BUFFER
      /
0752 0000      KLBUF, 0
0753 7340      CLA CLL CMA
0754 1055      TAD      BGNBUF      /START OF BUFFER =1
0755 3010      DCA      AUTO10      /SETUP AUTO INDEX
0756 1364      TAD      K7400
0757 3131      DCA      UATCNT      /SETUP COUNTER
0760 3410      DCA I      AUTO10      /CLEAR BUFFER
0761 2131      ISZ      UATCNT      /UPDATE COUNTER
0762 5360      JMP      ,=2      /NOT ALL CLEARED YET
0763 5752      JMP I      KLBUF      /BUFFER CLEARED
0764 7400      K7400, 7400

      /
0775 3641
0776 3676
0777 4007
      PAGE
      /
      /ROUTINE TO READ AND CHECK A CYLINDER
      /
1000 0000      REDTRK, 0
1001 1071      TAD      K7735
1002 3112      DCA      TCNTR1      /AMOUNT OF SECTORS TO DO
1003 3113      DCA      TCNTR2      /STARTING WITH 0
1004 1072      TAD      K7760
1005 3114      DCA      TCNTR3
1006 4435      KILBUF      /CLEAR BUFFER
1007 7340      CHKRI, CLA CLL CMA
1008 3136      DCA      SOFT      /SETUP SOFT ERROR FLAG
1009 1055      TAD      BGNBUF
1010 4443      LDCUR      /LOAD CURRENT ADDRESS
1011 1103      TAD      HIGHAD      /EXTENDED CYLINDER BIT
1012 1100      TAD      URIVNO      /CURRENT DRIVE
1013 1130      TAD      HOMEMA      /CURRENT FIELD
1014 4442      LDCMD      /LOAD COMMAND
1015 1120      TAD      EXBIT      /LOAD EXTENDED DRIVE BIT
1016 4446      LOSC
1020 4446

```

```

1021 7200      CLA      /CLEAR EXTENDED DRIVE BIT
1022 1113      TAD      TCNTR2
1023 0074      AND      K0037      /MASK SECTOR BITS OFF
1024 1102      TAD      LOWAD      /ADD IN OTHER DISK ADDRESS
1025 4444      LDADD      /LOAD AND GO
1026 4441      DSKSKP      /DISK SKIP IOT
1027 5226      JMP      ,=-1      /WAIT FOR FLAG
1030 4440      ROSTAT      /READ STATUS
1031 1070      TAD      K4000      /ADD IN FUDGE FACTOR
1032 7650      SNA CLA      /SKIP IF ERROR
1033 5241      JMP      STAOK      /STATUS O.K.
1034 1122      TAD      STREG      /GET STATUS READ
1035 0777      AND      K0010
1036 7650      SNA CLA      /WAS IT A CRC
1037 5306      JMP      STAER      /NO, JUST A HARD ERROR
1040 3136      DCA      SOFT      /CLEAR SOFT ERROR FLAG
1041 1121      STAOK, TAD      CMREG      /GET LAST COMMAND
1042 0062      AND      K0007
1043 1120      TAD      EXBIT      /ADD EXTENDED DRIVE BIT
1044 7041      CIA
1045 1454      TAD I      XHITRK      /GET WORD READ FROM DISK
1046 7650      SNA CLA      /SKIP IF ERROR
1047 5256      JMP      FRSTOK      /FIRST WORD O.K.
1050 1454      TAD I      XHITRK      /GET WORD
1051 3126      DCA      DTNEG      /SETUP ERROR PRINTER
1052 1121      TAD      CMREG
1053 0062      AND      K0007
1054 3117      DCA      GOREG2      /SETUP GOOD FOR PRINTER
1055 5303      JMP      DATER      /NO, DATA ERROR
1056 1453      FRSTOK, TAD I      XLOTRK      /GET WORD READ
1057 7041      CIA
1060 1123      TAD      DAMEG      /COMPARE TO GOOD
1061 7650      SNA CLA      /SKIP IF ERROR
1062 5271      JMP      DATOK      /WORD O.K.
1063 2125      ISZ      ADREG      /SETUP ERROR PRINTER
1064 1123      TAD      UAREG
1065 3117      DCA      GOREG2      /SETUP GOOD WORD FOR PRINTER
1066 1453      TAD I      XLOTRK      /GET WORD READ
1067 3126      DCA      DTNEG      /SETUP FOR PRINTER
1070 5303      JMP      DATER      /DATA ERROR
1071 1136      DATOK, TAD      SOFT      /GET SOFT ERROR FLAG
1072 7650      SNA CLA      /WAS IT CLEAR
1073 5306      JMP      STAER      /YES, STATUS ERROR
1074 1113      TAD      TCNTR2
1075 1060      TAD      K0003      /ADVANCE 3 SECTORS
1076 3113      DCA      TCNTR2
1077 2114      ISZ      TCNTR3
1080 5207      JMP      CHKRI      /MORE TO FORMAT
1081 2200      ISZ      REDTRK
1082 5000      JMP I      REDTRK      /EXIT, O.K.
1083 1776      DATER, TAD      K7741
1084 3313      DCA      TCHKT      /SETUP TEXT POINTER
1085 5312      JMP      CMKER      /ERROR
1086 1775      STAER, TAD      K3000
1087 3313      DCA      TCHKT      /SETUP TEXT POINTER

```

```

1110 7330      CLA CLL CML RAR
1111 3117      DCA GONEG2      /SETUP GOOD STATUS PRINTEN
1112 4437      CMKR, ERROR      /ENRUR, READ DATA
1113 0000      TCMKT, 0      /MODIFIED TEXT POINTER
1114 4433      RECAL      /CLEAR CONTROL AND DRIVE
1115 5600      JMP I REDTRK      /TO NEXT DISK
1116 4452      CRLP
1117 4447      PRNTER      /PRINT "TRY SAME AGAIN"
1120 2000      ERME33
1121 4434      RECEIV
1122 5301      JMP DATER -2      /CHECK NEXT
1123 5316      JMP ,=3      /NE-PRINT
1124 5201      JMP REDTRK +1      /TRY SAME AGAIN

/
/THIS ROUTINE WILL TEST FOR APT AND NOP CONSOLE
/PACKAGE IF NEED BE
/
1125 0000      APT8, 0
1126 1022      TAD 22
1127 7700      SNA CLA
1130 5725      JMP I APT8
1131 1022      TAD 22
1132 0373      AND K7377      /ON APT, NOP CONSOLE PACKAGE
1133 3022      DCA 22
1134 1022      TAD 22
1135 0062      AND K0007      /ISOLATE DRIVE NUMBER OR
                                /NUMBER OF DRIVES TO BE DONE

1136 3107      DCA STCNT1
1137 1022      TAD 22
1140 0774      AND K0100
1141 7650      SNA CLA
1142 5353      JMP MULDSK      /SINGLE DRIVE TESTING
                                /NO, SEVERAL TO DO
1143 1137      TAD ADPOT1      /GET DISK POINTER
1144 1107      TAD STCNT1      /ESTABLISH DRIVE TO DO
1145 3107      DCA STCNT1
1146 7340      CLL CLA CMA      /-1
1147 3507      DCA I STCNT1
1150 7340      CLL CLA CMA      /ONE DISK TO DO
1151 3134      DCA LOC8ED
1152 5527      JMP I 0GNTST
1153 1107      TAD STCNT1      /UNIVE TO BE DONE
1154 7040      CMA
1155 3107      DCA STCNT1
1156 1137      TAD ADPOT1      /GET DISK POINTER
1157 1110      TAD STCNT2      /ESTABLISH DRIVE TO BE DONE
1160 3111      DCA STCNT3
1161 2134      ISZ LOC8ED
1162 7340      CLL CLA CMA
1163 3511      DCA I STCNT3      /DO THIS DRIVE
1164 2110      ISZ STCNT2
1165 2107      ISZ STCNT1
1166 5356      JMP MULDSK+3      /MORE TO DO
1167 1134      TAD LOC8ED
1170 7041      CIA
1171 3134      DCA LOC8ED      /NUMBER TO BE DONE

```

```

1172 5527      JMP I 0GNTST
1173 7377      K7377, 7377
1174 1556
1175 1326
1176 1325
1177 1324
1200 1200      PAGE
/
/SUBROUTINE TO PRINT TWO OCTAL
/
1200 0000      TOCT, 0
1201 3106      DCA SBCNT1      /SAVE AC
1202 1106      TAD SBCNT1
1203 7010      RAR
1204 7012      NTR
1205 0062      AND K0007
1206 1067      TAD K0260
1207 4436      TYPE      /PRINT FIRST BYTE
1210 1106      TAD SBCNT1
1211 0062      AND K0007
1212 1067      TAD K0260
1213 4436      TYPE      /PRINT SECOND BIT
1214 5600      JMP I TOCT      /EXIT

/
/
/ROUTINE TO DO CRLP
/
1215 0000      UPONE, 0
1216 7330      CLA CLL
1217 1225      TAD K0215
1220 4436      TYPE
1221 1226      TAD K0212
1222 4436      TYPE
1223 4436      TYPE      /TYPE ONE NULL
1224 5615      JMP I UPONE

/
K0215, 0215
K0212, 0212
/
/ROUTINE TO PRINT FOUR OCTAL
/
1227 0000      FROCT, 0
1230 7006      RTL
1231 7006      RTL
1232 3215      DCA UPONE
1233 1076      TAD M4
1234 3200      DCA TOCT
1235 1215      TAD UPONE
1236 0062      AND K0007
1237 1067      TAD K0260
1240 4436      TYPE
1241 1215      TAD UPONE
1242 7006      RTL
1243 7004      RAL

```

```

1244 3215      OCA      UPONE
1245 2200      ISZ      TOCT
1246 5235      JMP      ,=11
1247 1321      TAD      K0240
1250 4436      TYPE
1251 5627      JMP I     FRUCT

```

```

/
/SUBROUTINE TO PRINT TEXT
/

```

```

1252 0000      PRN,      0
1253 7300      CLA CLL
1254 1652      TAD I     PRN      /GET POINTER
1255 2252      ISZ      PRN
1256 3227      OCA      FRUCT
1257 1627      TAD I     FRUCT
1260 0322      AND      K7700
1261 7450      SNA
1262 5306      JMP      EXIT
1263 7500      SMA
1264 7020      CML
1265 7001      IAC
1266 7012      RTR
1267 7012      RTR
1270 7012      RTR
1271 4436      TYPE
1272 1627      TAD I     FRUCT
1273 0323      AND      K0077
1274 7450      SNA
1275 5306      JMP      EXIT
1276 1311      TAD      K3740
1277 7500      SMA
1300 1310      TAD      K4100
1301 1321      TAD      K0240
1302 4436      TYPE
1303 2227      ISZ      FRUCT
1304 7300      CLA CLL
1305 5257      JMP      PRN+5
1306 7300      EXIT,     CLA CLL
1307 5652      JMP I     PRN

```

```

/
1310 4100      K4100,    4100
1311 3740      K3740,    3740
/

```

```

/ROUTINE TO TYPE
/

```

```

1312 0000      PRINT,    0
1313 0046      TLS
1314 0041      TSF
1315 5314      JMP      ,=1
1316 0042      TCF
1317 7200      CLA
1320 5712      JMP I     PRINT
1321 0240      K0240,    0240
1322 7700      K7700,    7700

```

```

1323 0077      K0077,    0077
1324 0010      K0010,    10
1325 7741      K7741,    7741
1326 3600      K3600,    3600

```

```

/ROUTINE TO WAIT FOR KEY FROM OPERATOR
/

```

```

1327 0000      WAIT,      0
1330 7300      CLA CLL
1331 6032      KCC
1332 6031      KSF
1333 5332      JMP      ,=1
1334 6036      KRB
1335 0046      TLS
1336 0041      TSF
1337 5336      JMP      ,=1
1340 0370      AND      K0177
1341 1066      TAD      K0200
1342 3101      DCA      CHAR
1343 1101      TAD      CHAR
1344 3777      DCA      C0CHAR
1345 2776      ISZ      INMODE
1346 4775      JMS      XCBCNT      /CHECK FOR CONTROL CHARACTERS.
1347 7200      CLA
1350 7200      CLA
1351 3776      DCA      INMODE
1352 6032      KCC
1353 6042      TCF
1354 1101      TAO      CHAR
1355 7041      CIA
1356 1371      TAD      K0316
1357 7650      SNA CLA
1360 5727      JMP I     WAIT      /WAS IT A NO
1361 2327      ISZ      WAIT      /YES
1362 1101      TAD      CHAR      /UPDATE RETURN POINTER
1363 7041      CIA
1364 1372      TAD      K0331
1365 7650      SNA CLA
1366 2327      ISZ      WAIT      /WAS IT A YES
1367 5727      JMP I     WAIT      /WAS A YES
1370 0177      K0177,    0177      /WAS NEITHER
1371 0316      K0316,    0316
1372 0331      K0331,    0331
/

```

```

1375 3200
1376 3676
1377 3675
1400

```

```

PAGE
/

```

```

/ROUTINE TO RECALIBRATE SELECTED DRIVE
/

```

```

1400 0000      RESTOR,    0
1401 7301      CLA CLL IAC      /ENABLE CLEAR CONTROL
1402 4445      CLRALL          /CLEAR CONTROL
1403 1100      TAD      DRIVNO  /CURRENT DRIVE

```



```

1404 1130      TAD      HOMEHA      /CURRENT FIELD
1405 4442      LOCMD      /LOAD COMMAND
1406 1120      TAD      EXBIT
1407 4446      LOSE
1410 7330      CLA CLL  CML RAR      /LOAD EXTENDED DRIVE BIT
1411 3117      DCA      GDMRG2      /MAYBE EXPECTED STATUS
1412 7326      CLA CLL  CML RTL      /SETUP COMPARE REGISTER
1413 4445      CLRALL
1414 4441      DSKSKP      /ENABLE RECALIBRATE BIT
1415 5214      JMP      .-1          /"RECALIBRATE"
1416 4440      ROSTAT      /DISK SKIP IOT
1417 1327      TAD      K2000      /WAIT FOR FIRST DONE FLAG
1420 7450      SNA
1421 5225      JMP      RESTA      /READ STATUS
1422 1327      TAD      K2000
1423 7640      SZA CLA
1424 5243      JMP      RESTER
1425 4445      RESTA, CLRALL
1426 1066      TAD      K0200      /WAS IT BUSY AND DONE
1427 1121      TAD      CMREG      /YES, THEN ITS O.K.
1430 4442      LOCMD
1431 4441      DSKSKP      /NO, THEN IT MUST BE JUST DONE
1432 5231      JMP      .-1          /WAS IT JUST DONE
1433 4440      ROSTAT
1434 1070      TAD      K4000      /NO, ERROR
1435 7640      SZA CLA
1436 5243      JMP      RESTER
1437 7301      CLA CLL  IAC
1440 4445      CLRALL
1441 2200      ISZ      RESTOR      /CLEAR STATUS
1442 5600      JMP I      RESTOR    /ENABLE SET SECOND DONE FLAG
1443 4437      RESTER, ERROR
1444 3603      /ORIGINAL COMMAND
1445 4452      /LOAD COMMAND
1446 4447      PRNTER
1447 1756      ERMES2
1450 4434      RECEIV
1451 5254      JMP      .+3
1452 5245      JMP      .-5
1453 5201      JMP      RESTOR +1
1454 7301      CLA CLL  IAC
1455 1056      TAD      AMOUNT
1456 7450      SNA
1457 5535      JMP I      XEND
1460 3056      DCA      AMOUNT
1461 3516      OCA I      TCNTR5
1462 5600      JMP I      RESTOR
1463 0000      /GET AMOUNT ON SYSTEM
1464 4777      JMS      XC8SW      /WAS THERE ONLY 1 LEFT
1465 7010      RAR
1466 7620      SNL CLA
1467 5663      JMP I      CHANG
1470 4777      JMS      XC8SW
1471 0313      AND      A0770
1472 3314      DCA      CSAVE1
1473 1316      TAD      CCNTR1
1474 3315      DCA      CSAVE2
1475 1317      TAD      CHNPOT
1476 3200      DCA      RESTOR
1477 1600      CHANG, TAD I      RESTOR
1480 3311      DCA      KWAIT
1481 1711      TAD I      KWAIT
1482 0312      AND      A7007
1483 1314      TAD      CSAVE1
1484 3711      DCA I      KWAIT
1485 2200      ISZ      RESTOR
1486 2315      ISZ      CSAVE2
1487 5277      JMP      CHANGR
1488 5663      JMP I      CHANG
1489 0000      /GET ADDRESS POINTER
1490 7007      A7007, 7007
1491 0770      A0770, 0770
1492 0000      CSAVE1, 0
1493 0000      CSAVE2, 0
1494 7771      CCNTR1, 7771
1495 1520      CHNPOT, CHNPOT +1
1496 0734      IOT0
1497 0741      IOT1
1498 0746      IOT2
1499 0714      IOT3
1500 0705      IOT4
1501 0672      IOT5
1502 0727      IOT6
1503 2000      K2000, 2000
1504 0000      /
1505 7000      /THIS ROUTINE WILL GENERATE TIMING IF NEEDED BY THE APT SYSTEM
1506 1022      /
1507 0070      KTICK, 0
1508 7650      CLL CLA
1509 5351      TAD      22
1510 1730      AND      K4000
1511 3353      SNA CLA
1512 1355      JMP      EXTICK
1513 1730      TAD I      KTICK
1514 3353      DCA      COUNT
1515 2132      ISZ      CLKCNT
1516 5351      JMP      EXTICK
1517 1353      TAD      COUNT
1518 3132      DCA      CLKCNT
1519 2354      ISZ      CNT
1520 5351      JMP      EXTICK
1521 4425      TIME
1522 1355      TAD      KCNT
1523 3354      DCA      CNT

```

```

1466 7620      SNL CLA
1467 5663      JMP I      CHANG
1470 4777      JMS      XC8SW
1471 0313      AND      A0770
1472 3314      DCA      CSAVE1
1473 1316      TAD      CCNTR1
1474 3315      DCA      CSAVE2
1475 1317      TAD      CHNPOT
1476 3200      DCA      RESTOR
1477 1600      CHANG, TAD I      RESTOR
1480 3311      DCA      KWAIT
1481 1711      TAD I      KWAIT
1482 0312      AND      A7007
1483 1314      TAD      CSAVE1
1484 3711      DCA I      KWAIT
1485 2200      ISZ      RESTOR
1486 2315      ISZ      CSAVE2
1487 5277      JMP      CHANGR
1488 5663      JMP I      CHANG
1489 0000      /GET ADDRESS POINTER
1490 7007      A7007, 7007
1491 0770      A0770, 0770
1492 0000      CSAVE1, 0
1493 0000      CSAVE2, 0
1494 7771      CCNTR1, 7771
1495 1520      CHNPOT, CHNPOT +1
1496 0734      IOT0
1497 0741      IOT1
1498 0746      IOT2
1499 0714      IOT3
1500 0705      IOT4
1501 0672      IOT5
1502 0727      IOT6
1503 2000      K2000, 2000
1504 0000      /
1505 7000      /THIS ROUTINE WILL GENERATE TIMING IF NEEDED BY THE APT SYSTEM
1506 1022      /
1507 0070      KTICK, 0
1508 7650      CLL CLA
1509 5351      TAD      22
1510 1730      AND      K4000
1511 3353      SNA CLA
1512 1355      JMP      EXTICK
1513 1730      TAD I      KTICK
1514 3353      DCA      COUNT
1515 2132      ISZ      CLKCNT
1516 5351      JMP      EXTICK
1517 1353      TAD      COUNT
1518 3132      DCA      CLKCNT
1519 2354      ISZ      CNT
1520 5351      JMP      EXTICK
1521 4425      TIME
1522 1355      TAD      KCNT
1523 3354      DCA      CNT

```

```

1551 2330 EXTICK, ISZ KTICK
1552 5730 JMP I KTICK /MOVE BEYOND TIMING VALUE

1553 0000 COUNT, 0
1554 7776 CNT, -2
1555 7776 KCNT, -2
1556 0100 K0100, 0100
/
/
/ROUTINE TO NOTIFY APT OF USE IF REQUIRED
/
1557 0000 KTIME, 0
1560 0002 IOF /DISABLE INTERRUPTS
1561 0214 RUF /GET PRESENT DATA FIELD
1562 1075 TAD KCUF
1563 3364 DCA ,+1 /ESTABLISHES CURRENT DATA FIELD
1564 7402 HLT
1565 6272 CIF 70 /FIELD 7. LOCATION OF UV FROM
1566 4771 JMS I K6500
1567 7300 CLL CLA
1570 5757 JMP I KTIME
/
1571 6500 K6500, 6500
/
1577 3062 PAGE
1600 1600 /
/THIS ROUTINE WILL NOTIFY APT OF AN ERROR AND SEND PC TO
/APT SYSTEM. ALL ERRORS WILL RESULT IN PROGRAM HLT AND A TIME OUT ON
/APT. APT WILL TAKE OVER FROM THERE.
/
1600 0000 AENRO, 0
1601 0002 IOF /DISABLE INTERRUPTS
1602 7200 CLA
1603 1022 TAD 22 /CHECK FOR APT SYSTEM
1604 7700 SMA CLA
1605 5600 JMP I AENRO /RETURN NOT ON APT
1606 1621 TAD I KENRO /GET PC
1607 3222 DCA SAVPC
1610 6214 RUF /GET CURRENT DATA FIELD
1611 1075 TAD KCUF
1612 3214 DCA ,+2
1613 1222 TAD SAVPC
1614 7402 HLT
1615 6272 CIF 70 /REPLACED WILL CURRENT DATA FIELD
1616 5620 JMP I K6520 /CHANGE IF FOR APT RETURN TO FIELD 7
1617 7402 HLT /NOTIFIES APT OF ERROR
/
1620 6520 K6520, 6520
1621 0436 KENRO, ERNO
1622 0000 SAVPC, 0
/
/

```

```

/ROUTINE TO MOVE DISK POINTERS
/
1623 0000 MOVE, 0
1624 1237 TAD ADPT1
1625 3010 DCA AUTO10

1626 1240 TAD ADPT2
1627 3011 DCA AUTO11
1630 1077 TAD M10
1631 3241 DCA MCNTR1
1632 1410 TAD I AUTO10 /FROM HERE
1633 3411 DCA I AUTO11 /TO THERE
1634 2241 ISZ MCNTR1 /4 POINTERS
1635 5232 JMP ,+5
1636 5623 JMP I MOVE
/
1637 0137 ADPT1, DSK0A *-1
1640 0150 ADPT2, DSK0B *-1
1641 0000 MCNTR1, 0
/
/
1642 2003 TEXPC, TEXT "PC:"
1643 7200
1644 0704 TEXGO, TEXT "GO:"
1645 7200
1646 0530 TEXEX, TEXT "EX:"
1647 7200
1650 0315 TEXCM, TEXT "CM:"
1651 7200
1652 2324 TEXST, TEXT "ST:"
1653 7200
1654 0401 TEXDA, TEXT "DA:"
1655 7200
1656 0301 TEXCA, TEXT "CA:"
1657 7200
1660 0104 TEXAD, TEXT "AD:"
1661 7200
1662 0424 TEXDT, TEXT "DT:"
1663 7200
/
1664 2205 ERTX1, TEXT "READ STATUS ERROR"
1665 0104
1666 4023
1667 2401
1670 2425
1671 2340
1672 0522
1673 2217
1674 2200
1675 0411 ERTX2, TEXT "DISK DATA ERROR"
1676 2313
1677 4004
1700 0124
1701 0140
1702 0522

```

1703 2217
1704 2200
1705 2722 ERTX3, TEXT "WRITE STATUS ERROR"
1706 1124
1707 0540
1710 2324
1711 0124
1712 2523
1713 4005
1714 2222
1715 1722
1716 0000
1717 2205 ERTX4, TEXT "RECALIBRATE STATUS ERROR"
1720 0301
1721 1411
1722 0222
1723 0124
1724 0540
1725 2324
1726 0124
1727 2523
1730 4005
1731 2222
1732 1722
1733 0000

1734 2422 /
1735 3140 ERMES1, TEXT "TRY TO FORMAT SAME CYLINDER AGAIN?"
1736 2417
1737 4006
1740 1722
1741 1501
1742 2440
1743 2301
1744 1505
1745 4003
1746 3114
1747 1116
1750 0405
1751 2240
1752 0107
1753 0111
1754 1677
1755 0000
1756 2422 ERMES2, TEXT "TRY TO RECALIBRATE SAME DISK AGAIN?"
1757 3140
1760 2417
1761 4022
1762 0503
1763 0114
1764 1102
1765 2201
1766 2405
1767 4023
1770 0115

1771 0540
1772 0411
1773 2313
1774 4001
1775 0701
1776 1116
1777 7700
2000 2422 ERMES3, TEXT "TRY TO CHECK SAME CYLINDER AGAIN?"
2001 3140
2002 2417
2003 4003
2004 1005
2005 0313
2006 4023
2007 0115
2010 0540
2011 0331
2012 1411
2013 1604
2014 0522
2015 4001
2016 0701
2017 1116
2020 7700

2021 2213 /
2022 7005 TEXTEND, TEXT "RK8E/RK8L DISK FORMATTER PASS COMPLETE"
2023 5722
2024 1370
2025 1440
2026 0411
2027 2313
2030 4006
2031 1722
2032 1501
2033 2424
2034 0522
2035 4020
2036 0123
2037 2340
2040 0317
2041 1520
2042 1405
2043 2405
2044 0000
2045 2213 MES1, TEXT "RK8E/RK8L DISK FORMATTER PROGRAM"
2046 7005
2047 5722
2050 1370
2051 1440
2052 0411
2053 2313
2054 4006
2055 1722
2056 1501

```

2057 2424
2060 0522
2061 4020
2062 2217
2063 0722
2064 0115
2065 0000
2066 0617  MSG2, TEXT "FOR ALL QUESTIONS, ANSWER Y FOR YES OR N FOR NO."
2067 2240
2070 0114
2071 1440
2072 2125
2073 0523
2074 2411
2075 1716
2076 2354
2077 4001
2100 1623
2101 2705
2102 2240
2103 3140
2104 0617
2105 2240
2106 3105
2107 2340
2110 1722
2111 4016
2112 4006
2113 1722
2114 4016
2115 1756
2116 0000
2117 0617  MSG3, TEXT "FORMAT DISK "
2120 2215
2121 0124
2122 4004
2123 1123
2124 1340
2125 0000
2126 0122  MSG4, TEXT "ARE YOU SURE?"
2127 0540
2130 3117
2131 2540
2132 2325
2133 2205
2134 7700
2135 0617  MSG5, TEXT "FORMAT SAME DISK(S) AGAIN?"
2136 2215
2137 0124
2140 4023
2141 0115
2142 0540
2143 0411
2144 2313
2145 5023

```

```

2146 5140
2147 0107
2150 0111
2151 1677
2152 0000

2200 /
PAGE
/
2200 WRKBUF=.
/
2200 H1TRK=.
2201 LDIRK=. +1
/
2577 ENDBUF=. +377
/

/CONSOL SRC -V2-R0- CONSOLE PACKAGE

/LAS= CALL C0CASH OR JMS XCBSW
/THIS WILL READ THE SWITCH REGISTER FROM THE PLACE SPECIFIED
/BY LOCATION 20 BIT 0.

/THE PROGRAM SHOULD CHECK FOR A CONTROL CHARACTER FROM THE TERMINAL
/EVERY FIVE(5) SECONDS OR SOONER.

/LOCATIONS THAT NEED TO BE SET UP FOR USING THE CONSOLE PACKAGE.

/CNTVAL IN XCBPASS THIS LOCATION DETERMINES THE NUMBER OF
/PROGRAM COMPLETIONS THAT ARE NEEDED BEFORE THE PASS MESSAGE IS TYPED
/THE VALUE SHOULD PUT THE PASS MESSAGE OUT IN THE RANGE OF 1 TO 5 MINUTES.
/THIS SHOULD BE A POSITIVE NUMBER.

/CBSTRT THIS IS FOUND IN CNTRL ROUTINE CONTROL R PART
/IT IS THE RETURN WHEN CONTROL R IS ENTERED (RESTART PROGRAM)
/THE RETURN JUMPS TO XD0SW WHICH CONTAINS CBSTRT SO PUT THE LABEL CBSTRT
/WHERE YOU WANT TO RESTART THE PROGRAM.

/SETUP1 IN XCBEERR THIS IS THE MASK BIT FOR HALT ON ERROR
/PLACE THE CORRECT BIT IN THIS LOCATION FOR HALTING ON ERRORS.

/SETUP2 IN XCBPASS THIS IS THE MASK FOR HALT A END OF PASS.

/THE CALL TABLE IS A CONDITIONAL ASSEMBLY.
/TO ASSEMBLE THE CALL REMOVE THE / BEFORE CONSOL=0.
/IN COMBINING THE CONSOL PACKAGE TO A DIAGNOSTIC.
/THE CALL TABLE IS TO BE AT THE BEGINNING OF A PROGRAM.

/CONSOL=0
6661 PSKF= 6661
6662 PCLF= 6662

```

6663 PSKE= 6663
 6664 PSTB= 6664
 6665 PSIE= 6665
 6004 GTF= 6004
 7701 ACL= 7701
 6007 CAF= 6007
 7421 MQL= 7421
 7501 MQA= 7501

3000 *3000

/*
 /*****
 /C8PASS
 /THIS IS CALLED AT THE END OF EACH PROGRAM COMPLETION
 /THE VALUE OF** CNTVAL** WILL BE DETERMINED BY THE TIME IT TAKES
 /THE PROGRAM TO COMPLETE THIS MANY C8PASS TO BE IN THE 1 TO 4 MINUTE
 /RANGE
 / C8PASS*JMS XC8PAS
 /EX. OF CALL C8PASS
 / HLT
 / JMP START1 /HALT IF NON CONSOL PACKAGE
 /CONTINUE RUNNING THIS PROGRAM

/RETURN TO LOCATION CALL PLUS ONE WITH THE AC=0 IF NON CONSOL PACKAGE AND HLT
 /IF CONTINUE TO RUN THEN RETURN TO CALL PLUS2 AC=0
 /THE LOCATION SETUP2 IS THE MASK BIT FOR THE HALT AT END OF PASS
 /CHECK THAT IT IS CORRECT FOR THE CURRENT PROGRAM

/CALLS USED BY XC8PAS ARE CHKCLA-XC8CKLFL-XC8OCTA-XC8SW-XC8PNT-XC8ING-

3000 0000 XC8PAS, 0
 3001 7200 CLA
 3002 4777* JMS CHKCLA /IS WORD 22 BIT 3 ACTIVE CONSOLE?
 3003 5212 JMP DOPACK /IS CLASSIC
 3004 4776* JMS C8GET /GET THE REGISTERS.
 3005 4262 JMS XC8SW /DEACTIVE CONSOL CHECK SR SETTING
 3006 0375 AND (400 /FOR HALT ON END OF C8PASS
 3007 7640 SZA CLA /1= HALT 0 CONTINUE
 3010 5600 JMP I XC8PAS /GO TO HALT
 3011 5230 JMP C8BY1 /CONTINUE ON RUNNING PROGRAM
 3012 4232 JMS CKCOUT /CLASS CHECK C8PASS COUNT
 3013 5230 JMP C8BY1 /C8PASS COUNT NOT DONE REDO PROGRAM
 3014 2250 ISZ PASCNT /C8PASS COUNT DONE SET C8PASS COUNT
 3015 4774* JMS XC8CRLF
 3016 4303 JMS XC8PNT /C8PNT BUFFER
 3017 3053 MESPAS
 3020 1250 TAD PASCNT /GET NUMBER
 3021 4773* JMS XC8OCTA /CONVERT IT TO ASCII
 3022 4774* JMS XC8CRLF /DO A CARRIAGE RETURN
 3023 4776* JMS C8GET /GET THE REGISTERS.
 3024 4262 JMS XC8SW /CHECK A HALT AT END OF C8PASS
 3025 0375 SETUP2, AND (400 /MASK BIT
 3026 7640 SZA CLA /HALT =1 NO SKIP CONTINUE =0
 3027 4772* JMS XC8ING /STOP PROGRAM EXECUTION-LOOK FOR INPUT

3030 2200 C8BY1, ISZ XC8PAS /BUMP RETURN
 3031 5600 JMP I XC8PAS
 3032 0000 CKCOUT, 0
 3033 1251 TAD DOSET /CHECK IF SET UP NEEDED
 3034 7640 SZA CLA /0=SET UP C8PASS COUNT VALUE
 3035 5242 JMP NOSET /1=C8PASS COUNT VALUE OK
 3036 1252 TAD CNTVAL /C8PASS COUNT VALUE ON
 3037 7640 CMA /GET COUNT VALUE FOR THIS PROG
 3040 3247 DCA DOCNT /SET TO NEGATIVE
 3041 2251 ISZ DOSET /STORE IN HERE
 3042 2247 NOSET, ISZ DOCNT /INDICATE VALUE SET UP
 3043 5230 JMP C8BY1 /COUNT THE NUMBER OF PASSES
 3044 3251 DCA DOSET /EXIT FOR ANOTHER PASS
 3045 2232 ISZ CKCOUT /SET TO C8PNT C8PASS
 3046 5632 JMP I CKCOUT /BUMP RETURN FOR
 3047 0000 DOCNT, 0 /C8PASS C8TYPE OUT
 3050 0000 PASCNT, 0
 3051 0000 DOSET, 0
 3052 0000 CNTVAL, 0
 3053 0410 MESPAS, TEXT "DMRKD PASS "
 3054 2213
 3055 0404
 3056 4040
 3057 2001
 3060 2323
 3061 4000

/*

/C8CKSW

/THIS ROUTINE CAN BE USED INPLACE OF A READ THE SWITCHES LAS.
 /ROUTINE THAT WILL CHECK WHERE TO READ THE
 /C8 SWITCHES FROM IE. FROM PANEL OR PSEUDO SWITCH REGISTER
 /THE SELECTION IS DETERMINED BY THE STATE OF BIT 0 IN LOCATION 21.

/C8CKSW= JMS XC8SW /READ THE C8SWIT REGISTER
 /EX. JMS XC8SW /RETURN WITH THE CONTENTS OF SWITCH REGISTER

/RETURN TO NEXT LOCATION FOLLOWING CALL WITH THE AC= TO VALUE OF C8SWIT SETTING

/CALLS USED ARE=XC8CKPA=

3062 0000 XC8SW, 0
 3063 4771* JMS XC8CKPA /GO CHECK THE IF ANY CONTRL
 3064 7000 NOP
 3065 1021 TAD 21 /GET WD FOR INDICATOR
 3066 7710 SPA CLA /CHECK IF FROM PANEL 4000
 3067 7614 /DO LAS AND SKIP GET FROM PANEL WITH LAS

```

3070 1020      TAD      20      /PSEUDU SWITCH
3071 5662      JMP I   XC8SW    /EXIT WITH STATUS BIT IN AC.

```

```

/*****

```

```

/C8TTYI
/THIS ROUTINE WILL LOOK FOR A INPUT FROM THE TERMINAL
/AND REMOVE ANY PARITY BITS, THEN MAKE IT 8 BIT ASCII.
/      C8TTYI= JMS XC8TTY
/EX.      JMS      XC8TTYI      /READ CHAR FROM THE CONSOL DEVICE
/                          /RETURN TO CALL PLUS ONE AC CONTAINS THE CHAR

```

```

/CALLS USED -NONE- BUT C8CHAR IS OFF PAGE AND IN ROUTINE CALLED XC8ECHO

```

```

/
/
3072 0000      XC8TTY, 0
3073 6031      KSF          /LOOK FOR KEYBOARD FLAG
3074 5273      JMP          0-1
3075 6036      KRB          /GET CHAR
3076 0370      AND          (177 /MASK FOR 7 BITS
3077 1367      TAD          (200 /ADD THE EIGHTH BIT
3100 3766      OCA          C8CHAR /STORE IT
3101 1766      TAD          C8CHAR
3102 5672      JMP I       XC8TTY /EXIT

```

```

/*****

```

```

/C8PRNT

```

```

/THIS ROUTINE WILL TYPE THE CONTENTS OF THE C8 PRINT BUFFER, THE LOCATION
/OF THE BUFFER WILL BE IN THE ADDR3 FOLLOWING THE CALL. PRINTING OF THE BUFFER
/Will STOP WHEN A 00 CHAR IS DETECTED. CHARACTERS ARE PACKED 2 PER WORD.

```

```

/      C8PRNT= JMS XC8PNT

```

```

/EX.      JMS      XC8PNT      /C8PNT THE CONTENTS OF THE FOLLOWING BUFFER
/      MESS77      /LOCATION OF C8PNT BUFFER

```

```

/C8PNT WILL USE THE LOCATION FOLLOWING THE CALL AS THE POINTER FOR THE
/C8PNT ROUTINE, RETURN TO CALL PLUS TWO WITH AC= 0

```

```

/CALLS USED ARE-XC8TYPE-XC8PNT

```

```

3103 0000      XC8PNT, 0
3104 7300      CLA CLL
3105 1703      TAD I       XC8PNT /GET C8PNT BUFFERS STARTING LOCATION
3106 3336      OCA        PTSTOR /STORE IN PTSTOR

```

```

3107 2303      ISZ      XC8PNT /BUMP RETURN
3110 1736      C8D01, TAD I   PTSTOR /GET DATA WORD
3111 0365      AND      (7700 /MASK FOR LEFT BYTE
3112 7450      SNA          /CHECK IF 00 TERMINATE
3113 5703      JMP I       XC8PNT /EXIT
3114 7500      SNA          /IS AC MINUS
3115 7020      CML          /MAKE CHAN A 300 AFTER ROTATE
3116 7001      IAC          /MAKE CHAN A 200 AFTER ROTATE
3117 7012      RTR
3120 7012      RTR
3121 7012      RTR
3122 4764      JMS      XC8TYPE /PUT CHAR IN BITS 4-11 MAKE IT 8 BIT ASCII
3123 1736      TAD I       PTSTOR /C8PNT IT ON CONSOLE
3124 0363      AND      (0077 /GET DATA WORD
3125 7450      SNA          /MASK FOR RIGHT BYTE
3126 5703      JMP I       XC8PNT /CHECK IF 00 TERMINATOR
3127 1362      TAD      (3740 /EXIT
3130 7500      SNA          /ADD FUOGE FACTOR TO DETERMINE IF 200
3131 1361      TAD      (100 /OR 300 IS TO BE ADD TO CHAN
3132 1360      TAD      (240 /ADD 100
3133 4764      JMS      XC8TYPE /C8TYPE ONLY BITS 4-11
3134 2336      ISZ      PTSTOR /BUMP POINTER FOR NEXT WORD
3135 5310      JMP      C8D01 /DO AGAIN
3136 0000      PTSTOR, 0 /STORE FOR C8PNT BUFFER

```

```

/*****

```

```

/C8PAUS

```

```

/THIS ROUTINE WILL CHECK IF THE CONSOL PACKAGE IS ACTIVE, IF ACTIVE
/IT WILL RETURN TO CALL PLUS ONE AC= 0, AND DO THAT INSTRUCTION.
/IF THE CONSOL PACKAGE IS NOT ACTIVE THE CALL WILL BE REPLACED
/WITH A 7402 HALT AND THEN RETURN TO THE HALT.

```

```

/      C8PAUS= JMS XC8PAU

```

```

/EX.      JMS      XC8PAUS      /CHECK IF ON ACTIVE CONSOL IF NOT HALT HERE
/      ANYTHING /RETURN HERE IF ON ACTIVE CONSOL

```

```

/CALLS USED ARE -CHKCLA-

```

```

3137 0000      XC8PAU, 0
3140 7300      CLA CLL
3141 4777      JMS      CHKCLA /CHECK LOC 22 BIT 3 CONSOLE BIT
3142 5350      JMP      C8D03 /GO DO CONSOL PART RETURN CALL +1
3143 7040      CMA          /DEACTIVE CONSOLE PACKAGE PUT HLT IN CALL
3144 1337      TAD      XC8PAU /GET CURRENT RETURN ADDR3
3145 3337      OCA      XC8PAU /SET UP RETURN
3146 1357      TAD      (7402 /GET CODE FOR HLT
3147 3737      OCA I       XC8PAU /PUT HLT IN CALL LOCATION
3150 5737      C8D03, JMP I   XC8PAU /GO TO HALT OR RETURN TO NEXT LOCATION

```

3157 7402
3160 0240
3161 0100
3162 3740
3163 0077
3164 3677
3165 7700
3166 3675
3167 0200
3170 0177
3171 3641
3172 3435
3173 3600
3174 3623
3175 0400
3176 3424
3177 4000
3200 3200

PAGE

/*****

/C0CNTM

/THIS ROUTINE WILL CHECK FOR THE PRESENCE OF CONTROL CHARACTERS

/IT WILL CHECK FOR THE FOLLOWING CHAR C-R-Q-L-S

/ C0CNTM= JMS XC0CNT

/EX.

/ JMS XC0CNTM

/ JMS ANYTHING

/ JMS ANYTHING

/

/CHECK FOR CONTROL CHARACTER

/LOC FOLLOWING CALL IS FOR CONTINUING THE PROGRAM

/LOC. IS FOR RETURN IF INMODE SET AND NOT CNTRL CHAR

/RETURN IS TO CALL PLUS ONE IF CONTINUE

/RETURN IS TO CALL PLUS TWO IF INMODE SET AND NOT CONTROL CHAR

/RETURN IS TO CALL PLUS TWO IF INMODE IS NOT SET AND NO

/CONTROL CHAR .,THIS WILL PRINT THE CHARACTER AND A ?

/CLEAR THE AC AND RETURN CALL+2.

/CALLS USED ARE=CHKCLA=XC0TYPE=XC0CLF=C0GET=UPANOW=XC0TYI=XC0PSW=

/

/

/

3200 0000
3201 3777
3202 4776
3203 5206
3204 1777
3205 5600
3206 6004
3207 3775
3210 7501
3211 3774
3212 3255
3213 1257

XC0CNT, 0

DCA ACSAVE

/SAVE THE AC

JMS CHKCLA

/CHECK LOC.22 BITS FOR CONSOLE BIT

JMP .+3

/ON ACTIVE CONSOLE

TAD ACSAVE

/DEACTIVE CONSOLEGET AC FOR RETURN

JMP I XC0CNT

/EXIT NOT ON ACTIVE CONSOLE

GTF

DCA PLSAVE

MCA

DCA MQSAVE

/SAVE THE MQ

DCA INDEXA

/SET DISPLACEMENT INTO TABLE B

TAD XTABLA

/GET ADDRS OF TABLE A

3214 3256
3215 1656
3216 7450
3217 5226
3220 1773
3221 7650
3222 5243
3223 3255
3224 2256
3225 5215
3226 1772
3227 7640
3230 5240
3231 1773
3232 4771
3233 1370
3234 4771
3235 4767
3236 2200
3237 5600
3240 2200
3241 1773
3242 5600
3243 1773
3244 1366
3245 3773
3246 1260
3247 1255
3250 3254
3251 1654
3252 3254
3253 5654
3254 0000
3255 0000
3256 0000
3257 3261
3260 3271
3261 7575
3262 7564
3263 7557
3264 7556
3265 7555
3266 7573
3267 7574
3270 0000

REDOA, DCA GETDAT

TAD I GETDAT

SNA

JMP DONEA

TAD C0CHAR

SNA CLA

JMP GOITA

ISZ INDEXA

ISZ GETDAT

JMP REDOA

TAD INMODE

SZA CLA

JMP EXITA

TAD C0CHAR

JMS XC0TYPE

TAD (277)

JMS XC0TYPE

JMS XC0CLF

ISZ XC0CNT

JMP I XC0CNT

ISZ XC0CNT

TAD C0CHAR

JMP I XC0CNT

GOITA, TAD C0CHAR

TAD (100)

DCA C0CHAR

TAD XTABLB

TAD INDEXA

DCA GOTOA

TAD I GOTOA

DCA GOTOA

JMP I GOTOA

GOTOA, 0000

INDEXA, 0000

GETDAT, 0000

XTABLA, TABLA

XTABLB, TABLB

TABLA, 7575

7564

7557

7556

7555

7573

7574

0000

TABLB, CNTRL0

CNTRL1

CNTRL2

CNTRL3

CNTRL4

CNTRL5

CNTRL6

CNTRL7

/

/CNTRL Q

/CONTAINS POINTER TO CONTROL CHAR

/GET CONTROL CHAR FROM TABLE

/CHECK FOR A 0 END OF TABLE

/END OF TABLE NO CONTROL CHAR

/COMPARE CHAR TO CONTROL CHAR

/0 IF MATCH

/MATCH

/NO MATCH NOT END OF TABLE REDO

/BUMP INDEX FOR EXIT WHEN CONTROL FOUND

/BUMP GETDAT FOR COMPARE OF NEXT CNTRL CHAR.

/CHECK IF PROGRAM EXPECTS CHAR

/1=CHAR EXPECTED 0= NO CHAR EXPECTED

/CHAR EXPECTED

/GET CHAR = NOT CONTROL + NOT EXPECTED

/C0PKNT CHAR

/GET CODE FOR "2"

/BUMP RETURN

/EXIT CALL+2

/BUMP RETURN FOR MAIN PROGRAM CHECK OF CHAR

/PUT CHAR IN AC.

/EXIT

/GET THE CONTENTS OF CHAR

/ADD 100 TO FORM A GOOD ASCII CHARACTER

/RESTORE COFFSET CHAR

/GET START OF TABLE B

/GET NOW FAR INTO TABLE

/STORE IT

/GET THE ROUTINE STARTTING ADDRESS

/STORE IT IN HERE

/GOTO CONTROL CHAR ROUTINE

/ADD UP CNTRL ROUTINE TO EXECUTE

/DISPLACEMENT INTO CNTRL TABLE

/LOCATION OF ADDRS OF CONTROL CHAR.

/ADDNS OF TABLEA

/ADDNS OF TABLEB

/CNTRL C BACK TO MONITOR 203

/CNTRL L SWITCH ERROR PRINTING DEVICE 214

/CNTRL Q START DISPLAYING CHAR. AGAIN 221

/CNTRL R BACK TO BEGINNING OF PROGRAM 222

/CNTRL S STOP SENDING CHAR TO DISPLAY WAIT FOR CNTRL Q 223

/CNTRL E CONTINUE WITH PROGRAM 205

/CNTRL D CHANGE SWITCH REGISTER ON FLY

```

/START SENDING CHAR. TO THE DISPLAY
/THIS WILL RETURN CONTROL TO CALL THAT WAS SET BY
/THE CALL FOR CONTROL S.
/
3300 3772' CNTRLQ, DCA INMODE /SET SUFT FLAG FOR UNEXPECTED CHAN
3301 1334 TAD C0SETS /CHECK IF CONTROL S TYPED IN
3302 7600 SZA CLA
3303 5306 JMP BYMETR /CONTROL S TYPED IN
3304 4765' JMS C0GET /NO CONTROL S TYPED PREVIOUSLY
3305 5600 JMP I XC0CNTR /LEAVE VIA CNTR ENTRY ADDRESS
3306 3334 BYMETR, DCA C0SETS /CLEAR THE SUFT FLAG
3307 4765' JMS C0GET /RESTORE REGISTERS
3310 5735 JMP I C0RETR /EXIT TO ADDRESS SET BY CONTROL S

```

```

/
/CONTROL R
/GO TO THE QUESTION C0SWIT
3311 3764' CNTRLR, DCA TTYLPT /CLEAR THE TYPE FLAG SET TO TTY
3312 3334 DCA C0SETS /CLEAR SUFT FLAG FOR CNTRL S
3313 3772' DCA INMODE
3314 4763' JMS UPAROW /PRINT THE " AND C0CHAM
3315 3762' C0BY4, DCA C0SWST /CLEAR FLAG FOR CNTRL D OR H
3316 5717 JMP I X0USW /GO TO ADDRS OF C0SWIT
3317 0200 X0DSW, BGN /D0SW IS LABEL FOR C0SWIT QUESTION

```

```

/
/CONTROL S
/STOP SENDING CHAR. TO DISPLAY UNTIL A "U IS RECEIVED
/
3320 1334 CNTRL5, TAD C0SETS /IF! DU NOT STORE IN C0RETR
3321 7600 SZA CLA
3322 5326 JMP C0U07 /DONT SET UP C0RETR
3323 7001 IAC /MAKE RETURN CALL PLUS 2
3324 1200 TAD XC0CNT /GET RETURN FOR THIS CALL
3325 3335 DCA C0RETR /STORE IT HERE FOR USE BE CNTRL U
3326 2334 C0U07, ISZ C0SETS /SET FLAG TO SAVE CALL
3327 4761' JMS XC0TTYI /LOOK FOR THE INPUT
3330 4765' JMS C0GET /GET REGISTERS
3331 4200 JMS XC0CNTR /CHECK FOR THE CONTROL CHAR
3332 7200 CLA
3333 5320 JMP CNTRL5 /IF NOT A CNTRL Q R C REASK
3334 0000 C0SETS, 0
3335 0000 C0RETR, 0

```

```

/
/SWITCH OUTPUT FROM ONE OUTPUT DEVICE TO ANOTHER - THE TWO OUTPUTS ARE THE
/CONSOLE AND THE PRINTER WITH DEVICE CODE 06.
/
3336 1764' CNTRL6, TAD TTYLPT /GET PRESENT C0SWIT INDICATUR
3337 7000 CMA /COMPLEMENT IT
3338 3764' DCA TTYLPT /STOM NEW C0SWIT
3339 4763' JMS UPAROW /C0PNT " AND CHAR ON NEW DEVICE
3340 4765' JMS C0GET /RESTORE THE REGISTERS
3343 5600 JMP I XC0CNT /EXIT

```

```

/
/CONTROL E
/CONTINUE RUNNING FROM A INQUIRE OR ERROR
/
3344 4763' CNTRL6, JMS UPAROW /PRINT THE CONTROL CHAR
3345 4765' JMS C0GET /GET THE REGISTERS
3346 5600 JMP I XC0CNT /RETURN TO CALL PLUS ONE
/
/CONTROL C
/RETURN TO MONITOR CONTROL C
3347 3764' CNTRLC, DCA TTYLPT /CLEAR THE LPT FLAG TO PRINT ON DISPLAY
3348 4763' JMS UPAROW /C0PNT " AND LETTER IN CHAR
3351 6203 CDF CIP /GO TO 0 FLD
3352 6007 CAF /CLEAR THE WORLD
3353 5760 JMP I 17000 /GO TO DIAGNUSTIC MONITOR

```

```

/*****
/
/
/

```

```

3360 7600
3361 3072
3362 3545
3363 3415
3364 3721
3365 3424
3366 0100
3367 3623
3370 0277
3371 3677
3372 3676
3373 3675
3374 4123
3375 4124
3376 4000
3377 4122
3400

```

PAGE

```

/
/CONTROL D
/CHANGE THE SWITCH REGISTER ANYTIME CNTRL D AND RETURN TO
/THE PROGRAM RUNNING.
3400 4215 CNTRLD, JMS UPAROW
3401 1213 TAD C0RETO /CHECK IF THE RETURN ADDRS IS SAFE
3402 7600 SZA CLA
3403 5207 JMP C0U011 /DO NOT CHANGE THE RETURN ADDRS
3404 1777' TAD XC0CNT /GET THE RETURN ADDRS AND SAVE IT
3405 3214 DCA C0RETO /SAVE THE RETURN HERE
3406 2213 ISZ C0RETO /INDICATE RETURN SAVED DONT DESTROY
3407 4256 C0U011, JMS C0SPSW /GO CHANGE THE SWITCH REGISTER
3410 3213 DCA C0RETO /CLEAR THE FLAG
3411 4224 JMS C0GET /RESTORE THE AC HQ LINK ETC

```



```

3412 5614          JMP I   CBKETO          /RETURN TO THE PROGRAM
          /
3413 0000          CBKETO, 0
3414 0000          CBKETO, 0

          /THIS WILL TYPE A UP ARROW AND THE CHAR IN CBCHAR.

3415 0000          UPAROW, 0              /CBKENT THE "-" AND THE CHAR CBTYPED IN
3416 1376          TAD          (336)      /CODE FOR "
3417 4775'          JMS          XCBTYP     /
3420 1774'          TAD          CBCHAR     /CBTYPE THE CHAR
3421 4775'          JMS          XCBTYP
3422 4773'          JMS          XCBCRLF
3423 5615          JMP I   UPAROW          /EXIT

```

/ 城市与农村人口空间均衡分布 /

```

3424 0000      CGET, 0
3425 7200      CLA
3426 1772*     TAD      MQSAVE
3427 7421      MQL      /RESTORE MQ
3430 1771*     TAD      FLSAVE
3431 7004      HAL      /RESTORE THE LINK
3432 7200      CLA
3433 1770*     TAD      ACSAVE /RESTORE THE AC
3434 5624      JMP I    CGET /GET THE REGISTERS

```

[illegible]

```

/CBINGQU
/CBINGQU ROUTINE WILL PRINT A WAITING
/AND THE PROGRAM IS EXPECTING A CONTROL CHAR INPUT
/IF CONTINUE FROM CONTROL CHAR RETURN IS CALL PLUS ONE
/IF NO CONTROL CHAR ENTERED THEN WAITING IS REPRINTED
/AND PROGRAM WAITS FOR A CONTROL CHAR AGAIN.

/      CBINGQU =      JMS XCBIING

/EX.      JMS      XCBIING      /CB WILL PRINT A WAITINGAND WAIT FOR INPUT
/      DO ANYTHING      /RETURN IS CALL PLUS ONE AC =0 CONTINUE

/CALLS USED ARE -CHKCLA-XCBPNT-XCBTYI-CBGET-XCBENTRC-

```

```

3435 0000      XCBIQ, 0
3436 7300      CLA CLL
3437 4767*      JMS      CHKCLA      /CHECK LOC 22 BIT 3 CONSOLE BIT
3440 7410      SKP      /ACTIVE CONSOLE PACKAGE
3441 5635      JMP I     XCBIQ      /NOT CONSOLE LEAVE

```

```

3442 4766*      JMS      XC8PNT
3443 3451      WATMES      /INQUIRE WAITING
3444 4765*      JMS      XC8TTY1  /GET CHARACTER
3445 4224      JMS      C8GET
3446 4777*      JMS      XC8CNTR  /CHECK IF CONTROL CHARACTER
3447 5635      JMP I      XC8INQ  /EXIT AND CONTINUE
3450 5236      JMP      XC8INQ+1 /REASK
3451 2701      WATMES, TEXT "WAITING "
3452 1124
3453 1116
3454 0740
3455 0000

```

[illegible]

/CBSWIR

```

/ROUTINE WILL CHECK IF CONSOL IS ACTIVE IF IT IS ACTIVE DISPLAY
/SM QUESTION , IN NOT ACTIVE IT WILL NOT PRINT THE SM QUESTION BUT
/RETURN TO CALL PLUS ONE AC=0.
/C8SWII WILL SET UP THE PSEUDO SWITCH
/REGISTER WITH THE NEW DATA ENTERED

```

```

/          C8SWIT =          JMS XC8PSW

/EX.          JMS          XC8PSW          /SET UP PSEUDO C8SWIT REGISTER IF
                                         /ON THE CONSOL PACKAGE. RETURN IS CALL PLUS ONE AC = 0

```

/CALLS USED ARE -CHKCLA-XCBPSW-XCBPNT-XCBQCTA-XCBTYPE-

3456	0000	XC0PSW, 0		
3457	4767°	JMS	CHKCLA	/CHECK LOC 22 BIT 3 CONSOLE BIT
3460	7410	SKP		/ACTIVE CONSOLE
3461	5656	JMP I	XC0PSW	/DEACTIVE CONSOLE PACKAGE
				/RETURN WITHOUT ASKING PSEUDO SWITCH
3462	1345	TAD	C0SWST	/IS THE SOFT FLAG SET FOR SWITCH?
3463	7640	STA	CLA	/SKIP IF ONE ENTRY AT ATIME OK
3464	5764°	JMP	C0BY4	/SECOND ENTRY WITH OUT A EXIT GO TO SW QUESTION
3465	2345	ISZ	C0SWST	/FIRST ENTRY SET FLAG
3466	4766°	C0NDPS, JMS	XC0PNT	/C0PNT SR=
3467	3547	MESA		
3470	1020	TAD	Z0	/GET CONTENTS OF SW
3471	4763°	JMS	XC00CTA	/CONVERT IT TO ASCII
3472	1362	TAD	(40	/GET SPACE
3473	4775°	JMS	XC0TYPE	
3474	2761°	ISZ	INMODE	/SET FLAG FOR CHAR EXECTED
3475	4760°	JMS	XC0ECHO	/LOOK FOR INPUT
3476	4315	JMS	TSCHA	/NOT CONTROL TEST IT IS LEGAL
3477	1774°	TAD	C0CHAR	/STORE NEW CHAR IN SW REG
3500	3020	DCA	Z0	
3501	1357	TAD	(-3	/GET A MINUS 3
3502	3346	DCA	TEMPCNT	/STORE IN TEMP COUNT

```

3503 4760* GETCH1, JMS XC8ECHO /GET NEXT CHAR
3504 4315 JMS TSTCHA /CHECK IF CR + GOOD CHAR
3505 1020 TAD 20 /GET C8SWIT REGISTER
3506 7106 RTL CLL /ROTATE IT LEFT 3 PLACES
3507 7004 RAL
3510 1774* TAD C8CHAR /GET CHAR + ADD IT TO PREVIOUS CONTENTS
3511 3020 DCA 20 /SAVE NEW CONTENTS
3512 2346 ISZ TMPCNT /BUMP COUNT
3513 5303 JMP GETCH1 /JMP BACK + GET NEXT CHAR
3514 5342 JMP ENDIT /END 4 CHAR C8TYPED IN
3515 0000 TSTCHA, 0
3516 7041 CIA /CMPL CHAR IN AC
3517 1356 TAD (215 /TEST IF IT IS A CARRIAGE RETURN
3520 7650 SNA CLA /SKIP IN NOT CR.
3521 5342 JMP ENDIT /HAS CARRIAGE RETURN
3522 1774* TAD C8CHAR /NOT CM, GET CHAR
3523 1355 TAD (-260 /CHECK IF IT IS IN RANGE
3524 7710 SPA CLA /IF NOT POSITIVE C8ERR CHAR SMALLER THEN 260
3525 5336 JMP ERR1 /C8ERR = CHAR TOO SMALL
3526 1774* TAD C8CHAR /GET CHAR
3527 1354 TAD (-270 /GET A -270 + CHECK IF IT IS LARGER THEN 7
3530 7700 SNA CLA /SKIP IF LESS THEN 7
3531 5336 JMP ERR1 /C8ERR ON CHAR NOT IN RANGE
3532 1774* TAD C8CHAR /GET CHAR
3533 0353 AND (7 /MASK FOR RIGHT BYTE
3534 3774* DCA C8CHAR /STORE IN CHAR
/GET CHAR IN AC
/EXIT
/C8PHNT
/?
/EXIT + ASK AGAIN
/DO A CR LF
/CLEAR THE PSW ENTRY FLAG
/EXIT ROUTINE
3535 5715 JMP I TSTCHA
3536 1352 ERR1, TAD (277
3537 4775* JMS XC8TYPE
3540 4773* JMS XC8CRLF
3541 5266 JMP C8NDPS
3542 4773* ENDIT, JMS XC8CRLF
3543 3345 DCA C8SWST
3544 5656 JMP I XC8PSW
3545 0000 C8SWST, 0
3546 0000 TMPCNT, 0
3547 2322 MESA, TEXT "SW= "
3550 7540
3551 0000

```

```

3552 0277
3553 0007
3554 7510
3555 7520
3556 0215
3557 7775
3560 3663
3561 3676
3562 0040
3563 3600
3564 3315
3565 3072

```

```

3566 3103
3567 4000
3570 4122
3571 4124
3572 4123
3573 3623
3574 3675
3575 3677
3576 0336
3577 3200
3600
3600 PAGE
/COCTA
/OCTAL TO ASCII CONVERSION
/THIS ROUTINE WILL TAKE THE OCTAL NUMBER IN THE AC AND CONVERT IT TO ASCII
/THE RESULT WILL BE PRINTED ON THE CONSOLE TERMINAL
/ C8OCTA* JMS XC8OCT
/
/EX, JMS XC8OCTA /AC CONTAINS NUMBER TO BE CHANGE
/ RETURN IS TO CALL PLUS ONE AC=0
/
/CALLS USED ARE =XC8TYPE=
3600 0000 XC8OCT, 0
3601 7106 CLL RTL
3602 7006 RTL /POSITION THE FIRST CHAR FOR PRINTING
3603 3221 DCA C8TMP1 /SAVE CORRECT POSITIONED WORD HERE
3604 1377 TAD (-4
3605 3222 DCA C8CKP /STORE COUNTER IN HERE
3606 1221 TAD C8TMP1 /GET FIRST NUMBER
3607 0376 AND (0007 /MASK
3610 1375 TAD (260 /ADD THE PRINT CONSTANT
3611 4277 JMS XC8TYPE /TYPE THE NUMBER
3612 1221 TAD C8TMP1
3613 7006 RTL
3614 7004 RAL /PUT NEXT NUMBER IN POSITION
3615 3221 DCA C8TMP1 /STORE IT
3616 2222 ISZ C8CKP /DONE YET WITH FOUR NUMBERS
3617 5206 JMP C8O04 /NOT YET DO MORE
3620 5000 JMP I XC8OCT /DONE WITH FOUR
3621 0000 C8TMP1, 0
3622 0000 C8CKP, 0
/*****
/C8CRLF
/C8TYPE CR AND LF WITH FILLERS FOLLOWING EACH LF AND CR
/
/ C8CRLF* JMS XC8CRLF
/
/EX, JMS XC8CRLF /C8PHNT A CR AND LF WITH FILL
/ /RETURN TO CALL PLUS ONE AC =0

```

/CALLS USED ARE =XC8TYPE=

```

3623 0000 XC8CRLF,0
3624 7300 CLA CLL
3625 1374 TAD (215 /GET CODE FOR CR
3626 4277 JMS XC8TYPE
3627 1237 TAD FILLER
3630 7040 CMA
3631 3240 OCA FILCNT /STORE FILLER IN HERE
3632 1373 TAD (212 /GET CODE FOR LF
3633 4277 C8UO2, JMS XC8TYPE
3634 2240 ISZ FILCNT /CHECK ON FILLER CHAR
3635 5233 JMP C8UO2 /TYPE A NON PRINTING CHAR
3636 5623 JMP I XC8CRLF /EXIT
3637 0004 FILLER, 0004 /FILLER SET FOR 4 CHAR
3640 0000 FILCNT, 0 /COUNTER FOR FILL

```

```

//*****
/C8CKPA
/THIS ROUTINE WILL CHECK IF A CHARACTER WAS ENTERED FROM THE
/TERMINAL. IF THE FLAG IS SET AND THE CONSOLE PACKAGE IS
/ACTIVE A CHECK IS MADE TO DETERMINE IF IT IS A CONTROL CHAR.
/IF IT WAS A CONTROL CHAR THEN ITS CONTROL FUNCTION IS PERFORMED.
/IF NOT A CONTROL CHARACTER OR A CONTROL E-D-L-O- IT WILL DO
/THE CONTROL FUNCTION AND RETURN TO CALL PLUS 2,
/A NON CONTROL CHARACTER WILL BE PRINTED AND A "?" IT WILL RETURN TO
/CALL PLUS 2.
/IF NO FLAG IS SET OR THE CONSOLE IS NOT ACTIVE THE RETURN IS TO
/CALL PLUS 1.

```

/ C8CKPA= JMS XC8CKP

```

/EX. JMS XC8CKPA /CALL TO CHECK IF CONTROL CHAR SET
/ ANYTHING(SKIP) /RETURN IF NOT FLAG OR NOT CONSOLE ACTIVE
/ ANYTHING(JMP EXIT SKIP CHAIN) /RETURN IF NOT CONTROL OR CONTINUE CONTROL

```

/CALLS USED ARE =XC8TTYI=XC8CNTR=C8GET=

```

3641 0000 XC8CKP, 0
3642 3772 OCA ACSAVE /SAVE THE AC
3643 0004 GTF /SAVE THE FLAGS
3644 3771 OCA FL3AVE /SAVE THE FLAGS
3645 7501 MQA /PUT MQ IN AC
3646 3770 OCA MQSAVE /SAVE THE MQ
3647 0031 KSF /CHECK THE KEYBOARD FLAG
3650 5261 JMP C8BY3 /EXIT TO CALL PLUS 1
3651 4767 JMS CHKCLA /CHECK LOG 22 BIT 3 CONSOLE BIT
3652 7410 SKP /ACTIVE CONSOLE PACKAGE

```

```

3653 5261 JMP C8BY3 /EXIT TO CALL PLUS 1
3654 4766 JMS XC8TTYI /GET THE CHAR
3655 4765 JMS C8GET /GET THE FLAGS
3656 4764 JMS XC8CNTR /CHECK IF CONTROL CHAR.
3657 7000 NOP /RETURN IF A CONTINUE CHAR.
3660 2241 ISZ XC8CKP /BUMP RETURN FOR CALL PLUS 2
3661 4765 JMS C8GET /GET REGISTERS
3662 5641 JMP I XC8CKP /SAY GOOD BY

```

```

//*****
/C8ECHO
/THIS ROUTINE WILL LOOK FOR A CHAR FROM THE KEYBOARD. STORE IT IN LOCATION CHAR
/CHECK IF IT WAS A CONTROL CHARACTER - SET INMODE - PRINT CHARACTER

```

```

/ C8ECHO = JMS XC8ECHO
/EX. JMS XC8ECHO /LOOK FOR CONSOLE CHAR C8PRINT IT
/RETURN CALL PLUS ONE AC = CHAR C8TYPED IN

```

/CALLS USED ARE =XC8TTYI=XC8CNTR=C8GET=XC8ECHO=XC8TYPE=

```

/
3663 0000 XC8ECHO, 0
3664 4766 JMS XC8TTYI /WAIT FOR CHAR FROM KEYBOARD
3665 4765 JMS C8GET /RESTORE THE REGISTERS
3666 2276 ISZ INMODE /SET INMODE IDENTIFYING THIS AS A EXPECTED CHAR
3667 4764 JMS XC8CNTR /GO CHECK IF IT IS A CONTROL CHAR
3670 5663 JMP I XC8ECHO /WAS A CONTROL CHAR - CONTINUE RUNNING
3671 4277 JMS XC8TYPE /NOT A CONTROL CHAR C8PRINT IT
3672 3276 OCA INMODE /CLEAR FLAG THAT CHAR EXPECTED
3673 1275 TAD C8CHAR /GET CHAR IN AC
3674 5663 JMP I XC8ECHO /EXIT
3675 0000 C8CHAR, 0
3676 0000 INMODE, 0

```

```

//*****
/C8TYPE
/THIS ROUTINE WILL C8PRINT ON THE CONSOLE OR THE LPT WITH DEVICE CODE 66.
/
/ C8TYPE= JMS XC8TYP
/EX. JMS XC8TYP /C8PRINT THE CHAR IN THE AC.
/RETURN CALL PLUS ONE AC =0000
/DO NOT CLEAR THE LINK IN THIS ROUTINE NEEDED BYC8OCT

```

/CALLS USED ARE =C8HANG=XC8CNTR=XC8PNT=XC8CRLF=XC8INQU=

```

3677 0000 XC8TYP, 0
3678 5320 OCA PNTBUF /STORE CHAN
3679 1321 TAD TTYLPT /CHECK Q=TTY 7777=LPT
3680 7640 SZA CLA
3683 5312 JMP X00LPT /DO OUT PUT ON LPT
3684 1320 TAD PNTBUF

```

```

3705 6046      TIS
3706 6041      TSF
3707 5306      JMP      .-1
3710 6042      TCF
3711 5316      JMP      C0BY5
3712 1320      XDULPT, TAD      PNTBUF      /GET CHAR
3713 6666      PSTB      /C0PNT IT
3714 4322      JMS      C0MANG      /CHECK KEYBOARD IF MUNG
3715 6662      PCLF      /CLEAR THE FLAG
3716 7600      C0BY5, 7600      /CLEAR THE AC
3717 5677      JMP I      XC0TYP      /EXIT
3720 0000      PNTBUF, 0
3721 0000      TTYLPT, 0

3722 0000      C0MANG, 0
3723 7200      CLA
3724 1316      TAD      C0BY5      /GET CONSTANT 7600
3725 3320      DCA      PNTBUF      /PNTBUF IS NOW A COUNTER
3726 6661      PSKF      /SKIP ON PRINTER DONE
3727 7410      SKP
3730 5722      JMP I      C0MANG      /NOT DONE YET
3731 2345      ISZ      C0CONT      /SAW FLAG DONE
3732 5326      JMP      .-4      /FIRST COUNTER FAST ONE
3733 2320      ISZ      PNTBUF      /CHECK IF FLAG SET YET
3734 5331      JMP      .-3      /MADE 4096 COUNTS ON FAST COUNTER
3735 1764      TAD      XC0CNTR      /KEEP IT UP FOR 5 SEC
3736 3322      DCA      C0MANG      /GET THE RETURN ADDRESS IN CONTROL
3737 3321      DCA      TTYLPT      /SAVE IT IN MANG
3740 4763      JMS      XC0PNT      /ALLOW PRINTING ON TTY
3741 3746      MESHANG
3742 4223      JMS      XC0CRLF      /LPT ERROR
3743 4762      JMS      XC0INQU      /PRINT WAITING
3744 5722      JMP I      C0MANG      /CONTINUE TO SAVE ADDRESS
3745 0000      C0CONT, 0      /COUNTER FOR TIMER
3746 1420      MESHANG,TEXT      "LPT ERROR"
3747 2440
3750 0522
3751 2217
3752 2200

3762 3435
3763 3103
3764 3200
3765 3424
3766 3072
3767 4200
3770 4123
3771 4124
3772 4122
3773 0212
3774 0215
3775 0260
3776 0007
3777 7774

```

```

4000      PAGE
/*****
/*****

/THIS ROUTINE WILL CHECK LOCATION 22 THE HARD WARE CONFIG WORD.
/TO SEE IF THE CONSOLE BIT 3 (400) IS SET IF SET THEN RETURN
/TO CALL PLUS TWO FOR A ACTIVE CONSOLE PACKAGE AC=0
/IF NOT SET THEN TO CALL PLUS ONE FOR A DEACTIVE CONSOLE PACKAGE.

4000 0000      CHKCLA, 0
4001 7200      CLA
4002 1022      TAD      22      /GET THE CONTENTA OF LOCATION 22
4003 0377      AND      (400      /MASK FOR BIT 3 (400)
4004 7650      SNA CLA      /
4005 2200      ISZ      CHKCLA      /ACTIVE CONSOLE PACKAGE RETURN
/CALL PLUS ONE (1) FOR ACTIVE
/DEACTIVE CONSOLE PACKAGE RETURN
/CALL PLUS TWO (2)

4006 5600      JMP I      CHKCLA

/CBERR
/THIS ROUTINE WILL DETERMINE WHAT TO DO WHEN A CBERR IS ENCOUNTERED
/WILL CHECK IF CLASSIC SYSTEM, WILL CHECK C0SWIT REGISTERS,
/ CBERR= JMS XC0ERR
/EX. JMS XC0ERR      /GO TO CBERR CALL IF NOT CONSOLE
/RETURN IS CALL PLUS ONE AC =0000

/CALLS USED ARE -CHKCLA-XC0CRLF-XC0SW-XC0INQU-XC0PNT-XC0OCTA-

4007 0000      XC0ERR, 0
4010 6002      IOF
4011 3322      DCA      AC0SAVE      /SAVE AC
4012 6004      GTF
4013 3324      DCA      FL0SAVE      /SAVE THE FLAGS
4014 7501      MOA
4015 3323      DCA      MO0SAVE      /SAVE THE MO
4016 7340      CLA CLL CMA      /SUBTRACT A 1 FOR TRUE LOCATION
4017 1207      TAD      XC0ERR      /GET RETURN LOCATION
4020 3321      DCA      PC0SAVE      /SAVE ADD OF CBERR CALL
4021 4200      JMS      CHKCLA      /CHECK LOC.22 BIT 3 CONSOLE BIT
4022 7410      SKP
4023 5263      JMP      NTCLAS      /ACTIVE CONSOLE PACKAGE
/NOT CLASSIC SYSTEM
4024 4776      JMS      C0GET      /GET THE REGISTERS.
4025 4775      JMS      XC0SW      /CHECK SWITCH REG FOR BIT THAT INDICATES
/NO ERROR MESSAGE
/NO ERROR MESSAGE
/NO ERROR MESSAGE
/IF THIS ERROR MESSAGE IS TO ALWAYS
/BE PRINTED LEAVE AND VALUE AT 0000
/SKIP IF BIT IS 0 PRINT ERROR MESSAGE
/DO NOT PRINT

4026 0374      SETUP1, AND      (0000

4027 7640      SZA CLA
4030 5255      JMP      C0DD10
4031 4773      JMS      XC0CRLF
4032 4772      JMS      XC0PNT
4033 4075      ERRMES
4034 4772      JMS      XC0PNT      /PRINT THE ERROR MESSAGE

```

```

4035 4105      MESPC
4036 1321      TAD      PCSAVE
4037 4771'     JMS      XC8OCTA
4040 4772'     JMS      XC8PNT
4041 4110      MESAC
4042 1322      TAD      ACSAVE
4043 4771'     JMS      XC8OCTA
4044 4772'     JMS      XC8PNT
4045 4113      MESMQ
4046 1323      TAD      MQSAVE
4047 4771'     JMS      XC8OCTA
4050 4772'     JMS      XC8PNT
4051 4116      MESFL
4052 1324      TAD      FLSAVE
4053 4771'     JMS      XC8OCTA
4054 4773'     JMS      XC8CRLF
4055 4776'     C8DU10, JMS      C8GET
4056 4775'     JMS      XC8SW
4057 7610      SKP CLA
4060 5273      JMP      C8BY2
4061 4770'     JMS      XC8ING
4062 5273      JMP      C8BY2
4063 4776'     NTCLAS, JMS      C8GET
4064 4775'     JMS      XC8SW

4065 7610      SKP CLA
4066 5607      JMP I      XC8ERR
4067 1367      TAD      (7402
4070 3721      DCA I      PCSAVE
4071 4776'     JMS      C8GET
4072 5721      JMP I      PCSAVE
4073 4776'     C8BY2, JMS      C8GET
4074 5607      JMP I      XC8ERR
4075 0410      ERMHES, TEXT  "DHRKDD FAILED "
4076 2213
4077 0404
4100 4040
4101 0601
4102 1114
4103 0504
4104 4000
4105 4040      MESPC, TEXT  " PC:"
4106 2003
4107 7200
4110 4040      MESAC, TEXT  " AC:"
4111 0103
4112 7200
4113 4040      MESMQ, TEXT  " MQ:"
4114 1521
4115 7200
4116 4040      MESFL, TEXT  " FL:"
4117 0614
4120 7200
4121 7777      PCSAVE, 7777
4122 7777      ACSAVE, 7777

```

/PRINT THE PC STATEMENT

/CONVERT 4 DIGIT PC TO ASCII

/PRINT THE AC MESS

/PRINT MQ

/PRINT FL

/GET THE REGISTERS.

/CHECK SWITCH REGISTER

/SKIP IF BIT 0 SET

/LEAVE

/GO TO THE INQUIRE ROUTINE

/LEAVE

/GET THE REGISTERS.

/CHECK PSEUDO SWITCH REGISTER

/CHECK THE C8SWIT REGISTER

/SKIP IF HALT

/NO HALT CONTINUE

/CODE FOR HLT

/PUT IT IN CALL LOC.

/EXIT TO CALL AND HALT

/GET THE REGISTERS

```

4123 7777      MQSAVE, 7777
4124 7777      FLSAVE, 7777

```

\$\$\$

```

4167 7402
4170 3435
4171 3600
4172 3103
4173 3623
4174 0000
4175 3062
4176 3424
4177 0400

```

```
0000 11110000 11000000 11111111 11111111 11111111 11111111 11111111 11111111
0100 11111111 11111111 11111111 11111111 11111111 11111111 11000000 00000000

0200 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11111111
0300 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11100111

0400 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11111111
0500 11111111 11111111 11111111 11111111 11111111 11111111 00000000 00000111

0600 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11111111
0700 11111111 11111111 11111111 11111111 11111111 11111111 11110000 00000111

1000 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11111111
1100 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11111111

1200 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11111111
1300 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11100111

1400 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11111111
1500 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11000001

1600 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11111111
1700 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11111111

2000 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11111111
2100 11111111 11111111 11111111 11111111 11111111 11100000 00000000 00000000

2200
2300

2400
2500

2600
2700

3000 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11111111
3100 11111111 11111111 11111111 11111111 11111111 10000001 11111111 11111111

3200 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11111111
3300 11111111 11111111 11111111 11111111 11111111 11110000 11111111 11111111

3400 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11111111
3500 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11111111

3600 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11111111
3700 11111111 11111111 11111111 11111111 11111111 11100000 00111111 11111111
```

```
4000 11111111 11111111 11111111 11111111 11111111 11111111 11111111 11111111
4100 11111111 11111111 11111000 00000000 00000000 00000000 00000001 11111111

4200
4300

4400
4500

4600
4700

5000
5100

5200
5300

5400
5500

5600
5700

6000
6100

6200
6300

6400
6500

6600
6700

7000
7100

7200
7300

7400
7500

7600
7700
```

A0770	1513	CHKCLA	4000	DSK5B	0156	INMODE	3676
A7007	1512	CHKDAT	0353	DSK6A	0146	IO70	3734
ACL	7701	CHKDSK	0337	DSK6B	0157	IO71	0741
ACSAVE	4122	CHKER	1112	DSK7A	0147	IO72	0746
ADPOT1	0137	CHKR1	1007	DSK7B	0160	IO73	0714
ADPOT2	0150	CHNPOT	1517	DSK8CNT	0105	IO74	0705
ADPT1	1637	CKCOUT	3052	DSKP	0741	IO75	0672
ADPT2	1640	CLDR	0745	DSKSKP	4441	IO76	0727
ADREG	0125	CLKENT	0132	DTREG	0126	IO7CHN	4430
AERRO	1600	CLRALL	4445	ENDBUF	2577	K0003	0060
AGAIN	0533	CMREG	0121	ENDIT	3542	K0007	0062
ALLAGN	0220	CNT	1554	ENDTST	0424	K0010	1324
AMOUNT	0056	CNTRLC	3347	ERHMT0	0756	K0037	0074
APT8	1125	CNTRL0	3400	ERHMT2	0750	K0040	0063
APT8A	4424	CNTRLE	3344	ERHMT3	0716	K0077	1323
AUTO10	0010	CNTRLQ	3336	ERHMT4	0707	K0100	1556
AUTO11	0011	CNTRLR	3300	ERHMT5	0674	K0177	1370
BGN	0200	CNTRLK	3311	ERHMT6	0731	K0200	0066
BGNBUF	0055	CNTRL9	3320	ERMES1	1734	K0212	1226
BGNTST	0127	CNTVAL	3052	ERMES2	1756	K0215	1225
BYRETR	3306	COUNT	1533	ERMES3	2000	K0240	1321
C0BY1	3030	CRLF	4452	ERR1	3536	K0260	0067
C0BY2	4073	CSAVE1	1514	ERRMES	4075	K0277	0065
C0BY3	3661	CSAVE2	1515	ERRU	0436	K0316	1371
C0BY4	3315	DAREG	0123	ERROR	4437	K0331	1372
C0BY5	3716	DATCNT	0131	ERTX1	1664	K0400	0073
C0CHAR	3675	DATER	1103	ERTX2	1675	K2000	1527
C0CKP	3622	DATOK	1071	ERTX3	1705	K3600	1426
C0CNT	3745	DCLR	0742	ERTX4	1717	K3740	1311
C0D01	3110	DLAG	0743	EXBIT	0120	K4	0061
C0D010	4055	DLCA	0744	EXIT	1506	K4000	0070
C0D011	3407	DLDC	0746	EXITA	3240	K4100	1310
C0D02	3633	DLSC	0740	EXTICK	1551	K5000	0067
C0D03	3150	DMAN	0747	FILCNT	3640	K6500	1571
C0D04	3606	DOCNT	3047	FILLER	3637	K6520	1620
C0D07	3326	DONE	0250	FLSAVE	4124	K7377	1173
C0GET	3424	ONEA	3226	FORMAT	0302	K7400	0764
C0HANG	3722	DOPACK	3012	FRMOSK	0263	K7577	0070
C0RDP3	3466	D0SET	3051	FROCT	1227	K7700	1322
C0RETD	3414	DRIVND	0100	FRSTUK	1056	K7735	0071
C0RETR	3335	DWST	0745	GOREG2	0117	K7741	1325
C0SETO	3413	DSK0A	0140	GETCML	3503	K7760	0072
C0SETS	3334	DSK0B	0131	GETDAT	3256	K7771	0557
C0SWST	3545	DSK1A	0141	G0ITA	3243	KAERRO	4426
C0TMP1	3621	DSK1B	0152	G0TDA	3254	KCDF	0075
CAF	6007	DSK2A	0142	GTF	0004	KCNT	1555
CAREG	0124	DSK2B	0153	MEDLST	0553	KERRO	1621
CCNTR1	1516	DSK3A	0143	MEDTAD	0552	KILBUF	4435
CHANG	1463	DSK3B	0154	HIGHAD	0103	KLBUF	0752
CHANGR	1477	DSK4A	0144	MITHK	2200	KTICK	1530
CHAR	0101	DSK4B	0155	MMEMA	0150	KTIME	1557
CHECK	0400	DSK5A	0145	INDEXA	3255	KWAIT	1511

LDA0	0711	PRNTER	4447	TEXT	1652	XRDST	0040
LDA0D	4444	PSIE	6665	TICK	4427	XRDTRK	0032
L0CA	0700	PSKE	6663	TIME	4425	XREG	0546
LDCM	0720	PSKF	6661	TPCNT	3546	XRESTR	0033
LDCM0	4442	PSTB	6664	TOCT	1200	XSKP	0041
LDCUR	4443	PTSTOR	3136	TRKCNT	0104	XTABLA	3257
L0SC	4446	QUES1	0232	TSTCHA	3515	XTABLB	3260
L0CBED	0134	R0ST	0671	TTYLPT	3721	XTEXT	0545
L0DER	0654	R0STAT	4440	TWOCI	4451	XTICK	0027
L0DR1	0611	RECAL	4433	TYPE	4446	XTIME	0025
L0DTRK	4431	RECEIV	4434	UPARUH	3415	XTOCT	0051
L0TRK	2201	REDOSK	4432	UPONE	1215	XWAIT	0034
L0WAD	0102	REDOA	3215	WAIT	1327	XWTRK	0031
M10	0077	REDTRK	1000	WASOSK	0242	XLDSK	0046
M313	0064	RENEX1	0335	WATMES	3451		
M4	0076	RENEX2	0414	WRKBUF	2200		
MCNTR1	1641	RE8TA	1425	WRTOSK	0521		
MES1	2045	RE8TER	1443	WRTTHK	0000		
MES2	2066	RE8TOR	1400	XAERN0	0026		
MES3	2117	RETRN1	0544	XAPT8	0024		
MES4	2126	\$AMAGN	0224	XC8CAP	3641		
MES5	2135	\$AVPC	1622	XC8CNT	3200		
MESA	3547	80CNT1	0106	XC8CML	5623		
MESAC	4110	80KP	0740	XC8CCH	5663		
MESFL	4116	SETUP1	4026	XC8ERR	4007		
MESHAN	3746	SETUP2	3025	XC8ING	3435		
MESMQ	4113	SOFT	0136	XC8OCT	3600		
MESPA3	3053	STAER	1106	XC8PAS	3000		
MESPC	4105	STAOK	1041	XC8PAU	3137		
MOVE	1623	STCNT1	0107	XC8PNT	3103		
MQA	7501	STCNT2	0110	XC8P3W	3456		
ML	7421	STCNT3	0111	XC8SW	5062		
MOSAVE	4123	STRAUT	0513	XC8TTY	3072		
MULOSK	1153	STREG	0122	XC8TYP	3677		
NEXCHK	0347	SWITCH	0057	XCHANG	0030		
NEXFRM	0276	TABLA	3261	XCL0H	0045		
NOSET	3042	TABLB	3271	XCRLP	0052		
NOTOSK	0244	TCHKT	1113	XDOLPT	3712		
NOTEX	0536	TCNTR1	0112	XDOSW	3317		
NTCLAS	4063	TCNTR2	0113	XEND	0135		
NTGD	0474	TCNTR3	0114	XERRU	0037		
OCTEL	4450	TCNTR4	0115	XFR0CT	0050		
PASCNT	3050	TCNTR5	0116	XMITTK	0034		
PCLF	6662	TEXAD	1600	KKL0UP	0035		
PCNTR1	0547	TEXCA	1656	XLDAU	0044		
PCNTR2	0550	TEXCM	1650	XL0CA	0043		
PCNTR3	0551	TEXOA	1654	XLDCH	0042		
PCOUNT	0161	TEXOT	1662	XLOSC	0733		
PCSAVE	4121	TEXENO	2021	XLOTHK	0053		
PNTBUF	3720	TEXEX	1646	XMOVE	0133		
PRINT	1312	TEXGD	1644	XPRINT	0036		
PRN	1252	TEXPC	1642	XPRN	0047		

ERRORS DETECTED: 0

LINKS GENERATED: 132

RUN-TIME: 4 SECONDS

3K CORE USED