

EK-RX012-PS-002

RX01/RX02

Pocket Service Guide

1st Edition, November 1980
2nd Edition, September 1981

Copyright © 1981
by Digital Equipment Corporation.
All Rights Reserved.

The reproduction of this material, in part or whole, is strictly prohibited. For copy information, contact the Educational Services Department, Digital Equipment Corporation, Maynard, Massachusetts 01754.

The information in this document is subject to change without notice. Digital Equipment Corporation assumes no responsibility for any errors that may appear in this document.

Printed in U.S.A.

The following are trademarks of Digital Equipment Corporation, Maynard, Massachusetts.

DEC	DECnet	OMNIBUS
DECUS	DECsystem-10	OS/8
DIGITAL	DECSYSTEM-20	PDT
Digital Logo	DECwriter	RSTS
PDP	DIBOL	RSX
UNIBUS	EduSystem	VMS
VAX	IAS	VT
	MASSBUS	

CONTENTS

1 TROUBLESHOOTING

1.1	General	1
1.2	Troubleshooting Charts	2
1.3	Power Supply Voltages	8
1.4	RX8/RX28 Subsystem	9
1.4.1	Bootstrap	13
1.4.2	Registers	13
1.4.3	Interface (M8357)	15
1.5	RX11/RXV11 Subsystem	15
1.5.1	Bootstrap	16
1.5.2	Registers	16
1.5.3	Interfaces (M7846 and M7946)	18
1.6	RX211/RXV21 Subsystem	18
1.6.1	Bootstrap	20
1.6.2	Registers	20
1.6.3	Interfaces (M8256 and M8029)	20

2 MECHANICAL SERVICING

2.1	General	25
2.2	RX01/RX02 Disk Drive Assembly	26
2.2.1	Rack-Mount	26
2.2.2	Case-Mount	27
2.3	Controller Board	29
2.4	Read/Write Board	30
2.5	Drive	32
2.6	Power Supply	35
2.7	Power Board Assembly (Regulators)	36
2.8	Drive Belt and AC Motor Pulley	37
2.9	Door Handle	38
2.9.1	Door Handle Removal	38
2.9.2	Door Handle Installation	38
2.10	Read/Write Head	39
2.11	Stepper Motor Lead Shaft	39

3 ALIGNMENT AND ADJUSTMENT

3.1	Handle Latch Wire	41
3.2	Drive Belt and AC Motor Pulley	41
3.3	Head Gap	43

APPENDIX A SPARE PARTS LIST

FIGURES

1-1	What System/Subsystem Is This?	3
1-2	Diskette Media	4
1-3	Head Plug (P3) to M7727	7
1-4	Power Supply Voltage Checks	9
1-5	RX8/RX28 Registers	14
1-6	M8357 Interface (RX8/RX28)	16
1-7	RX11/RXV11 Registers	17
1-8	M7846 Interface (RX11)	18
1-9	M7946 Interface (RXV11)	19
1-10	RX211/RXV21 Registers	21
1-11	M8256 Interface (RX211)	23
1-12	M8029 Interface (RXV21)	24
2-1	Subassembly Removal and Replacement	25
2-2	Removing and Replacing RX01/RX02 (Case-Mount)	27
2-3	Controller Board Connections	28
2-4	RX01 Read/Write Board Connections	30
2-5	RX02 Read/Write Board Connections	31
2-6	Plenum/Fan Assembly	33
2-7	Drive and Power Supply Removal	34
2-8	Power Supply Components	35
2-9	Capacitor C1 and C2 Connections	36
2-10	Drive Belt and AC Motor Pulley	37
2-11	Door Handle Assembly	39
2-12	Head Carriage Components (Top View)	40
3-1	Motor Pulley Alignment	41
3-2	Underside View of Drive	42
3-3	Head Gap Adjustment	43
3-4	RX01 Pressure Pad Mechanism (Front View)	44
3-5	RX02 Pressure Pad Mechanism (Front View)	45

TABLES

1-1	Reference Documentation	1
1-2	RX01/RX02 Field Replaceable Units	2
1-3	RX01/RX02 Troubleshooting Chart	3
1-4	Intermittent Problems	7
1-5	Voltages	8
1-6	Diagnostic Error Code Definitions and Probable Causes	10
1-7	Diagnostic Printout Troubleshooting Chart	12
1-8	RX8/RX28 Bootstraps	13
1-9	RX11/RXV11 Bootstrap	16
1-10	RX211/RXV21 Bootstrap	20
2-1	Switch Configuration for M7744	29